

SOLAR PATH LIGHT WITH LINKABLE & PIR SENSOR

Model Number: ELI1621G INSTALLATION INSTRUCTIONS

PLEASE READ CAREFULLY AND SAVE THESE INSTRUCTIONS, AS YOU MAY NEED THEM AT A LATER DATE.

▲ IMPORTANT SAFETY OPERATING INSTRUCTIONS

- 1. Please read all **warning** and instruction labels which are included in the box and fixture to avoid personal injury, property damage caused by fire, cuts, bruises, death and other dangers
- 2. Please follow these general precautions before installing, maintaining, or fixing

A WARNING

- 1. The packing contains small parts that could be swallowed by children
- 2. Keep the packaging material away from children and pets
- 3. The solar light is not a toy
- 4. We do not take responsibility if the instruction manual is not followed correctly or if the product is handled improperly resulting in damage to person or property

PRECAUTION

- 1. It is important to select an outdoor location with full, direct sunlight where the solar panel can receive at least 6 hours of sunlight each day.
- 2. It is important to avoid placing the solar light by light sources, such as street lights or porch lights, which may cause the solar light to turn off automatically.
- 3. To avoid explosion and corrosion, please keep the solar light away from from fire and humid environment
- 4. No striking to avoid any damages to solar cell

REF. PARTS

Solar Unit (4pcs)

Connection Tube (4pcs)

Ground Spike (4pcs)

PARAMETER


- 1. Dimension: approx. 6.30"D x 14.37"H
- 2. Light source: 4pcs LEDs per light
- 3. Brightness: Standby: 10lumens; up to 300lumnes when activated
- 4. Sensor range: 110 degree / 16ft
- 5. Wireless transmit distance: up to 164feet (50m)

HOW TO OPERATE AND INSTALL (Ref Figure 1 & Figure 2)

- Twist the Solar Panel Unit (Part A) from the Lens (Part B)
- Slide the power switch to your desired channel (CH1/CH2/CH3/CH4). Slide the CCT switch to your desired color temperature (3000K/4000K/5000K) on the bottom of the Solar Unit (Part A), reassembly the Solar Panel Unit and The Lens.
- Insert the Ground Spike (Part D) to the Tube (Part C).
- Insert the assemblied Ground Spike (Part C & D) into the ground where it can receive a full 8 hours of sunlight to allow the rechargeable battery to reach maximum capacity.
- Put the assemblied Solar Panel Unit (Part A & Part B) into the Tube (Part C & D)

Note: Lights with solar panels may have a protective film over the solar panel. This must be removed prior to use.


• Then the light will light on automatically at the dusk



HOW IT WORKS



 Solar panel collects sunlight to charge the battery (included) during the day





 Autmatically turns to bright light at night when people walks into the detection range of a pathway light



 Meantime all the others pathway lights turn to bright light automatically Note: the best distance

between each light is less



5. Autmatically turn to dim light at night after people walks out of the detection

CLEANING AND MAINTENANCE

- 1. Use a damp cloth to clean the solar panel
- 2. To avoid any damage to this light, please do not use any chemical or abrasive cleaner

RECHARGEABLE BATTERY

This product contains (1)3.2V 14550 600mAH LiFePO4 rechargeable battery. When the battery expires, it must be recycled or disposed of properly. Please contact your local waste disposal authority for correct procedure. Do not put battery into fire.

- Only rechargeable batteries are to be used.
- Exhausted batteries must be removed from the product.
- Batteries must be placed at the correct polarity.

Battery replacement

- Twist the Solar Panel Unit (Part A) from the Lens (Part B)
- Remove the battery compartment cover
- Take out the old battery from the battery compartment
- Replace with a new battery, making sure the polarity is correct.
- Put the battery cover back

FCC

FCC Warnning:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:Reorient or relocate the receiving antenna.Increase the separation between the equipment and receiver.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio/TV technician for help.Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.