



2K Video Doorbell

Quick Start Guide

lorex.com



Package Contents




User-supplied Tools



NOTE
The 15/64" masonry drill bit may be required if installing on concrete, stucco or brick.

2

Product Overview




Description of Call Button
Press the button to ring the doorbell

Description of Indicator Light

Restarting	Blue Solid
Restore to Default	Red Solid
Motion Detected	Blue Flashing (By Default)
Offline	Red Flashing
Talking	Green Flashing
Calling	Green Spinning

3






Description of Power Ports
Used to connect indoor mechanical or electronic chime and supply power

Description of Micro-SD Card Slot
Insert micro SD card for videos/snapshots storage

Description of Micro-USB Port
Used as an alternative port to supply power if you do not want to drill holes on the wall

4

Step 1: Mark mounting holes



A If you have an existing doorbell, turn off the power, remove the doorbell from the wall and disconnect the wires. These are the wires to be used to install your new doorbell.


B Place the mounting bracket to fit your existing doorbell wiring. Then mark the screw holes according to the bracket.

(Optional) Step 2: Install angled mounting brackets


Attach the horizontal or vertical bracket to the mounting bracket if you want to change the angle of the doorbell for a better view.

5

Step 3: Secure the mounting bracket



A For wood, drywall or soft surfaces: Secure the mounting bracket to the mounting surface using the Phillips head screwdriver and mounting screws.



B For concrete, stucco or brick: Use a 15/64" drillbit to drill holes where marked. Use included mounting screws and wall anchors to secure the mounting bracket to the wall.

6

Step 4: Scan the doorbell

A Download and install the free **Lorex Home** app from the App Store or Google Play Store.

B Tap the Lorex Home icon to launch the app. Tap **Sign up**, then follow the on-screen prompts to create an account.

Record your account details and store it in a secure location.

C Once the status LED on the doorbell is flashing blue, tap **+** in the Lorex Home app.

D Scan the QR code on the back of the doorbell with your mobile device's camera.



NOTE


If your mobile device cannot scan the QR code, tap **Manually enter Device ID**.

Once you have scanned the doorbell into your Lorex Home app, you can choose to follow along with the in-app setup video, or continue with the printed instructions.



7


Step 5: Wire the doorbell



A Loosen the power port screws with the Phillips head screwdriver.

B Hook the power cables underneath the power port screws, then re-tighten the screws to secure the cables.

NOTE



If your existing doorbell wiring is too short, remove the power port screws completely, then thread the screws through the included extra wires. Use the included wire caps to extend your wiring.




To attach the wire cap, align the ends of your existing wiring and extra wires, place the wire cap over the exposed wiring and twist the wire nut clockwise to tighten.

Ensure there is enough space to fit the cable connectors and wire caps into the hole in your wall.

8

Step 6: Connect the doorbell



Push the wiring back into the wall. Slide the mounting bracket upwards so the plastic tab on the bracket locks into the notch on the doorbell.

Remove the mounting bracket



To remove the mounting bracket from the doorbell, insert the pin into the hole at the bottom of the mounting bracket until the inner buckle is reached. Then slide the bracket down.

9

Need Help?

Visit us online for up-to-date software and complete instruction manuals.



- 1 Visit lorex.com
- 2 Search for the model number of your product
- 3 Click on your product in the search results
- 4 Click on the **Downloads** tab

10

Regulatory Information

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage, et
2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

The user manual for local area network devices shall contain instructions related to the restrictions mentioned in the above sections, namely that:

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall comply with the e.i.r.p. limit; and

(iii) the maximum antenna gain permitted for devices in the band 5725-5825 MHz shall comply with the e.i.r.p. limits specified for point-to-point and non point-to-point operation as appropriate.

(i) Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

ii) le gain d'antenne maximal autorisé pour les appareils dans les bandes 5250-5350 MHz et 5470-5725 MHz doivent respecter le pire limiter; et

(iii) le gain d'antenne maximal autorisé pour les appareils dans la bande 5725-5825 MHz doivent respecter le pire limites spécifiées pour le point-à-point et l'exploitation non point à point, le cas échéant.

Users should also be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5250-5350 MHz et 5650-5850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Caution: The user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
The statement for this device will be marked with "V"

(a) This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(b) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For full FCC compliance declarations, visit

<https://www.lorextechnology.com/FCC-compliance>