

Specifications

Rated Voltage	AC110V-220V, 50Hz
Max Current	10A
Rated Power Consumptions	<2W
Working Temperature	-5°C-+45°C
Working Humidity	< 90%
Dimensions (mm)	130*65*55

Download App

Use your cell phone to scan the QR on the right side or go to the App market and then search **LeChange**.



LeChange



Wireless Remote Control Outlet
Quick Start Guide

Please contact the service engineer or your local retailer if there is any problem.


Zhejiang Dahua Technology Co.,Ltd

No.1199 Bin'an Road, Binjiang District, Hangzhou, China, 310053.

Website: www.lechange.cn.

Please read the quick start guide carefully before you use this series product!!

This quick start guide is for (including but not limited to) RC1 and DH-CE-Z100 series product.



- **Power button**
Press it manually to turn on/off the device power. Press it for a long time (About 6 seconds) to pair.
- **Indicator light**
The blue light is flashing quickly when it is in pair mode. The blue light is on if the connection is OK. The yellow light is on if the pair is OK but there is no network.
- **Socket**
Insert the power socket.
- **Fuse cover**
Open it to replace fuse.

Thanks you for using our product

You can use this series product to control the device on/off status remotely, track device running status, collect power consumption statistics, schedule boot up and shut down the device.

Features

- General power consumption statistics.
- Smart on/off.

Quick Setup

Please follow the steps listed below to pair the wireless remote control outlet and the LeBox up.

Step 1

Open the software management interface and then select Add device button.

Step 2

Press the Pair button for about 6 seconds; you can go to the pair mode. Now you can see the blue indicator light becomes flashing quickly. The light becomes on after the pair process is successful. You can view the pair is successful on the LeBox and the device is added to the wireless remote control outlet category.

Functions

- **Power consumption statistics**
On the client, it can collect the device power consumptions connected to the outlet.
- **Remote boot up and shut down**
On the client, you can boot up or shut down the device remotely.
- **Schedule boot up and shut down**
On the client, you can set boot up and shut down time.
- **Countdown boot up and shut down**
On the client, you can set device boot up and shut down countdown time.

FCC Compliance Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2. The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

3. (b) For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.