



**Wireless Weather Station with Moon Phase**




**Contents**

Initial Setup .....	2
Moon Phase .....	2
Buttons .....	2
LCD Features .....	3
Settings Menu .....	3
MIN/MAX Temperature Readings .....	4
Position Outdoor Sensor .....	4
Care & Maintenance .....	4
Specifications .....	5
Warranty and Support Information .....	5
FCC Statement .....	6

## Initial Setup

**Step 1:** Insert 2 AAA batteries into the TX45UTH-IT outdoor sensor.

**Step 2:** Insert 2 AAA batteries into the weather station.




**Step 3:** Wait 5 minutes for sensor to lock in. Place sensor outside in a shaded location.



**Note:** If the outdoor temperature is not displayed after 3 minutes, remove batteries from the sensor and the station for 15 minutes and start again from step 1.

## Moon Phase


The moon icon of the weather station will display all 8-moon phases. A bar segment above the moon phase will indicate current moon phase.



## Buttons



## LCD Features



1- Manual set time	2- Month/Date	3- Moon Phase Indicator	4- Moon Phase
5- Indoor Temperature	6- Low Battery-Station	7-Indoor Icon	8- Indoor Humidity
9- Outdoor Temperature	10- Low Battery-Sensor	11-Sensor Reception Icon	12-Outdoor Humidity

## Settings Menu

1. Hold the SET button for three seconds to enter setting mode.
2. Press and release the + button to change a value.
3. Press and release the SET button to confirm a setting and move to the next item.

### Setting order:

1. 12/24 hour time format  
**Note:** Displays date/month (24h time display) or month/date (12h time display)
2. Hours
3. Minutes
4. Year

5. Month
6. Date
7. Fahrenheit/Celsius

### **MIN/MAX Temperature Readings**

The minimum and maximum temperatures are recorded from the power up of the temperature station until you reset the values. Reset daily, if you want a 24-hour MIN/MAX reading.

**View:** Press the MIN/MAX button to view:

Indoor minimum, indoor maximum, outdoor minimum and outdoor maximum temperature readings.

**Reset:** Hold MIN/MAX button for three seconds to reset all the indoor and outdoor temperature to current temperatures.

### **Position Outdoor Sensor**

- Mount the Outdoor Sensor on a north-facing wall or in any well shaded area. Under an eave or deck rail is preferred.
- The maximum wireless transmission range to the alarm clock is over 260 feet (80 meters) in open air, not including walls or floors.
- Be sure the outdoor sensor is mounted vertically.

**Restart:** When the outdoor readings show dashes:

1. Bring the sensor in the house five feet from the weather station.
2. Remove batteries from the sensor, and the batteries from the weather station.
3. Press any button 20 times.
4. After 15 minutes insert batteries into the sensor, as well as batteries into the weather station.
5. Wait 15 minutes to establish a strong connection. Place sensor outside in shaded location.

### **Care & Maintenance**

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+and -).

- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove expired batteries promptly.
- The specifications of this product may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.

### Specifications

<b>Indoor Range:</b>	14.1°F to +139.8°F (“OF.L” if outside this range)
<b>Outdoor Range:</b>	-39.8°F to +139.8°F (“OF.L” if outside this range)
<b>Indoor Humidity:</b>	20% to 95%
<b>Outdoor Humidity:</b>	1% to 99%
<b>Indoor Temp Update:</b>	every 16 seconds
<b>Indoor Humidity Update:</b>	every 64 seconds
<b>Outdoor Temp &amp; Humidity:</b>	every 4 seconds
<b>Transmission Range:</b>	up to 260 feet (80 meters) (open space)
<b>Weather Station:</b>	2-AAA, IEC LR3, 1.5V not included
<b>TX45UTH-IT:</b>	2-AAA, IEC LR3, 1.5V not included
<b>Battery life:</b>	up to 12 months
<b>Dimensions (W x D x H):</b>	
<b>Weather Station:</b>	3.22" W x 0.78" D x 5" H (81.8 x 20 x 127.1mm)
<b>TX45UTH-IT:</b>	1.41" W x 0.62"D x 4.03" H (36 x 16 x 102.6mm)

### Warranty and Support Information

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

**Before returning a product, please contact our friendly customer support with questions or visit our online help (manuals and FAQs):**

**Phone:** 1-608-782-1610

**Online Product Support:** [www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)

**View full warranty details online at:**

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)

**Warranty Address:**

La Crosse Technology, Ltd  
2830 S. 26<sup>th</sup> St.

La Crosse, WI 54601

**Protected under U.S. Patents:**

5,978,738 | 6,076,044 | RE43903



## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

### **Operation is subject to the following two conditions:**

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### **Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.