


DOS ASSEMBLER 5
DOSASM5
User's Guide
Version 3

January, 1976

Model Code No. 50019

DATAPoint CORPORATION



The Leader in
Dispersed Data Processing

PREFACE

This manual explains the operating instructions for the ASSEMBLER 5 and defines the directives and macros which are available to the user. The programmer will find the Datapoint DOS User's Guide helpful if more detailed systems information is required, and the Datapoint 2200 Reference Manual should be consulted for further instruction definition.

TABLE OF CONTENTS

	page
1. INTRODUCTION	1-1
2. STATEMENTS	2-1
2.1 LABEL FIELD	2-1
2.2 INSTRUCTION FIELD	2-2
2.3 EXPRESSION FIELD	2-3
2.4 EXAMPLES OF EXPRESSIONS	2-6
2.5 COMMENT FIELD	2-7
3. ASSEMBLER DIRECTIVES	3-1
3.1 INCLUDE	3-1
3.2 EQUIVALENCE	3-1
3.3 SET	3-1
3.4 SKIP	3-2
3.5 TABULATE PAGE	3-2
3.6 TABULATE MAYBE	3-2
3.7 DEFINE CONSTANT	3-2
3.8 DEFINE ADDRESS	3-3
3.9 LOCATION	3-3
3.10 ORIGINATE	3-4
3.11 USAGE	3-4
3.12 REPEAT	3-4
3.13 END	3-5
3.14 PERIOD	3-5
3.15 PLUS SIGN	3-5
3.16 ASTERISK	3-5
3.17 LIST	3-6
3.18 ERROR	3-6
3.19 IF	3-7
3.20 XIF	3-7
4. ASSEMBLER MACROS	4-1
4.1 HL	4-1
4.2 DE	4-1
4.3 BC	4-1
4.4 MEMORY STORE	4-2
4.5 MEMORY LOAD	4-2
4.6 SHIFT RIGHT NUMERIC	4-2
4.7 SHIFT LEFT NUMERIC	4-3
5. OPERATING PROCEDURES	5-1
5.1 PARAMETERIZATION	5-1
5.2 EXECUTION-TIME COMMANDS	5-2

5.3 ASSEMBLER PASS ONE	5-2
5.4 ASSEMBLER PASS TWO	5-2
5.5 CROSS-REFERENCE GENERATION	5-3
5.6 ASSEMBLY ERRORS	5-4

Appendix A. INSTRUCTION REPERTOIRE

Appendix B. MNEMONIC OPCODE REPERTOIRE

Appendix C. EXTERNAL COMMAND REPERTOIRE

Appendix D. OBJECT FILE FORMAT

Appendix E. SAMPLE PROGRAM

CHAPTER 1. INTRODUCTION

Generating machine language programs for the Datapoint 2200 with ASSEMBLER 5 consists of using the DOS EDITOR to create one or more symbolic source file(s) comprised of mnemonic instructions, symbolic variables, and symbolic routine names which can then be processed by the ASSEMBLER to create an absolute, executable object file which can be loaded and executed by the OPERATING SYSTEM.

Since ASSEMBLER 5 and this manual assume many details which are inherent to the DOS and 2200, a working knowledge of both the DOS and the 2200 VI and VII processors is recommended before proceeding.

Basically, the ASSEMBLER is a program that assigns numerical values to symbols and puts out these values upon input of the associated symbols. Symbols in certain fields have preassigned values (such as instruction mnemonics) while other symbols are defined by the user (such as labels).

The value assigned to an instruction mnemonic is the binary bit configuration recognized by the 2200 processor for that instruction. For example, the following instruction mnemonics have the following octal values:

<u>MNEMONIC</u>	<u>VALUE</u>
ADB	0201
RET	0007
SU	0024

Symbols in fields other than the instruction field (except for the expression field in EXternal commands) may be defined by the user. Pre-defined symbols are kept separately by the ASSEMBLER so that the user may define symbols that are the same as the pre-defined symbols without encountering any difficulties. For example:

<u>LABEL</u>	<u>INSTRUCTION</u>	<u>EXPRESSION</u>
L1	AD	1
	JMP	CALL
L2	AD	2
CALL	CALL	SUBR1
INPUT	INPUT	

will not present a problem in differentiating the two CALL and INPUT symbols since the ones in the instruction field are pre-defined and the ones in the label and expression fields are user-defined.

Along with relating symbols to numbers, another major function of the ASSEMBLER is to enable the programmer to reference a symbol that is defined later in the program. This is called FORWARD REFERENCING, and may be handled in a variety of ways. One of the simplest is to look at the source code twice. The first look determines the definitions of all the symbols and the second look uses the symbols to produce the object code. Each "look" at the source code is called a "PASS". Therefore, we end up with a two pass assembly process.

An optional function of the ASSEMBLER is that of producing a tabularized listing of all user-defined symbols, their octal value, and all references to them. This cross-reference table generation consists of recording all references to user-defined symbols during pass two, sorting the references, and merging them with their values.

The ASSEMBLER maintains two internal counters called the ADDRESS COUNTER and the LOCATION COUNTER. The ADDRESS COUNTER indicates the memory address of the object code currently being generated and the LOCATION COUNTER indicates the memory address at which the object code currently being generated will be executed. These counters are usually the same except in the case of Located Code (see Section 3.9). Each time a byte of code is generated, both counters are incremented. The values of these counters are initially set to 010000 but directives are available for changing their values either initially or dynamically (see Sections 3 and 5). The content of the ADDRESS COUNTER when processing of the current line is initiated is usually displayed at the left side of the listing. When the Location flag is set by a LOC directive, the LOCATION COUNTER (identified by a trailing L) is displayed instead of the ADDRESS COUNTER. The symbol \$ has special meaning in that it has the value of the LOCATION COUNTER when processing of the current line began. For example:

<u>ADRCTR</u>	<u>OBJECT CODE</u>	<u>SOURCE CODE</u>
01000		SET 01000
01000	104 000 002	XXX JMP XXX
01003	104 003 002	DOG JMP \$
01006		A EQU \$
00001		B EQU 1
01006	123 123	DC 0123,83
05400L		LOC 05400
05400L	104 000 013	C JMP \$
05403		D EQU \$
01013		LOC *

The ASSEMBLER maintains a stack of 16 dynamic Program Address Blocks (PAB'S) which may be used to locate data and code at Assembly time. A PAB is actually an ADDRESS COUNTER which has been given a symbolic name. This name is not used as a dictionary entry but is used solely for the purpose of requesting an ADDRESS COUNTER swap with the current PAB (see Sections 3.10 and 3.11).

An ABSOLUTE PAB is defined by the ASSEMBLER and is implicitly used anytime the programmer neglects to Originate (ORG) and Use (USE) additional PAB's (see Section 3.10 and 3.11). When a new PAB is requested, the current PAB's ADDRESS COUNTER is stored and the next available address associated with the requested PAB is placed in the ADDRESS and LOCATION COUNTERS.

The first word address and the length of each PAB is printed at the end of pass 1.

Example of PAB usage:

<u>ADRCTR</u>	<u>OBJECT CODE</u>	<u>SOURCE CODE</u>
01000		BUFFER ORG 01000
07000		CODE ORG 07000
00120		LTH EQU 80
07000		USE CODE
07000	002 000 120	DC *BUF1,LTH
07003	002 120 120	DC *BUF2,LTH
01000		USE BUFFER
01000	BUF1	SK LTH
01120	BUF2	SK LTH
07006		USE *
07006	377	HALT

CHAPTER 2. STATEMENTS

A 2200 assembly code statement consists of a label field, an instruction field, an expression field and a comment field. For example:

```

   1      2      3      4
 LABEL    JTC     START   THIS IS A COMMENT FIELD
```

Field 1 is the LABEL FIELD
Field 2 is the INSTRUCTION FIELD
Field 3 is the EXPRESSION FIELD
Field 4 is the COMMENT FIELD

The 2200 editor provides tabulation so that the fields may be justified to begin in a certain column for ease of reading. Tab stops at columns 9, 15 and 30 create a good appearance. However, the ASSEMBLER only requires the following:

A non-space in the first column means that the first field is a label except for a leading period, plus, or asterisk, which designates the entire line as a comment line.

A space in the first column means no label and the first symbol on the line is an instruction.

Scanning proceeds from left to right. One or more spaces serve as delimiters for the LABEL and INSTRUCTION fields. Spaces may appear in the expression field without terminating the expression (see, however, Section 2.3).

2.1 LABEL FIELD

The Label Field may consist of any number of characters. However, only the first six will be used as a label name in the dictionary and, therefore, the first six must be unique. The first character may be any alphabetic character or a \$ sign. The other characters may be any alphanumeric character or a \$ sign. An asterisk or colon immediately following the label (with no intervening spaces) will declare the label as a program entry point and the label will be written to the entry point file by the ASSEMBLER (see Section 5). If the label field is terminated by an equal sign followed by a space, this occurrence of the label may

not be the first; in which case, a redefinition of the label's value will occur and the normal 'D' error flag will not be generated. Extreme care must be exercised when using this redefinition capability as directives must not use multiply defined symbols in their expression field and the ASSEMBLER will not error flag such usage. Some examples of labels follow.

VALID LABELS

LBL123

LABEL\$

LABELA*

LABELB=

INVALID LABELS

REASON FOR ILLEGALITY

1LABEL	Starts with numeric
LABEL#	Non-alphanumeric or \$ character (#)
LABELA.	Non-alphanumeric or \$ character (.)
L1-2L3	Non-alphanumeric or \$ character (-)

A label may appear in a statement which has empty instruction and expression fields. Invalid labels are flagged as 'E' errors (see 5.5.3).

2.2 INSTRUCTION FIELD

The Instruction Field may be any of the instruction mnemonics, assembler directives, or assembler macros. It has the same syntactical restrictions as the Label Field (any number of characters starting with a letter and containing only alphanumerics or \$'s) except only the first two or three characters are used and consequently the user may abbreviate some instructions. For example:

CALL CALBCDEFG	These are both CALL instructions
INP INPUT	These are both INPUT instructions
INC	This is an INCLUDE directive
RET RETURN	These are both RETURN instructions

Any illegal or undefined instruction mnemonics will cause 'I' error flags to be generated.

2.3 EXPRESSION FIELD

The Expression Field consists of one or more expressions, delimited by commas, comprised of any number of strings, numbers, or symbols with operators between them. However, only the first expression will have significance except in the case of certain assembler directives (DC, DA, and IFnn) as noted in Sections 3.7, 3.8, and 3.19. DOSASM5 will allow spaces within an expression field in most cases; however, the use of spaces within expressions is not encouraged since other assemblers (i. e. SNAP1 and SNAP2) will not accept expressions with imbedded spaces. Numbers are assumed to be decimal (base 10) unless they have one or more leading zeros, in which case they are taken to be octal. That is, 123 is 123 decimal, whereas 0123 or 00123 (the octal number 123) is really 83 decimal.

String quantities are denoted (preceded and followed) by apostrophes. In expressions, only one character is allowed with the exception of the DC directive. The character's value is the ASCII binary number with the parity bit always a zero. A null string is illegal. A forcing character (#) is used in strings to indicate that the next character should be taken as ASCII no matter what it is. This is useful for entering the characters (') and (#) themselves string. For example:

'##' is the character string '#'

Expressions are evaluated strictly from left to right and all operators have the same precedence (with no parentheses allowed). The expression scanner generates a 16-bit two's complement value giving a decimal range of -32768 to +32767. Instructions which use only eight bits will discard the most significant byte (MSB) of the value generated by the expression scanner and use only the least significant byte (LSB) of the value. Syntax errors in

expressions will be flagged with 'E' error flags. A 'U' flag is issued in pass one when an assembler directive other than DA or DC is operating on an expression containing a label not yet in the dictionary. A 'U' flag is issued in pass two whenever an expression contains an undefined label. The expression field is omitted for instructions which require no expression.

There are eleven operators allowed in expressions:

- 2.3.1 + This means addition.
- 2.3.2 - This means subtraction. Note that the minus sign may be placed at the beginning of an expression if the value of the first item is to be negated.
- 2.3.3 * When used as the first character in the expression, this operator will set the ASSEMBLER'S star flag (see Sections 3.7, 3.8, 4.4, and 4.5). It may be followed by a minus operator (e.g. *-DOG+1).
- 2.3.4 * When used as other than the first character in the expression, signifies 16-bit integer multiplication.
- 2.3.5 / A slash indicates least whole integer division. This means that any remainder produced by the division will not be used.
- 2.3.6 > This means shift right. The value accumulated up to this point is logically shifted right the number of places indicated in the following label value or number (all bits shifted off the end are discarded and zeros are filled in on the left). Because the operation is a logical shift, sign is not maintained. Thus, negative numbers will be treated as positive 16-bit values instead of two's complement 16-bit values.
- 2.3.7 < This is the same as > except shifting is to the left with zero fill on the right.

- 2.3.8 .AND. This means to perform a logical 'AND' of the two positive 16-bit numbers.
- 2.3.9 .OR. These mean to perform a logical inclusive
.IOR. 'OR' of the two positive 16-bit numbers.
- 2.3.10 .XOR. This means to perform a logical exclusive 'OR' of the two positive 16-bit numbers.

Note that only the first character of a logical operation is used to determine the operation type and that additional characters prior to the second period are ignored.

2.4 EXAMPLES OF EXPRESSIONS

The following examples assume that the value of DOG is 1 and that the value of CAT is 2.

<u>VALID EXPRESSIONS</u>	<u>VALUE</u>	
DOG	1	
DOG+1	2	
1+DOG	2	
DOG+CAT	3	
'A'+1	0102	
*-CAT+1	-1	Note that star flag will be set.
-DOG<3	-8	
-DOG>3	8191	Note that sign is not extended on right shifts.
8>3+1	2	Note that shift occurs before addition.
CAT*CAT	4	
CAT.AND.DOG	0	
DOG.OR.CAT	3	
0377.XOR.DOG	0376	

ILLEGAL EXPRESSIONS

DOG+	Terminating character not a space or comma.
DOG#1	Illegal binary operator.
'AB'	Illegal if not a DC statement. Only 1 character allowed in all other expression strings.
'A'+1	Illegal only in a DC statement because a separator is expected after a string and + is not a valid separator (see Section 3.7).
CAT+DOG=	Illegal terminator character.
CAT.NOT.1	Illegal binary operator.
**12	Star flag set but no multiplier exists for second asterisk.
.XOR.1	No value prior to operator.

2.5 COMMENT FIELD

The Comment Field begins anywhere after the Expression Field, Instruction Field (if the Expression Field is not used), or Column 2 (if Column 1 contains a period, plus, or asterisk as noted in Sections 3.14, 3.15, and 3.16). The Comment Field may contain any character and is terminated by the end of the line. The ASSEMBLER puts out its listing of the source line exactly as it is provided in the source code so formatting of comments will be maintained.

CHAPTER 3. ASSEMBLER DIRECTIVES

Assembler Directives are used for setting the LOCATION COUNTER, ADDRESS COUNTER, and LABEL values to other than the normal sequential assignments and for defining constants. Other Directives are used to control certain ASSEMBLER functions such as input file linking, source file assembly, and program listing. Note that the normal forward referencing in the expression field is only permitted in the DC and DA directives.

3.1 INCLUDE

INC Includes the source from the file specification given in DOS format in the expression field. Up to 25 files may be included at nesting levels of up to 4 deep. Exceeding these limits will result in 'F' errors and the inclusion(s) will not be made. Lines of source code originating from an included file are noted by a trailing alphabetic character in the line number. Note that the label field of an INCLUDE directive is ignored and no dictionary entry made.

3.2 EQUIVALENCE

EQU Sets the value of the label on the statement to the value of the expression field. Object code is not generated by EQU's, but dictionary labels are. External references can be handled by equating labels to external locations and then referencing the labels. Will produce an 'E' error if no label is found.

3.3 SET

SET Sets the first word and current word address of the ABSOLUTE PAB (initially 010000) to the value of the expression field, clears the Location flag, and initiates usage (USE) of the ABSOLUTE PAB (see Section 3.11).

3.4 SKIP

SK Increments the values of the LOCATION and ADDRESS COUNTERS by the value of the expression field.

3.5 TABULATE PAGE

TP Increments the value of the ADDRESS COUNTER until it is a multiple of 256 (LSB = 000). This is useful for setting up page-dependent data areas which are addressable by single precision (leaving H fixed and manipulating only the L-register). If the Location flag is set, the ADDRESS COUNTER is not incremented and an 'I' error is produced.

3.6 TABULATE MAYBE

TM Performs a Tabulate Page if the value of the expression field would cause a page overflow if added to the current ADDRESS COUNTER. Will produce an 'I' error if the Location flag is set.

3.7 DEFINE CONSTANT

DC Generates eight bit object bytes from one or more expressions or strings delimited by commas found in the expression field. A leading asterisk on any expression will produce two object bytes (LSB, MSB) and therefore addresses may be imbedded within DC directives. A special exception is made for string items found in the DC directive. All the characters of a string item are significant and as many words as necessary are generated to accommodate all the characters of the given string. This special string item is in effect only if the expression is opened with an apostrophe.

String items in expressions still have only one character of significance. For example:

```
DC 1,2+3,2+'A','ABC'
```

generates the following octal values:

```
001,005,0103,0101,0102,0103
```

Note that 'A'+2 is illegal as the DC directive will consider it as a special multiple-character string and the + is not a legal terminator (only space or comma) but that 2+'A' is legal since the normal expression scanner will be used to determine its value.

3.8 DEFINE ADDRESS

DA Generates a two byte constant which is the address, LSB first, of the expression. Placing an * in front of an expression will cause the two bytes to be generated in the reverse order (MSB first, LSB second). For example:

```
DOG EQU 01234
DA DOG,*DOG,1
```

gives the following octal values:

```
234,002,002,234,001,000
```

3.9 LOCATION

LOC Sets LOCATION COUNTER to the value of the expression field and sets the Location flag. If the expression field consists of an asterisk, the Location flag is cleared and the LOCATION COUNTER is set to the ADDRESS COUNTER. Note that the listing will have the LOCATION COUNTER (noted by a trailing L) printed instead of the ADDRESS COUNTER.

3.10 ORIGINATE

ORG Initializes a new PAB and sets its first and current word addresses to the value of the expression field. The label field only defines the PAB's name and not a label for the dictionary. An 'E' error flag will be issued if the PAB has been previously defined or if there is no label. This error is fatal and causes pass two to abort.

3.11 USAGE

USE Declares the usage of the PAB whose name is given in the expression field. An asterisk in the field will revert back to the last PAB used. An 'E' error will be issued if the PAB named has not been originated. This error is fatal and will abort pass two.

3.12 REPEAT

RPT Will cause the following line of source code to be processed the number of times indicated by the LSB of the expression field's value. For example:

```
RPT 5  
CALL INCHL
```

will produce the same code as:

```
CALL INCHL  
CALL INCHL  
CALL INCHL  
CALL INCHL  
CALL INCHL
```

Repeating statements with labels which do not have a trailing = to signify a multiple definition will result in 'D' error flags.

3.13 END

END Indicates that there is no more source code to be processed and that the ASSEMBLER should proceed to pass 2 if in pass 1 or complete generating the output if in pass 2. Note that an 'F' error will be issued if an END is found in an Included file. The expression field has special significance in the END statement in that its value is taken as the Primary Transfer Address at which program execution will begin. This is optional and a Secondary Transfer Address is set by the ASSEMBLER to the location of the first byte of object code.

3.14 PERIOD

. A period in the first column will cause the ASSEMBLER to treat the entire line as a comment line.

3.15 PLUS SIGN

+ A plus sign in the first column will cause a page eject during the listing of the program. The line will be treated as a comment line as well and printing will occur after the ejection.

3.16 ASTERISK

* An asterisk in the first column will cause a page eject if the listing is within two inches of the bottom of a page. The line is treated as a comment line and printing occurs after any possible ejection.

3.17 LIST

LIS This is a directive which is used to alter the settings of the ASSEMBLER'S listing control flags. Each flag is specified by one character which turns the flag on when mentioned in a LIST statement unless it is preceded by a minus sign which will turn the flag off. Commas may be used to delimit more than one flag character. The flag characters, their default settings, and their usage are as follows:

- | | | |
|---|-----|---|
| L | ON | Master list control. If turned off, no pass two output will be listed until this flag is turned on again regardless of other control flags. |
| G | OFF | Generated lines. If turned off, this flag will suppress the listing of code lines generated by DC, DA, and RPT statements. |
| I | OFF | Included lines. Lines of source code included from additional source files will not be listed unless this flag is on. |
| F | OFF | If-skipped lines. This flag must be on to produce a listing of all lines of code skipped by an IF<nn> statement. |

3.18 ERROR

ERR Produces a 'P' error in both pass 1 and pass 2. Usually follows a conditional assembly statement to trap a page, table, overflow etc. For example:

TABLE	SK	LEN
	IFNE	\$>8, TABLE>8
	ERR	TABLE OVERFLOWS A PAGE!
	XIF	

3.19 IF

IFnn This is the conditional assembly directive. Condition 'nn' (assumed to be 'EQ' if not given) must be met when comparing the two expressions found separated by a comma in the expression field in order to assemble following lines of code. The second expression will be assumed zero if not given. Only an XIF directive will turn the conditional assembly back on. However, IF statement nesting may occur to any depth. An undefined expression operand in pass 1 is fatal and this occurrence will cause pass 2 to be aborted. The available condition codes are:

EQ	Field 1 must be equal to field 2
GT	Field 1 must be greater than field 2
LT	Field 1 must be less than field 2
NE	Field 1 must not be equal to field 2
GE	Field 1 must be either greater than or equal to field 2
LE	Field 1 must be either less than or equal to field 2
Z	Field 1 must be zero
NZ	Field 1 must be non-zero
C	Field 1 must be clear (flag-testing, same as Z)
S	Field 1 must be set (flag-testing, same as NZ)

3.20 XIF

XIF Forces the assembly on if it has been conditionally turned off.

CHAPTER 4. ASSEMBLER MACROS

Assembler MACROS are opcode mnemonics which directly result in the generation of a sequence of machine instructions.

4.1 HL

HL (exp) The HL macro generates the load H register and load L register instructions necessary to place the value of the expression field in the H and the L registers properly so that a load to or from memory will use that address i.e. H contains the MSB and L contains the LSB. The HL macro generates four bytes of object code. For example:

```
OOPS EQU 02005
HL OOPS
```

generates the following code:

```
066 005 056 004
```

4.2 DE

DE (exp) The DE macro works the same as the HL macro except it loads the D and E registers instead of H and L.

4.3 BC

BC (exp) The BC macro works the same as the HL macro except it loads the B and C registers instead of H and L.

4.4 MEMORY STORE

MS(r) (*) (exp) The Memory Store macro allows the user to store a given register into a given memory location. Placing an * in front of the expression causes the H-register to be loaded as well as the L. The expansion is as follows:

```
LL      (exp)
LH      (exp)>8 if * is present
LM(r)
```

4.5 MEMORY LOAD

ML(r) (*) (exp) The Memory Load macro works the same as the Memory Store (MSr) macro with the exception that the register is loaded from memory rather than being stored into memory.

4.6 SHIFT RIGHT NUMERIC

SRN (exp) The Shift Right Numeric macro allows the user to generate SRC instructions the number of times specified in the expression field. The expression must be defined in pass one and must have a value between zero and seven. For example:

```
SRN 3
```

will generate the following code:

```
012 012 012
```

4.7 SHIFT LEFT NUMERIC

SLN (exp)

The Shift Left Numeric macro works the same as the SRN macro with the exception that SLC instructions (002) are generated.



CHAPTER 5. OPERATING PROCEDURES

The DOS command requesting execution of the Version 5 ASSEMBLER should be as follows:

```
ASM source(,object(,entryp))(;(D)(L)(X)(F)(I)(G))
```

where each pair of parentheses and their content is optional.

5.1 PARAMETERIZATION

The first file spec (which is required) is the source file, the second file specification is for the object file, and the third file specification is for the entry point file. Each of these three files must be physically different. The source file has a default extension of TXT. The object file, if not given, is assumed to have the same name as the source file and has a default extension of ABS. The entry point file, if required and not given, is assumed to have the same name as the source file with a default extension of EPT. The entry point file is written after pass one only if entry points have been declared in the program. The EPT file is written in a compressed symbolic format which can be INCLUDED by a later assembly to provide a program linking capability.

The characters on the command line following the semicolon specify output options. The character L will cause the output to be listed on a Servo printer, if one is on-line. Otherwise, L produces a listing on the local printer. If the character X appears, a cross-reference map will be listed on the Servo or local printer (as above). X may appear in the command line without L if a cross-reference table but no program listing is desired. The character D signifies that the output should be displayed on the 2200 CRT, and the remaining valid characters instruct the ASSEMBLER to turn on their respective listing control flags (see Section 3.17). If neither L nor X appear as parameters, no printed output is produced. Assembly error messages are displayed on the CRT regardless of which options are specified.

5.2 EXECUTION-TIME COMMANDS

During the ASSEMBLER pass one and pass two, two execution-time commands may be invoked. Depressing the DISPLAY key will prevent the 2200 CRT screen from rolling up until the key is released. The KEYBOARD key may be used to terminate the

assembly and return to DOS.

5.3 ASSEMBLER PASS ONE

Initially the ASSEMBLER will validate the three file specifications and the parameter string and will then request an 80-character heading if either the L or X parameter was specified. Next it will print its Version number and the maximum number of labels it can handle in its dictionary. The ASSEMBLER will then read the source file and any INCLUDED files in order to build a dictionary containing all symbolic names used by the programmer and their equivalent octal value or address. A notation is printed as each INCLUDE is processed along with any lines which contain errors. At the end of pass one, one or more of the following items will be printed:

- 1) Any pass one error flags
- 2) Dictionary overflow message if overflow occurred
- 3) Fatal error message if error occurred
- 4) Program Entry Points--name, value
- 5) List of undefined symbols
- 6) List of unused symbols
- 7) List of multiply defined symbols
- 8) PAB starting locations and lengths

5.4 ASSEMBLER PASS TWO

If no fatal pass one errors occurred, the ASSEMBLER will now write the entry point file, if required, and proceed into pass two. Pass two is responsible for the actual generation of object code and a program listing. However, if a cross-reference listing is to be generated, pass two will also write a reference file (ASMREF/SYS) which will contain all symbolic references made in the program.

5.5 CROSS-REFERENCE GENERATION

At the completion of pass two, the ASSEMBLER will call in overlay 1 if a cross-reference listing is desired. Overlay 1 uses DOS SORT to sort ASMREF/SYS into the ordered file ASMSREF/SYS and produces from it a cross-reference table. The actual listing of references will contain the symbolic name preceded by its actual octal value, unless the name is undefined in which case it is preceded by asterisks. Following the symbolic name is a list of all line numbers at which that symbolic name was defined or referenced. All definition lines are flagged with a leading asterisk while all Inclusions are noted by a trailing colon followed by the Inclusion file character (see Section 3.1). For

example:

11304	DECHL	*32:A	*32:B		
00341	DISPL	*24			
00024	IDLE	*197212		212	212
10176	INCHL	71	*102	151	156
00007	MANY	21:A	*25:A	21:B	*25:B
*****	ILDE	213			

5.6 ASSEMBLY ERRORS

The ERROR FLAGS produced by the 2200 ASSEMBLER during both passes are as follows:

- 5.5.1 D The D flag means DIFFERENT DEFINITION. It is generated if an attempt has been made to define the label more than once without a trailing = mark. Generated in pass one only.
- 5.5.2 I The I flag means INSTRUCTION MNEMONIC UNDEFINED. The instruction was not an acceptable instruction and a zero or 0377 is inserted for the instruction.
- 5.5.3 E The E flag means that an error has occurred in an EXPRESSION or some unrecognizable character appeared in the wrong place. In this case, a zero is substituted for the expression or in whatever was unrecognizable if code generation was expected.
- 5.5.4 U The U flag means UNDEFINED LABEL. It is issued in pass two whenever a label is referenced and is not defined and it is issued in pass one when an assembly directive (except DA or DC) is operating on an expression containing a label not yet in the dictionary (forward referencing).
- 5.5.5 F The F flag means FILE error. It can be issued in either pass when the ASSEMBLER'S limits for an inclusion are exceeded or when an INCLUDED file contains an END directive.
- 5.5.6 P The P flag means PROGRAMMER PRODUCED. It is issued in both passes when an ERR directive is encountered.

APPENDIX A. INSTRUCTION REPERTOIRE

Notes: Opcodes shown without mnemonics are undefined.
 See Datapoint 2200 reference manual for further
 instruction definition.

OP CODE	MNEMONIC	OP CODE	MNEMONIC
000		040	DI
001		041	
002	SLC	042	
003	RFC	043	RTC
004 XXX	AD <exp>	044 XXX	ND <exp>
005		045	
006 XXX	LA <exp>	046 XXX	LE <exp>
007	RET	047	
010	SYNC	050	EI
011		051	
012	SRC	052	
013	RFZ	053	RTZ
014 XXX	AC <exp>	054 XXX	XR <exp>
015		055	
016 XXX	LB <exp>	056 XXX	LH <exp>
017		057	
020	BETA	060	POP
021		061	
022		062	
023	RFS	063	RTS
024 XXX	SU <exp>	064 XXX	OR <exp>
025		065	
026 XXX	LC <exp>	066 XXX	LL <exp>
027		067	
030	ALPHA	070	PUSH
031		071	
032		072	
033	RFP	073	RTP
034 XXX	SB <exp>	074 XXX	CP <exp>
035		075	
036 XXX	LD <exp>	076	
037		077	

OP CODE		MNEMONIC	OP CODE		MNEMONIC
100	LSB MSB	JFC <exp>	140	LSB MSB	JTC <exp>
101		INPUT	141		
102	LSB MSB	CFC <exp>	142	LSB MSB	CTC <exp>
103			143		
104	LSB MSB	JMP <exp>	144		
105			145		
106	LSB MSB	CALL <exp>	146		
107			147		
110	LSB MSB	JFZ <exp>	150	LSB MSB	JTZ <exp>
111			151		EX BEEP
112	LSB MSB	CFZ <exp>	152	LSB MSB	CTZ <exp>
113			153		EX CLICK
114			154		
115			155		EX DECK1
116			156		
117			157		EX DECK2
120	LSB MSB	JFS <exp>	160	LSB MSB	JTS <exp>
121		EX ADR	161		EX RBK
122	LSB MSB	CFS <exp>	162	LSB MSB	CTS <exp>
123		EX STATUS	163		EX WBK
124			164		
125		EX DATA	165		
126			166		
127		EX WRITE	167		EX BSP
130	LSB MSB	JFP <exp>	170	LSB MSB	JTP <exp>
131		EX COM1	171		EX SF
132	LSB MSB	CFP <exp>	172	LSB MSB	CTP <exp>
133		EX COM2	173		EX SB
134			174		
135		EX COM3	175		EX REWND
136			176		
137		EX COM4	177		EX TSTOP

OP CODE	MNEMONIC	OP CODE	MNEMONIC
200	ADA	240	NDA
201	ADB	241	NDB
202	ADC	242	NDC
203	ADD	243	NDD
204	ADE	244	NDE
205	ADH	245	NDH
206	ADL	246	NDL
207	ADM	247	NDM
210	ACA	250	XRA
211	ACB	251	XRБ
212	ACC	252	XRC
213	ACD	253	XRD
214	ACE	254	XRE
215	ACH	255	XRH
216	ACL	256	XRL
217	ACM	257	XRM
220	SUA	260	ORA
221	SUB	261	ORB
222	SUC	262	ORC
223	SUD	263	ORD
224	SUE	264	ORE
225	SUH	265	ORH
226	SUL	266	ORL
227	SUM	267	ORM
230	SBA	270	CPA
231	SBB	271	CPB
232	SBC	272	CPC
233	SBD	273	CPD
234	SBE	274	CPE
235	SBH	275	CPH
236	SBL	276	CPL
237	SBM	277	CPM

OP CODE	MNEMONIC	OP CODE	MNEMONIC
300	NOP	340	LEA
301	LAB	341	LEB
302	LAC	342	LEC
303	LAD	343	LED
304	LAE	344	
305	LAH	345	LEH
306	LAL	346	LEL
307	LAM	347	LEM
310	LBA	350	LHA
311		351	LHB
312	LBC	352	LHC
313	LBD	353	LHD
314	LBE	354	LHE
315	LBH	355	
316	LBL	356	LHL
317	LBM	357	LHM
320	LCA	360	LLA
321	LCB	361	LLB
322		362	LLC
323	LCD	363	LLD
324	LCE	364	LLE
325	LCH	365	LLH
326	LCL	366	
327	LCM	367	LLM
330	LDA	370	LMA
331	LDB	371	LMB
332	LDC	372	LMC
333		373	LMD
334	LDE	374	LME
335	LDH	375	LMH
336	LDL	376	LML
337	LDM	377	HALT

APPENDIX B. MNEMONIC OPCODE REPERTOIRE

This appendix contains a list of all valid mnemonics which can be used in the opcode field of the ASSEMBLER. Each mnemonic is followed with a brief definition of its usage. Note that the condition flip-flops which are specified as <c> may be specified as follows:

```


Carry --- C or B
Zero ---- Z or E
Sign ---- S or L or N
Parity -- P
    
```

The processor registers which are specified as <r> may be specified by the register name, i.e. A, B, C, D, E, H, L or M (if Memory Ref).

<u>OPCODE</u>	<u>DESCRIPTION</u>	<u>SECTION</u>
AC	Add with Carry Immediate Instruction	
AC<r>	Add with Carry Register Instruction	
AD	Add Immediate Instruction	
AD<r>	Add Register Instruction	
ALPHA	Select Alpha Mode Instruction	
BC	Load B and C Macro	4.3
BETA	Select Beta Mode Instruction	
CALL	Subroutine Call Instruction	
CF<c>	Conditional Subroutine Call Instruction	
CT<c>	Conditional Subroutine Call Instruction	
CP	Compare Immediate Instruction	
CP<r>	Compare With Register Instruction	
DA	Define Address Directive	3.8
DC	Define Constant Directive	3.7
DE	Load D and E Macro	4.2
DI	Disable Interrupt Instruction	
EI	Enable Interrupt Instruction	
END	End Source Code Directive	3.13
EQU	Equivalence Directive	3.2
ERR	Produce Error Directive	3.18

<u>OPCODE</u>	<u>DESCRIPTION</u>	<u>SECTION</u>
EX	External I/O Instruction	
HALT	Processor Halt Instruction	
HL	Load H and L Macro	4.1
IF<nn>	Conditional Assembly Directive	3.19
INCLUDE	Source File Inclusion Directive	3.1
INPUT	I/O Input Instruction	
JF<c>	Jump on False Condition Instruction	
JMP	Jump Instruction	
JT<c>	Jump on True Condition Instruction	
L<r>	Load Immediate Instruction	
L<r><r>	Load from Register Instruction	
LIST	Listing Control Directive	3.17
LOC	Location Counter Manipulative Directive	3.9
ML<r>	Memory Load Macro	4.5
MS<r>	Memory Store Macro	4.4
ND	And Immediate Instruction	
ND<r>	And with Register Instruction	
NOP	No Operation Instruction	
OR	Or Immediate Instruction	
OR<r>	Or with Register Instruction	
ORG	PAB Origination Directive	3.10
POP	Pushdown Stack Manipulation Instruction	
PUSH	Pushdown Stack Manipulation Instruction	
RET	Subroutine Return Instruction	
RF<c>	Conditional Subroutine Return Instruction	
RT<c>	Conditional Subroutine Return Instruction	
RPT	Repeat Source Line Directive	3.12
SB	Subtract with Borrow Immediate Instruction	
SB<r>	Subtract with Borrow Register Instruction	
SET	Address Counter Manipulation Directive	3.3
SKIP	Address/Location Counter Directive	3.4
SLC	Shift Left Circular Instruction	
SLN	Shift Left Numeric Macro	4.7
SRC	Shift Right Circular Instruction	
SRN	Shift Right Numeric Macro	4.6

<u>OPCODE</u>	<u>DESCRIPTION</u>	<u>SECTION</u>
SU	Subtract Immediate Instruction	
SU<r>	Subtract Register Instruction	
SYNC	Processor Sync Instruction	
TM	Tab Page Maybe Directive	3.6
TP	Tab Page Directive	3.5
USE	PAB Manipulation Directive	3.11
XIF	End Conditional Assembly Directive	
XR	Exclusive Or Immediate Instruction	
XR<r>	Exclusive Or Register Instruction	



APPENDIX C. EXTERNAL COMMAND REPERTOIRE

<u>MNEMONIC</u>	<u>SIGNAL</u>	<u>ADDRESS</u>	<u>DESCRIPTION</u>
ADR	Address	All	Select New Device
BEEP	--	All	Activate Tone Producing Mechanism
BSP	--	0360	Back Up One Record
CLICK	--	All	Activate Click Producing Mechanism
COM1	Command 1	All	Output a Control Function
COM2	Command 2	All	Output a Control Function
COM3	Command 3	All	Output a Control Function
COM4	Command 4	All	Output a Control Function
DATA	Sense Data	All	Connects Device Data to Input Lines
DECK1	--	0360	Select Cassette Deck 1
DECK2	--	0360	Select Cassette Deck 2
RBK	--	0360	Enable Read Circuitry and Forward Motion
REWIND	--	0360	Rewind The Selected Deck
SB	--	0360	Slew Backward Motion
SF	--	0360	Slew Forward Motion
STATUS	Sense Status	All	Connects Device Status to Input Lines
TSTOP	--	0360	Stop Any Deck Motion

<u>MNEMONIC</u>	<u>SIGNAL</u>	<u>ADDRESS</u>	<u>DESCRIPTION</u>
WBK	--	0360	Enable Write Circuitry and Forward Motion
WRITE	Write Strobe	All	Indicates Output Data Availability

APPENDIX D. OBJECT FILE FORMAT

The object file created by the ASSEMBLER has a system loader object format (see DOS User's Guide, Part IV, Sections 3.1 and 3.2):

<u>Logical Record Number</u>	<u>Byte #</u>	<u>Description</u>
LRN 0 (RIB)	0	Physical File Number
	1	Logical Record Number (LSB)
	2	Logical Record Number (MSB)
	3	0377
	4	Segment Descriptor 1
	5	
	6	Segment Descriptor 2
	.	
	.	
	2N+2	Segment Descriptor N
	2N+3	
2N+4	0377	
2N+5	0377	
LRN 1 (RIB COPY)		
LRN 2	0	Physical File Number
	1	Logical Record Number (LSB)
	2	Logical Record Number (MSB)
	3	0 - indicating data block
	4	Starting address of block (LSB)
	5	Starting address of block (MSB)
	6	One's complement of LSB of starting address
	7	One's complement of MSB of starting address
	8	Block length (n)
	9	Beginning of data
	.	
	.	
	n+9	0 - Next data block
n+10	Starting address of block (LSB)	
n+11	Starting address of block (MSB)	
n+12	One's complement of LSB of	

```

                                starting address
n+13  One's complement of MSB of
                                starting address
n+14  Block length (m)
n+15  Beginning of block data
.
.
.
n+m+15 0 - Next data block
.
.
.
.      0377 - End of Record

LRN 3      0      Physical File Number
           1      Logical Record Number (LSB)
           2      Logical Record Number (MSB)
           3      0 - Next data block
           .
           .
           .

LRN N      0
           .
           .
           .
           .      0 - Last data block
           .      Transfer address (LSB)
           .      Transfer address (MSB)
           .      One's complement of the LSB of the
                   transfer address
           .      One's complement of the MSB of the
                   transfer address
           .      0 - block length equal to zero
                   signifies end-of-file

```

APPENDIX E. SAMPLE PROGRAM

The following pages contain a sample assembly language program to give the reader a better understanding of the output he will see from the ASSEMBLER. Due to its tutorial nature, the program itself does not do anything useful. However, an example of every instruction, expression, directive, and Assembler Macro is given along with examples of how various errors are flagged and treated.

DOSASM5 3.1 568 LABELS

INCLUSION A: ASM5TST2/TXT

E 17.A	4DOGS	EQU	\$	THIS IS AN ERROR DURING INCLUSION
U 19.A	HICUPS	EQU	MANY	THIS WILL PRODUCE A 'D' ERROR
F 43.A		END		ERROR! THIS IS AN INCLUDED LINE

INCLUSION B: ASM5TST2/TXT

E 17.B	4DOGS	EQU	\$	THIS IS AN ERROR DURING INCLUSION
D 19.B	HICUPS	EQU	MANY	THIS WILL PRODUCE A 'D' ERROR
F 43.B		END		ERROR! THIS IS AN INCLUDED LINE
D 287.	TABLE	DC	010,020,030	THREE CODE BYTES ARE GENERATED
E 306.		DC	'PROGRAM XXXXX VERSION ', '0'+VER	
E 313.		DC	'PROGRAM XXXXX VERSION ', '0'+VER	
E 320.	1DOG	LA	5	
E 321.	2DOG	LA	DOGGIE	ONLY ONE ERROR FLAG WILL BE SEEN
E 322.	QUICK%	DC	'INVALID DUE TO TRAILING % MARK'	
E 332.		SLN	25	
E 341.		DA	**3+TABLE	

ERRORS: DEUF

PROGRAM ADDRESS BLOCKS:	007314	/ABSOLUTE/	LTH=000673
	010000	/DATA/	LTH=000364
	012000	/CODE/	LTH=000000
	014000	/BUFFER/	LTH=000360
	014000	/INIT/	LTH=000137

PRIMARY TRANSFER ADDRESS: 014000

ENTRY POINTS:	014000	BUFFER
	010006	PNTR
	010176	INCHL

MULTIPLE DEFINITIONS:	SEC
	MANY
	PNTR
	DECHL

UNDEFINED LABELS: DOGGIE

UNUSED LABELS:	QUICK
	DISPL

```

1.
2.
3.
4.      . ASSEMBLER 5 SAMPLE PROGRAM
5.
6.      . THESE LINES ARE COMMENT LINES
7.      . IT IS USUALLY A GOOD IDEA TO IDENTIFY YOUR PROGRAM AT THE
8.      . BEGINNING WITH SEVERAL COMMENT LINES WHICH CONTAIN THE
9.      . NAME OF THE PROGRAM AND ITS PURPOSE.  ANOTHER IMPORTANT
10.     . USE OF COMMENT LINES IS TO DESCRIBE THE LOGIC FLOW OF THE
11.     . PROGRAM IN A BLOCK FORM WHICH CAN BE DESCRIBED IN DETAIL
12.     . IN THE COMMENT FIELD OF SOURCE CODE.
13.
14.
15.
16.     . THE USE OF EQU'S AND ORG'S AT THE BEGINNING OF THE PROGRAM FOR
17.     . SETTING UP CONSTANTS WHICH ARE SUBJECT TO CHANGE (SUCH AS
18.     . DEVICE ADDRESS, BUFFER LENGTHS, PROGRAM BLOCK ADDRESSES,
19.     . TABLE ENTRY LENGTHS, COUNTER STEP SIZES, ETC) MAKES THE
20.     . PROGRAM EASIER TO 'READ' AND CAN SAVE A LOT OF TIME WHEN
21.     . THE NEED ARISES TO CHANGE ONE OF THESE CONSTANTS.
22.
23.
24.
25.
26.     000341      KEYBD      EQU      0341          DEVICE ADDRESS OF 2200 KEYBOARD
27.     000341      DISPL      EQU      KEYBD        NOTICE THAT SIMPLY CHANGING THE
28.
29.
30.
31.     . THE LABEL 'DISPL' WILL BE LISTED ON PAGE 1 UNDER 'UNUSED'
32.     . LABELS SINCE IT IS NOT REFERENCED ANYWHERE IN THE PROGRAM.
33.     . 'UNUSED' LABELS ARE DEFINED AS LABELS WHICH ARE UNREFERENCED
34.     . IN THE PROGRAM, NOT DECLARED AS ENTRY POINTS FOR USE BY
35.     . OTHER PROGRAMS, AND WHICH ARE NOT DEFINED IN AN INCLUDED
36.     . FILE.  ALL THREE CONDITIONS MUST BE MET!
37.
38.     000252      M252       EQU      0252          THESE ARE MASKS WHICH WILL
39.     000125      M125       EQU      0125          BE USED LATER WITH THE LOGICAL
40.     000377      M377       EQU      0377          EXPRESSION FIELD OPERANDS
41.
42.     010000      DATA      ORG      010000        DATA BLOCK
43.     012000      CODE       ORG      012000        CODE BLOCK
44.     014000      BUFFER     ORG      014000        BUFFERS
45.     014000      INIT       ORG      014000        INITIALIZATION (OVERLAYS BUFFER AREA)

```

APPENDIX E. SAMPLE ASSEMBLY LANGUAGE PROGRAM

```
46. + THIS WILL FORCE A NEW LISTING PAGE
47. .
48. .
49. 007314 SET 007314 NOTICE THAT THE ABSOLUTE PAB
50. . WILL IMPLICITLY BE USED HERE
51. .
52. 007400 TP THIS WILL FORCE A NEW MEMORY PAGE
53. .
54. 007400 SK 200 IF WE HAVE A TABLE 60 BYTES IN LENGTH
55. . WHICH WE ARE COUNTING ON AS BEING
56. . ON ONE PAGE (PAGE-DEPENDENT), WE
57. . CAN USE A TM DIRECTIVE LIKE THIS
58. 010000 TM 60 TO MAKE SURE THAT THE ENTIRE TABLE
59. . WILL EITHER FIT ON THE CURRENT MEMORY
60. . PAGE OR A NEW PAGE WILL BE STARTED
```



```

61.
62.
63.
64. 010000 006 341
65. 010002 121
66. 010003 101
67. 010004 044 002
68. 010006 150 003 020
69. 010011 125
70.
71. 010012 101
72. 010013 066 056 056 020
73. 010017 370
74. 010020 106 176 020
75. 010023 377
76. 010024 151
77.
78. 010025 123
79. 010026 101
80. 010027 012
81.
82. 010030 100 026 020
83.
84.
85. 010033 066 056 056 020 370
86.
87. 010040 066 056 056 020
88. 010044 370
89.
90. 010045 056 020
91. 010047 066 056
92. 010051 370
93.
94. 010052 127
95. 010053 104 053 020
96.
97.
98. 010056
99.
100.
101.
102.
103.
104.
105. 010176 306
106. 010177 004 001
107. 010201 360
108. 010202 305
109. 010203 014 000
110. 010205 350

```

+
. THE FOLLOWING PORTION OF CODE IS A SAMPLE 2200 I/O ROUTINE
.

```

        LA    KEYBD      PICK UP AN OCTAL 341 IN THE A-REGISTER
        EX    ADR        AND ADDRESS THE KEYBOARD
WAITI   INPUT          GET THE DEVICE STATUS IN A
        ND    2          CHECK FOR THE READ READY BIT
        JTZ   WAITI      AND WAIT UNTIL IT IS SET TO A 1
        EX    DATA     SWITCH FROM STATUS TO DATA ON THE
                        2200 INPUT LINES
        IN                    AND INPUT THE ACTUAL DATA CHARACTER
        HL    CHAR      POINT H AND L TO MEMORY LOCATION 'CHAR'
        LMA                    AND STORE THE CHARACTER WHICH IS IN A
        CALL  INCHL     POINT H AND L TO THE NEXT MEMORY LOCATION
        HALT                    STOP THE 2200
        EX    BEEP      AND BEEP WHEN 'RUN' IS PRESSED
. NOTICE THE FOLLOWING TWO LINES AND THE SEPARATE USES OF 'STATUS'
        EX    STATUS     SWITCH BACK TO THE DEVICE STATUS
STATUS  IN                    AND GET THE NEW STATUS
        SRC                    CHECK FOR DISPLAY READY BY POSITIONING
                        THE READY BIT SUCH AS TO SET THE CARRY FLAG
        JFC    STATUS    AND WAIT FOR THE BIT TO BECOME NON-ZERO
. BELOW ARE THREE MANNERS IN WHICH TO GENERATE THE 5 BYTES OF
. CODE WHICH ARE REQUIRES TO STORE THE A-REGISTER IN 'CHAR'
        MSA    *CHAR    YOU CAN USE A SINGLE MACRO
.
        HL    CHAR      YOU CAN USE A MACRO
        LMA                    AND A 2200 MNEMONIC
.
        LH    CHAR>8    YOU CAN ALSO USE THREE
        LL    CHAR      INDEPENDENT 2200
        LMA                    INSTRUCTION MNEMONICS
.
        EX    WRITE     OUTPUT THE CHARACTER IN A
        JMP    $         THIS WILL HANG IN AN ENDLESS LOOP!
. NOTICE THAT THE STORAGE ARRAY CALLED 'CHAR' MAY BE INTERSPERSED
. WITH THE CODE PROVIDING THAT NO ATTEMPT IS MADE TO EXECUTE IT
CHAR   SK    80        THIS WILL ALLOW 80 MEMORY LOCATIONS
                        TO BE USED FOR THE ARRAY BUT NO
                        DATA WILL BE LOADED INTO THE ARRAY
.
.
* FORCE THE FOLLOWING ROUTINE TO BE PRINTED ON ONE PAGE
. INCHL -- INCREMENT H AND L BY 1
.
INCHL*  LAL          LOAD THE L-REG INTO THE A-REG
        AD    1          ADD ONE TO THE A-REG
        LLA         LOAD THE L-REG BACK FROM THE A-REG
        LAH         LOAD THE H-REG INTO THE A-REG
        AC    0          ADD 1 ONLY IF L OVERFLOWED
        LHA         RELOAD H-REG FROM THE A-REG

```

```

112.
113.
114.
115.
116. 014000
117. 014000
118. 010000
119. 010000 000 030
120. 014120
121. 014120
122. 010002
123. 010002 120 030
124. 014240
125. 014240
126. 010004
127. 010004 240 030
128.
129.
130.
131.
132.
133. 010006
134.
135.
136. 010006 000 030
136. 010010 120 030
136. 010012 240 030
137.
138.

```

```

+
. NOTICE THAT THE ASSEMBLER KEEPS TRACK OF THE ADDRESS COUNTER
. WHEN SWITCHING BETWEEN PABS TO GENERATE TABLES
.
BUFFER* USE BUFFER SET UP 3 BUFFERS IN ONE BLOCK
BUF1 SK 80
USE DATA POINT TO THE 3 BUFFERS
PNTR* DA BUF1
USE BUFFER RETURN TO THE BUFFER BLOCK
BUF2 SK 80
USE DATA
DA BUF2
USE * IMPLIED USAGE OF 'BUFFER' PAB
BUF3 SK 80
USE * IMPLIED USAGE OF 'DATA' PAB
DA BUF3
.
. NOTICE THAT A SIMPLIER MANNER IN WHICH TO GENERATE THE POINTER
. TABLE FOLLOWS AND THAT THIS PROCEDURE WILL NOT GENERATE
. DICTIONARY ENTRIES WHICH MAY NOT OTHERWISE BE NEEDED.
.
PNTR= EQU $ NOTICE THAT ALL REFERENCES TO 'PNTR'
WILL USE THE CURRENT ADDRESS
.
RPT 3
DA $-PNTR/2*80+BUFFER
DA $-PNTR/2*80+BUFFER
DA $-PNTR/2*80+BUFFER
.
. ALSO NOTICE THAT THE EXPRESSION FIELD IS TOTALLY ORDER-DEPENDENT!

```

```

139.
140.
141.
142.
143.
144.
145.
146.
147. 014000
148.
149. 014000 066 000 056 000
150. 014004 070
151. 014005 066 040 056 030
152. 014011 026 077
153. 014013 307
154. 014014 106 176 020
155. 014017 335
156. 014020 346
157. 014021 060
158. 014022 370
159. 014023 106 176 020
160. 014026 070
161. 014027 302
162. 014030 024 001
163. 014032 320
164. 014033 353
165. 014034 364
166. 014035 100 013 030
167.
168.
169.
170.
171.
172.
173.
174.

```

+
. ANOTHER FEATURE OF USING PAB'S IS THAT THE ASSEMBLER CAN KEEP
. TRACK OF THE USAGE OF THE SAME BLOCK OF CODE WITH TWO DIFFERENT
. PAB'S FOR USE IN SETTING UP BUFFERS, ETC. WHICH DO NOT ACTUALLY
. LOAD MEMORY (THEY GENERALLY ARE SKIPS) AND THEN OVERLAY THESE
. BUFFERS WITH ONE-SHOT INITIALIZATION PROCESSES.
.
.
. USE INIT OVERLAY THE BUFFERS
. THIS CODE MOVES THE ROUTINE 'INT' INTO LOW CORE (LOC'N 0000)
START HL 0000 POINT TO DESTINATION ADDRESS
PUSH AND PUSH IT ON THE STACK
HL INT POINT TO SOURCE ADDRESS
LC INTEND-INT C = ROUTINE LENGTH
MOVE LAM PICK UP A BYTE
CALL INCHL BUMP THE SOURCE ADDRESS
LDH AND STORE IT IN D AND E
LEL
POP GET THE DESTINATION ADDRESS
LMA AND STORE THE BYTE
CALL INCHL BUMP THE DESTINATION ADDRESS
PUSH AND STORE IT ON THE STACK
LAC MOVE THE COUNTER FROM C TO A
SU 1 DECREMENT THE COUNT BY ONE
LCA RELOAD C WITH THE COUNTER
LHD RESTORE SOURCE ADDRESS
LLE
JFC MOVE LOOP UNTIL ENTIRE ROUTINE IS MOVED

. NOTICE THAT THE STACK IS LEFT WITH THE LAST DESTINATION ADDRESS+1
. AT THIS POINT. THIS WILL DO NO HARM IF THE PROGRAMMER DOES NOT
. EXECUTE A RETURN INSTRUCTION FROM THIS STACK LEVEL. HOWEVER,
. IT IS A GOOD PRACTICE FOR SUBROUTINES TO ALWAYS RETURN THE STACK
. TO THE SAME LEVEL AS WHEN ENTERED UPON EXIT.
.
.
.

```

175.
176.
177.
178.
179.
180.
181.
182.
183.
184.
185.
186.
187.
188. 014040      INT      EQU      $          THIS IS THE LOADING ADDRESS
189. 000000L     LOC      0000      WHEREAS THIS IS THE EXECUTION ADDRESS
190. 000000L 040  DI          DISABLE INTERRUPTS
191. 000001L 020  BETA       SWITCH TO BETA MODE REGISTERS
192. 000003      MSEC     EQU      $+1    MILLISECOND TIMER
193. 000002L 006 000  LA      0000      LOAD THE MILLISECOND TIMER
194. 000004L 004 001  AD      1          AND BUMP IT BY ONE
195. 000006L 074 372  CP      250      CHECK FOR 1/4 SECOND VALUE
196. 000010L 100 037 000  JFC     INT2     AND JUMP IF ATTAINED
197. 000013L 066 003 056 000  HL      MSEC     POINT HL TO 'MSEC'
198. 000017L 300      NOP
199. 000020L 300      NOP          THESE NOP'S ARE FOR TIMING!
200. 000021L 300      NOP
201. 000022L 026 004  LC      4          SET TIMING LOOP COUNT
202. 000024L 370  IDLE     LMA       STORE THE NEW TIMER VALUE
203. 000025L 302      LAC       GET THE LOOP COUNT
204. 000026L 024 001  TIMEIT  SU      1    DECREMENT THE COUNT
205. 000030L 300      NOP          USED FOR TIMING
206. 000031L 110 026 000  JFZ     TIMEIT   CYCLE IN TIMING LOOP
207. 000034L 030  GOBACK  ALPHA    RETURN TO THE ALPHA MODE REGISTERS
208. 000035L 050      EI          ENABLE THE INTERRUPT SYSTEM
209. 000036L 007      RET        RETURN TO INTERRUPTED PROGRAM
210. 000037L 250  INT2    XRA       LOAD THE A-REGISTER WITH ZEROES
211. 000040L 066 003 056 000 370  MSA     *MSEC   CLEAR THE MILLISECOND TIMER
212.      . NOTICE THE USE OF THE * IN THE MSA AND MLA MACROS
213. 000045L 066 075 307  MLA     QSEC   PICK UP THE QUARTER SECOND TIMER
214. 000050L 004 001  AD      1          BUMP IT
215. 000052L 044 003  ND      3          AND FORCE MODULO 4 (SAME AS CP 4 HERE)
216. 000054L 026 002  LC      2          SET UP TIMING LOOP COUNTER
217. 000056L 110 024 000  JFZ     IDLE    GO BACK IF NOT A FULL SECOND
218. 000061L 006 000  LA      0
219. 000063L 370      LMA       CLEAR THE QUARTER SECOND TIMER
220. 000064L 066 076 307  MLA     SEC     PICK UP THE ACCUMULATED SECONDS
221. 000067L 004 001  AD      1          BUMP IT
222. 000071L 370      LMA       AND STORE IT
223. 000072L 104 034 000  JMP     GOBACK   THEN RETURN
224. 000075L 000  QSEC    DC      0
225. 000076L 000  SEC     DC      0          THIS IS THE ACTUAL 1 SECOND TIMER
226. 014137      INTEND  LOC      *          THIS IS THE END OF THE ROUTINE
227. 000076      SEC=    EQU      $-1-INT  THIS WILL ALSO SET THE TIMER'S ADDRESS

```

```

228.
229. +
230. . HERE ARE A FEW EXAMPLES OF CONDITIONAL ASSEMBLY IF STATEMENTS
231. .
232. . USE DATA
233. . LIST -G
234. . 010014 000 002 000 004 000 TABLE DA 01000,02000,03000,04000,05000,06000
235. . NOW TEST TO MAKE SURE THAT THE ABOVE 'TABLE' IS ALL ON THE SAME PAGE
236. . IFNE $>8,TABLE>8
237. . ERR ***** TABLE ERROR *****
238. . XIF
239. .
240. . MASK TESTING CAN ALSO BE DONE
241. .
242. . IF M252.O.M125,M377
243. . 010030 300 NOP THIS WILL BE ASSEMBLED
244. . XIF
245. .
246. . IFZ M252.A.M125
247. . IFGT 5,4
248. . IFS M377
249. . CONDITIONAL ASSEMBLY TESTS MAY BE NESTED TO ANY DEPTH. IN SUCH A
250. . CASE, THE CODE WILL ONLY BE ASSEMBLED IF ALL PRECEEDING TESTS ARE
251. . TRUE. NOTICE THAT ALTHOUGH THE THREE PRECEEDING IF'S ARE TRUE AS
252. . CAN BE SEEN BY THE ASSEMBLY OF THIS DC STATEMENT,
253. . 010031 001 002 003 004 005 DC 1,2,3,4,5
254. . THE FOLLOWING IF IS NOT SATISFIED AND THEREFORE THE LINES OF CODE
255. . WHICH FOLLOW IT WILL NOT BE EXAMINED BY THE STATEMENT SCANNER.
256. . IFLE 010,7
257. . SKIP 4 ALL OF THESE STATEMENTS ARE IGNORED
258. . HALT
259. . ERR
260. . DC 0,0
261. . DO NOTE THAT SINCE THE SCANNER IS ONLY LOOKING FOR AN XIF AT THIS
262. . TIME THAT ALTHOUGH THE FOLLOWING IF'S ARE SATISFIED ON A LINE FOR
263. . LINE BASIS, THEY WILL BE IGNORED AND WILL NOT ALLOW ASSEMBLY OF
264. . THE CODE WHICH FOLLOWS THEM.
265. . IFEQ 2,2
266. . DC 2
267. . IF 3,2*1+1
268. . DC 3
269. . NOP
270. . XIF
271. . 010036 005 004 DC 5,4 BUT THIS WILL TURN ON THE ASSEMBLY
ALLOWING THIS TO ASSEMBLE!

```

```

272.
273.
274.
275.
276.
E 17.A 010040
F 43.A
277.
278.
279.
280.
281.
1.B
2.B
3.B
4.B
5.B
6.B
7.B
8.B
9.B
10.B
11.B
12.B
13.B
14.B
15.B
16.B
E 17.B 010040
18.B
19.B 000007
20.B
21.B
22.B
23.B 000007
24.B
25.B
26.B
27.B
28.B
29.B
30.B 011304
31.B
32.B
33.B
34.B
35.B
36.B
37.B
38.B
39.B
40.B
41.B
42.B

+
. INCLUDE TEXT FROM ANOTHER FILE
.
      LIST -I          DO NOT LIST INCLUDED LINES
      INC  ASM5TST2
4DOGS EQU  $          THIS IS AN ERROR DURING INCLUSION
      END              ERROR! THIS IS AN INCLUDED LINE
.
. NOW INCLUDE THE SAME TEXT BUT LIST IT
.
      LIST I
      INC  ASM5TST2    THIS INCLUSION USES SUFFIX 'B'
.
. NOTICE THAT THIS IS LINE NUMBER 4 OF AN INCLUDED FILE.
. THE INCLUSION LEVEL IS INDICATED BY THE TRAILING CHARACTER
. OF THE LINE NUMBER WHICH WILL START WITH AN 'A' AND INCREMENT
. THROUGH THE ALPHABET AS EACH INCLUSION IS MADE REGARDLESS
. OF WHETHER THE INCLUDED LINES ARE LISTED OR NOT.
.
. ALL OF THE INCLUSION FILE INFORMATION LINKING EACH INCLUSION
. OF EACH FILE WITH AN ALPHABETIC CHARACTER IS GIVEN ON PAGE 1
. OF THIS LISTING IN SEQUENTIAL ORDER.
.
. NOTICE THAT THE CROSS-REFERENCE MAP WILL FLAG ALL REFERENCES
. WITH THEIR FILE IDENTIFICATION CHARACTER.
.
4DOGS EQU  $          THIS IS AN ERROR DURING INCLUSION
.
HICUPS EQU  MANY      THIS WILL PRODUCE A 'D' ERROR
.                      SINCE IT IS NOT SPECIFIED AS
.                      MULTIPLY DEFINABLE.
.
MANY= EQU  7          ALL INCLUDED ITEMS MUST HAVE THE
.                      TRAILING = MARK IF THEY MIGHT
.                      POSSIBLY BE DEFINED MORE THAN
.                      ONCE, SUCH AS IN THE CASE OF
.                      INCLUDED SUBROUTINES WHICH ALL
.                      USE COMMON OPERATING SYSTEM
.                      ROUTINES
.
DECHL= EQU  011304    HERE IS SUCH A CRITTER
.
. THE INCLUDED FILE IS ALSO AN INTEGRAL PART OF THE ASSEMBLER'S
. ENTRY POINT / EXTERNAL REFERENCE 'LINKING' CAPABILITY. THE
. ONLY MANNER IN WHICH THE ENTRY POINT FILE CAN BE USED IS BY
. AN INCLUSION IN AN OVERLAYED PROGRAM'S SOURCE FILE.
.
. INCLUDED FILES MAY NOT CONTAIN AN 'END' STATEMENT. FILES
. WHICH DO CONTAIN END'S ARE NOT TERMINATED AT THE END BUT ARE
. READ TO THEIR END OF FILE MARK WITH THE END STATEMENT(S) FLAGGED
. BY 'F' ERRORS WHICH ARE PRINTED REGARDLESS OF THE 'I' CONTROL FLAG.

```

PAGE 10

ASM5SMPL/TXT

APPENDIX E. SAMPLE ASSEMBLY LANGUAGE PROGRAM

F 43.B
44.B
45.B
46.B
47.B

END

ERROR! THIS IS AN INCLUDED LINE

.
. THESE ARE THE LAST TWO LINES OF THE INCLUDED FILE 'ASM5TST2' AND
. THE LINE IMMEDIATELY FOLLOWING THE INCLUDE WILL NOW BE SCANNED.

```

282.
283.
284.
285.
286.
287. 010040 010 020 030
288.
289.
290.
291.
292. 010043 124 110 111 123 040
    010050 115 125 114 124 111
    010055 055 103 110 101 122
    010062 101 103 124 105 122
    010067 040 115 105 123 123
    010074 101 107 105 040 111
    010101 123 040 107 117 117
    010106 104
293. 010107 102 105 103 101 125
    010114 123 105 105 101 103
    010121 110 105 130 120 122
    010126 105 123 123 111 117
    010133 116 123 124 101 122
    010140 124 123
294. 010142 127 111 124 110 101
    010147 123 124 122 111 116
    010154 107
295.
296.
297.
298.
299.
300. 000003
301.
302. 010155 120 122 117 107 122
    010162 101 115 040 130 130
    010167 130 130 130 040 126
    010174 105 122 123 111 117
    010201 116 040 063
303.
304.
305.
306. 010204 120 122 117 107 122
    010211 101 115 040 130 130
    010216 130 130 130 040 126
    010223 105 122 123 111 117
    010230 116 040 060 000
307.
308.
309.
310.
311.
312.
313. 010234 120 122 117 107 122

```

+
. NOW A MULTIPLE DEFINITION OF A PREVIOUS LABEL
. WHERE NO TRAILING EQUAL (=) IS USED PRODUCES
. AN ERROR IN PASS ONE (SEE PAGE ONE)
TABLE DC 010,020,030 THREE CODE BYTES ARE GENERATED
*
. HERE IS AN EXAMPLE OF THE SPECIAL DC STRINGS
.
LIST G
DC 'THIS MULTI-CHARACTER MESSAGE IS GOOD'
DC 'BECAUSE','EACH','EXPRESSION','STARTS'
DC 'WITH','A','STRING'
.
. A GOOD MANNER IN WHICH TO CHANGE A NUMBER WITHIN A DISPLAY
. MESSAGE WITHOUT SEARCHING FOR THE ACTUAL DC STATEMENT COULD
. BE HANDLED FROM AN EQU AT THE START OF THE PROGRAM.
.
VER EQU 3 PROGRAM VERSION NUMBER
. AND IMBEDDED WITHIN THE PROGRAM WOULD BE THE FOLLOWING:
DC 'PROGRAM XXXXX VERSION ',VER+'0'
.
. HOWEVER, THIS WILL PRODUCE AN ERROR:
.
DC 'PROGRAM XXXXX VERSION ', '0'+VER
.
. THE ASSEMBLER WILL PRINT ALL ERROR LINES REGARDLESS OF THE
. LIST CONTROL FLAGS. HERE IS THE ABOVE EXAMPLE WITH THE 'G'
. FLAG TURNED OFF AND THE ERROR PRINTED.
.
LIST -G
DC 'PROGRAM XXXXX VERSION ', '0'+VER


```

E 314. 010260 116 040 060 000
315.
316.
317.
318.
319.
E 320. 010264 006 005
U 321. 010266 006 000
E 322. 010270 111 116 126 101 114
      010275 111 104 040 104 125
      010302 105 040 124 117 040
      010307 124 122 101 111 114
      010314 111 116 107 040 045
      010321 040 115 101 122 113
323.
324.
325.
326. 010326 002 002 002 002 002
327. 010333 012 012 012
328.
329.
330.
331.
E 332. 010336 002 002 002 002 002
      010343 002 002 002
333.
334.
335.
336.
337. 010346 000 030 030 000
338. 010352 014 020 020 014 357
      010357 364 364 357
339.
340.
E 341. 010362 000 000
342.
343.
344.
345.
346.
347.
348.
349.
350.
351. 014000
ERRORS: EUF

```

*
. NOW NOTICE THE FLAGGING OF AN ILLEGAL LABEL WILL STILL
. ALLOW THE PRODUCTION OF CODE

```

      LIST G
1DOG LA 5
2DOG LA DOGGIE ONLY ONE ERROR FLAG WILL BE SEEN
QUICK% DC 'INVALID DUE TO TRAILING % MARK'

```

*
. THE SLN AND SRN MACROS GENERATE SEVERAL SLC OR SRC INSTRUCTIONS

```

      SLN 5
      SRN 3

```

. SINCE A ZERO SHIFT COUNT WILL NOT PRODUCE CODE, A VARIABLE
. MAY BE USED AS LONG AS THE RANGE 0-7 IS MAINTAINED

```

      SLN VER-VER

```

. ERROR OCCURS IF THE COUNT IS OUT OF RANGE

```

      SLN 25

```

*
. NOW NOTICE THE ORDER OF GENERATION OF THE MSP AND LSP IN THE
. FOLLOWING DA DIRECTIVES

```

      DA START,*START
      DA TABLE,*TABLE,*-TABLE,-TABLE

```

. ALTHOUGH A LEADING ASTERISK WILL SET THE 'STAR' FLAG, THE SECOND
. ASTERISK IMPLIES MULTIPLICATION AND THE MULTIPLIER DOES NOT EXIST

```

      DA **3+TABLE

```

*
. THE MNEMONIC STARTING ADDRESS IS 'START' AND BY PLACING THIS
. NAME IN THE EXPRESSION FIELD OF THE END STATEMENT, THE
. ASSEMBLER WILL FLAG ITS OCTAL ADDRESS AS THE 'PRIMARY
. TRANSFER ADDRESS' FOR THE LOADER. (ALSO NOTED AT THE FIRST
. OF THE LISTING)

```

      END START END OF ALL SOURCE STATEMENTS

```

14000	BUF1	*117	119						
14120	BUF2	*121	123						
14240	BUF3	*125	127						
14000	BUFFER	*116	136	136	136				
10056	CHAR	72	85	87	90	91	*98		
11304	DECHL	*30:A	*30:B						
00341	DISPL	*27							
*****	DOGGIE	321							
00034	GOBACK	*207	223						
00007	HICUPS	*19:A	*19:B						
00024	IDLE	*202	217						
10176	INCHL	74	*105	154	159				
14040	INT	151	152	*188	227				
00037	INT2	196	*210						
14137	INTEND	152	*226						
00341	KEYBD	*26	27	64					
00125	M125	*39	242	246					
00252	M252	*38	242	246					
00377	M377	*40	242	248					
00007	MANY	19:A	19:B	*23:A	*23:B				
14013	MOVE	*153	166						
00003	MSEC	*192	197	211					
10000	PNTR	*119	*133	136	136	136			
00075	QSEC	213	*224						
10270	QUICK	*322							
00076	SEC	220	*225	*227					
14000	START	*149	337	337	351				
10026	STATUS	*79	82						
10014	TABLE	*233	235	*287	338	338	338	338	
00026	TIMEIT	*204	206						
00003	VER	*300	302	330	330				
10003	WAITI	*66	68						

NUMBER OF SYMBOLS USED 32