

STEP 1



Remove Easy-Load Basket

Pull **Easy-Grip Handle** straight out.


STEP 2



Load Fry Basket

Arrange the food you are cooking inside the nonstick **Fry Basket**.

STEP 3



Return Easy-Load Basket to Unit

Do not press the **Basket Release Button** or it will separate from the **Fry Basket**.

STEP 4



Setting Time & Temperature

Follow instructions specific to your recipe. See included recipe book.

STEP 5



Separating Fry Basket from Easy-Load Basket

Remove **Easy Load Basket**. Set **Unit** on a secure, heat-resistant surface. Move **Sliding Button Guard** and press **Basket Release Button** gently.

NOTE:

- Before plugging the **Power AirFryer XL** into a power outlet, make sure all packaging material is removed from both outside and inside the **Unit**.
- After the cooking cycle has ended, the **Red Heat Light** will disappear along with all other icons on the **Digital Control Panel**. The **Blue Fan Icon** will continue to spin while the **Unit** cools down. After 20 seconds, the **Unit** will power **OFF** automatically.

Wash All Components Before First Use