

NETGEAR®

AC1200 WiFi DSL Modem Router— Essentials Edition

Model D6100

User Manual



December 2014
202-11364-01

350 East Plumeria Drive
San Jose, CA 95134
USA

Support

Thank you for selecting NETGEAR products.

After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>. You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website.

For product updates and web support, visit <http://support.netgear.com>.

Phone (US & Canada only): 1-888-NETGEAR.

Phone (Other Countries): Check the list of phone numbers at <http://support.netgear.com/general/contact/default.aspx>.

Compliance

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory>.

See the regulatory compliance document before connecting the power supply.

Trademarks

© NETGEAR, Inc. NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

Contents

Chapter 1 Hardware Overview of the Modem Router

Unpack Your Modem Router	9
Front Panel with LEDs	10
Back Panel with Ports, Buttons, and Connector	12
Right Side Panel with WPS and WiFi On/Off Buttons	13
Bottom Panel Product Label	14

Chapter 2 Install and Access the Modem Router and Its Network

Position Your Modem Router	16
Before You Connect to the Modem Router	17
Wired Connection	17
WiFi Connection	17
Types of Logins	17
NETGEAR genie Automatic Setup Utility	18
Set Up Your Modem Router for DSL Service	19
DSL Service	19
Cable the Modem Router for DSL Service and Access the Modem Router	20
Set Up Your Modem Router for Cable or Fiber Service	26
Log In to the Modem Router After Setup to View or Change Settings	33
Change the Language	34
Change the admin Password and Automatic Login Time-Out Period	34
Set Up Password Recovery	36
Let the Modem Router Automatically Update Its Firmware	36
Access the Modem Router with the NETGEAR genie App	37

Chapter 3 Manage the Internet Settings Manually

Use the Internet Setup Wizard After Initial Setup	40
Manually Set Up the Internet Connection	45
Specify an Internet Connection Without a Login	45
Specify an Internet Connection That Uses a Login and PPTP or L2TP Service	48
Specify an Internet Connection That Uses a Login and PPPoE Service	51
Specify an Internet Connection That Uses a Login and PPPoA Service	54
Specify an IPv6 Internet Connection	56
IPv6 Internet Connections and IPv6 Addresses	56
Set Up and IPv6 Connection Through Auto Detect	57
Set Up and IPv6 Connection Through Auto Config	59
Set Up an IPv6 6to4 Tunnel Connection	61
Set Up an IPv6 Pass-Through Connection	63

Set Up an IPv6 Fixed Connection	64
Set Up an IPv6 DHCP Connection	66
Set Up an IPv6 PPPoE Connection	68
Manage the MTU Size.....	70
MTU Concepts.....	70
Change the MTU Size.....	71

Chapter 4 Manage the WiFi Network Settings

Manage the Basic WiFi Settings and WiFi Security of the Main Network.....	73
View or Change the Basic WiFi Settings	73
Configure WPA/WPA2 Enterprise WiFi Security.....	78
Configure WEP Legacy WiFi Security	80
Use WPS to Add a Device to the WiFi Network	81
Use WPS with the Push Button Method	82
Use WPS with the PIN Method	83
Manage the Basic WiFi Settings and WiFi Security of the Guest Network....	84
Control the WiFi Radios	88
Use the WiFi On/Off Button	88
Enable or Disable the WiFi Radios.....	88
Set Up a WiFi Schedule.....	90
Manage the WPS Settings	92
Manage Advanced WiFi Features	93
Use the Modem Router as a WiFi Access Point.....	95

Chapter 5 Control Access to the Internet

Set Up Parental Controls	98
Allow or Block Access to Your Network.....	100
Enable and Manage Network Access Control.....	100
Manage Network Access Control Lists	102
Use Keywords to Block Internet Sites	105
Set Up Blocking	105
Remove a Keyword or Domain from the Blocked List.....	107
Remove All Keywords and Domains from the Blocked List	107
Specify a Trusted Computer	108
Set Up a Schedule for Keyword Blocking and Outbound Firewall Rules	109
Set Up Security Event Email Notifications.....	111

Chapter 6 Optimize Performance

Optimize Traffic with QoS	114
Manage Default and Custom QoS Rules	115
Add a Custom QoS Rule for a Service or Application	115
Add a Custom QoS Rule for a Device.....	117
Change a QoS Rule or Change the Priority for a Rule	119
Remove a QoS Rule.....	120
Remove All QoS Rules.....	121
Manage Uplink Bandwidth Control.....	121

Improve Network Connections with Universal Plug and Play	123
Manage Wi-Fi Multimedia Quality of Service	124

Chapter 7 Manage the WAN and LAN Network Settings

Manage the ADSL Settings	126
Change the WAN Connection Preference	127
Manage the WAN Security Settings	128
Set Up a Default DMZ Server	129
Manage IGMP Proxying and VPN Pass-Through	130
Manage NAT Filtering	131
Enable and Configure a VLAN	131
Manage the SIP Application-Level Gateway	132
Manage Dynamic DNS	133
Set Up a New Dynamic DNS Account	133
Specify a DNS Account That You Already Created	134
Manage the Modem Router’s LAN IP Address Settings	135
Manage the Router Information Protocol Settings	137
Manage Reserved LAN IP Addresses	138
Reserve a LAN IP address	138
Change a Reserved IP Address	139
Remove a Reserved IP Address Entry	139
Change the Modem Router’s Device Name	140
Manage the DHCP Server Address Pool	140
Disable the Built-In DHCP Server	142
Set Up and Manage Custom Static Routes	143
Set Up a Static Route	143
Change a Static Route	145
Remove a Static Route	145

Chapter 8 Manage the Modem Router and Monitor the Traffic

Update the Firmware of the Modem Router	148
Check for New Firmware and Update the Modem Router	148
Manually Upload New Firmware and Update the Modem Router	149
Manage the Configuration File of the Modem Router	151
Back Up the Settings	151
Restore the Settings	151
Recover the admin Password	152
Return the Modem Router to Its Factory Default Settings	153
Use the Reset Button	153
Erase the Settings	154
View the Status and Statistics of the Modem Router	155
View Information About the Modem Router and the Internet, Modem, and WiFi Settings	155
View the Traffic Statistics	159
View or Change a TCP/IP Internet Connection	161
View or Change a PPPoE or PPPoA Internet Connection	163
View or Change a PPTP or L2TP Internet Connection	164

Manage the Activity Log and Syslog	165
View the Logs	165
Specify Which Activities Are Logged.....	167
Specify a Syslog Server.....	167
View Devices Currently on the Network.....	168
Monitor and Meter Internet Traffic	169
Start the Traffic Meter Without Traffic Volume Restrictions.....	169
View the Traffic Statistics and Traffic Status	170
Restrict Internet Traffic by Volume	171
Restrict Internet Traffic by Connection Time.....	173
Unblock the Traffic Meter After the Traffic Limit Is Reached	174
Manage the Modem Router Remotely.....	175
Configure the Modem Router as a DSL Modem Only	177

Chapter 9 Manage Firewall Rules, Port Forwarding, and Port Triggering

Manage Outbound Firewall Rules for Services and Applications	179
Add an Outbound Firewall Rule.....	179
Change an Outbound Firewall Rule.....	181
Change the Priority of an Outbound Firewall Rule.....	182
Disable or Enable an Outbound Firewall Rule	183
Remove an Outbound Firewall Rule	184
Add a Custom Service or Application for Use in an Outbound Firewall Rule.....	185
Change a Custom Service or Application for Use in an Outbound Firewall Rule	187
Remove a Custom Service or Application for Use in an Outbound Firewall Rule	188
Manage Port Forwarding to a Local Server for Services and Applications...	189
Forward Incoming Traffic for a Default Service or Application	189
Add a Port Forwarding Rule with a Custom Service or Application.....	191
Change a Port Forwarding Rule	192
Remove a Port Forwarding Rule	193
Application Example: Make a Local Web Server Public.....	194
How the Modem Router Implements the Port Forwarding Rule	195
Manage Port Triggering for Services and Applications	195
Add a Port Triggering Rule.....	196
Change a Port Triggering Rule	197
Remove a Port Triggering Rule	199
Specify the Time-Out Period for Port Triggering	200
Disable Port Triggering.....	200
Application Example: Port Triggering for Internet Relay Chat.....	201

Chapter 10 Diagnostics and Troubleshooting

Perform Diagnostics	204
Ping an IP Address.....	204
Perform a DNS Lookup.....	204
Display the Routing Table.....	205

Reboot the Modem Router from the Web Management Interface	206
Quick Tips for Troubleshooting	206
Troubleshoot with the LEDs	207
Power LED Remains Solid Amber	208
Power LED Is Off	208
WiFi LED Is Off	208
You Cannot Log In to the Modem Router	209
Troubleshoot the Internet Connection	210
Troubleshoot the DSL Link	210
Internet LED Is Off	211
Obtain an Internet IP Address	211
Troubleshoot PPPoE or PPPoA	212
Troubleshoot Internet Browsing	213
Changes Are Not Saved	214
Troubleshoot the WiFi Connectivity	214
Troubleshoot Your Network Using the Ping Utility	215
Test the LAN Path to Your Modem Router	215
Test the Path from Your Computer to a Remote Device	216

Appendix A Supplemental Information

Factory Settings	218
Technical Specifications	220

Hardware Overview of the Modem Router

1

The NETGEAR® AC1200 WiFi DSL Modem Router—Essentials Edition Model D6100, in this manual referred to as the modem router, delivers WiFi connection speeds up to¹ 300 Mbps on 2.4 GHz 802.11n and up to 867 Mbps on 5 GHz 802.11ac. Both 2.4 GHz and 5 GHz bands can be active simultaneously. The modem router is compatible with most major DSL Internet service providers and also supports cable or fiber Internet service.

The chapter contains the following sections:

- *Unpack Your Modem Router*
- *Front Panel with LEDs*
- *Back Panel with Ports, Buttons, and Connector*
- *Right Side Panel with WPS and WiFi On/Off Buttons*
- *Bottom Panel Product Label*

Note: For more information about the topics that are covered in this manual, visit the support website at support.netgear.com.

Note: Firmware updates with new features and bug fixes are made available from time to time at downloadcenter.netgear.com. You can check for and download new firmware manually. If the features or behavior of your product does not match what is described in this guide, you might need to update your firmware.

Note: In this manual, the terms *wireless* and *WiFi* are interchangeable.

1. Actual data throughput and WiFi coverage will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, and network overhead, lower actual data throughput rate and WiFi coverage. NETGEAR makes no express or implied representations or warranties about this product's compatibility with any future standards.

Unpack Your Modem Router

Your package contains the following items.




Figure 1. Package contents for the modem router

Your package might contain more items. The filter or phone cable provided depends on the region, and in some locations, a CD is included.

Front Panel with LEDs

The modem router displays status LEDs on the front panel.




Figure 2. Modem router top view

The following table describes the LEDs from right to left and their behavior. For information about how to troubleshoot with the LEDs, see [Troubleshoot with the LEDs](#) on page 207.

Table 1. LED descriptions

LED	Icon	Description
Power		<ul style="list-style-type: none"> Solid green. The power is on and the modem router is functioning normally. Solid amber. The modem router is booting. After about one minute and 10 seconds, the Power LED turns solid green. If the LED does not turn green, a power-on self-test (POST) failure occurred or the modem router is malfunctioning. For more information, see Power LED Remains Solid Amber on page 208. Blinking amber. The Reset button on the back panel is pressed. When you release the Reset button, the Power LED blinks amber three times and then turns green as the modem router resets to the factory defaults. Off. The modem router is not receiving power.
DSL		<ul style="list-style-type: none"> Solid green. The modem router is providing a DSL connection. In technical terms, the DSL port is synchronized with an ISP's network-access device. Blinking green. The modem router is negotiating the best possible speed on the DSL line. Off. The modem router is not negotiating the speed on the DSL line and is not providing a DSL connection.
Internet		<ul style="list-style-type: none"> Solid green. The modem router is connected to the Internet. Solid Amber. The modem router failed to connect to the Internet. For more information, see Troubleshoot the Internet Connection on page 210. Alternating green and amber. The traffic meter is enabled and the traffic limit was reached. Off. The modem router did not detect an Internet connection or functions in bridge mode (that is, an external device handles the IP connection).
WiFi		<ul style="list-style-type: none"> Solid blue. One or both WiFi radios are enabled and the modem router is providing WiFi connectivity. Blinking blue. WPS (Wi-Fi Protected Setup) is active. Off. Both WiFi radios are disabled and the modem router is not providing WiFi connectivity. You can still plug an Ethernet cable into one of the LAN ports to get wired connectivity.

Back Panel with Ports, Buttons, and Connector

The back panel of the modem router provides ports, buttons, and a DC power connector. The following figure shows only part of the back panel.




Figure 3. Modem router back panel

Viewed from left to right, the back panel contains the following components:


- **ADSL port.** One RJ-11 asynchronous DSL (ADSL) port for connecting the modem router to an ADSL line.
- **Internet port.** One Gigabit Ethernet RJ-45 WAN port to connect the modem router to a fiber or cable modem. This port is colored red.

Note: You can use either the ADSL port or the Gigabit Ethernet port for WAN connectivity.

- **Ethernet LAN ports.** Two Gigabit Ethernet RJ-45 LAN ports to connect the modem router to LAN devices. These ports are colored yellow.
- **Power On/Off button.** Press the **Power On/Off** button to provide power to the modem router.
- **Reset button.** For information about using the **Reset** button, see *Use the Reset Button* on page 153.
- **DC power connector.** Connect the power adapter that came in the product package to the DC power connector.

Right Side Panel with WPS and WiFi On/Off Buttons

The right side panel provides the WiFi On/Off button and the WPS button.



The following table describes the buttons.

Table 2. Button descriptions

Button	Icon	Description
WiFi On/Off		By default, the 2.4 GHz and 5 GHz WiFi radios are enabled. Pressing this button for two seconds disables both radios. Pressing the button again for two seconds enables both radios. If you disable the radios, the WiFi LED on the front panel turns off. If you enable the radios, the WiFi LED on the front panel lights blue.
WPS		Pressing this button for two seconds activates WPS (Wi-Fi Protected Setup) to let you add a WiFi device to the WiFi network without typing the WiFi password. While WPS is active, the WiFi LED on the front panel blinks blue.

Bottom Panel Product Label

The product label on the bottom panel of the modem router lists the login information, WiFi network name (SSID) and password (network key), serial number, and MAC address of the modem router.




Figure 4. Modem router product label

Install and Access the Modem Router and Its Network

2

This chapter describes how you can install and access the modem router and its network.

The chapter contains the following sections:

- *Position Your Modem Router*
- *Before You Connect to the Modem Router*
- *Set Up Your Modem Router for DSL Service*
- *Set Up Your Modem Router for Cable or Fiber Service*
- *Log In to the Modem Router After Setup to View or Change Settings*
- *Change the Language*
- *Change the admin Password and Automatic Login Time-Out Period*
- *Set Up Password Recovery*
- *Let the Modem Router Automatically Update Its Firmware*
- *Access the Modem Router with the NETGEAR genie App*

Position Your Modem Router

The modem router lets you access your network anywhere within the operating range of your WiFi network. However, the operating distance or range of your WiFi connection can vary significantly depending on the physical placement of your modem router. For example, the thickness and number of walls the WiFi signal passes through can limit the range.

Additionally, other WiFi access points in and around your home might affect your modem router's signal. WiFi access points are routers, repeaters, WiFi range extenders, and any other device that emits a WiFi signal for network access.

Position your modem router according to the following guidelines:

- Place your modem router near the center of the area where your computers and other devices operate and within line of sight to your WiFi devices.
- Make sure that the modem router is within reach of an AC power outlet and near Ethernet cables for wired computers.
- Place the modem router in an elevated location, minimizing the number walls and ceilings between the modem router and your other devices.
- Place the modem router away from electrical devices such as these:
 - Ceiling fans
 - Home security systems
 - Microwaves
 - Computers
 - Base of a cordless phone
 - 2.4 GHz cordless phone
- Place the modem router away from large metal surfaces, large glass surfaces, insulated walls, and items such as these:
 - Solid metal door
 - Aluminum studs
 - Fish tanks
 - Mirrors
 - Brick
 - Concrete

If you are using adjacent access points, use different radio frequency channels to reduce interference.

Before You Connect to the Modem Router

During and after installation, you can connect to the modem router's network through a wired or WiFi connection. If you set up your computer to use a static IP address, change the settings of your computer so that it uses Dynamic Host Configuration Protocol (DHCP).

Wired Connection

You can connect your computer to the modem router using an Ethernet cable and join the modem router's local area network (LAN).

WiFi Connection

You can connect to the modem router's WiFi network, which is listed on the product label in the WiFi Network Name (SSID) field. The password that you must use to connect to the WiFi network is listed in the Network Key (Password) field.




Figure 5. Modem router product label with WiFi network name (SSID) and password (network key)

Types of Logins

Separate types of logins serve different purposes. This section describes the differences so that you know which login to use when.

Types of logins:

- **ISP login.** The login that your Internet service provider (ISP) gave you logs you in to your Internet service. Your ISP gave you this login information in a letter or some other way. If you cannot find this login information, contact your ISP.
- **WiFi network key or password.** Your modem router is preset with a unique WiFi network name (SSID) and password for WiFi access. This information is on the product label. Use this information to connect a WiFi device to the WiFi network of the modem router.
- **Modem router login.** This logs you in to the modem router interface from an Internet browser as admin.

NETGEAR genie Automatic Setup Utility

You can use the NETGEAR genie automatic setup utility during initial installation and setup of your modem router. This utility functions with both types of Internet service that the modem router supports:

- **DSL service.** If you install your modem router for DSL service, you can set up your modem router with the NETGEAR genie automatic setup utility, which launches the first time that you set up the Internet connection for your modem router. The NETGEAR genie automatic setup utility runs on any device with a web browser.

For more information, see *Set Up Your Modem Router for DSL Service* on page 19.

- **Cable or fiber service.** If you install your modem router for cable or fiber service, you can set up your modem router with the NETGEAR genie automatic setup utility, which launches the first time that you set up the Internet connection for your modem router. The NETGEAR genie automatic setup utility runs on any device with a web browser.

For more information, see *Set Up Your Modem Router for Cable or Fiber Service* on page 26.

Note: After initial installation and setup, the NETGEAR genie Setup Wizard is always accessible to assist you with setting up an installation with DSL service or an installation with cable or fiber service. For more information, see *Use the Internet Setup Wizard After Initial Setup* on page 40.

Whether you install your modem router for DSL service or for cable or fiber service, you can always use the genie menus and screens to set up your modem router manually.

Before you start the setup process, get your ISP information and make sure that the settings that are described here are specified for the computers and devices in the network.

When your Internet service starts, your Internet service provider (ISP) typically gives you all the information that you need to connect to the Internet. For DSL service, you might need the following information to set up your modem router:

- The ISP configuration information for your DSL account
- ISP login name and password
- Fixed or static IP address settings (special deployment by ISP; this setting is rare)

If you cannot locate this information, ask your ISP to provide it. When your Internet connection is working, you no longer need to launch the ISP login program on your computer to access the Internet. When you start an Internet application, your modem router automatically logs you in.

Set Up Your Modem Router for DSL Service

You can install your modem router for DSL service or for cable or fiber (Ethernet WAN) service. If you use a DSL modem, follow the procedure that is described in *Cable the Modem Router for DSL Service and Access the Modem Router* on page 20. If you use a cable or fiber modem, follow the procedure that is described in *Set Up Your Modem Router for Cable or Fiber Service* on page 26.

DSL Service

Make sure that your DSL service is active before you install the modem router. You need the following information to install your DSL modem and connect to the Internet:

- **DSL user name and password.** This information is included in the welcome letter your DSL ISP sent you when you signed up for your service. Record your DSL Internet service account user name and password.
- **Your telephone number or DSL account number.** If you do not use voice service, you can use your DSL account number in place of a phone number.

If you do not know or cannot locate your DSL user name and password, call your DSL Internet service provider (ISP). Be specific when speaking with your DSL Internet service provider. For example, you could say, “I need my DSL service user name and password. Can you help me?”

Note: If your provider says that they do not support NETGEAR services, tell them that you need only your DSL user name and password; you do not need support.

Cable the Modem Router for DSL Service and Access the Modem Router

The following figure shows the cabling of your modem router for DSL service.




Figure 6. Modem router cabling for DSL service

➤ **To connect your modem router to a DSL service:**

1. Unplug your DSL modem's power, leaving the DSL modem connected to the wall jack for your Internet service.
2. If your DSL modem includes a battery backup, remove the battery.
3. Install an ADSL microfilter between the phone line and the phone.
The product package contains an ADSL microfilter.
4. Use a phone cable to connect the microfilter to the gray ADSL port on the modem router.
The product package contains a phone cable.
5. If your DSL modem includes a battery backup, reinsert the battery.
6. Plug in your DSL modem's power and turn on your DSL modem.
7. Connect the power adapter to the modem router and plug it into an electrical outlet.
Wait for the Power LED  to light solid green, which takes about one minute.
8. If the Power LED does not light, press the **Power On/Off** button.

9. Connect a computer to the modem router by one of the following methods:

- **Ethernet cable.** Use an Ethernet cable to connect your computer to a yellow Ethernet LAN port on the modem router.


The product package contains a yellow Ethernet cable.
Your computer connects to the modem router's LAN.
- **WiFi.** Connect to the default WiFi network of the modem router:
 - a. On your computer or WiFi device, find and select the WiFi network.

The WiFi network name (SSID) is on the product label.
 - b. Join the WiFi network and enter the WiFi password.

The password (network key) is on the product label.
Your computer or WiFi device connects to the modem router's WiFi network.

10. Launch a web browser.

The NETGEAR genie automatic setup utility displays. (This utility is also called the Setup Wizard.)



If the NETGEAR genie automatic setup utility displays, skip to [Step 12](#). If it does not display, do the following:

- a. In the address field of the web browser, enter www.routerlogin.net.
- b. When prompted, enter **admin** for the user name and **password** for the password.


If the NETGEAR genie automatic setup utility displays, skip to [Step 12](#). If the NETGEAR genie automatic setup utility still does not display, see [Step 11](#).

11. If the browser cannot display the web page, do the following:

- Make sure that the computer is connected to one of the two Ethernet LAN ports or over WiFi to the modem router.
- Make sure that the Power LED of the modem router is lit green .
- Make sure that your browser does not cache the previous page by closing and reopening the browser.

- Clear the browser cache.
- If the computer is set to a static or fixed IP address (this setting is uncommon), either change the computer to obtain an IP address automatically from the modem router through DHCP, or change the IP address of the computer to a static or fixed IP address in the 192.168.0.2–192.168.0.254 range.

12. Click the **Next** button.



13. From the **Country** menu, select the country in which you use the modem router.


14. From the **ISP** menu, select the ISP that you are using.

If your ISP is not in the menu, select **Other**.

15. Select the **Yes** radio button.


16. Click the **Next** button.

The Setup Wizard searches your Internet connection for servers and protocols to determine your ISP configuration.



When the modem router is connected to the Internet, the **Congratulations!** screen displays, and you successfully completed the setup process.

If the **Congratulations!** screen does not display, other screens might display and you might need to provide more information, in which case you must continue with the next step. The screens that display depend on your type of ISP connection and configuration.



17. (Only if the following screen displays) Specify a full scan to let the Setup Wizard find the PVC protocol.


The screen that displays might ask you if you need the Setup Wizard to do a full scan to find the PVC protocol. If this screen does not display, continue with the next step.



Do the following:

- Select the **Yes** radio button.
- Click the **Next** button.

The Setup Wizard performs a full scan, which might take up to six minutes.



18. (Only if the following screen displays) Specify how to manage problems with the detection of the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection. If this screen does not display, continue with the next step.

Problem Detecting the Internet Connection

This is most likely due to one of the following reasons:

1. The modem was not power cycled during the cabling step.

To solve this problem, power cycle the modem (turn it off and on). To power cycle a modem with battery backup, you might need to remove and reinsert its battery. After the power cycle, wait 2 minutes for the modem to completely start up.

2. The yellow Ethernet cable is not fully inserted, or is inserted in the wrong place.

To solve this problem, make sure that the yellow Ethernet cable is securely plugged in to the broadband modem port and the router Internet port.

- I just power cycled the modem and waited for 2 minutes.
- I corrected a problem with the Ethernet cable.
- None of the above.

Next

Note: The option for the Ethernet cable connection that is stated onscreen applies to a cable or fiber Internet connection only (see *Set Up Your Modem Router for Cable or Fiber Service* on page 26).

Take one of the following actions:

- If you already power-cycled the DSL modem (see *Step 1* through *Step 6*), do the following:
 - a. Select the **None of the above** radio button.
 - b. Click the **Next** button.
- If you did not yet power-cycle the DSL modem:
 - a. Unplug your DSL modem's power, leaving the DSL modem connected to the wall jack for your Internet service.
 - b. If your DSL modem includes a battery backup, remove the battery.
 - c. Wait 10 seconds.
 - d. If your DSL modem includes a battery backup, reinsert the battery.
 - e. Plug in your DSL modem's power and turn on your DSL modem.
 - f. Wait two minutes.
 - g. Select the **I just power cycled the modem and waited for 2 minutes** radio button.
 - h. Click the **Next** button.

19. (Only if the following screen displays) Specify how to manage problems with the detection of the IP address for the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection IP address.

Problem Detecting the Internet Connection - IP Address

Did your Internet Service Provider (ISP) assign to you a fixed (static) IP address? This is a **very rare special deployment**.

Select an option and click **Next** to proceed.

- Yes. My ISP assigned a fixed (static) IP address to me.
- No, I did not get a fixed (static) IP address from my ISP.
- I don't know.

Next

Take one of the following actions:

- If your ISP assigned you a fixed (static) IP address, do the following:
 - a. Select the **Yes** radio button.
 - b. Click the **Next** button.


Fixed Internet IP Settings

Enter the fixed IP settings assigned by your Internet Service Provider and click **Next** to proceed.

My IP Address	<input type="text"/>
Subnet Mask	<input type="text"/>
Default Gateway	<input type="text"/>
Preferred DNS Server	<input type="text"/>
Alternate DNS Server	<input type="text"/>

Next

- c. Enter the address information that your ISP gave you for your fixed IP address configuration.
- d. Click the **Next** button.
- If your ISP did not assign you a fixed IP address or you do not know if your ISP assigned you a fixed IP address, do the following:
 - a. Select either the **No** or the **I don't know** radio button.
 - b. Click the **Next** button.



c. Enter the MAC address of the computer or router with which you previously were able to connect to the Internet.

You might find the MAC address on the product label of your device. Enter the MAC address in the AABBCCDDEEFF format, not in the AA:BB:CC:DD:EE:FF format.

d. Click the **Next** button.

20. If the Congratulations! screen still does not display and the modem router still does not connect to the Internet, do the following:

a. Review all your settings.

Make sure that you selected the correct options and entered everything correctly.

b. Run the Setup Wizard one more time.

c. Contact your ISP to verify that you are using the correct configuration information.

d. Read *Troubleshoot the Internet Connection* on page 210.

e. If problems persist, register your NETGEAR product and contact NETGEAR technical support.

Set Up Your Modem Router for Cable or Fiber Service

You can install your modem router for cable or fiber (Ethernet WAN) service or for DSL service. If you use a cable or fiber modem, follow the procedure that is described in this section. If you use a DSL modem, follow the procedure that is described in *Cable the Modem Router for DSL Service and Access the Modem Router* on page 20.

The following figure shows the cabling of your modem router for cable or fiber service.




Figure 7. Modem router cabling for cable or fiber service


➤ **To connect your modem router to a cable or fiber service:**

1. Unplug your cable or fiber modem's power, leaving the modem connected to the wall jack for your Internet service.
2. If your cable or fiber modem includes a battery backup, remove the battery.
3. Use an Ethernet cable to connect the cable or fiber modem to the red Internet port on the modem router.
4. Plug in and turn on your cable or fiber modem.
5. If your cable or fiber modem includes a battery backup, reinsert the battery.
6. Connect the power adapter to the modem router and plug it into an electrical outlet. Wait for the Power LED  to light solid green, which takes about one minute.
7. If the Power LED does not light, press the **Power On/Off** button.
8. Connect a computer to the modem router by one of the following methods:
 - **Ethernet cable.** Use an Ethernet cable to connect your computer to a yellow Ethernet LAN port on the modem router.
The product package contains a yellow Ethernet cable.
Your computer connects to the modem router's LAN.

- **WiFi.** Connect to the default WiFi network of the modem router:
 - a. On your computer or WiFi device, find and select the WiFi network.
The WiFi network name (SSID) is on the product label.
 - b. Join the WiFi network and enter the WiFi password.
The password (network key) is on the product label.Your computer or WiFi device connects to the modem router's WiFi network.

9. Launch a web browser.

The NETGEAR genie automatic setup utility displays. (This utility is also called the Setup Wizard.)



If the NETGEAR genie automatic setup utility displays, skip to [Step 11](#). If it does not display, do the following:


- a. In the address field of the web browser, enter www.routerlogin.net.
- b. When prompted, enter **admin** for the user name and **password** for the password.

If the NETGEAR genie automatic setup utility displays, skip to [Step 11](#). If the NETGEAR genie automatic setup utility still does not display, see [Step 10](#).

10. If the browser cannot display the web page, do the following:

- Make sure that the computer is connected to one of the two Ethernet LAN ports or over WiFi to the modem router.
- Make sure that the Power LED of the modem router is lit green .
- Make sure that your browser does not cache the previous page by closing and reopening the browser.
- Clear the browser cache.
- If the computer is set to a static or fixed IP address (this setting is uncommon), either change the computer to obtain an IP address automatically from the modem router through DHCP, or change the IP address of the computer to a static or fixed IP address in the 192.168.0.2–192.168.0.254 range.

11. Click the **Next** button.



12. From the **Country** menu, select the country in which you use the modem router.


13. From the **ISP** menu, select the ISP that you are using.

If your ISP is not in the menu, select **Other**.

14. Select the **Yes** radio button.

15. Click the **Next** button.

The Setup Wizard searches your Internet connection for servers and protocols to determine your ISP configuration.



When the modem router is connected to the Internet, the **Congratulations!** screen displays, and you successfully completed the setup process.

If the **Congratulations!** screen does not display, other screens might display and you might need to provide more information, in which case you must continue with the next step. The screens that display depend on your type of ISP connection and configuration.

Congratulations!

You are successfully connected to the Internet.

This router is preset with the following unique wireless network name (SSID) and [network key \(password\)](#)

2.4GHz Wireless Network Name (SSID): **NETGEAR23**
Wireless [Network Key \(Password\)](#) : jaggedtrumpet276

5GHz Wireless Network Name (SSID): **NETGEAR23-5G**
Wireless [Network Key \(Password\)](#) : jaggedtrumpet276

[Print this](#) [Take me to the Internet](#)

16. (Only if the following screen displays) Specify how to manage problems with the detection of the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection. If this screen does not display, continue with the next step.

Problem Detecting the Internet Connection

This is most likely due to one of the following reasons:

1. The modem was not power cycled during the cabling step.
To solve this problem, power cycle the modem (turn it off and on). To power cycle a modem with battery backup, you might need to remove and reinsert its battery. After the power cycle, wait 2 minutes for the modem to completely start up.

2. The yellow Ethernet cable is not fully inserted, or is inserted in the wrong place.
To solve this problem, make sure that the yellow Ethernet cable is securely plugged in to the broadband modem port and the router Internet port.

I just power cycled the modem and waited for 2 minutes.
 I corrected a problem with the Ethernet cable.
 None of the above.

[Next](#)

Note: The option for power-cycling the modem router that is stated onscreen applies to a DSL Internet connection only (see [Set Up Your Modem Router for DSL Service](#) on page 19).

Take one of the following actions:

- If the yellow Ethernet cable is fully inserted in the correct places at the cable or fiber modem and at the modem router, do the following:
 - a. Select the **None of the above** radio button.
 - b. Click the **Next** button.

- If the yellow Ethernet cable is not fully inserted or is inserted at a wrong place, do the following:
 - Fully insert the Ethernet cable in the correct port on the cable or fiber modem and in the red Internet port on the modem router.
 - Select the **I corrected a problem with the Ethernet cable** radio button.
 - Click the **Next** button.

17. (Only if the following screen displays) Specify how to manage problems with the detection of the IP address for the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection IP address.

Problem Detecting the Internet Connection - IP Address

Did your Internet Service Provider (ISP) assign to you a fixed (static) IP address? This is a **very rare** special deployment.

Select an option and click **Next** to proceed.

Yes, My ISP assigned a fixed (static) IP address to me.

No, I did not get a fixed (static) IP address from my ISP.

I don't know.

Next

Take one of the following actions:

- If your ISP assigned you a fixed (static) IP address, do the following:
 - Select the **Yes** radio button.
 - Click the **Next** button.

Fixed Internet IP Settings


Enter the fixed IP settings assigned by your Internet Service Provider and click **Next** to proceed.

My IP Address	<input type="text"/>
Subnet Mask	<input type="text"/>
Default Gateway	<input type="text"/>
Preferred DNS Server	<input type="text"/>
Alternate DNS Server	<input type="text"/>

Next

- Enter the address information that your ISP gave you for your fixed IP address configuration.

- d. Click the **Next** button.
- If your ISP did not assign you a fixed IP address or you do not know if your ISP assigned you a fixed IP address, do the following:
 - a. Select either the **No** or the **I don't know** radio button.
 - b. Click the **Next** button.



- c. Enter the MAC address of the computer or router with which you previously were able to connect to the Internet.

You might find the MAC address on the product label of your device. Enter the MAC address in the AABBCCDDEEFF format, not in the AA:BB:CC:DD:EE:FF format.
- d. Click the **Next** button.

18. If the **Congratulations!** screen still does not display and the modem router still does not connect to the Internet, do the following:

- a. Review all your settings.

Make sure that you selected the correct options and entered everything correctly.
- b. Run the Setup Wizard one more time.
- c. Contact your ISP to verify that you are using the correct configuration information.
- d. Read *Troubleshoot the Internet Connection* on page 210.
- e. If problems persist, register your NETGEAR product and contact NETGEAR technical support.


Log In to the Modem Router After Setup to View or Change Settings

After you set up the modem router for DSL, cable, or fiber service, you can view or change the settings for the modem router by accessing NETGEAR genie.

➤ **To log in to the modem router:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net> or <http://www.routerlogin.com>.


The nature of the login screen that displays depends on your Internet browser.



3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.



The BASIC Home screen displays a dashboard that lets you see the status of your Internet connection and network at a glance. You can click any of the five sections of the dashboard to view more detailed information. The left column displays the menus, and at the top is an ADVANCED tab that you can use to access more menus and screens.

Change the Language

By default, the language is set as Auto. You can change the language.

➤ **To change the language:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. In the upper right corner, select a language from the menu.
6. When prompted, click the **OK** button to confirm this change.

The screen refreshes with the language that you selected.

Change the admin Password and Automatic Login Time-Out Period


NETGEAR recommends that you change the default password that you use to log in to the modem router to a more secure password. This is the password that you use to log in to the modem router with the user name admin.

The ideal password contains no dictionary words from any language and contains uppercase and lowercase letters, numbers, and symbols. It can be up to 30 characters.

Note: This admin password is not the password that you use for WiFi access. The label on your modem router shows your unique WiFi network name (SSID) and password for WiFi access.

➤ **To change the password for the user name admin and the login time-out period:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Administration > Set Password**.



6. Enter the old password.
7. Enter the new password twice.
8. To change the automatic login time-out, enter a new value in minutes in the field.
By default, you are logged out of the web management interface after five minutes of inactivity.
9. Click the **Apply** button.
Your settings are saved.

Set Up Password Recovery

NETGEAR recommends that you enable password recovery if you change the password for the modem router user name admin. Then you can recover the password if it is forgotten. This recovery process is supported in Internet Explorer, Firefox, and Chrome browsers, but not in the Safari browser.

➤ **To set up password recovery:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Set Password**.

The Set Password screen displays.

6. Select the **Enable Password Recovery** check box.

7. Select two security questions and provide answers to them.

8. Click the **Apply** button.

Your settings are saved.

Let the Modem Router Automatically Update Its Firmware

When you set up your modem router and are connected to the Internet, the modem router automatically checks for you to see if newer firmware is available. If it is, a message is displayed at the top of the screen. For information about manually upgrading firmware, see *Update the Firmware of the Modem Router* on page 148.

➤ **To automatically update the firmware:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Wait for the modem router to check if newer firmware is available.

This process might take a few minutes. If the modem router detects new firmware, the modem router displays a message at the top of the screen.

6. Click the message.

7. To upgrade the modem router with the latest firmware, click the **Yes** button.

After the upgrade, the modem router restarts.



WARNING:

To avoid the risk of corrupting the firmware, do not interrupt the upload. For example, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.

Access the Modem Router with the NETGEAR genie App

The genie app  is the easy dashboard for managing, monitoring, and repairing your home network from a smartphone, tablet, or computer. The genie app can help you with the following:


- Automatically repair common WiFi network problems.
- Easily manage modem router features such as Live Parental Controls, guest access, Internet traffic meter, speed test, and more.
- Share and stream music or videos.

➤ **To use the genie app to access the modem router:**

1. Visit the NETGEAR genie web page at www.NETGEAR.com/genie.
2. Follow the onscreen instructions to install the app on your smartphone, tablet, or computer.
3. Launch the genie app.

The genie app dashboard screen displays.

The following figure shows the genie app dashboard for a PC.



Note: The AC1200 WiFi DSL Modem Router—Essentials Edition Model D6100 does not support ReadySHARE.

3 Manage the Internet Settings Manually

3

This chapter describes how you can manage the Internet settings of the modem router manually.

Usually, the quickest way to set up the modem router is to allow the NETGEAR genie automatic setup utility to detect the Internet connection when you first access the modem router with an Internet browser. For a cable or fiber service, you can use the Setup Wizard to detect the Internet connection. These options are described in [Chapter 2, Install and Access the Modem Router and Its Network](#). You can also customize or specify your Internet settings manually.

The chapter contains the following sections:

- [Use the Internet Setup Wizard After Initial Setup](#)
- [Manually Set Up the Internet Connection](#)
- [Specify an IPv6 Internet Connection](#)
- [Manage the MTU Size](#)

Use the Internet Setup Wizard After Initial Setup

Whether you use DSL service or cable or fiber service, you can use the Setup Wizard to detect your Internet settings and automatically set up your modem router.

Note: The Setup Wizard is the same as the NETGEAR genie automatic setup utility that launches the first time you connect to your modem router.

➤ **To use the Setup Wizard:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup Wizard**.



6. From the **Country** menu, select the country in which you use the modem router.
7. From the **ISP** menu, select the ISP that you are using.

If your ISP is not in the menu, select **Other**.


8. Select the **Yes** radio button.

[Manage the Internet Settings Manually](#)

If you select the **No** radio button, you are taken to the Internet Setup screen (see *Manually Set Up the Internet Connection* on page 45) after you click the **Next** button.


9. Click the **Next** button.

The Setup Wizard searches your Internet connection for servers and protocols to determine your ISP configuration.



When the modem router is connected to the Internet, the **Congratulations!** screen displays, and you successfully completed the setup process.

If the **Congratulations!** screen does not display, other screens might display and you might need to provide more information, in which case you must continue with the next step. The screens that display depend on your type of ISP connection and configuration.



10. (Only if the following screen displays) Specify a full scan to let the Setup Wizard find the PVC protocol.

The screen that might display asks you if you need the Setup Wizard to do a full scan to find the PVC protocol. If this screen does not display, continue with the next step.



Do the following:


- a. Select the **Yes** radio button.
- b. Click the **Next** button.

The Setup Wizard performs a full scan, which might take up to six minutes.



11. (Only if the following screen displays) Specify how to manage problems with the detection of the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection. If this screen does not display, continue with the next step.




Take one of the following actions:

- If your setup includes a DSL modem, power-cycle the DSL modem:
 - a. Unplug your DSL modem's power, leaving the DSL modem connected to the wall jack for your Internet service.
 - b. If your DSL modem includes a battery backup, remove the battery.
 - c. Wait 10 seconds.
 - d. If your DSL modem includes a battery backup, reinsert the battery.
 - e. Plug in your DSL modem's power and turn on your DSL modem.
 - f. Wait two minutes.

- g. Select the **I just power cycled the modem and waited for 2 minutes** radio button.
- h. Click the **Next** button.
- If your setup includes a cable or fiber modem, see if the yellow Ethernet cable is not fully inserted or is inserted at the wrong place. If necessary, do the following:
 - a. Fully insert the Ethernet cable in the correct port on the cable or fiber modem and in the red Internet port on the modem router.
 - b. Select the **I corrected a problem with the Ethernet cable** radio button.
 - c. Click the **Next** button.
- If you do not need to power-cycle the DSL modem or the Ethernet cable is already fully inserted in the correct ports, do the following:
 - a. Select the **None of the above** radio button.
 - b. Click the **Next** button.

12. (Only if the following screen displays) Specify how to manage problems with the detection of the IP address for the Internet connection.

The screen that might display states that a problem occurred while detecting the Internet connection IP address.



Take one of the following actions:

- If your ISP assigned you a fixed (static) IP address, do the following:
 - a. Select the **Yes** radio button.
 - b. Click the **Next** button.

Fixed Internet IP Settings

Enter the fixed IP settings assigned by your Internet Service Provider and click **Next** to proceed.

My IP Address	<input type="text"/>
Subnet Mask	<input type="text"/>
Default Gateway	<input type="text"/>
Preferred DNS Server	<input type="text"/>
Alternate DNS Server	<input type="text"/>

Next

- c. Enter the address information that your ISP gave you for your fixed IP address configuration.
- d. Click the **Next** button.
- If your ISP did not assign you a fixed IP address or you do not know if your ISP assigned you a fixed IP address, do the following:
 - a. Select either the **No** or the **I don't know** radio button.
 - b. Click the **Next** button.

Problem Detecting the Internet Connection - MAC Address

If you previously connected to your Internet service with a computer or another router, NETGEAR Genie can use the same MAC address that worked before.

A MAC address is a unique number. You can find the MAC address of the computer or router on its product label.

Enter the MAC address here.

(format AABBCCDDEEFF)

Next

- c. Enter the MAC address of the computer or router with which you previously were able to connect to the Internet.

You might find the MAC address on the product label of your device. Enter the MAC address in the AABBCCDDEEFF format, not in the AA:BB:CC:DD:EE:FF format.

- d. Click the **Next** button.

13. If the **Congratulations!** screen still does not display and the modem router still does not connect to the Internet, do the following:

- a. Review all your settings.

Make sure that you selected the correct options and entered everything correctly.

- b. Run the Setup Wizard one more time.

- c. Contact your ISP to verify that you are using the correct configuration information.
- d. Read *Troubleshoot the Internet Connection* on page 210.
- e. If problems persist, register your NETGEAR product and contact NETGEAR technical support.

Manually Set Up the Internet Connection

You can view or change the modem router's Internet connection settings manually. The following sections describe the options to manually set up the Internet connection:

- *Specify an Internet Connection Without a Login* on page 45
- *Specify an Internet Connection That Uses a Login and PPTP or L2TP Service* on page 48
- *Specify an Internet Connection That Uses a Login and PPPoE Service* on page 51
- *Specify an Internet Connection That Uses a Login and PPPoA Service* on page 54

Specify an Internet Connection Without a Login

If you want to manually configure the Internet connection settings, use the information that your ISP gave you to log in to your Internet service. If you cannot find this information, contact your ISP.

➤ **To view or specify the Internet connection settings without a login:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.
A login screen displays.
3. Enter the modem router user name and password.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **Internet**.
The Internet Setup screen displays.
6. In the Does your Internet connection require a login? section, select the **No** radio button.

Internet Setup

Does your Internet connection require a login?

Yes
 No

Account Name (If Required): D6100

Domain Name (If Required):

Internet IP Address

Get Dynamically from ISP
 Use Static IP Address

IP Address: 0.0.0.0

IP Subnet Mask: 0.0.0.0

Gateway IP Address: 0.0.0.0

Use IP Over ATM (IPoA)

IP Address: 0.0.0.0

IP Subnet Mask: 0.0.0.0

Gateway IP Address: 0.0.0.0

Domain Name Server (DNS) Address

Get Automatically from ISP
 Use These DNS Servers

Primary DNS: 0.0.0.0

Secondary DNS: 0.0.0.0

Router MAC Address

Use Default Address
 Use Computer MAC Address
 Use This MAC Address: C4:04:15:B3:BE:D9

NAT (Network Address Translation)

Enable
 Disable

7. Enter the settings as described in the following table.

Field	Description
Account Name (If Required)	Enter the account name provided by your ISP. This name might also be called the host name. If you do not know the account name, leave this field blank. By default, the Account Name field contains the model number of the modem router.
Domain Name (If Required)	Enter the domain name provided by your ISP. If you do not know the domain name, leave this field blank.
Internet IP Address	
Get Dynamically from ISP	Your ISP uses DHCP to assign your IP address. Your ISP automatically assigns these addresses.

Manage the Internet Settings Manually

Field	Description
Use Static IP Address	Enter the IP address, IP subnet mask, and gateway IP address that your ISP assigned for static IP address service. The gateway is the ISP router to which your modem router connects.
Use IP over ATM (IPoA)	Enter the IP address, IP subnet mask, and gateway IP address that your ISP assigned for IPoA service. The gateway is the ISP router to which your modem router connects.
Domain Name Server (DNS) Address	
The DNS server is used to look up site addresses based on their names.	
Get Automatically from ISP	Your ISP uses DHCP to assign your DNS servers. Your ISP automatically assigns this address.
Use These DNS Servers	If you know that your ISP does not automatically transmit DNS addresses to the modem router during login, select this option and enter the IP address of your ISP primary DNS server. If a secondary DNS server address is available, enter it also.
Router MAC Address	
The Ethernet MAC address that the modem router uses on the Internet port. Some ISPs register the MAC address of the network interface card in your computer when your account is first opened. They accept traffic only from the MAC address of that computer. This feature allows your modem router to use your computer's MAC address (also called cloning).	
Use Default Address	Use the default MAC address.
Use Computer MAC Address	The modem router captures and uses the MAC address of the computer that you are now using. You must use the one computer that is registered by the ISP.
Use This MAC Address	Enter the MAC address that you want to use.
NAT (Network Address Translation)	
NAT allows computers on your home network to share the modem router Internet connection. NAT is enabled by default because it is needed in most situations. Select the NAT setting:	
<ul style="list-style-type: none"> • Enable. NAT is enabled. This is the default setting. • Disable. NAT is disabled. 	

8. Click the **Apply** button.

Your settings are saved.

9. Click the **Test** button to test your Internet connection.

If the NETGEAR website does not display within one minute, see *Troubleshoot the Internet Connection* on page 210.

Specify an Internet Connection That Uses a Login and PPTP or L2TP Service

If you want to manually configure the Internet connection settings, use the information that your ISP gave you to log in to your Internet service. If you cannot find this information, contact your ISP.

The information that you must specify for a PPTP service is identical to the one that you must specify for an L2TP service, except for a connection ID or name, which applies to a PPTP service only.

➤ **To view or specify the Internet connection settings with a login for PPTP or L2TP service:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Internet**.

The Internet Setup screen displays.

6. In the Does your Internet connection require a login? section, make sure that the **Yes** radio button is selected

The **Yes** radio button is selected by default.

7. From the **Encapsulation** menu, select **PPTP or L2TP**.

The following figure shows the PPTP fields. The fields that display for an L2TP service are identical to the ones that display for a PPTP service, except for the **Connection ID/Name** field, which displays for a PPTP service only.

Internet Setup

Does your Internet connection require a login?

Yes
 No

Encapsulation: PPTP

Login: guest

Password:

Connection Mode: Always On

Idle Timeout (In Minutes): 5

My IP Address:

IP Subnet Mask:

Server Address: 10.0.0.138

Gateway IP Address:

Connection ID/Name:

Domain Name Server (DNS) Address:

Get Automatically from ISP
 Use These DNS Servers

Primary DNS:

Secondary DNS:

Router MAC Address:

Use Default Address
 Use Computer MAC Address
 Use This MAC Address: C4:04:15:B3:BE:D9

NAT (Network Address Translation): Enable Disable

8. Enter the settings as described in the following table.

Field	Description
Login	Enter the login name that your ISP gave you. This login name is often an email address.
Password	Enter the password that you use to log in to your Internet service.
Connection Mode	From the Connection Mode menu, select Always On , Dial on Demand , or Manually Connect .
Idle Timeout (In Minutes)	To change the number of minutes until the Internet login times out, enter the number of minutes. The idle time-out specifies how long the modem router keeps the Internet connection active when no one on the network is using the Internet connection. A value of 0 (zero) means never log out.

Manage the Internet Settings Manually

Field	Description
My IP Address	Enter the IP address assigned by the ISP to make the connection with the ISP server.
IP Subnet Mask	Enter the IP subnet mask assigned by the ISP to make the connection with the ISP server.
Server Address	Enter the IP address of the ISP server that your ISP gave you.
Gateway IP Address	Enter the IP address of the ISP gateway that your ISP gave you. If your ISP did not give you a gateway IP address, leave this field blank.
Connection ID/Name	Enter the IP connection ID or name that your ISP gave you. If your ISP did not give you a connection ID or name, leave this field blank. (It is not common that you must enter a connection ID or name.) Note: This field displays for PPTP service only.
Domain Name Server (DNS) Address	
The DNS server is used to look up site addresses based on their names.	
Get Automatically from ISP	Your ISP uses DHCP to assign your DNS servers. Your ISP automatically assigns this address.
Use These DNS Servers	If you know that your ISP does not automatically transmit DNS addresses to the modem router during login, select this option and enter the IP address of your ISP primary DNS server. If a secondary DNS server address is available, enter it also.
Router MAC Address	
The Ethernet MAC address that the modem router uses on the Internet port. Some ISPs register the MAC address of the network interface card in your computer when your account is first opened. They accept traffic only from the MAC address of that computer. This feature allows your modem router to use your computer's MAC address (also called cloning).	
Use Default Address	Use the default MAC address.
Use Computer MAC Address	The modem router captures and uses the MAC address of the computer that you are now using. You must use the one computer that is allowed by the ISP.
Use This MAC Address	Enter the MAC address that you want to use.
NAT (Network Address Translation)	
NAT allows computers on your home network to share the modem router Internet connection. NAT is enabled by default because it is needed in most situations. Select the NAT setting:	
<ul style="list-style-type: none"> • Enable. NAT is enabled. This is the default setting. • Disable. NAT is disabled. 	

9. Click the **Apply** button.

Your settings are saved.

10. Click the **Test** button to test your Internet connection.

If the NETGEAR website does not display within one minute, see *Troubleshoot the Internet Connection* on page 210.

Specify an Internet Connection That Uses a Login and PPPoE Service

If you want to manually configure the Internet connection settings, use the information that your ISP gave you to log in to your Internet service. If you cannot find this information, contact your ISP.

➤ **To view or specify the Internet connection settings with a login for PPPoE service:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Internet**.

The Internet Setup screen displays.

6. In the Does your Internet connection require a login? section, make sure that the **Yes** radio button is selected

The **Yes** radio button is selected by default.

7. From the **Encapsulation** menu, select **PPPoE (PPP over Ethernet)**.

8. Enter the settings as described in the following table.

Field	Description
Login	Enter the login name that your ISP gave you. This login name is often an email address.
Password	Enter the password that you use to log in to your Internet service.
Service Name (If Required)	Enter the service name that your ISP gave you. Often, a service name is not required.
Connection Mode	From the Connection Mode menu, select Always On , Dial on Demand , or Manually Connect .

Manage the Internet Settings Manually

Field	Description
Idle Timeout (In Minutes)	To change the number of minutes until the Internet login times out, enter the number of minutes. The idle time-out specifies how long the modem router keeps the Internet connection active when no one on the network is using the Internet connection. A value of 0 (zero) means never log out.
Internet IP Address	
Get Dynamically from ISP	Your ISP uses DHCP to assign your IP address. Your ISP automatically assigns these addresses.
Use Static IP Address	Enter the IP address, IP subnet mask, and gateway IP address that your ISP assigned for static IP address service. The gateway is the ISP router to which your modem router connects.
Domain Name Server (DNS) Address	
The DNS server is used to look up site addresses based on their names.	
Get Automatically from ISP	Your ISP uses DHCP to assign your DNS servers. Your ISP automatically assigns this address.
Use These DNS Servers	If you know that your ISP does not automatically transmit DNS addresses to the modem router during login, select this option and enter the IP address of your ISP primary DNS server. If a secondary DNS server address is available, enter it also.
Router MAC Address	
The Ethernet MAC address that the modem router uses on the Internet port. Some ISPs register the MAC address of the network interface card in your computer when your account is first opened. They accept traffic only from the MAC address of that computer. This feature allows your modem router to use your computer's MAC address (also called cloning).	
Use Default Address	Use the default MAC address.
Use Computer MAC Address	The modem router captures and uses the MAC address of the computer that you are now using. You must use the one computer that is allowed by the ISP.
Use This MAC Address	Enter the MAC address that you want to use.
NAT (Network Address Translation)	
NAT allows computers on your home network to share the modem router Internet connection. NAT is enabled by default because it is needed in most situations. Select the NAT setting:	
<ul style="list-style-type: none"> • Enable. NAT is enabled. This is the default setting. • Disable. NAT is disabled. 	

9. Click the **Apply** button.

Your settings are saved.

10. Click the **Test** button to test your Internet connection.

If the NETGEAR website does not display within one minute, see *Troubleshoot the Internet Connection* on page 210.

Specify an Internet Connection That Uses a Login and PPPoA Service

If you want to manually configure the Internet connection settings, use the information that your ISP gave you to log in to your Internet service. If you cannot find this information, contact your ISP.

Note: PPP over ATM (PPPoA) is available only if you connect the modem router to the Internet over a DSL service. PPPoA is not available for cable or fiber service.

➤ **To view or specify the Internet connection settings with a login for PPPoA service:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Internet**.

The Internet Setup screen displays.

6. In the Does your Internet connection require a login? section, make sure that the **Yes** radio button is selected

The **Yes** radio button is selected by default.

7. From the **Encapsulation** menu, select **PPPoA (PPP over ATM)**.

8. Enter the settings as described in the following table.

Field	Description
Login	Enter the login name that your ISP gave you. This login name is often an email address.
Password	Enter the password that you use to log in to your Internet service.
Connection Mode	From the Connection Mode menu, select Always On , Dial on Demand , or Manually Connect .
Idle Timeout (In Minutes)	To change the number of minutes until the Internet login times out, enter the number of minutes. The idle time-out specifies how long the modem router keeps the Internet connection active when no one on the network is using the Internet connection. A value of 0 (zero) means never log out.
Account Name (If Required)	Enter the account name provided by your ISP. This name might also be called the host name. If you do not know the account name, leave this field blank.
Domain Name (If Required)	Enter the domain name provided by your ISP. If you do not know the domain name, leave this field blank.

Manage the Internet Settings Manually

Field	Description
Internet IP Address	
Get Dynamically from ISP	Your ISP uses DHCP to assign your IP address. Your ISP automatically assigns these addresses.
Use Static IP Address	Enter the IP address, IP subnet mask, and gateway IP address that your ISP assigned. The gateway is the ISP modem router to which your modem router connects.
Domain Name Server (DNS) Address	
The DNS server is used to look up site addresses based on their names.	
Get Automatically from ISP	Your ISP uses DHCP to assign your DNS servers. Your ISP automatically assigns this address.
Use These DNS Servers	If you know that your ISP does not automatically transmit DNS addresses to the modem router during login, select this option and enter the IP address of your ISP primary DNS server. If a secondary DNS server address is available, enter it also.
NAT (Network Address Translation)	
NAT allows computers on your home network to share the modem router Internet connection. NAT is enabled by default because it is needed in most situations. Select the NAT setting:	
<ul style="list-style-type: none"> • Enable. NAT is enabled. This is the default setting. • Disable. NAT is disabled. 	

9. Click the **Apply** button.

Your settings are saved.

10. Click the **Test** button to test your Internet connection.

If the NETGEAR website does not display within one minute, see *Troubleshoot the Internet Connection* on page 210.

Specify an IPv6 Internet Connection

If you want to use an IPv6 Internet connection, you must specify the settings manually. NETGEAR genie does not detect an IPv6 Internet connection automatically.

IPv6 Internet Connections and IPv6 Addresses

The modem router can support an IPv6 Internet connection through the following connection types:

- **Auto Detect.** For more information, see *Set Up and IPv6 Connection Through Auto Detect* on page 57.
- **Auto Config.** For more information, see *Set Up and IPv6 Connection Through Auto Config* on page 59.
- **6to4 tunnel.** For more information, see *Set Up an IPv6 6to4 Tunnel Connection* on page 61.

- **Pass-through.** For more information, see *Set Up an IPv6 Pass-Through Connection* on page 63.
- **Fixed.** For more information, see *Set Up an IPv6 Fixed Connection* on page 64.
- **DHCP.** For more information, see *Set Up an IPv6 DHCP Connection* on page 66.
- **PPP over Ethernet.** For more information, see *Set Up an IPv6 PPPoE Connection* on page 68.

Which connection type you must use depends on your IPv6 ISP. Follow the directions that your IPv6 ISP gave you.

- If your ISP did not provide details, use the 6to4 tunnel connection type (see *Set Up an IPv6 6to4 Tunnel Connection* on page 61).
- If you are not sure what type of IPv6 connection the modem router uses, use the Auto Detect connection type, which lets the modem router detect the IPv6 type that is in use (see *Set Up and IPv6 Connection Through Auto Detect* on page 57).
- If your Internet connection does not use PPPoE, DHCP, a fixed IP address, or pass-through but is IPv6, use the Auto Config connection type, which lets the modem router autoconfigure its IPv6 connection (see *Set Up and IPv6 Connection Through Auto Config* on page 59).

When you enable IPv6 and select any connection type other than IPv6 pass-through, the modem router starts the stateful packet inspection (SPI) firewall function on the WAN interface. The modem router creates connection records and checks every inbound IPv6 packet. If the inbound packet is not destined to the modem router itself and the modem router does not expect to receive such a packet, or the packet is not in the connection record, the modem router blocks this packet. This function works in two modes: In secured mode, the modem router inspects both TCP and UDP packets. In open mode, the modem router inspects UDP packets only.

IPv6 addresses are denoted by eight groups of hexadecimal quartets that are separated by colons. You can reduce any four-digit group of zeros within an IPv6 address to a single zero or omit it. The following errors invalidate an IPv6 address:

- More than eight groups of hexadecimal quartets
- More than four hexadecimal characters in a quartet
- More than two colons in a row

Set Up and IPv6 Connection Through Auto Detect

If you are not sure what type of IPv6 connection the modem router uses, use the Auto Detect connection type, which lets the modem router detect the IPv6 type that is in use.

➤ **To set up an IPv6 Internet connection through auto detection:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > IPv6**.

The IPv6 screen displays.

6. From the **Internet Connection Type** menu, select **Auto Detect**.



The modem router automatically detects the information in the following fields:

- **Connection Type.** This field indicates the connection type that is detected.
- **Router's IPv6 Address on WAN.** This field shows the IPv6 address that is acquired for the modem router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.
- **Router's IPv6 Address on LAN1.** This field shows the IPv6 address that is acquired for the modem router's LAN interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.

7. Select an IP Address Assignment radio button:

- **Use DHCP Server.** This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function.
- **Auto Config.** This is the default setting.

8. To specify the interface ID for the IPv6 address of the modem router's LAN interface, select the **Use This Interface ID** check box, and enter the interface ID.

If you do not specify an ID here, the modem router generates one automatically from its MAC address.

9. Select the IPv6 filtering mode:
 - **Secured.** In secured mode, which is the default mode, the modem router inspects both TCP and UDP packets.
 - **Open.** In open mode, the modem router inspects UDP packets only.
10. Click the **Apply** button.


Your settings are saved.

Set Up and IPv6 Connection Through Auto Config

If your Internet connection does not use PPPoE, DHCP, a fixed IP address, or pass-through but is IPv6, use the Auto Config connection type, which lets the modem router autoconfigure its IPv6 connection.

➤ **To set up an IPv6 Internet connection through auto configuration:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the modem router user name and password.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Advanced Setup > IPv6**.
The IPv6 screen displays.
6. From the **Internet Connection Type** menu, select **Auto Config**.



The modem router automatically detects the information in the following fields:

- **Router's IPv6 Address on WAN.** This field shows the IPv6 address that is acquired for the modem router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.
- **Router's IPv6 Address on LAN1.** This field shows the IPv6 address that is acquired for the modem router's LAN interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.

7. If your ISP gave you a specific host name, in the **DHCP User Class (If Required)** field, enter the host name.
 If your ISP did not give you a specific host name, leave this field blank.

8. To specify a domain name, in the **DHCP Domain Name (If Required)** field, enter a domain name.
 If your ISP gave you a specific domain name, enter it in this field. (For example, Earthlink Cable might require a host name of *home*, and Comcast sometimes supplies a domain name.)
 If your ISP did not give you a specific domain name, you can either leave this field blank or enter the domain name of your IPv6 ISP. (Do not enter the domain name for the IPv4 ISP here.) For example, if your ISP's mail server is *mail.xxx.yyy.zzz*, enter *xxx.yyy.zzz* as the domain name.

9. Select an IP Address Assignment radio button:
 - **Use DHCP Server.** This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function.
 - **Auto Config.** This is the default setting.
10. To specify the interface ID for the IPv6 address of the modem router's LAN interface, select the **Use This Interface ID** check box, and enter the interface ID.
If you do not specify an ID here, the modem router generates one automatically from its MAC address.
11. Specify the IPv6 filtering mode:
 - **Secured.** In secured mode, which is the default mode, the modem router inspects both TCP and UDP packets.
 - **Open.** In open mode, the modem router inspects UDP packets only.
12. Click the **Apply** button.

Your settings are saved.


Set Up an IPv6 6to4 Tunnel Connection

With an IPv6 connection, your modem router creates a 6to4 tunnel to a remote relay router. Make sure that the IPv4 Internet connection is working before you apply the 6to4 tunnel settings for the IPv6 connection.

Note: Follow the directions that your IPv6 ISP gave you.

➤ **To set up an IPv6 Internet connection by using a 6to4 tunnel:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the modem router user name and password.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Advanced Setup > IPv6**.
The IPv6 screen displays.
6. From the **Internet Connection Type** menu, select **6to4 Tunnel**.



The modem router automatically detects the information in the Router's IPv6 Address On LAN field. This field shows the IPv6 address that is acquired for the modem router's LAN interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address.

7. Select a Remote 6to4 Relay Router radio button:
 - **Auto.** Your modem router uses any remote relay modem router that is available on the Internet. This is the default setting.
 - **Static IP Address.** Enter the static IPv4 (not IPv6) address of the remote relay modem router. Your IPv6 ISP usually provides this address.
8. Select an IP Address Assignment radio button:
 - **Use DHCP Server.** The modem router assigns IPv6 addresses to the devices on your home network (the LAN) through a DHCP server. This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. This is the default setting.
 - **Auto Config.** The modem router automatically configures its IPv6 address based on the IPv6 protocol.
9. To specify the interface ID for the IPv6 address of the modem router's LAN interface, select the **Use This Interface ID** check box, and enter the interface ID.

If you do not specify an ID here, the modem router generates one automatically from its MAC address.

10. Specify the IPv6 filtering mode:

- **Secured.** In secured mode, the modem router inspects both TCP and UDP packets.
- **Open.** In open mode, the modem router inspects UDP packets only. This is the default mode.

11. Click the **Apply** button.

Your settings are saved.

Set Up an IPv6 Pass-Through Connection

In IPv6 pass-through mode, the modem router works as a Layer 2 Ethernet switch with two ports (LAN and WAN Ethernet ports) for IPv6 packets. The modem router does not process any IPv6 header packets.

Note: Follow the directions that your IPv6 ISP gave you.

➤ **To set up an IPv6 pass-through Internet connection:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > IPv6**.

The IPv6 screen displays.

6. From the **Internet Connection Type** menu, select **Pass Through**.

The screen adjusts, but no additional fields display.

7. Click the **Apply** button.

Your settings are saved.

Set Up an IPv6 Fixed Connection

A fixed IPv6 connection is based on a static or fixed IPv6 address that your IPv6 ISP gave you.

Note: Follow the directions that your IPv6 ISP gave you.

➤ **To set up a fixed IPv6 Internet connection:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > IPv6**.

The IPv6 screen displays.

6. From the **Internet Connection Type** menu, select **Fixed**.



Manage the Internet Settings Manually

7. Configure the fixed IPv6 addresses for the WAN connection:
 - **IPv6 Address/Prefix Length.** The IPv6 address and prefix length of the modem router WAN interface.
 - **Default IPv6 Gateway.** The IPv6 address of the default IPv6 gateway for the modem router's WAN interface.
 - **Primary DNS Server.** The primary DNS server that resolves IPv6 domain name records for the modem router.
 - **Secondary DNS Server.** The secondary DNS server that resolves IPv6 domain name records for the modem router.

Note: If you do not specify the DNS servers, the modem router uses the DNS servers that are configured for the IPv4 Internet connection on the Internet Setup screen (see *Manually Set Up the Internet Connection* on page 45).

8. Select an IP Address Assignment radio button:
 - **Use DHCP Server.** The modem router assigns IPv6 addresses to the devices on your home network (the LAN) through a DHCP server. This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. This is the default setting.
 - **Auto Config.** The modem router automatically configures its IPv6 address based on the IPv6 protocol.
9. In the **IPv6 Address/Prefix Length** fields, specify the static IPv6 address and prefix length of the modem router's LAN interface.
If you do not specify an address here, the modem router generates one automatically from its MAC address.
10. Specify the IPv6 filtering mode:
 - **Secured.** In secured mode, the modem router inspects both TCP and UDP packets.
 - **Open.** In open mode, the modem router inspects UDP packets only. This is the default mode.
11. Click the **Apply** button.

Your settings are saved.

Set Up an IPv6 DHCP Connection

An IPv6 DHCP connection is based on a dynamic IPv6 address that a DHCPv6 server assigns to the modem router.

Note: Follow the directions that your IPv6 ISP gave you.

➤ **To set up an IPv6 Internet connection with a DHCP server:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > IPv6**.

The IPv6 screen displays.

6. From the **Internet Connection Type** menu, select **DHCP**.



The modem router automatically detects the information in the following fields:

- **Router's IPv6 Address On WAN.** This field shows the IPv6 address that is acquired for the modem router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.
- **Router's IPv6 Address On LAN.** This field shows the IPv6 address that is acquired for the modem router's LAN interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.

7. If your IPv6 ISP gave you a specific host name, in the **User Class (If Required)** field, enter the host name.
 If your IPv6 ISP did not give you a specific host name, you can leave this field blank.

8. To specify a domain name, in the **DHCP Domain Name (If Required)** field, enter a domain name.
 If your ISP gave you a specific domain name, enter it in this field. (For example, Earthlink Cable might require a host name of *home*, and Comcast sometimes supplies a domain name.)
 If your ISP did not give you a specific domain name, you can either leave this field blank or enter the domain name of your IPv6 ISP. (Do not enter the domain name for the IPv4 ISP here.) For example, if your ISP's mail server is mail.xxx.yyy.zzz, enter xxx.yyy.zzz as the domain name.

9. Select an IP Address Assignment radio button:

- **Use DHCP Server.** The modem router assigns IPv6 addresses to the devices on your home network (the LAN) through a DHCP server. This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. This is the default setting.
- **Auto Config.** The modem router automatically configures its IPv6 address based on the IPv6 protocol.

10. To specify the interface ID for the IPv6 address of the modem router's LAN interface, select the **Use This Interface ID** check box, and enter the interface ID.
 If you do not specify an ID here, the modem router generates one automatically from its MAC address.

11. Specify the IPv6 filtering mode:

- **Secured.** In secured mode, the modem router inspects both TCP and UDP packets.
- **Open.** In open mode, the modem router inspects UDP packets only. This is the default mode.

12. Click the **Apply** button.

Your settings are saved.

Set Up an IPv6 PPPoE Connection

An IPv6 PPPoE connection is based on a dynamic IPv6 address that a PPPoE service assigns to the modem router.

Note: Follow the directions that your IPv6 ISP gave you.

➤ **To set up an IPv6 PPPoE Internet connection:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > IPv6**.

The IPv6 screen displays.

6. From the **Internet Connection Type** menu, select **PPPoE**.



Manage the Internet Settings Manually

The modem router automatically detects the information in the following fields:

- **Router's IPv6 Address On WAN.** This field shows the IPv6 address that is acquired for the modem router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.
- **Router's IPv6 Address On LAN.** This field shows the IPv6 address that is acquired for the modem router's LAN interface. The number after the slash (/) is the length of the prefix, which is also indicated by the underline (_) under the IPv6 address. If no address is acquired, the field displays Not Available.

7. In the **Login** field, enter the login information for the ISP connection.

This is usually the name that you use in your email address. For example, if your main mail account is JerAB@ISP.com, you would enter JerAB in this field. Some ISPs (such as Earthlink) require that you use your full email address when you log in. If your ISP requires your full email address, enter it in this field.

8. In the **Password** field, enter the password for the ISP connection.

9. In the **Service Name** field, enter a service name.

If your ISP did not provide a service name, leave this field blank.

Note: The default setting of the **Connection Mode** menu is **Always On** to provide a steady IPv6 connection. The modem router never terminates the connection. If the connection is terminated, for example, when the modem is turned off, the modem router attempts to reestablish the connection immediately after the PPPoE connection becomes available again.

10. Select an IP Address Assignment radio button:

- **Use DHCP Server.** The modem router assigns IPv6 addresses to the devices on your home network (the LAN) through a DHCP server. This method passes more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. This is the default setting.
- **Auto Config.** The modem router automatically configures its IPv6 address based on the IPv6 protocol.

11. To specify the interface ID for the IPv6 address of the modem router's LAN interface, select the **Use This Interface ID** check box, and enter the interface ID.

If you do not specify an ID here, the modem router generates one automatically from its MAC address.

12. Specify the IPv6 filtering mode:

- **Secured.** In secured mode, the modem router inspects both TCP and UDP packets.
- **Open.** In open mode, the modem router inspects UDP packets only. This is the default mode.

13. Click the **Apply** button.

Your settings are saved.

Manage the MTU Size

The maximum transmission unit (MTU) is the largest data packet a network device transmits.

MTU Concepts

When one network device communicates across the Internet with another, the data packets travel through many devices along the way. If a device in the data path uses a lower MTU setting than the other devices, the data packets must be split or “fragmented” to accommodate the device with the smallest MTU.

The best MTU setting for NETGEAR equipment is often the default value. In some situations, changing the value fixes one problem but causes another.

Leave the MTU unchanged unless one of these situations occurs:

- You experience problems connecting to your ISP or other Internet service, and the technical support of either the ISP or NETGEAR recommends changing the MTU setting. These web-based applications might require an MTU change:
 - A secure website that does not open or displays only part of a web page
 - Yahoo email
 - MSN portal
 - America Online's DSL service
- You use VPN and experience severe performance problems.
- You used a program to optimize MTU for performance reasons and now you are experiencing connectivity or performance problems.

If you suspect an MTU problem, a common solution is to change the MTU to 1400. If you are willing to experiment, you can gradually reduce the MTU from the maximum value of 1500 until the problem goes away. The following table describes common MTU sizes and applications.

Table 3. Common MTU sizes

MTU	Application
1500	The largest Ethernet packet size. This setting is typical for connections that do not use PPPoE or VPN and is the default value for NETGEAR modem routers, adapters, and switches.
1492	Used in PPPoE environments.
1472	Maximum size to use for pinging. (Larger packets are fragmented.)
1468	Used in some DHCP environments.
1460	Usable by AOL if you do not send or receive large email attachments, for example.
1436	Used in PPTP environments or with VPN.
1400	Maximum size for AOL DSL.

Change the MTU Size



WARNING:

An incorrect MTU setting can cause Internet communication problems. For example, you might not be able to access certain websites, frames within websites, secure login pages, or FTP or POP servers. Change the MTU only if you are sure that it is necessary for your ISP connection.

➤ **To change the MTU size:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.
A login screen displays.
3. Enter the modem router user name and password.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Setup > WAN Setup**.
The WAN Setup screen displays.
6. In the **MTU Size** field, enter a value from 616 to 1500.
The normal MTU (maximum transmit unit) value for most Ethernet networks is 1500 bytes, 1492 bytes for PPPoE connections, or 1436 for PPTP connections.
7. Click the **Apply** button.
Your change is saved.

Manage the WiFi Network Settings

4

This chapter describes how you can manage the WiFi network settings of the modem router.

The chapter includes the following sections:

- *Manage the Basic WiFi Settings and WiFi Security of the Main Network*
- *Use WPS to Add a Device to the WiFi Network*
- *Manage the Basic WiFi Settings and WiFi Security of the Guest Network*
- *Control the WiFi Radios*
- *Set Up a WiFi Schedule*
- *Manage the WPS Settings*
- *Manage Advanced WiFi Features*
- *Use the Modem Router as a WiFi Access Point*

Manage the Basic WiFi Settings and WiFi Security of the Main Network

The modem router comes with preset security. This means that the WiFi network name (SSID), network key (password), and security option (encryption protocol) are preset in the factory. The preset SSID and password are uniquely generated for every device to protect and maximize your WiFi security. You can find the preset SSID and password on the product label (see *Bottom Panel Product Label* on page 14).

IMPORTANT:

NETGEAR recommends that you do *not* change your preset security settings. If you decide to change your preset security settings, make a note of the new settings and store the note in a safe place where you can easily find it.

View or Change the Basic WiFi Settings

You can view or change the basic WiFi settings and WiFi security. The modem router simultaneously supports the 2.4 GHz band for 802.11b/g/n devices and the 5 GHz band for 802.11a/n/ac devices.

Tip: If you decide to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

➤ **To view or change the basic WiFi settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

Tip: If you do decide to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Wireless**.



6. View or change the basic WiFi settings and security settings.

The following table describes the fields on the Wireless Settings screen.

Field	Description
Region Selection	
Region	<p>From the menu, select the region in which the modem router operates.</p> <p>Note: It might not be legal to operate the modem router in a region other than the regions listed in the menu. If your country or region is not listed, check with your local government agency.</p>
Wireless Network (2.4GHz b/g/n)	
Enable SSID Broadcast	<p>By default, the modem router broadcasts its SSID so that WiFi stations can detect the WiFi name (SSID) in their scanned network lists. To turn off the SSID broadcast, clear the Enable SSID Broadcast check box. Turning off the SSID broadcast provides additional WiFi security, but users must know the SSID to be able to join the WiFi network of the modem router.</p>
Name (SSID)	<p>The SSID is the WiFi network name. If you did not change the SSID, the default SSID displays. The default SSID is also printed on the product label (see <i>Bottom Panel Product Label</i> on page 14).</p> <p>Note: NETGEAR recommends that you do not change the default SSID. If you must change the SSID, enter a 32-character (maximum), case-sensitive name in this field.</p>
Channel	<p>From the Channel menu, select Auto for automatic channel selection or select an individual channel. The default selection is Auto.</p> <p>Note: In some regions, not all channels are available. Do not change the channel unless you experience interference (shown by lost connections or slow data transfers). If this situation occurs, experiment with different channels to see which is the best.</p> <p>Note: If you use multiple WiFi access points (APs), reduce interference by selecting different channels for adjacent APs. NETGEAR recommends a channel spacing of four channels between adjacent APs (for example, use Channels 1 and 5, or 6 and 10).</p>
Mode	<p>From the Mode menu, select one of the following modes:</p> <ul style="list-style-type: none"> • Up to 54 Mbps. Legacy mode. This mode allows 802.11n, 802.11g, and 802.11b devices to join the network but limits 802.11n devices to function at up to 54 Mbps. • Up to 145 Mbps. Neighbor-friendly mode for reduced interference with neighboring WiFi networks. This mode allows 802.11n, 802.11g, and 802.11b devices to join the network but limits 802.11n devices to function at up to 145 Mbps. • Up to 300 Mbps. Performance mode. This mode allows 802.11n, 802.11g, and 802.11b devices to join the network and allows 802.11n devices to function at up to 300 Mbps. This mode is the default mode. <p>Note: WPA-PSK security supports speeds of up to 54 Mbps. Even if your devices are capable of a higher speed, WPA-PSK security limits their speed to 54 Mbps.</p>

Field	Description
Security Options	
This information applies to the 2.4 GHz WiFi network.	
<p>Note: NETGEAR recommends that you do <i>not</i> change your preset security settings (WPA2-PSK [AES]).</p> <p>If you must change the WiFi security, select one of the following WiFi security options for the modem router's WiFi network:</p> <ul style="list-style-type: none"> • None. An open WiFi network that does not provide any security. Any WiFi device can join the network. NETGEAR recommends that you do <i>not</i> use an open WiFi network. • WEP. Wired Equivalent Privacy (WEP) security is a legacy authentication and data encryption mode that is superseded by WPA-PSK and WPA2-PSK. The WEP option displays only if you select Up to 54 Mbps from the Mode menu. For information about configuring WEP, see <i>Configure WEP Legacy WiFi Security</i> on page 80. • WPA2-PSK [AES]. This type of security is the default setting and enables WiFi devices that support WPA2 to join the modem router's 2.4 GHz WiFi network. If you did not change the passphrase, the default passphrase displays. The default passphrase is printed on the product label (see <i>Bottom Panel Product Label</i> on page 14). WPA2 provides a secure connection but some older WiFi devices do not detect WPA2 and support only WPA. If your network includes such older devices, select WPA-PSK [TKIP] + WPA2-PSK [AES] security. <p>NETGEAR recommends that you do not change the default passphrase. If you must change the passphrase, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the modem router's WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA-PSK [TKIP] + WPA2-PSK [AES]. This type of security enables WiFi devices that support either WPA or WPA2 to join the modem router's 2.4 GHz WiFi network. However, WPA-PSK [TKIP] is less secure than WPA2-PSK [AES] and limits the speed of WiFi devices to 54 Mbps. <p>To use this type of security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the modem router's WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA/WPA2 Enterprise. This type of security requires that your WiFi network can access a RADIUS server. For information about configuring WPA/WPA2 Enterprise, see <i>Configure WPA/WPA2 Enterprise WiFi Security</i> on page 78. 	
Wireless Network (5GHz 802.11a/n/ac)	
Enable SSID Broadcast	By default, the modem router broadcasts its SSID so that WiFi stations can detect the WiFi name (SSID) in their scanned network lists. To turn off the SSID broadcast, clear the Enable SSID Broadcast check box. Turning off the SSID broadcast provides additional WiFi security, but users must know the SSID to be able to join the WiFi network of the modem router.
Enable Video Network	If you want to stream high-definition video, select this check box. When this option is selected, the modem router uses video reliability algorithms to reduce jitter and packet loss during video presentations. If you do not stream videos, leave this check box cleared.
Name (SSID)	<p>The SSID is the WiFi network name. If you did not change the SSID, the default SSID displays. The default SSID is also printed on the product label (see <i>Bottom Panel Product Label</i> on page 14).</p> <p>Note: NETGEAR recommends that you do not change the default SSID. If you must change the SSID, enter a 32-character (maximum), case-sensitive name in this field.</p>

Field	Description
Channel	<p>From the Channel menu, select Auto for automatic channel selection or select an individual channel. The default selection is Auto.</p> <p>Note: In some regions, not all channels are available. Do not change the channel unless you experience interference (shown by lost connections or slow data transfers). If this situation occurs, experiment with different channels to see which is the best.</p> <p>Note: If you use multiple WiFi access points (APs), reduce interference by selecting different channels for adjacent APs. NETGEAR recommends a channel spacing of four channels between adjacent APs.</p>
Mode	<p>From the Mode menu, select one of the following modes:</p> <ul style="list-style-type: none"> • Up to 173 Mbps. Legacy mode. This mode allows 802.11ac, 802.11na, and 802.11a devices to join the network but limits 802.11ac and 802.11na devices to function at up to 173 Mbps. • Up to 400 Mbps. Neighbor-friendly mode for reduced interference with neighboring WiFi networks. This mode allows 802.11ac, 802.11na, and 802.11a devices to join the network but limits 802.11na and 802.11ac devices to function at up to 400 Mbps. • Up to 867 Mbps. Performance mode. This mode allows 802.11ac, 802.11na, and 802.11a devices to join the network and allows 802.11ac and 802.11na devices to function at up to 867 Mbps. This mode is the default mode. <p>Note: WPA-PSK security supports speeds of up to 54 Mbps. Even if your devices are capable of a higher speed, WPA-PSK security limits their speed to 54 Mbps.</p>
Security Options	
This information applies to the 5 GHz WiFi network.	
<p>Note: NETGEAR recommends that you do <i>not</i> change your preset security settings (WPA2-PSK [AES]).</p> <p>If you must change the WiFi security, select one of the following WiFi security options for the modem router's WiFi network:</p> <ul style="list-style-type: none"> • None. An open WiFi network that does not provide any security. Any WiFi device can join the network. NETGEAR recommends that you do <i>not</i> use an open WiFi network. • WPA2-PSK [AES]. This type of security is the default setting and enables WiFi devices that support WPA2 to join the modem router's 2.4 GHz WiFi network. If you did not change the passphrase, the default passphrase displays. The default passphrase is printed on the product label (see <i>Bottom Panel Product Label</i> on page 14). WPA2 provides a secure connection but some older WiFi devices do not detect WPA2 and support only WPA. If your network includes such older devices, select WPA-PSK [TKIP] + WPA2-PSK [AES] security. <p>NETGEAR recommends that you do not change the default passphrase. If you must change the passphrase, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the modem router's WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA-PSK [TKIP] + WPA2-PSK [AES]. This type of security enables WiFi devices that support either WPA or WPA2 to join the modem router's 2.4 GHz WiFi network. However, WPA-PSK [TKIP] is less secure than WPA2-PSK [AES] and limits the speed of WiFi devices to 54 Mbps. <p>To use this type of security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the modem router's WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA/WPA2 Enterprise. This type of security requires that your WiFi network can access a RADIUS server. For information about configuring WPA/WPA2 Enterprise, see <i>Configure WPA/WPA2 Enterprise WiFi Security</i> on page 78. 	

7. Click the **Apply** button.

Your settings are saved.

If you connected over WiFi to the network and you changed the SSID, you are disconnected from the network.

8. Make sure that you can reconnect over WiFi to the network with its new settings.

If you cannot connect over WiFi, check the following:

- If your computer or WiFi device is already connected to another WiFi network in your area, disconnect it from that WiFi network and connect it to the WiFi network that the modem router provides. Some WiFi devices automatically connect to the first open network without WiFi security that they discover.
- If your computer or WiFi device is trying to connect to your network with its old settings (before you changed the settings), update the WiFi network selection in your computer or WiFi device to match the current settings for your network.
- Does your WiFi device display as an attached device? (See *View Devices Currently on the Network* on page 168.) If it does, it is connected to the network.
- Are you using the correct network name (SSID) and password?

Configure WPA/WPA2 Enterprise WiFi Security

Remote Authentication Dial In User Service (RADIUS) is an enterprise-level method for centralized Authentication, Authorization, and Accounting (AAA) management. To provide WPA/WPA2 enterprise WiFi security, the WiFi network that the modem router provides must be able to access a RADIUS server.

Tip: If you want to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

➤ **To configure WPA/WPA2 enterprise security:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Wireless**.

The Wireless Settings screen displays.

Note: If you are configuring a guest network, select **Guest Network** instead. The Guest Network Settings screen displays.

6. In the Security Options section, select the **WPA/WPA2 Enterprise** radio button.

7. In the Security Options (WPA/WPA2 Enterprise) section, enter the settings as described in the following table.

Field	Description
WPA Mode	From the WPA Mode menu, select the enterprise mode: <ul style="list-style-type: none"> WPA2 [AES]. WPA2 provides a secure connection but some older WiFi devices do not detect WPA2 and support only WPA. If your network includes such older devices, select WPA [TKIP] + WPA2 [AES] security. WPA [TKIP] +WPA2 [AES]. This type of security enables WiFi devices that support either WPA or WPA2 to join the modem router's WiFi network.
RADIUS server IP Address	Enter the IPv4 address of the RADIUS server to which the WiFi network can connect.
RADIUS server Port	Enter the number of the port on the modem router that is used to access the RADIUS server for authentication. The default port number is 1812.
RADIUS server Shared Secret	Enter the shared secret (RADIUS password) that is used between the modem router and the RADIUS server during authentication of a WiFi user.

8. Click the **Apply** button.

Your settings are saved.

9. Make sure that you can reconnect over WiFi to the network with its new security settings.

If you cannot connect over WiFi, check the following:

- If your computer or WiFi device is already connected to another WiFi network in your area, disconnect it from that WiFi network and connect it to the WiFi network that the modem router provides. Some WiFi devices automatically connect to the first open network without WiFi security that they discover.
- If your computer or WiFi device is trying to connect to your network with its old settings (before you changed the settings), update the WiFi network selection in your computer or WiFi device to match the current settings for your network.
- Does your WiFi device display as an attached device? (See *View Devices Currently on the Network* on page 168.) If it does, it is connected to the network.
- Are you using the correct network name (SSID) and password?

Configure WEP Legacy WiFi Security

Wired Equivalent Privacy (WEP) security is a legacy authentication and data encryption mode that is superseded by WPA-PSK and WPA2-PSK. WEP limits the WiFi transmission speed to 54 Mbps (the modem router is capable of speeds of up 300 Mbps).

Tip: If you want to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

➤ **To configure WEP security:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Wireless**.

The Wireless Settings screen displays.

6. From the **Mode** menu, select **Up to 54 Mbps**.

The screen adjusts to display the **WEP** radio button.

7. In the Security Options section, select the **WEP** radio button.

Wireless Network(2.4GHz b/g/n)

Enable SSID Broadcast

Name (SSID): NETGEAR23

Channel: Auto

Mode: Up to 54 Mbps

Security Options

None

WEP

WPA2-PSK [AES]

WPA-PSK [TKIP] + WPA2-PSK [AES]

WPA/WPA2 Enterprise

Security Encryption (WEP)

Authentication Type: Automatic

Encryption Strength: 64-bit

Security Encryption (WEP) Key

Key 1

Key 2

Key 3

Key 4

8. From the **Authentication Type** menu, select one of the following types:
 - **Automatic**. Clients can use either Open System or Shared Key authentication.
 - **Shared Key**. Clients can use only Shared Key authentication.
9. From the **Encryption Strength** menu, select the encryption key size:
 - **64-bit**. Standard WEP encryption, using 40/64-bit encryption.
 - **128-bit**. Standard WEP encryption, using 104/128-bit encryption. This selection provides higher encryption security.
10. Specify the active key by selecting the **Key 1**, **Key 2**, **Key 3**, or **Key 4** radio button.

Only one key can be the active key.
11. Enter the value for the key:
 - For 64-bit WEP, enter 10 hexadecimal digits (any combination of 0–9, A–F). The key values are not case-sensitive.
 - For 128-bit WEP, enter 26 hexadecimal digits (any combination of 0–9, A–F). The key values are not case-sensitive.

To join the modem router's WiFi network, a user must enter the key value for the key that you specified as the active key.
12. Click the **Apply** button.

Your settings are saved.
13. Make sure that you can reconnect over WiFi to the network with its new security settings.

If you cannot connect over WiFi, check the following:

 - If your computer or WiFi device is already connected to another WiFi network in your area, disconnect it from that WiFi network and connect it to the WiFi network that the modem router provides. Some WiFi devices automatically connect to the first open network without WiFi security that they discover.
 - If your computer or WiFi device is trying to connect to your network with its old settings (before you changed the settings), update the WiFi network selection in your computer or WiFi device to match the current settings for your network.
 - Does your WiFi device display as an attached device? (See *[View Devices Currently on the Network](#)* on page 168.) If it does, it is connected to the network.
 - Are you using the correct network name (SSID) and password?

Use WPS to Add a Device to the WiFi Network

WPS (Wi-Fi Protected Setup) lets you connect a computer or WiFi device to the modem router's network without entering the WiFi network passphrase or key. Instead, you use a **WPS** button or enter a PIN to connect.

If you use the push button method, the WiFi device that you are trying to connect must provide either a physical button or a software button. If you use the PIN method, you must know the PIN of the WiFi device that you are trying to connect.

WPS supports WPA and WPA2 WiFi security. If your modem router network is open (no WiFi security is set, which is not the default setting for the modem router), connecting with WPS automatically sets WPA + WPA2 WiFi security on the modem router network and generates a random passphrase. You can view this passphrase (see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73).

Use WPS with the Push Button Method

For you to use the push button method to connect a WiFi device to the modem router's WiFi network, the WiFi device that you are trying to connect must provide either a physical button or a software button. You can use the physical button and software button to let a WiFi device join only the main WiFi network, not the guest WiFi network.

➤ **To let a WiFi device join the modem router's main WiFi network using WPS with the push button method:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > WPS Wizard**.

The screen displays a description of the WPS method.

6. Click the **Next** button.



By default, the **Push Button (recommended)** radio button is selected.

7. Either click the  button onscreen or press the **WPS** button on the right side panel of the modem router.

For two minutes, the modem router attempts to find the WiFi device (that is, the client) that you want to join the modem router's main WiFi network.

During this time, the WiFi LED on the front panel of the modem router blinks blue.

8. Within two minutes, go to the WiFi device and press its **WPS** button to join the modem router's main WiFi network without entering a password.

After the modem router establishes a WPS connection, the WiFi LED lights solid blue and the Add WPS Client screen displays a confirmation message.

9. To verify that the WiFi device is connected to the modem router's main WiFi network, select **BASIC > Attached Device**.

The WiFi device displays onscreen.

Use WPS with the PIN Method

To use the PIN method to connect a WiFi device to the modem router's WiFi network, you must know the PIN of the WiFi device that you are trying to connect.

➤ **To let a WiFi device join the modem router's WiFi network using WPS with the PIN method:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > WPS Wizard**.


The screen displays a description of the WPS method.

6. Click the **Next** button.

The Add WPS Client screen adjusts.

The **Push Button (recommended)** radio button is selected by default.

7. Select the **PIN Number** radio button.



8. In the **Enter Client's PIN** field, enter the PIN number of the WiFi device.
9. Click the **Next** button.

For four minutes, the modem router attempts to find the WiFi device (that is, the client) that you want to join the modem router's main WiFi network.

During this time, the WiFi LED on the front panel of the modem router blinks blue.

10. Within four minutes, go to the WiFi device and use its WPS software to join the network without entering a password.

When the modem router establishes a WPS connection, the WiFi LED lights solid blue and the Add WPS Client screen displays a confirmation message.

11. To verify that the WiFi device is connected to the modem router's main WiFi network, select **BASIC > Attached Device**.

The WiFi device displays onscreen.

Manage the Basic WiFi Settings and WiFi Security of the Guest Network

A guest network allows visitors to use the Internet without using your WiFi security key. By default, the guest WiFi network is disabled. You can enable and configure the guest WiFi network for each WiFi band: 2.4 GHz b/g/n and 5.0 GHz a/n/ac.

The WiFi mode of the guest WiFi network depends on the WiFi mode of the main WiFi network. For example, if you configure the WiFi mode for the main WiFi network as Up to 54 Mbps in the 2.4 GHz band, the guest WiFi network also functions in the Up to 54 Mbps mode in the 2.4 GHz band. For information about configuring the WiFi mode, see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73.

➤ **To set up a guest network:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.


A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

4. Select **Guest Network**.



5. Enable the guest network and configure its WiFi settings as described in the following table.

Field	Description
Wireless Network (2.4GHz b/g/n)	
Enable Guest Network	By default, the guest WiFi network is disabled. To enable the guest WiFi network for the 2.4 GHz WiFi band, select the Enable Guest Network check box.
Enable SSID Broadcast	By default, the modem router broadcasts its SSID of the 2.4 GHz WiFi band so that WiFi stations can detect the WiFi name (SSID) in their scanned network lists. To turn off the SSID broadcast for the 2.4 GHz WiFi band for the guest WiFi network, clear the Enable SSID Broadcast check box.
Allow guest to access My Local Network	By default, WiFi clients that are connected to the 2.4 GHz WiFi band of the guest WiFi network cannot access WiFi devices or Ethernet devices that are connected to the main WiFi network. To allow access to the main WiFi network, select the Allow guest to access My Local Network check box.
Guest Wireless Network Name (SSID)	The SSID is the 2.4 GHz WiFi band name. If you did not change the SSID, the default SSID displays, which is NETGEAR_Guest1. If you want to change the SSID in the 2.4 GHz WiFi band for the guest WiFi network, enter a 32-character (maximum), case-sensitive name in this field.
Security Options Profile	
If you want to change the WiFi security, select one of the following WiFi security options for the 2.4 GHz band of the guest WiFi network:	
<ul style="list-style-type: none"> • None. An open WiFi network that does not provide any security. Any WiFi device can join the 2.4 GHz band of the guest WiFi network. This is the default setting for the guest WiFi network. • WEP. Wired Equivalent Privacy (WEP) security is a legacy authentication and data encryption mode that is superseded by WPA-PSK and WPA2-PSK. The WEP option displays only if you configure the WiFi mode for the main WiFi network as Up to 54 Mbps in the 2.4 GHz band (see <i>Manage the Basic WiFi Settings and WiFi Security of the Main Network</i> on page 73.). For information about configuring WEP, see <i>Configure WEP Legacy WiFi Security</i> on page 80. • WPA2-PSK [AES]. WPA2 provides a secure and fast connection but some older WiFi devices do not detect WPA2 and support only WPA. Select WPA2 to allow 802.11n devices to connect to the 2.4 GHz band of the guest WiFi network at the fastest speed. If your network includes older devices that do not support WPA2, select WPA-PSK [TKIP] + WPA2-PSK [AES] security. To use WPA2 security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the 2.4 GHz band of the guest WiFi network, a user must enter this passphrase. • WPA-PSK [TKIP] + WPA2-PSK [AES]. This type of security enables WiFi devices that support either WPA or WPA2 to join the 2.4 GHz band of the guest WiFi network. However, WPA-PSK [TKIP] is less secure than WPA2-PSK [AES] and limits the speed of WiFi devices to 54 Mbps. To use WPA + WPA2 security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the 2.4 GHz band of the guest WiFi network, a user must enter this passphrase. • WPA/WPA2 Enterprise. This type of security requires that your WiFi network can access a RADIUS server. For information about configuring WPA/WPA2 Enterprise, see <i>Configure WPA/WPA2 Enterprise WiFi Security</i> on page 78. 	
Security Options	
Passphrase	The passphrase that provides users access to the guest WiFi network in the 2.4 GHZ band. The passphrase is also referred to as the password or key.

Field	Description
Wireless Network (5GHz a/n/ac)	
Enable Guest Network	By default, the guest WiFi network is disabled. To enable the guest WiFi network for the 5 GHz WiFi band, select the Enable Guest Network check box.
Enable SSID Broadcast	By default, the modem router broadcasts its SSID of the 5 GHz WiFi band so that WiFi stations can detect the WiFi name (SSID) in their scanned network lists. To turn off the SSID broadcast for the 5 GHz WiFi band for the guest WiFi network, clear the Enable SSID Broadcast check box.
Enable Video Network	If you want to stream high-definition video on the 5 GHz WiFi band of the guest WiFi network, select this check box. When this option is selected, the modem router uses video reliability algorithms to reduce jitter and packet loss during video presentations. If you do not stream videos on the 5 GHz WiFi band of guest WiFi network, leave this check box cleared.
Allow guest to access My Local Network	By default, WiFi clients that are connected to the 5 GHz WiFi band of the guest WiFi network cannot access WiFi devices or Ethernet devices that are connected to the main WiFi network. To allow access to the main WiFi network, select the Allow guest to access My Local Network check box.
Guest Wireless Network Name (SSID)	The SSID is the 5 GHz WiFi band name. If you did not change the SSID, the default SSID displays, which is NETGEAR-5G_Guest1. If you want to change the SSID in the 5 GHz WiFi band for the guest WiFi network, enter a 32-character (maximum), case-sensitive name in this field.
<p>If you want to change the WiFi security, select one of the following WiFi security options for the 5 GHz band of the guest WiFi network:</p> <ul style="list-style-type: none"> • None. An open WiFi network that does not provide any security. Any WiFi device can join the 5 GHz band of the guest WiFi network. This is the default setting for the guest WiFi network. • WPA2-PSK [AES]. WPA2 provides a secure and fast connection but some older WiFi devices do not detect WPA2 and support only WPA. Select WPA2 to allow 802.11n devices to connect to the 5 GHz band of the guest WiFi network at the fastest speed. If your network includes older devices that do not support WPA2, select WPA-PSK [TKIP] + WPA2-PSK [AES] security. <p>To use WPA2 security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the 5 GHz band of the guest WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA-PSK [TKIP] + WPA2-PSK [AES]. This type of security enables WiFi devices that support either WPA or WPA2 to join the 5 GHz band of the guest WiFi network. However, WPA-PSK [TKIP] is less secure than WPA2-PSK [AES] and limits the speed of WiFi devices to 54 Mbps. <p>To use WPA + WPA2 security, in the Passphrase field, enter a phrase of 8 to 63 characters. To join the 5 GHz band of the guest WiFi network, a user must enter this passphrase.</p> <ul style="list-style-type: none"> • WPA/WPA2 Enterprise. This type of security requires that your WiFi network can access a RADIUS server. For information about configuring WPA/WPA2 Enterprise, see <i>Configure WPA/WPA2 Enterprise WiFi Security</i> on page 78. 	
Security Options	
Passphrase	The passphrase that provides users access to the guest WiFi network in the 5 GHz band. The passphrase is also referred to as the password or key.

6. Click the **Apply** button.

Your settings are saved.

7. Make sure that you can reconnect over WiFi to the guest network.

If you cannot connect over WiFi, check the following:

- If your computer or WiFi device is already connected to another WiFi network in your area, disconnect it from that WiFi network and connect it to the WiFi network that the modem router provides. Some WiFi devices automatically connect to the first open network without WiFi security that they discover.
- Does your WiFi device display as an attached device? (See *View Devices Currently on the Network* on page 168.) If it does, it is connected to the network.
- Are you using the correct network name (SSID) and password?

Control the WiFi Radios

The modem router provides internal WiFi radios that broadcast signals in the 2.4 GHz and 5 GHz ranges. By default, they are on so that you can connect over WiFi to the modem router. When the WiFi radios are off, you can still use an Ethernet cable for a LAN connection to the modem router.

You can turn the WiFi radios on and off with the **WiFi On/Off** button on the modem router, or you can log in to the modem router and enable or disable the WiFi radios through the web management interface. If you are close to the modem router, it might be easier to press the **WiFi On/Off** button. If you are away from the modem router or already logged in, it might be easier to enable or disable the radios through the web management interface. You can also turn the WiFi radios off and on based on a schedule. (See *Set Up a WiFi Schedule* on page 90.)

Use the WiFi On/Off Button

➤ **To turn the WiFi radios off and on with the WiFi On/Off button:**

Press the **WiFi On/Off** button on the right side panel of the modem router for two seconds.

If you turned off the WiFi radios, the WiFi LED turns off. If you turned on the WiFi radios, the WiFi LED lights solid blue.

Tip: If you want to disable the WiFi radio or radios of the modem router, use a wired connection to avoid being disconnected when WiFi radio or radios turn off.

Enable or Disable the WiFi Radios

If you used the **WiFi On/Off** button to turn off the WiFi radios, you cannot log in to the modem router to turn them back on. You must press the **WiFi On/Off** button again for two seconds to turn the WiFi radios back on.

➤ **To enable or disable the WiFi radios:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Wireless Settings**.



6. Do one of the following in the Advanced Wireless Settings (2.4GHz b/g/n) section, Advanced Wireless Settings (5GHz 802.11a/n/ac) section, or both sections:
 - **Turn off the radio.** Clear the **Enable Wireless Radio** check box.
If both radios are disabled, the WiFi LED turns off (see *Front Panel with LEDs* on page 10).
 - **Turn on the radio.** Select the **Enable Wireless Radio** check box.
If at least one radio is enabled, the WiFi LED lights solid blue.

7. Click the **Apply** button.

Your settings are saved.

Set Up a WiFi Schedule

You can use this feature to turn off the WiFi signal from your modem router at times when you do not need a WiFi connection. For example, you might turn it off for the weekend if you leave town.

Note: You can set up a WiFi schedule only if the modem router is connected to the Internet and synchronized its internal clock with a time server on the Internet. For more information about whether the modem router synchronized its clock, see *Set Up a Schedule for Keyword Blocking and Outbound Firewall Rules* on page 109.

➤ **To set up the WiFi schedule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.


A login screen displays.

3. Enter the modem router user name and password.


The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

4. Select **ADVANCED > Advanced Setup > Wireless Settings**.



5. Click the **Add a new period** button.



6. Use the menus, radio buttons, and check boxes to set up a period during which you want to turn off the WiFi signal and specify whether the schedule is recurrent.

7. Click the **Apply** button.

The Advanced Wireless Settings screen displays.

8. Select the **Turn off wireless signal by schedule** check box to activate the schedule.

9. Click the **Apply** button.

Your settings are saved.

Manage the WPS Settings

Wi-Fi Protected Setup (WPS) lets you join the WiFi network without typing the WiFi password. You can change the WPS default settings.

➤ **To manage WPS Settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.


The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

4. Select **ADVANCED > Advanced Setup > Wireless Settings**.

The Advanced Wireless Settings screen displays.

5. Scroll down to the bottom of the screen.



The **Router's PIN** field displays the fixed PIN that you use to configure the modem router's WiFi settings from another platform through WPS.

6. To disable the PIN, clear the **Enable Router's PIN** check box.

By default, the **Enable Router's PIN** check box is selected and the modem router's PIN is enabled. For enhanced security, you can disable the modem router's PIN by clearing the **Enable Router's PIN** check box. However, when you disable the modem router's PIN, WPS is not disabled because you can still use the physical **WPS** button.

Note: The PIN function might temporarily be disabled automatically if the modem router detects suspicious attempts to break into the modem router's WiFi settings by using the router's PIN through WPS.

- To allow the wireless settings to be changed automatically when you use WPS, clear the **Keep Existing Wireless Settings** check box.

By default, the **Keep Existing Wireless Settings** check box is selected. NETGEAR recommends that you leave this check box selected. If you clear this check box, the next time a new WiFi client uses WPS to connect to the modem router, the modem router WiFi settings change to an automatically generated random SSID and passphrase. For information about viewing this SSID and passphrase, see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73. Clear the **Keep Existing Wireless Settings** check box only if you want to allow the WPS process to change the SSID and passphrase for WiFi access.



WARNING:

If you clear the **Keep Existing Wireless Settings** check box and use WPS to add a computer or WiFi device to the modem router's WiFi network, the SSID and passphrase are automatically generated and other WiFi devices that are already connected to the modem router's WiFi network might be disconnected.

- Click the **Apply** button.

Your settings are saved.

Manage Advanced WiFi Features

For most WiFi networks, the advanced WiFi features work fine and you do not need to change the settings.

Tip: If you want to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

➤ **To manage advanced WiFi features:**

- Launch an Internet browser from a computer or WiFi device that is connected to the network.
- Type **http://www.routerlogin.net**.

A login screen displays.


- Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Wireless Settings**.



6. Enter the settings as described in the following table.

Except for the description of 20/40 MHz coexistence, the descriptions in the table (not the settings onscreen) apply to both the Advanced Wireless Settings (2.4GHz b/g/n) section and the Advanced Wireless Settings (5GHz 802.11a/n/ac) section.

Field	Description
Enable 20/40 MHz Coexistence	By default, 20/40 MHz coexistence is enabled to prevent interference between WiFi networks in your environment at the expense of the WiFi speed. If no other WiFi networks are present in your environment, you can clear the Enable 20/40 MHz Coexistence check box to increase the WiFi speed to the maximum supported speed. Note: 20/40 MHz coexistence applies to the 2.4 GHz band only.
Fragmentation Length (256-2346)	The fragmentation length (the default is 2346), CTS/RTS threshold (the default is 2347), and the preamble mode (the default is Automatic) are reserved for WiFi testing and advanced configuration only. Do not change these settings unless directed by NETGEAR support or unless you are sure what the consequences are. Incorrect settings might disable the WiFi function of the modem router unexpectedly.
CTS/RTS Threshold (1-2347)	
Preamble Mode	

Field	Description
Transmit Power Control	You can lower the WiFi transmit power by selecting a value lower than 100% from the Transmit Power Control menu. The setting of 100% allows the modem router to use the maximum WiFi transmit power to transmit WiFi packets. Reducing the transmit power can save the power consumption for the modem router but also reduces the WiFi coverage. If you want to ensure maximum WiFi coverage, NETGEAR recommends that you leave the setting on the Transmit Power Control menu at 100%.

7. Click the **Apply** button.

Your settings are saved.


Use the Modem Router as a WiFi Access Point

You can set up the modem router to function as a WiFi access point (AP) on the same local network as another router. When the modem router functions as a WiFi AP, many router-related features are disabled.

Tip: If you want to change the modem router's function, use a wired connection to avoid being disconnected when the new function takes effect.

➤ **To set up the modem router as an AP:**

1. Use an Ethernet cable to connect the Internet port of the modem router to a LAN port on the other router.



2. Launch an Internet browser from a computer or WiFi device that is connected to the network.

3. Type <http://www.routerlogin.net>.


A login screen displays.

4. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Wireless Access Point**.



6. Select the **Enable Access Point Mode** check box.

The screen adjusts.

7. Scroll down and select the radio button for the IP address setting that you want to use:

- **Get dynamically from existing router.** The other router on the network assigns an IP address to the modem router while the modem router functions in access point mode.
- **Enable fixed IP settings on this device (not recommended).** Use this setting if you want to manually assign a specific IP address to the modem router while it functions in Access Point Mode. Using this option effectively requires advanced network experience.

Note: To avoid interference with other routers or gateways on your network, NETGEAR recommends that you use different WiFi settings on each router. You can also turn off the WiFi radio on the other router or gateway and use the modem router only for WiFi client access.

8. Click the **Apply** button.

The IP address of the modem router changes, and you are disconnected.

9. To reconnect, close and restart your browser and type <http://www.routerlogin.net>.

Control Access to the Internet

5

The modem router comes with a built-in firewall that helps protect your home network from unwanted intrusions from the Internet.

This chapter includes the following sections:

- *Set Up Parental Controls*
- *Allow or Block Access to Your Network*
- *Use Keywords to Block Internet Sites*
- *Set Up a Schedule for Keyword Blocking and Outbound Firewall Rules*
- *Set Up Security Event Email Notifications*

For information about more advanced ways to configure Internet security, see *Chapter 9, Manage Firewall Rules, Port Forwarding, and Port Triggering*.

Set Up Parental Controls

The first time that you select **Parental Controls** from the BASIC Home screen, your browser goes to the *Parental Controls* website. You can learn more about Parental Controls or download the application.



Figure 8. Parental Controls website

➤ **To set up parental controls:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **Parental Controls**.
The *Parental Controls* website opens.
6. Click the button for the app or version that you want to download and use.


- Follow the onscreen instructions to download and install the NETGEAR Live Parental Controls Management utility.

After installation, Live Parental Controls automatically starts.



- Click the **Next** button, read the note, and click the **Next** button again.

Because Live Parental Controls uses free OpenDNS accounts, you are prompted to log in or create a free account.



- Select a radio button as follows:

- If you already own an OpenDNS account, leave the **Yes** radio button selected.
- If you do not own an OpenDNS account, select the **No** radio button.

If you are creating an account, the following screen displays:

- a. Complete the fields.
- b. Click the **Next** button.

After you log on or create your account, the filtering level screen displays:

Live Parental Controls: choose a filtering level for your network

All computers connected to your router will be protected from the content you select below. You can customize your Live Parental Controls later on our website.

High
 Protects against all adult-related sites, illegal activity, social networking sites, video sharing sites, phishing attacks and general time-wasters.

Moderate
 Protects against all adult-related sites, illegal activity and phishing attacks.

Low
 Protects against pornography and phishing attacks.

Minimal
 Protects only against phishing attacks.

None
 Nothing blocked.

10. Select the radio button for the filtering level that you want and click the **Next** button.

The Setup is complete screen displays.

11. Click the **Take me to the status screen** button.

Parental controls are now set up for the modem router. The dashboard shows Parental Controls as Enabled.

Allow or Block Access to Your Network

You can use access control to block or allow access of devices to your network. You define access by selecting or specifying the MAC addresses of the wired and WiFi devices that can either access your entire network or are blocked from accessing your entire network.

Enable and Manage Network Access Control

When you enable access control, you must select whether new devices are allowed to access the network or blocked from accessing the network. By default, currently connected devices are allowed to access the network, but you can also block these devices from accessing the network.

➤ **To set up network access control:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Access Control**.



6. Select the **Turn on Access Control** check box.

You must select this check box before you can specify an access rule and use the **Allow** and **Block** buttons. When this check box is cleared, all devices are allowed to connect, even if the device is in the blocked list.

7. Click the **Apply** button.

Your settings are saved.

8. Select an access rule for new devices:

- **Allow all new devices to connect.** With this setting, if you add a new device, it can access your network. You do not need to enter its MAC address on this screen. NETGEAR recommends that you leave this radio button selected.
- **Block all new devices from connecting.** With this setting, if you add a new device, before it can access your network, you must enter its MAC address for an Ethernet connection and its MAC address for a WiFi connection in the allowed list. For more information, see *Manage Network Access Control Lists* on page 102.

The access rule does not affect previously blocked or allowed devices. It applies only to devices joining your network in the future after you apply these settings.

9. To manage access for currently connected computers and devices:
 - If you blocked all new devices from connecting, to allow the computer or device that you are currently using to continue to access the network, select the check box next to your computer or device in the table, and click the **Allow** button.
 - To either continue to allow or to block other computers and devices that are currently connected, select the check box next to the computer or device in the table, and click either the **Allow** button or the **Block** button.

Allow		Block		Refresh
Status	Device Name	IP Address	MAC Address	Connection Type
<input checked="" type="checkbox"/> Blocked	N/A	192.168.0.4	20:D6:70:2C:70:70	Wireless(NETGEAR23)
<input type="checkbox"/> Allowed	BUSINESSLAPTOP	192.168.0.3	60:66:66:DA:66:7C	Wireless(NETGEAR23)

10. Click the **Apply** button.

Your settings are saved.

Manage Network Access Control Lists

You can use access control to block or allow access to your network. An access control list (ACL) functions with the MAC addresses of wired and WiFi devices that can either access your entire network or are blocked from accessing your entire network.

The modem router can detect the MAC addresses of devices that are connected to the network and list the MAC addresses of devices that were connected to the network.

Each network device owns a MAC address, which is a unique 12-character physical address, containing the hexadecimal characters 0–9, a–f, or A–F (uppercase or lowercase) only, and separated by colons (for example, 00:09:AB:CD:EF:01). Typically, the MAC address is on the label of the WiFi card or network interface device. If you cannot see the label, you can display the MAC address using the network configuration utilities of the computer. You might also find the MAC addresses through the web management interface of the modem router (see *[View Devices Currently on the Network](#)* on page 168).

Add or Remove Devices from the Allowed List

If you set up an access list that blocks all new devices from accessing your network, you must specify which devices are allowed to access your network.

➤ **To add or remove devices that are allowed:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Access Control**.

The Access Control screen displays.

6. Click the **View list of allowed devices not currently connected to the network** link.



A table displays the detected device name, MAC address, and connection type of the devices that are not connected but allowed to access the network.

7. To add a device to the allowed list, do the following:

- a. Click the **Add** button.

The Add Allowed Device screen displays.

- b. Enter the MAC address and device name for the device that you want to allow.
- c. Click the **Add** button on the Add Allowed Device screen.

The device is added to the allowed list on the Access Control screen.

8. To remove a device from allowed list, do the following:

- a. Select the check box for the device.
- b. Click the **Remove from the List** button.

The device is removed from the allowed list.

9. Click the **Apply** button.

Your settings are saved.

Add or Remove Devices from the Blocked List

If you set up an access list that allows all new devices to access your network but you want to block some devices from accessing your network, you must specify the devices that you want to block.

➤ **To add or remove devices that are blocked:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Access Control**.

The Access Control screen displays.

6. Click the **View list of blocked devices not currently connected to the network link**.



A table displays the detected device name, MAC address, and connection type of the devices that are not connected and blocked from accessing the network.

7. To add a device to the blocked list, do the following:

- a. Click the **Add** button.

The Add Blocked Device screen displays.

- b. Enter the MAC address and device name for the device that you want to block.
 - c. Click the **Add** button on the Add Blocked Device screen.

The device is added to the blocked list on the Access Control screen.

8. To remove a device from blocked list, do the following:
 - a. Select the check box for the device.
 - b. Click the **Remove from the List** button.

The device is removed from the blocked list.

9. Click the **Apply** button.

Your settings are saved.

Use Keywords to Block Internet Sites

You can block keywords and domains (websites) to prevent certain types of HTTP traffic from accessing your network. By default, keyword blocking is disabled and no domains are blocked.

Set Up Blocking

You can set up blocking of specific keywords and domains to occur continuously or according to a schedule.

➤ **To set up keyword and domain blocking:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Block Sites**.



6. Specify a keyword blocking option:
 - **Per Schedule.** Use keyword blocking according to a schedule that you set. For more information, see *Set Up a Schedule for Keyword Blocking and Outbound Firewall Rules* on page 109.
 - **Always.** Use keyword blocking continuously.
7. In the **Type keyword or domain name here** field, enter a keyword or domain. Here are some sample entries:
 - Specify XXX to block <http://www.badstuff.com/xxx.html>.
 - Specify .com if you want to allow only sites with domain suffixes such as .edu or .gov.
 - Enter a period (.) to block all Internet browsing access.
8. Click the **Add Keyword** button. The keyword or domain is added to the **Block sites containing these keywords or domain names** field (which is also referred to as the blocked list).
9. To add more keywords or domains, repeat *Step 7* and *Step 8*. The keyword list supports up to 32 entries.
10. Click the **Apply** button. Your settings are saved.

Remove a Keyword or Domain from the Blocked List

If you no longer need a keyword or domain on the blocked list, you can remove the keyword or domain.

➤ **To remove a keyword or domain from the blocked list:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Block Sites**.

The Block Sites screen displays.

6. In the **Block sites containing these keywords or domain names** field, select the keyword or domain that you want to remove.

7. Click the **Delete Keyword** button.

The keyword or domain is removed from the blocked list.

8. Click the **Apply** button.

Your settings are saved.

Remove All Keywords and Domains from the Blocked List

You can simultaneously remove all keywords and domains from the blocked list.

➤ **To remove all keywords and domains from the blocked list:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Block Sites**.

The Block Sites screen displays.

6. Click the **Clear List** button.

All keywords and domains are removed from the blocked list.

7. Click the **Apply** button.

Your settings are saved.

Specify a Trusted Computer

You can exempt one trusted device from blocking and logging. The device that you exempt must be assigned a fixed (static) IP address.

➤ **To specify a trusted device:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Block Sites**.



6. Scroll down and select the **Allow trusted IP address to visit blocked sites** check box.
7. In the **Trusted IP Address** field, enter the IP address of the trusted device. The first three octets of the IP address are automatically populated and depend on the IP address that is assigned to the modem router on the LAN Setup screen.
8. Click the **Apply** button.

Your settings are saved.

Set Up a Schedule for Keyword Blocking and Outbound Firewall Rules

You can set up a schedule that you can apply to keyword blocking (see *Use Keywords to Block Internet Sites* on page 105) and outbound firewall rules (see *Manage Outbound Firewall Rules for Services and Applications* on page 179).

If applied, the schedule specifies the days and time that keyword blocking, outbound firewall rules, or both are active.

By default, no schedule is set and you can either enable or disable these features.

➤ **To set up a schedule for blocking:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Schedule**.



6. Set up the schedule for blocking:

- **Days to Block.** Select the check box for each day that you want to block access or specify that blocking occurs on every day by selecting the **Every Day** check box.

By default, the **Every Day** check box is selected.

- **Time of Day to Block.** Select a start and end time for blocking in 24-hour format or select the **All Day** check box for 24-hour blocking.

By default, the **All Day** check box is selected.

7. From the **Time Zone** menu, select your time zone.

8. If you live in an area that observes daylight saving time, select the **Automatically adjust for daylight savings time** check box.

Note: If the modem router synchronized its internal clock with a time server on the Internet and you selected the correct time zone, the **Current Time** field displays the correct date and time.

9. Click the **Apply** button.

Your settings are saved.

Set Up Security Event Email Notifications

The modem router can email you its logs of its activity. The log records router activity and security events such as attempts to access blocked sites or services.

➤ **To set up email notifications:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > E-mail**.



6. Select the **Turn Email Notification On** check box.

7. Enter the settings as described in the following table.

Field	Description
Send alerts and logs through e-mail	
Your Outgoing Mail Server	<p>Enter the name of your ISP's outgoing (SMTP) mail server (such as mail.myISP.com). You might be able to find this information in the configuration screen of your email program. If you leave this field blank, log and alert messages are not sent.</p>
Send to This E-mail Address	Enter the email address to which logs and alerts must be sent.
Secure connection (use SSL)	Select this check box to send messages over a secure connection.
My mail server requires authentication	<p>If your outgoing email server requires authentication, select this check box and specify the following settings:</p> <ul style="list-style-type: none"> In the User Name field, enter the user name for the outgoing email server. In the Password field, enter the password for the outgoing email server.
Send Alert Immediately	
If a DoS attack is detected	Select this check box to enable the modem router to send an email alert when it detects a denial of service (DoS) attack.
If a Port Scan is detected	Select this check box to enable the modem router to send an email alert when it detects a port scan.
When someone attempts to visit a blocked site	By default, this check box is selected and email alerts are sent immediately when someone attempts to visit a blocked site.
Send logs according to this schedule	
<p>To send logs based on a schedule, select one of the following options from the menu:</p> <ul style="list-style-type: none"> When log is full. This is the default selection. Hourly. Logs are sent every hour. Daily. Logs are sent every day. From the Time menu, specify the time of day, and select the am or pm radio button. Weekly. Logs are sent every week. From the Day menu, select the day. From the Time menu, specify the time of day, and select the am or pm radio button. <p>If you do not want logs to be sent at all, select the None option from the menu.</p>	

8. Click the **Apply** button.

Your settings are saved.

Logs are sent automatically. If the log fills before the specified time, it is sent. After the log is sent, it is cleared from the modem router memory. If the modem router cannot email the log and the log buffer fills, the modem router overwrites the log.

Optimize Performance

6

This chapter describes how you can optimize the modem router's performance and manage the traffic flows through the modem router.

This chapter contains the following sections:

- *Optimize Traffic with QoS*
- *Manage Default and Custom QoS Rules*
- *Manage Uplink Bandwidth Control*
- *Improve Network Connections with Universal Plug and Play*
- *Manage Wi-Fi Multimedia Quality of Service*

Optimize Traffic with QoS

You can use Quality of Service (QoS) to assign different priorities to Internet traffic, applications, and services. The modem router provides default QoS rules. You add custom QoS rules and manage both default and custom QoS rules (see *Manage Default and Custom QoS Rules* on page 115).

NETGEAR recommends that you enable QoS if you use streaming Internet. However, when QoS assigns a high priority to streaming video, it also assigns lower priority to the rest of your Internet traffic. That means that other tasks such as downloading content from the Internet take longer.

➤ **To view the default QoS rules with their default priorities and turn on QoS:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.



If you did not add any custom rules and change priorities, the QoS rules table displays the default QoS rules and their default priority queues, from the highest queue (the leftmost column) to the lowest priority (the rightmost column).

6. Select the **Turn Internet Access QoS On** check box.
7. Click the **Apply** button.

Your settings are saved. The modem router assigns traffic priorities according to the QoS rules and their priority queues.

Manage Default and Custom QoS Rules

You can add custom QoS rules and change and remove both default and custom QoS rules. You can add QoS rules for services and applications but also for specific devices on your network.

Add a Custom QoS Rule for a Service or Application

If the service or application for which you want to assign a traffic priority is not part of the default QoS rules, you can add a custom QoS rule.

➤ **To add a QoS rule for a service or application:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.


5. Select **ADVANCED > Setup > QoS Setup**.



6. Make sure that the **By Service** radio button is selected.
7. From the **Applications** menu, select **Add a new application**.

This selection is located all the way at the bottom of the **Applications** menu.

The following figure shows only part of the QoS Setup screen.



8. Specify a new QoS rule for a service or application as described in the following table.

Field	Description
QoS Policy for	Enter a name for the QoS rule.
Priority	Select the priority (Highest , High , Normal , or Low) that must be assigned to the service or application. The priority selections correspond to the queue columns in the QoS rules table.

Field	Description
Specified Port Range	
Connection Type	Select the protocol (TCP or UDP) that is associated with the service or application. If you are unsure, select TCP/UDP .
Starting Port	Enter the start port number for the service or application.
Ending Port	Enter the end port number for the service or application.

9. Click the **Add** button.

The new QoS rule is added to the QoS rules table.

10. Click the **Apply** button.

Your settings are saved.

Add a Custom QoS Rule for a Device

You can assign a traffic priority to a device on your network.

➤ **To add a QoS rule for a device:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.



6. Select the **By Device** radio button.

The following figure shows only part of the QoS Setup screen.



7. Either select the radio button for a device in the MAC Device List to complete the fields automatically (by default, each device is assigned a normal priority) or specify the settings for the device as described in the following table.

Field	Description
QoS Policy for	Enter a name for the QoS rule.
MAC Address	Enter the MAC address for the device.
Device	Enter the name of the device.
Priority	Select the priority (Highest , High , Normal , or Low) that must be assigned to the service or application. The priority selections correspond to the queue columns in the QoS rules table.

8. Click the **Add** button.

The new QoS rule is added to the QoS rules table.

9. Click the **Apply** button.

Your settings are saved.

Change a QoS Rule or Change the Priority for a Rule

You can change an existing QoS rule. For default rules, you can change only the priority. For custom rules, you can change the priority and other settings.

➤ **To change a QoS rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.



6. In the QoS rules table, click the service, application, or device to select it.

7. Click the **Edit** button.

The QoS Priority Rules screen displays.

8. Change the settings.

For more information about the settings, see *Add a Custom QoS Rule for a Service or Application* on page 115 or *Add a Custom QoS Rule for a Device* on page 117.

9. Click the **Apply** button.

Your settings are saved. If you changed the priority, the QoS rule now displays in a different column of the QoS rules table on the QoS Setup screen.

Remove a QoS Rule

You can remove an individual custom or default QoS rule.

➤ **To remove a QoS rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.

The QoS Setup screen displays.

6. In the QoS rules table, click the service, application, or device to select it.

7. Click the **Delete** button.

The QoS rule is removed.

Remove All QoS Rules

You can permanently remove all custom and default QoS rules.



WARNING:

If you remove all QoS rules, both the custom and default QoS rules are permanently removed. The only way to get the default QoS rules back is by returning the modem router to factory default settings.

➤ **To remove all QoS rules:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.

The QoS Setup screen displays.

6. Click the **Delete All** button.

All QoS rules are permanently removed.

Manage Uplink Bandwidth Control

Uplink bandwidth control lets you check the maximum uplink bandwidth that your Internet connection can support and specify the maximum uplink bandwidth.

➤ **To turn on bandwidth control and specify the maximum uplink bandwidth:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.



6. Select the **Turn Bandwidth Control On** check box.
7. To find out what uplink bandwidth your Internet connection supports, select the **Automatically check Internet Uplink bandwidth** radio button and click the **Check** button.

The speed test checks your uplink bandwidth and the supported uplink bandwidth displays.

8. In the **Uplink bandwidth Maximum** field, enter the maximum uplink bandwidth that you want to specify.
9. From the associated menu, select **Kbps** or **Mbps**.
10. Click the **Apply** button.

Your settings are saved.

Improve Network Connections with Universal Plug and Play

Universal Plug and Play (UPnP) helps devices such as Internet appliances and computers access the network and connect to other devices as needed. UPnP devices can automatically discover the services from other registered UPnP devices on the network.

If you use applications such as multiplayer gaming, peer-to-peer connections, or real-time communications such as instant messaging or remote assistance, keep UPnP enabled, which it is by default.

➤ To manage Universal Plug and Play:

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > UPnP**.

The UPnP screen displays.

6. Select the **Turn UPnP On** check box.

By default, this check box is selected. UPnP for automatic device configuration can be enabled or disabled. If the **Turn UPnP On** check box is cleared, the modem router does not allow any device to automatically control router resources, such as port forwarding.

7. Enter the advertisement period in minutes.

The advertisement period specifies how often the modem router broadcasts its UPnP information. This value can range from 1 to 1440 minutes. The default period is 30 minutes. Shorter durations ensure that control points detect current device status at the expense of more network traffic. Longer durations can compromise the freshness of the device status but can significantly reduce network traffic.

8. Enter the advertisement time to live in hops.

The time to live for the advertisement is measured in hops (steps) for each UPnP packet sent. Hops are the steps a packet takes between routers. The number of hops can range from 1 to 255. The default value for the advertisement time to live is 4 hops, which should be fine for most home networks. If you notice that some devices are not being updated or reached correctly, it might be necessary to increase this value.

9. Click the **Apply** button.

The UPnP Portmap Table displays the IP address of each UPnP device that is accessing the modem router and which ports (internal and external) that device opened. The UPnP Portmap Table also displays what type of port is open and whether that port is still active for each IP address.

10. To refresh the information in the UPnP Portmap table, click the **Refresh** button.

Manage Wi-Fi Multimedia Quality of Service

Wi-Fi Multimedia Quality of Service (WMM QoS) prioritizes WiFi voice and video traffic over the WiFi link.

WMM QoS prioritizes WiFi data packets from different applications based on four access categories: voice, video, best effort, and background. For an application to receive the benefits of WMM QoS, WMM must be enabled on both the application and the client running that application. Legacy applications that do not support WMM and applications that do not require QoS are assigned to the best effort category, which receives a lower priority than voice and video.

WMM QoS is automatically enabled for the modem router. However, you can disable WMM QoS.

➤ **To disable WMM QoS:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > QoS Setup**.

The QoS Setup screen displays.

6. Clear the **Enable WMM (Wi-Fi multimedia) settings (2.4 GHz b/g/n)** check box.
7. Clear the **Enable WMM (Wi-Fi multimedia) settings (5 GHz a/n)** check box.
8. Click the **Apply** button.

Your settings are saved.

Manage the WAN and LAN Network Settings

7

This chapter describes how you can manage the WAN and LAN network settings of the modem router.

The chapter includes the following sections:

- *Manage the ADSL Settings*
- *Change the WAN Connection Preference*
- *Manage the WAN Security Settings*
- *Set Up a Default DMZ Server*
- *Manage IGMP Proxying and VPN Pass-Through*
- *Manage NAT Filtering*
- *Enable and Configure a VLAN*
- *Manage the SIP Application-Level Gateway*
- *Manage Dynamic DNS*
- *Manage the Modem Router's LAN IP Address Settings*
- *Manage the Router Information Protocol Settings*
- *Manage Reserved LAN IP Addresses*
- *Change the Modem Router's Device Name*
- *Manage the DHCP Server Address Pool*
- *Disable the Built-In DHCP Server*
- *Set Up and Manage Custom Static Routes*

For information about the MTU size, see [Manage the MTU Size](#) on page 70.

Manage the ADSL Settings

NETGEAR recommends that you use the NETGEAR genie automatic setup utility to detect the DSL connection and automatically set up the modem router (see *Set Up Your Modem Router for DSL Service* on page 19).

If you are technically experienced and are sure of the correct DSL mode, multiplexing method, and virtual circuit number for the virtual path identifier (VPI) and virtual channel identifier (VCI), you can change those settings. NETGEAR recommends that you enter the multiplexing method, VPI, and VCI only if your ISP gave you this information.

➤ **To view or change the DSL setup:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > ADSL Settings**.



6. From the **DSL Mode** menu, select the DSL mode that your ISP provided you:
 - **Auto**. The modem router detects the DSL mode automatically. This is the default setting.
 - **ADSL (G.dmt)**. Legacy version of ADSL.

- **ADSL2.** Legacy version of ADSL2.
- **ADSL2+.** ADSL2+ provides the fastest downstream rates and can interoperate with ADSL2 and ADSL (g.dmt).

7. Click the upper **Apply** button.

Your DSL mode changes are saved.

8. From the **Multiplexing Method** menu, select **LLC-BASED** or **VC-BASED**, as indicated by your ISP.

9. For the VPI, enter a number between 0 and 255, as indicated by your ISP.

The default setting is 0.

10. For the VCI, enter a number between 32 and 65535, as indicated by your ISP.

The default setting is 38.

11. Click the lower **Apply** button.

Your PVC changes are saved.

Change the WAN Connection Preference

The modem router can auto-detect the type of WAN connection. However, you can also set the WAN connection preference manually to either the ADSL port or the Ethernet WAN port.

Note: The modem router does not support load balancing over ADSL and Ethernet WAN interfaces. Only *one* WAN interface (either the ADSL port or the Ethernet WAN port) can be active at any time.

➤ **To change the WAN connection preference:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. From the **WAN Preference** menu, select one of the following options:
 - **Auto-Detect.** The modem router automatically detects whether the WAN connection is DSL over the ADSL port or Ethernet over the Internet port. **Auto-Detect** is the default setting.
 - **Must use DSL WAN.** The modem router uses the ADSL port for a DSL WAN connection. The Internet port is shut down.
 - **Must use Ethernet WAN.** The modem router uses the Internet port for an Ethernet WAN connection. The ADSL port is shut down.
7. Click the **Apply** button.

Your settings are saved.

Manage the WAN Security Settings

The WAN security settings include port scan protection and denial of service (DoS) protection, which can protect your LAN against attacks such as Syn flood, Smurf Attack, Ping of Death, and many others. By default, DoS protection is disabled and a port scan is rejected.

You can also enable the modem router to respond to a ping to its WAN (Internet) port. This feature allows your modem router to be discovered. Enable this feature only as a diagnostic tool or if a specific reason exists.

➤ **To change the default WAN security settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. To enable port scan and DoS protection, clear the **Disable Port Scan and DoS Protection** check box.

Note: Enabling port scan and DoS protection might affect the performance of the modem router.

7. To enable modem router to respond to a ping, select the **Respond to Ping on Internet Port** check box.

8. Click the **Apply** button.

Your settings are saved.

Set Up a Default DMZ Server

The default DMZ server feature is helpful when you are using some online games and videoconferencing applications that are incompatible with Network Address Translation (NAT). The modem router is programmed to recognize some of these applications and to work correctly with them, but other applications might not function well. In some cases, one local computer can run the application correctly if the IP address for that computer is entered as the default DMZ server.



WARNING:

DMZ servers pose a security risk. A computer designated as the default DMZ server loses much of the protection of the firewall and is exposed to exploits from the Internet. If compromised, the DMZ server computer can be used to attack other computers on your network.

The modem router usually detects and discards incoming traffic from the Internet that is not a response to one of your local computers or a service or application for which you set up a port forwarding or port triggering rule. Instead of discarding this traffic, you can direct the modem router to forward the traffic to one computer on your network. This computer is called the default DMZ server.

➤ **To set up a default DMZ server:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

4. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

5. Select the **Default DMZ Server** check box.
6. Enter the IP address of the server.
7. Click the **Apply** button.

Your settings are saved.

Manage IGMP Proxying and VPN Pass-Through

IGMP proxying allows a computer on the local area network (LAN) to receive the multicast traffic it is interested in from the Internet. If you do not need this feature, leave it disabled, which is the default setting.

When Network Address Translation (NAT) is enabled in the modem router (see *Manually Set Up the Internet Connection* on page 45), it filters encrypted tunnel packets through NAT, causing these packets to become invalid. VPN pass-through allows encrypted tunnel packets to go through without being filtered and is enabled by default for IPSec, PPTP, and L2TP packets. Do not disable VPN pass-through for IPSec, PPTP, or L2TP unless a specific reason exists.

➤ **To change the default IGMP proxying and VPN pass-through settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. To enable IGMP proxying, clear the **Disable IGMP Proxying** check box.

By default, the **Disable IGMP Proxying** check box is selected and IGMP proxying is disabled.

7. To disable VPN pass-through for one or more protocols, select the corresponding **Disable** radio buttons in the VPN Passthrough section.

By default, the VPN pass-through is enabled for all protocols for which the modem router supports pass-through (IPSec, PPT, and L2TP).

8. Click the **Apply** button.

Your settings are saved.

Manage NAT Filtering

Network Address Translation (NAT) determines how the modem router processes inbound traffic. Secured NAT protects computers on the LAN from attacks from the Internet but might prevent some Internet games, point-to-point applications, or multimedia applications from working. Open NAT provides a much less secured firewall but allows almost all Internet applications to work. Secured NAT is the default setting.

➤ **To change the default NAT filtering settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. Select a NAT Filtering radio button:

- **Secured**. Provides a secured firewall to protect the computers on the LAN from attacks from the Internet but might prevent some Internet games, point-to-point applications, or multimedia applications from functioning. By default, the **Secured** radio button is selected.
- **Open**. Provides a much less secured firewall but allows almost all Internet applications to function.

7. Click the **Apply** button.

Your settings are saved.

Enable and Configure a VLAN

A network of computers and devices can behave as if they are connected to the same network even though they might actually be physically on different segments of a LAN. Virtual LANs (VLANs) are configured through software rather than hardware, which makes them very flexible.

If you enable a VLAN and if the network devices (hubs and switches) on your LAN support the VLAN (802.1Q) standard, the VLAN ID for the wireless access point is associated with all traffic coming from the modem router.

➤ **To enable and configure the VLAN:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. Select the **Enable VLAN** check box.

7. Enter a VLAN ID.

The VLAN ID can be in a range from 0 to 4095. The default VLAN ID is 0.

8. Click the **Apply** button.

Your settings are saved.

Manage the SIP Application-Level Gateway

The application-level gateway (ALG) for the Session Initiation Protocol (SIP) is enabled by default for enhanced address and port translation. However, some types of VoIP and video traffic might not work well when the SIP ALG is enabled. For this reason, the modem router provides the option to disable the SIP ALG.

➤ **To change the default SIP ALG setting:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > WAN Setup**.

The WAN Setup screen displays.

6. To disable the SIP ALG, select the **Disable SIP ALG** check box.

The SIP ALG is enabled by default.

7. Click the **Apply** button.

Your settings are saved.

Manage Dynamic DNS

Internet service providers (ISPs) assign numbers called IP addresses to identify each Internet account. Most ISPs use dynamically assigned IP addresses. This means that the IP address can change at any time. You can use the IP address to access your network remotely, but most people do not know what their IP addresses are or when this number changes.

To make it easier to connect, you can get a free account with a Dynamic DNS service that lets you use a domain name to access your home network. To use this account, you must set up the modem router to use Dynamic DNS. Then the modem router notifies the Dynamic DNS service provider whenever its IP address changes. When you access your Dynamic DNS account, the service finds the current IP address of your home network and automatically connects you.

If your ISP assigns a private WAN IP address (such as 192.168.x.x or 10.x.x.x), the Dynamic DNS service does not work because private addresses are not routed on the Internet.

Set Up a New Dynamic DNS Account

NETGEAR offers you the option to set up a free Dynamic DNS account through the web management interface of the modem router.

➤ **To set up Dynamic DNS and register for a free NETGEAR account:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Dynamic DNS**.

The screenshot shows the 'Dynamic DNS' configuration page. The left sidebar has tabs for 'ADVANCED Home', 'Setup Wizard', 'WPS Wizard', 'Setup', 'Security', 'Administration', and 'Advanced Setup'. 'Advanced Setup' is expanded, showing 'Wireless Settings', 'Wireless Access Point', 'Port Forwarding / Port Triggering', 'Dynamic DNS' (which is selected and highlighted in purple), 'Static Routes', 'Remote Management', 'UPnP', 'IPv6', 'Traffic Meter', and 'Device Mode'. The main content area has tabs for 'Basic' and 'Advanced'. The 'Advanced' tab is selected. It shows a 'Dynamic DNS' section with a 'Use a Dynamic DNS Service' checkbox (unchecked), a 'Service Provider' dropdown set to 'NETGEAR', and a 'NETGEAR' logo. Below that, it asks if you have a NETGEAR DDNS or a No-IP DDNS account, with 'No' selected. It then asks for registration information: 'Host Name' (mynetgear.com), 'Email' (empty), and 'Password (6-32 characters)' (empty). A 'Register' button is present, and a note below it says 'By submitting this form I agree to the [terms of service](#) and that I will only create one free account.'

6. Select the **Use a Dynamic DNS Service** check box.
7. From the **Service Provider** menu, select **NETGEAR**.
8. Select the **No** radio button.
9. In the **Host Name** field, enter the name that you want to use for your URL.

The host name is sometimes called the domain name. Your free URL includes the host name that you specify and ends with mynetgear.com. For example, specify *MyName.mynetgear.com*.

10. In the **Email** field, enter the email address that you want to use for your account.
11. In the **Password (6-32 characters)** field, enter the password that you want to use for your account.
12. Click the **Register** button.
13. Follow the onscreen instructions to register for your NETGEAR Dynamic DNS service.

Specify a DNS Account That You Already Created

If you already created a Dynamic DNS account with NETGEAR, No-IP, or Dyn, you can set up the modem router to use your account.

➤ **To set up Dynamic DNS if you already created an account:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Settings > Dynamic DNS**.

The Dynamic DNS screen displays.

6. Select the **Use a Dynamic DNS Service** check box.

7. From the **Service Provider** menu, select your provider.

8. Select the **Yes** radio button.

The screen adjusts.

9. In the **Host Name** field, enter the host name (sometimes called the domain name) for your account.

10. Depending on the type of account, specify your user name or email address:

- For a No-IP or Dyn account, in the **User Name** field, enter the user name for your account.
- For a NETGEAR account, in the **Email** field, enter the email address for your account.

11. In the **Password (6-32 characters)** field, enter the password for your DDNS account.

12. Click the **Apply** button.

Your settings are saved.

13. To verify that your Dynamic DNS service is enabled in the modem router, click the **Show Status** button.

A message displays the Dynamic DNS status.

Manage the Modem Router's LAN IP Address Settings

The modem router is preconfigured to use private IP addresses on the LAN side and to act as a DHCP server. The modem router's default LAN IP configuration is as follows:

- **LAN IP address.** 192.168.0.1 (This is the same as www.routerlogin.net and www.routerlogin.com.)
- **Subnet mask.** 255.255.255.0

These addresses are part of the designated private address range for use in private networks and are suitable for most applications. The IP address and subnet mask identify which addresses are local to a specific device and which must be reached through a gateway or modem router. You might want to change these settings if you need a specific IP subnet that one or more devices on the network use, or if competing subnets use the same IP scheme.

➤ **To change the LAN IP address settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.



6. In the **IP Address** field, enter the LAN IP address for the modem router.
7. In the **IP Subnet Mask**, enter the LAN subnet mask for the modem router.
8. Click the **Apply** button.

Your settings are saved.

If you changed the LAN IP address of the modem router, you are disconnected when the changes take effect.

To reconnect, close your browser, relaunch it, and log in to the modem router at its new LAN IP address.

Manage the Router Information Protocol Settings

Router Information Protocol (RIP) lets the modem router exchange routing information with other routers. By default, RIP is enabled in both directions (in and out) without a particular RIP version.

➤ **To manage the RIP settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.

The LAN Setup screen displays.

6. Select an RIP direction:

- **Both**. The modem router broadcasts its routing table periodically and incorporates information that it receives. This is the default setting.
- **Out Only**. The modem router broadcasts its routing table periodically but does not incorporate the RIP information that it receives.
- **In Only**. The modem router incorporates the RIP information that it receives but does not broadcast its routing table.

7. Select an RIP version:

- **Disabled**. The RIP version is disabled. This is the default setting.
- **RIP-1**. This format is universally supported. It is adequate for most networks, unless you are using an unusual network setup.
- **RIP-2**. This format carries more information. Both RIP-2B and RIP-2M send the routing data in RIP-2 format. RIP-2B uses subnet broadcasting. RIP-2M uses multicasting.

8. Click the **Apply** button.

Your settings are saved.

Manage Reserved LAN IP Addresses

When you specify a reserved IP address for a computer on the LAN, that computer always receives the same IP address each time it accesses the modem router's DHCP server.

Reserve a LAN IP address

You can assign a reserved IP address to a computer or server that requires permanent IP settings.

➤ **To reserve an IP address:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.

The LAN Setup screen displays.

6. In the Address Reservation section, click the **Add** button.

7. Either select a device from the Address Reservation Table table by selecting the corresponding radio button or specify the reserved IP address information:

- In the **IP Address** field, enter the IP address to assign to the computer or device. Choose an IP address from the modem router's LAN subnet, such as 192.168.0.x.
- In the **MAC Address** field, enter the MAC address of the computer or device.
- In the **Device Name** field, enter the name of the computer or device.

8. Click the **Add** button.

The reserved address is entered into the table on the LAN Setup screen.

The reserved address is not assigned until the next time the computer or device contacts the modem router's DHCP server. Reboot the computer or device, or access its IP configuration and force a DHCP release and renew.

Change a Reserved IP Address

You can change a reserved IP address entry.

➤ **To change a reserved IP address entry:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.

The LAN Setup screen displays.

6. In the Address Reservation section, select the radio button next to the reserved address.

7. Click the **Edit** button.

The Edit screen displays.

8. Change the settings.

9. Click the **Apply** button.

Your settings are saved.

Remove a Reserved IP Address Entry

You can remove a reserved IP address entry.

➤ **To remove a reserved IP address entry:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.
The LAN Setup screen displays.
6. In the Address Reservation section, select the radio button next to the reserved address.
7. Click the **Delete** button.
The address entry is removed.

Change the Modem Router's Device Name

The modem router's default device name is D6100. This device name displays in a file manager when you browse your network.

➤ **To change the modem router's device name:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Setup > LAN Setup**.
The LAN Setup screen displays.
6. In the **Device Name** field, enter a new name.
7. Click the **Apply** button.
Your settings are saved.

Manage the DHCP Server Address Pool

By default, the modem router acts as a Dynamic Host Configuration Protocol (DHCP) server. The modem router assigns IP, DNS server, and default gateway addresses to all computers that are connected to its LAN and WiFi network. The assigned default gateway address is the LAN address of the modem router.

These addresses must be part of the same IP address subnet as the modem router's LAN IP address. The default DHCP address pool is 192.168.0.2–192.168.0.254.

The modem router delivers the following parameters to any LAN device that requests DHCP:

- An IP address from the range that you define
- Subnet mask
- Gateway IP address (the modem router's LAN IP address)
- DNS server IP address (the modem router's LAN IP address)

➤ **To specify the pool of IP addresses that the modem router assigns:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.



6. Make sure that the **Use Router as DHCP Server** check box is selected.

This check box is selected by default.

7. Specify the range of IP addresses that the modem router assigns:

- In the **Starting IP Address** field, enter the lowest number in the range.

This IP address must be in the same subnet as the modem router. By default, the starting IP address is 192.168.0.2.

- In the **Ending IP Address** field, enter the number at the end of the range of IP addresses.

This IP address must be in the same subnet as the modem router. By default, the ending IP address is 192.168.0.254.

8. Click the **Apply** button.

Your settings are saved.

Disable the Built-In DHCP Server

By default, the modem router functions as a DHCP server. The modem router assigns IP, DNS server, and default gateway addresses to all devices connected to the LAN. The assigned default gateway address is the LAN address of the modem router.

You can use another device on your network as the DHCP server or specify the network settings of all your computers.

Note: If you disable the DHCP server and no other DHCP server is available on your network, you must set your computer IP addresses manually so that they can access the modem router.

➤ **To disable the built-in DHCP server:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Setup > LAN Setup**.

The LAN Setup screen displays.

6. Clear the **Use Router as DHCP Server** check box.

7. Click the **Apply** button.

Your settings are saved.

Set Up and Manage Custom Static Routes

Static routes provide detailed routing information to your modem router. Typically, you do not need to add static routes. You must configure static routes only for unusual cases such as when you use multiple routers or multiple IP subnets on your network.

As an example of when a static route is needed, consider the following case:

- Your primary Internet access is through an ADSL modem to an ISP.
- You use an ISDN router on your home network for connecting to the company where you are employed. This router's address on your LAN is 192.168.0.100.
- Your company's network address is 134.177.0.0.

When you first configured your modem router, two implicit static routes were created. A default route was created with your ISP as the gateway and a second static route was created to your local network for all 192.168.0.x addresses. With this configuration, if you attempt to access a device on the 134.177.0.0 network, your modem router forwards your request to the ISP. The ISP forwards your request to the company where you are employed, and the request is likely to be denied by the company's firewall.

In this case, you must define a static route, instructing your modem router that 134.177.0.0 is accessed through the ISDN modem router at 192.168.0.100. Here is an example:

- Through the destination IP address and IP subnet mask, specify that this static route applies to all 134.177.x.x addresses.
- Through the gateway IP address, specify that all traffic for these addresses is forwarded to the ISDN modem router at 192.168.0.100.
- A metric value of 1 works fine because the ISDN modem router is on the LAN.

Set Up a Static Route

You can add a static route to a destination IP address and specify the subnet mask, gateway IP address, and metric.

➤ **To set up a static route:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Static Routes**.

The Static Routes screen displays.

6. Click the **Add** button.



7. To make the route private, select the **Private** check box.

A private static route is not reported in RIP.

8. To prevent the route from becoming active after you click the **Apply** button, clear the **Active** check box.

In some situations, you might want to set up a static route but keep it disabled until a later time. By default, the **Active** check box is selected and a route becomes active after you click the **Apply** button.

9. Enter the settings as described in the following table.

Field	Description
Destination IP Address	Enter the IP address for the final destination of the route.
IP Subnet Mask	Enter the IP subnet mask for the final destination of the route. If the destination is a single host, enter 255.255.255.255 .
Gateway IP Address	Enter the IP address of the gateway. The IP address of the gateway must be on the same LAN segment as the modem router.
Metric	Enter a number from 1 through 15. This value represents the number of routers between your network and the destination. Usually, a setting of 2 or 3 works, but if this is a direct connection, set it to 1.

10. Click the **Apply** button.

Your settings are saved. The static route is added to the table on the Static Routes screen.

Change a Static Route

You can change an existing static route.

➤ **To change a static route:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Static Routes**.

The Static Routes screen displays.

6. In the Static Routes table, select the radio button to the left of the route that you want to change.

7. Click the **Edit** button.

The screen adjusts.

8. Change the settings for the route.

For more information about the settings, see *Set Up a Static Route* on page 143.

9. Click the **Apply** button.

The route is updated in the table on the Static Routes screen.

Remove a Static Route

You can remove an existing static route that you no longer need.

➤ **To remove a static route:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Static Routes**.

The Static Routes screen displays.

6. In the Static Routes table, select the radio button to the left of the route that you want to remove.

7. Click the **Delete** button.

The route is removed from the table on the Static Routes screen.

Manage the Modem Router and Monitor the Traffic

This chapter describes how you can manage the settings for administering and maintaining your modem router and monitor the network.

The chapter includes the following sections:

- *Update the Firmware of the Modem Router*
- *Manage the Configuration File of the Modem Router*
- *Recover the admin Password*
- *Return the Modem Router to Its Factory Default Settings*
- *View the Status and Statistics of the Modem Router*
- *Manage the Activity Log and Syslog*
- *View Devices Currently on the Network*
- *Monitor and Meter Internet Traffic*
- *Manage the Modem Router Remotely*
- *Configure the Modem Router as a DSL Modem Only*

For information about changing the admin password, see *Change the admin Password and Automatic Login Time-Out Period* on page 34.

For information about setting up password recovery, see *Set Up Password Recovery* on page 36.

Update the Firmware of the Modem Router

The modem router firmware is stored in flash memory.

You can check to see if new firmware is available and update the modem router to the new firmware. You can also visit the NETGEAR support website, download the firmware manually, and update the modem router to the new firmware.

Check for New Firmware and Update the Modem Router

For you to check for new firmware, the modem router must be connected to the Internet.

➤ **To check for new firmware and update your modem router:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Firmware Update**.

The Firmware Update screen displays.

6. Click the **Check** button.

The modem router detects new firmware if any is available and displays a message asking if you want to download and install it.

7. To download and install the new firmware, click **Yes**.

The modem router locates the firmware, downloads it, and begins the update.



WARNING:

To avoid the risk of corrupting the firmware, do not interrupt the upload. For example, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.

A progress bar shows the progress of the firmware upload process. The firmware upload process takes several minutes. When the upload is complete, your modem router restarts.

8. Verify that the modem router runs the new firmware version:
 - a. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 - b. Type **http://www.routerlogin.net**.
A login screen displays.
 - c. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
 - d. Click the **OK** button.
The BASIC Home screen displays.
- The firmware version is stated in the top right, under the **Logout** button.
9. To determine whether you must reconfigure the modem router after updating (which is unlikely but possible), visit downloadcenter.netgear.com, go to the support page for your product, and locate and read the new firmware release notes.

Manually Upload New Firmware and Update the Modem Router

Downloading firmware and updating the modem router are two separate tasks that are combined in the following procedure.

➤ **To download new firmware manually and update your modem router:**

1. Visit downloadcenter.netgear.com, locate the support page for your product, and download the new firmware.
2. Read the new firmware release notes to determine whether you must reconfigure the modem router after updating (which is unlikely but possible).
3. Launch an Internet browser from a computer or WiFi device that is connected to the network.
4. Type **http://www.routerlogin.net**.
A login screen displays.
5. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
6. Click the **OK** button.
The BASIC Home screen displays.
7. Select **ADVANCED > Administration > Firmware Update**.
The Firmware Update screen displays.

8. Locate and select the firmware file on your computer:

- a. Click the **Browse** button.
 - b. Navigate to the firmware file.

The file ends in `.img`. An example of a firmware file name is `D6100-V1.0.0.34_0.0.34.img`.

- c. Select the firmware file.

9. Click the **Upload** button.



WARNING:

To avoid the risk of corrupting the firmware, do not interrupt the upload. For example, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.

A progress bar shows the progress of the firmware upload process. The firmware upload process takes several minutes. When the upload is complete, your modem router restarts.

10. Verify that the modem router runs the new firmware version:

- a. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 - b. Type <http://www.routerlogin.net>.

A login screen displays.

- c. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- d. Click the **OK** button.

The BASIC Home screen displays.

The version firmware is stated in the top right, under the **Logout** button.

Manage the Configuration File of the Modem Router

The configuration settings of the modem router are stored within the modem router in a configuration file. You can back up (save) this file to your computer or restore it.

Back Up the Settings

You can save a copy of the current configuration settings.

➤ **To back up the modem router's configuration settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Backup Settings**.

The Backup Settings screen displays.

6. Click the **Back Up** button.

7. Choose a location to store the file on your computer.

The name of the backup file is **NETGEAR_D6100.cfg**.

8. Follow the directions of your browser to save the file.

Restore the Settings

If you backed up the configuration file, you can restore the configuration from this file.

➤ **To restore configuration settings that you backed up:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Backup Settings**.

The Backup Settings screen displays.

6. Click the **Browse** button and navigate to and select the saved configuration file.

The name of the backup file from which you can restore the configuration is **NETGEAR_D6100.cfg**.

Follow the directions of your browser to locate and select the file.

7. Click the **Restore** button.

The configuration is uploaded to the modem router. When the restoration is complete, the modem router reboots. This process takes about one minute.



WARNING:

To avoid the risk of corrupting the firmware, do not interrupt the restoration. For example, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.

Recover the admin Password

NETGEAR recommends that you enable password recovery if you change the password for the modem router user name admin. Then you can recover the password if it is forgotten. This recovery process is supported in Internet Explorer, Firefox, and Chrome browsers, but not in the Safari browser.

For information about setting up password recovery, see *Set Up Password Recovery* on page 36. The following procedure works only if you did set up password recovery.

➤ **To recover your password:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. In the address field of your browser, type **www.routerlogin.net**.

A login screen displays.

3. Click **Cancel**.

If password recovery is enabled, you are prompted to enter the serial number of the modem router. The serial number is on the product label on the bottom panel of the modem router.

4. Enter the serial number of the modem router.
5. Click the **Continue** button.

A screen displays requesting the answers to your security questions.

6. Enter the saved answers to your security questions.
7. Click the **Continue** button.

A screen displays your recovered password.

8. Click the **Login again** button.

A login screen displays.

9. With your recovered password, log in to the modem router.

Return the Modem Router to Its Factory Default Settings

Under some circumstances (for example, if you lost track of the changes that you made to the modem router settings or you move the modem router to a different network), you might want to erase the configuration and reset it to factory default settings.

If you do not know the current IP address of the modem router, first try to use an IP scanner application to detect the IP address before you reset the modem router to factory default settings.

To reset the modem router to factory default settings, you can use either the **Reset** button on the back of the modem router or the Erase function. However, if you cannot find the IP address or lost the password to access the modem router, you must use the **Reset** button.

After you reset the modem router to factory default settings, the user name is admin, the password is password, the LAN IP address is 192.168.0.1 (which is the same as www.routerlogin.net and www.routerlogin.com), and the DHCP server is enabled. For a list of factory default settings, see *Factory Settings* on page 218.

Use the Reset Button




CAUTION:

This process erases all settings that you configured in the modem router.

➤ **To reset the modem router to factory default settings:**

1. On the back of the modem router, locate the **Reset** button.



2. Using a straightened paper clip, press and hold the **Reset** button for eight seconds.
3. Release the **Reset** button.

The configuration is reset to factory default settings. When the reset is complete, the modem router reboots. This process takes about one minute.



WARNING:

To avoid the risk of corrupting the firmware, do not interrupt the reset. For example, if you are connected to the web management interface, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.

Erase the Settings



CAUTION:

This process erases all settings that you configured in the modem router.

➤ **To erase the settings:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Backup Settings**.

The Backup Settings screen displays.

6. Click the **Erase** button.

7. To confirm the action, click the **Yes** button.

The configuration is reset to factory default settings. When the reset is complete, the modem router reboots. This process takes about one minute.

**WARNING:**

To avoid the risk of corrupting the firmware, do not interrupt the reset. For example, do not close the browser, click a link, or load a new page. Do not turn off the modem router. Wait until the modem router finishes restarting and the Power LED turns solid green.


View the Status and Statistics of the Modem Router

You can view information about the modem router, its broadband modem, and ports, and the status of the Internet connection and WiFi network. In addition, you can view traffic statistics for the various ports.

View Information About the Modem Router and the Internet, Modem, and WiFi Settings

You can view modem router information, the Internet port status, and WiFi settings.

- **To view information about the modem router and the Internet, modem, and WiFi settings:**
 1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 2. Type <http://www.routerlogin.net>.
A login screen displays.
 3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
 4. Click the **OK** button.
The BASIC Home screen displays.
 5. Select **ADVANCED > ADVANCED Home**.



The information onscreen uses the following color coding:

- A green flag indicates that a link is up.
- A red X indicates that a link is down.
- An amber exclamation mark indicates that a WiFi network is disabled. The following table describes the fields of the six panes on the ADVANCED Home screen.

Field	Description
Router Information	
Hardware Version	The modem router model.
Firmware Version	The version of the modem router firmware. If you upgrade the firmware on the modem router, the version changes.
GUI Language Version	The version of the modem router firmware. If you upgrade the firmware on the modem router, the version changes.

Field	Description
LAN Port	The settings of the LAN port. For information about how to configure the LAN settings, see Manage the Modem Router's LAN IP Address Settings on page 135 and Disable the Built-In DHCP Server on page 142.
MAC Address	The Media Access Control (MAC) address. This address is the unique physical address that is assigned to the Ethernet LAN port.
IP Address	The IP address that the Ethernet LAN port uses. The default IP address is 192.168.0.1.
DHCP	Displays whether the DHCP server of the modem router is enabled for devices that are attached to the LAN.
Internet Port	
The settings of Internet port. The Internet connection can run through the ADSL port with DSL service or through the WAN Ethernet port with cable or fiber service. For information about how to configure the Internet settings, see one of the following sections:	
<ul style="list-style-type: none"> • Set Up Your Modem Router for DSL Service on page 19 • Set Up Your Modem Router for Cable or Fiber Service on page 26 • Manually Set Up the Internet Connection on page 45. 	
MAC Address	The Media Access Control (MAC) address. This address is the unique physical address that is assigned to the Internet port.
IP Address	The IP address that the Internet port uses. If this field does not display an address or displays 0.0.0.0 as the address, the modem router is not connected to the Internet.
Connection	The type of Internet connection, which can be a PPPoE connection, PPPoA connection, fixed IP address connection, or DHCP connection.
IP Subnet Mask	The IP subnet mask that the Internet port uses.
Gateway IP Address	The IP address of the gateway that the Internet port uses.
Domain Name Server	The IP address of the Domain Name System (DNS) server that the Internet uses.
Wireless Settings (2.4GHz)	
The settings of the WiFi port for the 2.4 GHz band of the main network. For information about how to configure the settings of the main network, see Manage the Basic WiFi Settings and WiFi Security of the Main Network on page 73, Control the WiFi Radios on page 88, and Manage Advanced WiFi Features on page 93.	
Name (SSID)	The WiFi network name for the 2.4 GHz band of the main network.
Region	The location (country).
Channel	The channel that the 2.4 GHz band of the main network uses.
Mode	The WiFi mode in which the 2.4 GHz band operates for both the main network and the guest network.

Field	Description
Wireless AP	Displays whether the 2.4 GHz band of the main network is enabled. If the 2.4 GHz band is disabled but the 5 GHz band is enabled, the WiFi LED on the front of the modem router lights blue. If both radios are off, the WiFi LED is off too.
Broadcast Name	Displays whether the 2.4 GHz band of the main network broadcasts its SSID.
Wi-Fi Protected Setup	Displays whether the modem router keeps its existing WiFi settings when you use WPS to connect a device to the 2.4 GHz band of the main network: <ul style="list-style-type: none"> Configured. The modem router keeps its existing WiFi settings. This is the default setting. Not configured. The modem router generates a random SSID and passphrase and changes the security mode to WPA/WPA2-PSK mixed mode.
Wireless Settings (5.0GHz)	
The settings of the WiFi port for the 5 GHz band of the main network. For information about how to configure the settings of the main network, see <i>Manage the Basic WiFi Settings and WiFi Security of the Main Network</i> on page 73, <i>Control the WiFi Radios</i> on page 88, and <i>Manage Advanced WiFi Features</i> on page 93.	
Name (SSID)	The WiFi network name for the 5 GHz band of the main network.
Region	The location (country).
Channel	The channel that the 5 GHz band of the main network uses.
Mode	The WiFi mode in which the 5 GHz band operates for both the main network and the guest network.
Wireless AP	Displays whether the 5 GHz band of the main network is enabled. If the 5 GHz band is disabled but the 2.4 GHz band is enabled, the WiFi LED on the front of the modem router lights blue. If both radios are off, the WiFi LED is off too.
Broadcast Name	Displays whether the 5 GHz band of the main network broadcasts its SSID.
Wi-Fi Protected Setup	Displays whether the modem router keeps its existing WiFi settings when you use WPS to connect a device to the 5 GHz band of the main network: <ul style="list-style-type: none"> Configured. The modem router keeps its existing WiFi settings. This is the default setting. Not configured. The modem router generates a random SSID and passphrase and changes the security mode to WPA/WPA2-PSK mixed mode. For more information, see <i>Manage the WPS Settings</i> on page 92.
Guest Network (2.4GHz)	
The settings of the WiFi port for the 2.4 GHz band of the guest network. For information about how to configure the settings of the guest network, see <i>Manage the Basic WiFi Settings and WiFi Security of the Guest Network</i> on page 84.	
Name (SSID)	The WiFi network name for the 2.4 GHz band of the guest network.

Field	Description
Wireless AP	Displays whether the 2.4 GHz band of the guest network is enabled. The WiFi LED on the front of the modem router is not affected by the status of the guest network.
Broadcast Name	Displays whether the 2.4 GHz band of the guest network broadcasts its SSID.
Allow guest to access My Local Network	Displays whether users of the 2.4 GHz band of the guest network are allowed to access the main network.
Guest Network (5.0GHz)	
The settings of the WiFi port for the 5 GHz band of the guest network. For information about how to configure the settings of the guest network, see <i>Manage the Basic WiFi Settings and WiFi Security of the Guest Network</i> on page 84.	
Name (SSID)	The WiFi network name for the 5 GHz band of the guest network.
Wireless AP	Displays whether the 2.4 GHz band of the main network is enabled. If the 2.4 GHz band is disabled but the 5 GHz band is enabled, the WiFi LED on the front of the modem router lights blue. If both radios are off, the WiFi LED is off too.
Broadcast Name	Displays whether the 5 GHz band of the guest network broadcasts its SSID.
Allow guest to access My Local Network	Displays whether users of the 5 GHz band of the guest network are allowed to access the main network.

View the Traffic Statistics

You can view the traffic statistics for the ports of the modem router, change the polling frequency, and stop traffic polling.

➤ **To view the traffic statistics for the ports of the modem router:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, click the **Show Statistics** button.



The following table describes the fields and columns of the Show Statistics pop-up screen.

Field or Column	Description
System Up Time	The time elapsed since the modem router was last restarted.
Port	The statistics for the WAN (Internet over Ethernet) port, LAN (Ethernet) ports, WLAN b/g/n, and WLAN a/n/ac ports. For each port, the screen displays the information that is described in this table.
Status	The link status of the port.
TxPkts	The number of packets transmitted on this port since reset or manual clear.
RxPkts	The number of packets received on this port since reset or manual clear.
Collisions	The number of signal collisions that occurred on the port. A collision occurs when the port attempts to send data at the same time as the device that is connected to the port.
Tx B/s	The number of bytes transmitted per second on the port.
Rx B/s	The number of bytes received per second on the port.
Up Time	The time elapsed since this port acquired the link.
Poll Interval	The interval at which the statistics are updated in this screen.
ADSL Link	
In addition to the xDSL firmware version, the screen displays the ADSL link information that is described in this table.	
Data Rate	The downstream and upstream data rates in Kbps.
Line Attenuation (LATN)	The downstream and upstream LATN in dB. The LATN expresses the signal quality.
Signal-to-Noise Ratio Margin (SNRM)	The downstream and upstream SNRM in dB. The SNRM expresses the signal quality in relation to interference.

➤ **To change the traffic statistics polling frequency or stop polling:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > ADVANCED Home**.
The ADVANCED Home screen displays.
6. In the Internet Port pane, click the **Show Statistics** button.
A pop-up screen displays.
7. Change the polling frequency or stop polling:
 - To change the polling frequency:
 - a. In the **Poll Interval** field, enter a time in seconds.
 - b. Click the **Set Interval** button.
 - To stop polling, click the **Stop** button.

View or Change a TCP/IP Internet Connection

You can view information about a TCP/IP Internet connection of the modem router and renew or release such a connection. This information displays only if the modem router connects to the ISP network over a TCP/IP connection (see *Specify an Internet Connection Without a Login* on page 45).

➤ **To view or change the TCP/IP Internet connection status:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, click the **Connection Status** button.

The fields that display depend on the type of Internet connection.

The following screen shows the fields for an established TCP/IP connection with DHCP.

Connection Status	
IP Address	100.168.100.147
Subnet Mask	255.255.255.0
Default Gateway	100.168.100.1
DHCP Server	100.168.100.1
DNS Server	100.168.100.1 0.0.0.0
<input type="button" value="Release"/> <input type="button" value="Renew"/>	
<input type="button" value="Close Window"/>	

The following table describes the fields of the Connection Status pop-up screen.

Field	Description
IP Address	The IP address that is assigned by the ISP to the modem router.
Subnet Mask	The subnet mask that is assigned by the ISP to the modem router.
Default Gateway	The IP address of the default gateway of the ISP that the modem router communicates with.
DHCP Server	The IP address of the DHCP server of the ISP that issues the IP address to the modem router.
DNS Server	The IP address of the Domain Name System (DNS) server of the ISP that provides translation of network names to IP addresses.
Lease Obtained	The time at which the modem router obtained the DHCP lease. (The type of DHCP connection determines whether this field displays onscreen.)
Lease Expires	The time at which the DHCP lease expires. (The type of DHCP connection determines whether this field displays onscreen.)

7. To renew the Internet connection when the connection is active, click the **Renew** button.
8. To terminate the Internet connection when the connection is active, click the **Release** button.
9. Click the **Close Window** button.

The pop-up screen closes.

View or Change a PPPoE or PPPoA Internet Connection

You can view information about a PPPoE or PPPoA Internet connection of the modem router and establish or terminate such a connection. This information displays only if the modem router connects to the ISP network over a PPPoE connection (see *Specify an Internet Connection That Uses a Login and PPPoE Service* on page 51) or PPPoA connection (see *Specify an Internet Connection That Uses a Login and PPPoA Service* on page 54).

➤ **To view or change the PPPoE or PPPoA Internet connection status:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, click the **Connection Status** button.

The fields that display depend on the type of Internet connection.

The following screen shows an established PPPoE connection.

Connection Status	
Connection Time	00:03:45
Connection Status	connected
Negotiation	Success
Authentication	Success
IP Address	192.168.250.39
Subnet Mask	255.255.255.255
<input type="button" value="Connect"/> <input type="button" value="Disconnect"/>	
<input type="button" value="Close Window"/>	

The following table describes the fields of the Connection Status pop-up screen.

Field	Description
Connection Time	The time elapsed since the connection was established.
Connection Status	The status can be Connected or Disconnected.
Negotiation	The negotiation can be a series of dashes, which indicates that the connection is not established, or successful (Success).
Authentication	The authentication can be a series of dashes, which indicates that the connection is not established, or successful (Success).
IP Address	The IP address that is assigned by the ISP to the modem router.
Subnet Mask	The subnet mask that is assigned by the ISP to the modem router.

7. To establish the Internet connection when the connection is down, click the **Connect** button.
8. To terminate the Internet connection when the connection is active, click the **Disconnect** button.
9. Click the **Close Window** button.

The pop-up screen closes.

View or Change a PPTP or L2TP Internet Connection

You can view information about a PPTP or L2TP Internet connection of the modem router and establish or terminate such a connection. This information displays only if the modem router connects to the ISP network over a PPTP or L2TP connection (see *Specify an Internet Connection That Uses a Login and PPTP or L2TP Service* on page 48).

➤ **To view or change the PPTP or L2TP Internet connection status:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, click the **Connection Status** button.



The following table describes the fields of the Connection Status pop-up screen.

Field	Description
IP Address	The IP address that is assigned by the ISP to the modem router.
Subnet Mask	The subnet mask that is assigned by the ISP to the modem router.

7. To establish the Internet connection when the connection is down, click the **Connect** button.
8. To terminate the Internet connection when the connection is active, click the **Disconnect** button.
9. Click the **Close Window** button.

The pop-up screen closes.

Manage the Activity Log and Syslog

The log is a detailed record of the websites users on your network accessed or attempted to access and many other modem router actions. Up to 256 entries are stored in the log. You can also manage which activities are logged.

View the Logs

- **To manage which activities are logged and view the log:**
 1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 2. Type **http://www.routerlogin.net**.


A login screen displays.

 3. Enter the modem router user name and password.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

The BASIC Home screen displays.

 4. Select **ADVANCED > Administration > Logs**.



The Logs screen shows the following information:

- **Action.** The action that occurred, such as whether Internet access was blocked or allowed.
- **Source.** The name, IP address, or MAC address of the target device, application, or website for this log entry.
- **Target.** The name, IP address, or MAC address of the target device, application, or website for this log entry.
- **Date and time.** The date and time at which the action occurred.

5. To refresh the log screen, click the **Refresh** button.
6. To clear the log entries, click the **Clear Log** button.
7. To email the log immediately, click the **Send Log** button.

The modem router emails the logs to the address that you specified (see *Set Up Security Event Email Notifications* on page 111).

Specify Which Activities Are Logged

You can specify which activities are logged. These activities display in the log and are forwarded to the syslog server if you enabled the syslog server function.

➤ **To manage which activities are logged:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Logs**.

The Logs screen displays.

6. Scroll down and select the check boxes that correspond to the activities that you want to be logged.

By default, all check boxes are selected.

7. Clear the check boxes that correspond to the activities that do not want to be logged.

8. Click the **Apply** button.

Your settings are saved.

Specify a Syslog Server

You can let the modem router send the logs to a syslog server on your LAN or to an external syslog server. The modem router can also broadcast the syslog server message on your LAN.

➤ **To specify a syslog server and enable forwarding of log messages:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Logs**.

The Logs screen displays.

6. Scroll down to the Syslog section.

By default, the **Disable** button is selected and no log messages are forwarded.

7. Select how log messages are forwarded:

- **Broadcast on LAN.** The modem router broadcasts log messages on your LAN but does not send log messages to a syslog server.
- **Send to this Syslog server IP address.** The modem router sends log messages to an internal or external syslog server, for which you must enter the IP address.

8. Click the **Apply** button.

Your settings are saved.

View Devices Currently on the Network

You can view the active wired devices, 2.4 GHz WiFi devices, and 5 GHz WiFi devices in the network. If you do not recognize a device, it might be an intruder. If it is an intruder, make sure that your WiFi security is set up correctly (see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73) or set up access control to secure your network (see *Allow or Block Access to Your Network* on page 100).

➤ **To display the wired and WiFi devices:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **Attached Devices**.

The Attached Devices screen displays.

Wired devices are connected to the modem router with Ethernet cables. WiFi devices are connected to the modem router through the WiFi network, either in the 2.4 GHz band or the 5 GHz band.

The following table describes the fields on the Attached Devices screen.

Field	Description
#	The order in which the device joined the network.
SSID	The SSID to which the WiFi device is connected. (This field does not apply to wired devices.)
IP Address	The IP address that the modem router assigned to the device when it joined the network. This number can change when a device is disconnected and rejoins the network.
MAC Address	The unique MAC address. The MAC address does not change and is usually shown on the product label.
Device Name	The device name, if detected.

6. To refresh the information onscreen, click the **Refresh** button.

The information onscreen is updated.

Monitor and Meter Internet Traffic

Traffic metering allows you to monitor the volume of Internet traffic that passes through the modem router Internet port. With the traffic meter utility, you can set limits for traffic volume, set a monthly limit, and get a live update of traffic usage.

Start the Traffic Meter Without Traffic Volume Restrictions

You can monitor the traffic volume without setting a limit.

➤ **To start or restart the traffic meter without configuring traffic volume restrictions:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Traffic Meter**.



6. Select the **Enable Traffic Meter** check box.

By default, no traffic limit is specified and the traffic volume is not controlled.

7. In the Traffic Counter section, set the traffic counter to begin at a specific time and date.
8. If you want the traffic counter to start immediately, click the **Restart Counter Now** button.
9. Click the **Apply** button.

Your settings are saved.

The Internet Traffic Statistics section helps you to monitor the data traffic. For more information, see *[View the Traffic Statistics and Traffic Status](#)* on page 170.

View the Traffic Statistics and Traffic Status

If you enabled the traffic meter (see *[Start the Traffic Meter Without Traffic Volume Restrictions](#)* on page 169), you can view the traffic statistics and traffic status.

➤ **To view the traffic statistics and status of the traffic meter:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Traffic Meter**.

The Traffic Meter screen displays.

6. Scroll down to the Internet Traffic Statistics section.

Internet Traffic Statistics				
Start Date/Time: Mon Dec 8 00:57:00 2014 Current Date/Time: Mon Dec 8 00:58:57 2014 Traffic Volume Left: 0				
Period	Connection Time (hh:mm)	Traffic Volume (Mbytes)		
Today	0:1	0.58	3.63	4.21
Yesterday	0:0	0.00	0.00	0.00
This week	0:1	0.58/0.29	3.63/1.82	4.21/2.11
This month	0:1	0.58/0.07	3.63/0.45	4.21/0.53
Last month	0:1	0.01/0.00	0.00/0.00	0.01/0.00

Refresh **Traffic Status**

The Internet Traffic Statistics section displays when the traffic counter was started and what the traffic balance is. The table displays information about the connection time and traffic volume in MB.

7. To refresh the information onscreen, click the **Refresh** button.

The information onscreen is updated.

8. To display more information about the data traffic and to change the polling interval, click the **Traffic Status** button.

The Traffic Status pop-up screen displays.

Restrict Internet Traffic by Volume

You can record and restrict the traffic by volume in MB. This is useful when your ISP measures your traffic in volume.

➤ **To record and restrict the Internet traffic by volume:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- Click the **OK** button.

The BASIC Home screen displays.

- Select **ADVANCED > Advanced Setup > Traffic Meter**.



- Select the **Enable Traffic Meter** check box.
- Select the **Traffic volume control by** radio button.
- From the corresponding menu, select an option:
 - Download only.** The restriction is applied to incoming traffic only.
 - Both Directions.** The restriction is applied to both incoming and outgoing traffic.
- In the **Monthly Limit** field, enter how many MBytes (MB) per month are allowed.
- If your ISP charges you for extra data volume when you make a new connection, enter the extra data volume in MB in the **Round up data volume for each connection by** field.
- In the Traffic Counter section, set the traffic counter to begin at a specific time and date.
- In the Traffic Control section, enter a value in minutes to specify when the modem router issues a warning message before the monthly limit in hours is reached.

This setting is optional. The modem router issues a warning when the balance falls under the minutes that you enter. By default, the value is 0 and no warning message is issued.

- Select one or more of the following actions to occur when the limit is reached:
 - Turn the Internet LED to flashing green/amber.** This setting is optional. When the traffic limit is reached, the Internet LED blinks alternating green and amber.
 - Disconnect and disable the Internet connection.** This setting is optional. When the traffic limit is reached, the Internet connection is disconnected and disabled.

14. Click the **Apply** button.

Your settings are saved.

The Internet Traffic Statistics section helps you to monitor the data traffic. For more information, see *View the Traffic Statistics and Traffic Status* on page 170.

Restrict Internet Traffic by Connection Time

You can record and restrict the traffic by connection time. This is useful when your ISP measures your connection time.

➤ **To record and restrict the Internet traffic by time:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Traffic Meter**.



6. Select the **Enable Traffic Meter** check box.

7. Select the **Connection time control** radio button.

Note: The modem router must be connected to the Internet for you to be able to select the **Connection time control** radio button.

8. In the **Monthly Limit** field, enter how many hours per month are allowed.

Note: The modem router must be connected to the Internet for you to be able to enter information in the **Monthly Limit** field.

9. In the Traffic Counter section, set the traffic counter to begin at a specific time and date.

10. In the Traffic Control section, enter a value in minutes to specify when the modem router issues a warning message before the monthly limit in hours is reached.

This setting is optional. The modem router issues a warning when the balance falls under the minutes that you enter. By default, the value is 0 and no warning message is issued.

11. Select one or more of the following actions to occur when the limit is reached:

- **Turn the Internet LED to flashing green/amber.** This setting is optional. When the traffic limit is reached, the Internet LED alternates blinking green and amber.
- **Disconnect and disable the Internet connection.** This setting is optional. When the traffic limit is reached, the Internet connection is disconnected and disabled.

12. Click the **Apply** button.

Your settings are saved.

The Internet Traffic Statistics section helps you to monitor the data traffic. For more information, see *[View the Traffic Statistics and Traffic Status](#)* on page 170.

Unlock the Traffic Meter After the Traffic Limit Is Reached

If you configured the traffic meter to disconnect and disable the Internet connection after the traffic limit is reached, you cannot access the Internet until you unblock the traffic meter.



CAUTION:

If your ISP set a traffic limit, your ISP might charge you for the overage traffic.

➤ **To unblock the traffic meter:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Traffic Meter**.

The Traffic Meter screen displays.

6. In the Traffic Control section, clear the **Disconnect and disable the Internet connection** check box.

7. Click the **Apply** button.

Your settings are saved.

Manage the Modem Router Remotely

The remote management feature lets you access your modem router securely over the Internet to view or change its settings. You need to know the modem router's WAN IP address to use this feature. For information about remote access using Dynamic DNS, see *Manage Dynamic DNS* on page 133.

Note: Be sure to change the password for the user name admin to a secure password. The ideal password contains no dictionary words from any language and contains uppercase and lowercase letters, numbers, and symbols. It can be up to 30 characters. See *Change the admin Password and Automatic Login Time-Out Period* on page 34.

➤ **To set up remote management:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Remote Management**.



6. Select the **Turn Remote Management On** check box.
7. In the Allow Remote Access By section, specify the external IP addresses to be allowed to access the modem router's remote management:

Note: For enhanced security, restrict access to as few external IP addresses as practical.

Select one of the following radio buttons and configure the options accordingly:

- To allow access from a single IP address on the Internet, select the **Only This Computer** radio button. Enter the IP address to be allowed access.
- To allow access from a range of IP addresses on the Internet, select the **IP Address Range** radio button. Enter a beginning and ending IP address to define the allowed range.
- To allow access from any IP address on the Internet, select the **Everyone** radio button. This radio button is selected by default.

8. Specify the port number for accessing the web management interface.

The default is 8443, which is a common alternate for HTTPS. For greater security, enter a custom port number for the remote web management interface. Choose a number from 1024 to 65535, but do not use the number of any common service port.

9. Click the **Apply** button.

Your settings are saved.

➤ **To use remote access:**

1. Launch an Internet browser on a computer that is not on your home network.
2. Enter your modem router's WAN IP address into your browser's address or location field followed by a colon (:) and the custom port number.

For example, if your external address is 100.168.110.147 and you use port number 8443, enter <https://100.168.110.147:8443> in your browser.

Configure the Modem Router as a DSL Modem Only

By default, the modem router functions both as a modem and a router. You can change the operation mode to a mode in which the modem router functions as a DSL modem only with the routing, firewall, wireless support, and traffic meter features disabled.

A typical use of such a mode is when the modem router is used for DSL connectivity only behind a router, firewall, or security device manager that provides routing, firewall, wireless support, and traffic meter features.

➤ **To configure the modem router as a DSL modem only:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Device Mode**.

The Device Mode screen displays.

6. From the **Device Mode** menu, select **Modem (Modem Only)**.

7. Click the **Apply** button.

Your settings are saved. The modem router restarts.

Manage Firewall Rules, Port Forwarding, and Port Triggering

You can use outbound firewall rules, port forwarding, and port triggering to set up rules for Internet traffic for services and applications. You need networking knowledge to set up these features.

This chapter includes the following sections:

- *Manage Outbound Firewall Rules for Services and Applications*
- *Manage Port Forwarding to a Local Server for Services and Applications*
- *Manage Port Triggering for Services and Applications*

Manage Outbound Firewall Rules for Services and Applications

A firewall protects one network (the trusted network, such as your LAN) from another (the untrusted network, such as the Internet), while allowing communication between the two.

The modem router provides one default *outbound* firewall rule: It allows all access to the Internet (that is, the WAN). You can add rules to prevent access to specific services and applications on the Internet. In addition, you can specify if a rule applies to specific users on your LAN, to specific users on the Internet, or to both. You can also specify if the triggering of a firewall rule is logged.

The modem router lists many default services and applications that you can use in outbound rules. You can also add custom services and applications that you then can assign to outbound rules.

For information about blocking specific keywords, URLs, or sites, see *Use Keywords to Block Internet Sites* on page 105. This type of blocking is another aspect of the outbound firewall.

For information about *inbound* firewall rules, see the following sections:

- *Manage Port Forwarding to a Local Server for Services and Applications* on page 189
- *Manage Port Triggering for Services and Applications* on page 195

Add an Outbound Firewall Rule

You can add an outbound firewall rule to prevent access to a specific service or application on the Internet.

➤ **To add an outbound firewall rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.


3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Firewall Rules**.



6. Below the Outbound Firewall Rules table, click the **Add** button.

Service Type	Any
Action	BLOCK always
LAN Users	Any Start: 0.0.0.0 End: 0.0.0.0
WAN Servers	Any Start: 0.0.0.0 End: 0.0.0.0
Log	Never

7. Specify a new outbound rule as described in the following table.

Field	Description
Service Type	The service or application to be covered by this rule. If the service or application does not display in the list, you can add it (see Add a Custom Service or Application for Use in an Outbound Firewall Rule on page 185).
Action	<p>The action for outgoing connections covered by this rule:</p> <ul style="list-style-type: none"> • BLOCK always • BLOCK by schedule, otherwise allow • ALLOW always • ALLOW by schedule, otherwise block <p>Note: ALLOW rules are useful only if the traffic is already covered by a BLOCK rule. That is, you wish to allow a subset of traffic that is blocked by another rule.</p>

Field	Description
LAN Users	Specify which devices on your LAN (or LAN users) are affected by the rule, based on their IP address: <ul style="list-style-type: none"> • Any. All computers and devices on your LAN are covered by this rule. • Single address. Enter the required address in the Start field to apply the rule to a single device on your LAN. • Address range. Enter the required addresses in the Start and End fields to apply the rule to a range of devices.
WAN Users	Specify which Internet locations (or WAN users) are covered by the rule, based on their IP address: <ul style="list-style-type: none"> • Any. All Internet IP addresses are covered by this rule. • Single address. Enter the required address in the Start field. • Address range. Enter the required addresses the Start and End fields.
Log	Specify whether traffic that is covered by this rule is logged: <ul style="list-style-type: none"> • Never. The modem router does not log traffic that matches this rule. • Always. The modem router logs traffic that matches this rule. • Match. The modem router logs traffic that matches this rule. • Not Match. The modem router logs traffic that does not match this rule.

8. Click the **Add** button.

The new rule is added to the Outbound Firewall Rules table on the Firewall Rules screen.

Change an Outbound Firewall Rule

You can change an existing outbound firewall rule.

➤ **To change an outbound firewall rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.


The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two rules in addition to the default rule.



6. In the Outbound Firewall Rules table, select the radio button for the rule.

7. Below the Outbound Firewall Rules table, click the **Edit** button.

The Block Services Setup screen displays.

8. Change the settings.

For more information about the settings, see *Add an Outbound Firewall Rule* on page 179.

9. Click the **Accept** button.

Your settings are saved. The changed rule displays in the Outbound Firewall Rules table on the Firewall Rules screen.

Change the Priority of an Outbound Firewall Rule

Firewall rules are applied in the order in which they are listed in the modem router's outbound firewall rules table. You can change the priority of one or more rules by moving the rules up or down in the table.

➤ **To change the priority of an outbound firewall rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.


The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two rules in addition to the default rule.



6. In the Outbound Firewall Rules table, note the position of the rule and select the radio button for the rule.

The position is the number that displays next to the radio button in the Outbound Firewall Rules table.

7. Below the Outbound Firewall Rules table, click the **Move** button.

A pop-up screen displays.

8. Enter the new position and click the **OK** button.

The rules in the Outbound Firewall Rules table are reordered.

9. Click the **Apply** button.

Your settings are saved.

Disable or Enable an Outbound Firewall Rule

You can disable and enable an outbound firewall rule, which is easier than removing and redefining a rule.

➤ **To enable or disable an outbound firewall rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- Click the **OK** button.

The BASIC Home screen displays.

- Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two rules in addition to the default rule.

#	Enable	Service Type	Action	LAN Users	WAN Servers	Log
1	<input checked="" type="checkbox"/>	Real-Audio	BLOCK by schedule, otherwise Allow	all	all	Always
2	<input checked="" type="checkbox"/>	CU-SEEUME	BLOCK always	all	all	Never
Default	Yes	Any	ALLOW always	Any	Any	Never

- In the Outbound Firewall Rules table, select or clear the **Enable** check box for the rule.
- Click the **Apply** button.

Your settings are saved.

Remove an Outbound Firewall Rule

You can remove an outbound firewall rule that you no longer need.

➤ **To remove an outbound firewall rule:**

- Launch an Internet browser from a computer or WiFi device that is connected to the network.

- Type <http://www.routerlogin.net>.

A login screen displays.

- Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- Click the **OK** button.

The BASIC Home screen displays.

- Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two rules in addition to the default rule.


6. In the Outbound Firewall Rules table, select the radio button for the rule.
7. Below the Outbound Firewall Rules table, click the **Delete** button.

The rule is removed from the Outbound Firewall Rules table.


Add a Custom Service or Application for Use in an Outbound Firewall Rule

The modem router lists many default services and applications that you can use in outbound rules. If the service or application is not predefined, you can add a custom service or application that you then can assign to outbound rules.

- **To add a custom service or application for the outbound firewall:**
 1. Find out which protocol and port number or range of numbers the service or application uses.
You can usually find this information by contacting the publisher of the service or application or through online user or news groups.
 2. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 3. Type **http://www.routerlogin.net**.
A login screen displays.
 4. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
 5. Click the **OK** button.
The BASIC Home screen displays.
 6. Select **ADVANCED > Security > Firewall Rules**.



- Below the Service Table (which is empty if you did not add any custom services or applications), click the **Add Custom Service** button.



- Specify a new outbound rule as described in the following table.

Field	Description
Service Type/User Defined	Enter the name of the custom service or application.
Protocol	Select the protocol (TCP or UDP) that is associated with the service or application. If you are unsure, select TCP/UDP .
Starting Port	Enter the start port for the service or application.
Ending Port	If the service or application uses a range of ports, enter the end port for the range. If the service or application uses a single port, repeat the port number that you entered in the Starting Port field.

- Click the **Add** button.

The custom service or application is added to the Service Table on the Firewall Rules screen. You can now use the service or application in an outbound firewall rule (see [Add an Outbound Firewall Rule](#) on page 179).

Change a Custom Service or Application for Use in an Outbound Firewall Rule


You can change an existing custom service or application for use in an outbound firewall rule.

Note: You cannot change a custom service or application that is assigned to an outbound rule. You first must remove the service or application from the rule (see *Change an Outbound Firewall Rule* on page 181) or remove the rule altogether (see *Remove an Outbound Firewall Rule* on page 184).

➤ **To change a custom service or application:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two entries in the Service Table.



6. In the Service Table, select the radio button for the service or application.
7. Click the **Edit Service** button.

The Add Services screen displays.

8. Change the settings.

For more information about the settings, see *Add a Custom Service or Application for Use in an Outbound Firewall Rule* on page 185.

9. Click the **Accept** button.

Your settings are saved. The changes to the service or application display in the Service Table on the Firewall Rules screen.

Remove a Custom Service or Application for Use in an Outbound Firewall Rule

You can remove a custom service or application that you no longer want to assign to outbound firewall rules.

Note: You cannot remove a custom service or application that is assigned to an outbound rule. You first must remove the service or application from the rule (see *Change an Outbound Firewall Rule* on page 181) or remove the rule altogether (see *Remove an Outbound Firewall Rule* on page 184).

➤ **To remove a custom service or application:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Security > Firewall Rules**.

The following figure shows two entries in the Service Table.

6. In the Service Table, select the radio button for the service or application.
7. Click the **Delete Service** button.

The service or application is removed from the Service Table.

Manage Port Forwarding to a Local Server for Services and Applications

If a server is part of your network, you can allow certain types of incoming traffic to reach the server. For example, you might want to make a local web server, FTP server, or game server visible and available to the Internet.

The modem router can forward incoming traffic with specific protocols to computers on your local network. You can specify the servers for applications and you can also specify a default DMZ server to which the modem router forwards all other incoming protocols (see *Set Up a Default DMZ Server* on page 129).

Forward Incoming Traffic for a Default Service or Application

You can forward traffic for a default service or application to a computer on your network.

➤ **To forward incoming traffic for a default service or application:**

1. Decide which type of service, application, or game you want to provide.
2. Find the local IP address of the computer on your network that will provide the service. The server computer must always receive the same IP address. To specify this setting, use the reserved IP address feature. See *Manage Reserved LAN IP Addresses* on page 138.
3. Launch an Internet browser from a computer or WiFi device that is connected to the network.

- Type <http://www.routerlogin.net>.

A login screen displays.


- Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

- Click the **OK** button.

The BASIC Home screen displays.

- Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.



- Make sure that the **Port Forwarding** radio button is selected.

- From the **Service Name** menu, select the service or application.

If the service or application that you want to add is not in the list, create a port forwarding rule with a custom service or application (see *Add a Port Forwarding Rule with a Custom Service or Application* on page 191).

- In the **Server IP Address** field, enter the IP address of the computer that must provide the service or that runs the application.

- Click the **Add** button.

Your settings are saved and the rule is added to the table.

Add a Port Forwarding Rule with a Custom Service or Application

The modem router lists default services and applications that you can use in port forwarding rules. If the service or application is not predefined, you can add a port forwarding rule with a custom service or application.

➤ **To add a port forwarding rule with a custom service or application:**

1. Find out which port number or range of numbers the service or application uses.

You can usually find this information by contacting the publisher of the service or application or through user groups or news groups.

2. Launch an Internet browser from a computer or WiFi device that is connected to the network.

3. Type <http://www.routerlogin.net>.

A login screen displays.

4. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

5. Click the **OK** button.

The BASIC Home screen displays.

6. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

7. Make sure that the **Port Forwarding** radio button is selected.

8. Click the **Add Custom Service** button.

Ports - Custom Services

Service Name:

Protocol:

External Port Range: (Specify ports and port ranges split by commas, example:30, 50-60, 65500-65510)

Use the same port range for Internal port

Internal Port Range: (Specify ports and port ranges split by commas, example:30, 50-60, 65500-65510)

Internal IP address: 192 . 168 . 0 .

Or select from currently attached devices

	IP Address	Device Name
<input type="radio"/>	192.168.0.2	BusinessLaptop

9. Specify a new port forwarding rule with a custom service or application as described in the following table.

Field	Description
Service Name	Enter the name of the custom service or application.
Protocol	Select the protocol (TCP or UDP) that is associated with the service or application. If you are unsure, select TCP/UDP .
External Port Range	Enter one or more port numbers, one or more ranges of port numbers, or a combination of both. Divide ports and port ranges by commas.
Internal Port Range	Specify the internal ports by one of these methods: <ul style="list-style-type: none"> Leave the Use the same port range for Internal port check box selected. Clear the Use the same port range for Internal port check box and, in the Internal Port Range field, enter one or more port numbers, one or more ranges of port numbers, or a combination of both. Divide ports and port ranges by commas.
Internal IP address	Either enter an IP address in the Internal IP address field or select the radio button for an attached device that is listed in the table.

10. Click the **Apply** button.

Your settings are saved. The rule is added to the table on the Port Forwarding / Port Triggering screen.

11. To arrange the table entries by internal IP address, click the **Arrange by Internal IP** button.

The lowest internal IP address displays at the top and the highest at the bottom.

Change a Port Forwarding Rule

You can change an existing port forwarding rule.

➤ **To change a port forwarding rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The following figure shows two port forwarding rules.

#	Service Name	External Ports	Internal Ports	Internal IP address
1	EXPOTURBO	57900-57980	57900-57980	192.168.0.215
2	TAGSWITCHING	61235,61335,61435,61535	61236,61336,61436,61536	192.168.0.197

6. Make sure that the **Port Forwarding** radio button is selected.
7. In the table, select the radio button next to the service or application name.
8. Click the **Edit Service** button.

The Ports - Custom Services screen displays.

9. Change the settings.

For more information about the settings, see *Add a Port Forwarding Rule with a Custom Service or Application* on page 191.

10. Click the **Apply** button.

Your settings are saved. The changed rule displays in the table on the Port Forwarding / Port Triggering screen.

Remove a Port Forwarding Rule

You can remove a port forwarding rule that you no longer need.

➤ **To remove a port forwarding rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.


The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select ADVANCED > Advanced Setup > Port Forwarding / Port Triggering.

The following figure shows two port forwarding rules.



6. Make sure that the **Port Forwarding** radio button is selected.
7. In the table, select the radio button next to the service or application name.
8. Click the **Delete Service** button.

The rule is removed from the table.

Application Example: Make a Local Web Server Public

If you host a web server on your local network, you can use port forwarding to allow web requests from anyone on the Internet to reach your web server.

➤ **To make a local web server public:**

1. Assign your web server either a fixed IP address or a dynamic IP address using DHCP address reservation.

In this example, your modem router always gives your web server an IP address of 192.168.0.33.

2. On the Port Forwarding / Port Triggering screen, configure the modem router to forward the HTTP service to the local address of your web server at **192.168.0.33**.

HTTP (port 80) is the standard protocol for web servers.

3. (Optional) Register a host name with a Dynamic DNS service, and specify that name on the Dynamic DNS screen of the modem router.

Dynamic DNS makes it much easier to access a server from the Internet because you can enter the name in the Internet browser. Otherwise, you must know the IP address that the ISP assigned, which typically changes.

How the Modem Router Implements the Port Forwarding Rule

The following sequence shows the effects of a port forwarding rule:

1. When you enter the URL www.example.com in your browser, the browser sends a web page request message with the following destination information:
 - **Destination address.** The IP address of www.example.com, which is the address of your modem router.
 - **Destination port number.** 80, which is the standard port number for a web server process.
2. The modem router receives the message and finds your port forwarding rule for incoming port 80 traffic.
3. The modem router changes the destination in the message to IP address 192.168.0.123 and sends the message to that computer.
4. Your web server at IP address 192.168.0.123 receives the request and sends a reply message to your modem router.
5. Your modem router performs Network Address Translation (NAT) on the source IP address and sends the reply through the Internet to the computer or WiFi device that sent the web page request.

Manage Port Triggering for Services and Applications

Port triggering is a dynamic extension of port forwarding that is useful in these cases:

- An application must use port forwarding to more than one local computer (but not simultaneously).
- An application must open incoming ports that are different from the outgoing port.

With port triggering, the modem router monitors traffic to the Internet from an outbound “trigger” port that you specify. For outbound traffic from that port, the modem router saves the IP address of the computer that sent the traffic. The modem router temporarily opens the incoming port or ports that you specify in your rule and forwards that incoming traffic to that destination.

Port forwarding creates a static mapping of a port number or range of ports to a single local computer. Port triggering can dynamically open ports to any computer when needed and close the ports when they are no longer needed.

Note: If you use applications such as multiplayer gaming, peer-to-peer connections, real-time communications such as instant messaging, or remote assistance, enable Universal Plug and Play (UPnP). See *Improve Network Connections with Universal Plug and Play* on page 123.

Add a Port Triggering Rule

The modem router does not provide default services and applications for port triggering rules. You must define a custom service or application for each port triggering rule.

➤ **To add a port triggering rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.


4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

6. Select the **Port Triggering** radio button.



7. Click the **Add Service** button.

8. Specify a new port triggering rule with a custom service or application as described in the following table.

Field	Description
Service Name	Enter the name of the custom service or application.
Service User	From the Service User menu, select Any , or select Single address and enter the IP address of one computer: <ul style="list-style-type: none"> • Any. This is the default setting and allows any computer on the Internet to use this service. • Single address. Restricts the service to a particular computer.
Service Type	Select the protocol (TCP or UDP) that is associated with the service or application.
Triggering Port	Enter the number of the outbound traffic port that must open the inbound ports.
Inbound Connection	
Connection Type	Select the protocol (TCP or UDP) that is associated with the inbound connection. If you are unsure, select TCP/UDP .
Starting Port	Enter the start port number for the inbound connection.
Ending Port	Enter the end port number for the inbound connection.

9. Click the **Apply** button.

Your settings are saved and the rule is added to the Port Triggering Portmap Table on the Port Forwarding / Port Triggering screen.

Change a Port Triggering Rule

You can change an existing port triggering rule.

➤ **To change a port triggering rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.


The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

6. Select the **Port Triggering** radio button.

The following figure shows two port triggering rules.



7. In the Port Triggering Portmap Table, select the radio button next to the service or application name.
8. Click the **Edit Service** button.

The Port Triggering - Services screen displays.

9. Change the settings.

For more information about the settings, see [Add a Port Triggering Rule](#) on page 196.

10. Click the **Apply** button.

Your settings are saved. The changed rule displays in the Port Triggering Portmap Table on the Port Forwarding / Port Triggering screen.

Remove a Port Triggering Rule

You can remove a port triggering rule that you no longer need.

➤ **To remove a port triggering rule:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.


The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

6. Select the **Port Triggering** radio button.

The following figure shows two port triggering rules.



7. In the Port Triggering Portmap Table, select the radio button next to the service or application name.
8. Click the **Delete Service** button.

The rule is removed from the Port Triggering Portmap Table.

Specify the Time-Out Period for Port Triggering

The time-out period for port triggering controls how long the inbound ports stay open when the modem router detects no activity. A time-out period is required because the modem router cannot detect when the service or application terminates.

➤ **To specify the time-out for port triggering:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

6. Select the **Port Triggering** radio button.

The port triggering settings display.

7. In the **Port Triggering Time-out** field, enter a value up to 9999 minutes.

The default setting is 20 minutes.

8. Click the **Apply** button.

Your settings are saved.

Disable Port Triggering

By default, port triggering is enabled. You can disable port triggering temporarily without removing any port triggering rules.

➤ **To disable port triggering:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Advanced Setup > Port Forwarding / Port Triggering**.

The Port Forwarding / Port Triggering screen displays.

6. Select the **Port Triggering** radio button.

The port triggering settings display.

7. Clear the **Disable Port Triggering** check box.

If this check box is selected, the modem router does not apply port triggering rules even if you specified them.

8. Click the **Apply** button.

Your settings are saved.

Application Example: Port Triggering for Internet Relay Chat

Some application servers, such as FTP and IRC servers, send replies to multiple port numbers. Using port triggering, you can tell the modem router to open more incoming ports when a particular outgoing port starts a session.

An example is Internet Relay Chat (IRC). Your computer connects to an IRC server at destination port 6667. The IRC server not only responds to your originating source port but also sends an “identify” message to your computer on port 113. Using port triggering, you can tell the modem router, “When you initiate a session with destination port 6667, you must also allow incoming traffic on port 113 to reach the originating computer.”

The following sequence shows the effects of this port triggering rule:

1. You open an IRC client program to start a chat session on your computer.
2. Your IRC client composes a request message to an IRC server using a destination port number of 6667, the standard port number for an IRC server process. Your computer then sends this request message to your modem router.
3. Your modem router creates an entry in its internal session table describing this communication session between your computer and the IRC server. Your modem router stores the original information, performs Network Address Translation (NAT) on the source address and port, and sends this request message through the Internet to the IRC server.
4. Noting your port triggering rule and observing the destination port number of 6667, your modem router creates another session entry to send any incoming port 113 traffic to your computer.
5. The IRC server sends a return message to your modem router using the NAT-assigned source port (for example, port 33333) as the destination port and the IRC server also sends an “identify” message to your modem router with destination port 113.
6. When your modem router receives the incoming message to destination port 33333, it checks its session table to see if a session is active for port number 33333. Finding an active session, the modem router restores the original address information replaced by NAT and sends this reply message to your computer.

7. When your modem router receives the incoming message to destination port 113, it checks its session table and finds an active session for port 113 associated with your computer. The modem router replaces the message's destination IP address with your computer's IP address and forwards the message to your computer.
8. When you finish your chat session, your modem router eventually senses a period of inactivity in the communications. The modem router then removes the session information from its session table, and incoming traffic is no longer accepted on port numbers 33333 or 113.

This chapter provides information to help you diagnose and solve problems you might experience with your modem router. If you do not find the solution here, check the NETGEAR support site at <http://support.netgear.com> for product and contact information.

This chapter contains the following sections:

- *Perform Diagnostics*
- *Quick Tips for Troubleshooting*
- *Troubleshoot with the LEDs*
- *You Cannot Log In to the Modem Router*
- *Troubleshoot the Internet Connection*
- *Changes Are Not Saved*
- *Troubleshoot the WiFi Connectivity*
- *Troubleshoot Your Network Using the Ping Utility*

Perform Diagnostics

The modem router lets you perform various diagnostic tasks. For normal operation, these tasks are not required.

Ping an IP Address

Use this test to send a ping packet request to an IP address to test the connection. If the request times out because no reply is received, the destination might be unreachable. However, some network devices can be configured not to respond to a ping.

➤ **To ping an IP address:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Diagnostics**.

The Diagnostics screen displays.

6. In the **IP address or host name** field, enter an IP address or host name.

7. Click the **Ping** button.

The Diagnostics - Ping screen displays the results of the ping test.

To return to the Diagnostics screen, click the **Back** button.

Perform a DNS Lookup

Use this test to find the IP address of a web, FTP, mail, or other server on the Internet.

➤ **To look up an IP address:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Diagnostics**.

The Diagnostics screen displays.

6. In the **Internet Name** field, enter the server's host name such as www.netgear.com.

7. Click the **Lookup** button.

The results of the lookup display in the **IP address** and **DNS Server** fields.

Display the Routing Table

Displaying the modem router's internal routing table can assist you or NETGEAR technical support in diagnosing routing problems.

➤ **To display the routing table:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.

2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > Administration > Diagnostics**.

The Diagnostics screen displays.

6. Click the **Display** button.

The Diagnostics - Routing Table screen displays the routing table.

To return to the Diagnostics screen, click the **Back** button.

Reboot the Modem Router from the Web Management Interface

You or NETGEAR technical support can reboot the modem router from the web management interface, either locally or remotely, for example, when the modem router seems to be unstable or is not operating normally.

- **To reboot the modem router from the web management interface:**
 1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
 2. Type <http://www.routerlogin.net>.

A login screen displays.

 3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

 4. Click the **OK** button.

The BASIC Home screen displays.

 5. Select **ADVANCED > Administration > Diagnostics**.

The Diagnostics screen displays.

 6. Click the **Reboot** button.

The modem router reboots.

Quick Tips for Troubleshooting

The following table includes tips for troubleshooting some common problems.

Table 4. Quick tips for troubleshooting

Problem	Possible Solution
Your network is unresponsive or does not function normally.	<p>Restart your network:</p> <ol style="list-style-type: none"> 1. Turn off and unplug the DSL, cable, or fiber modem. 2. Turn off the modem router. 3. Plug in the DSL, cable, or fiber modem and turn it on. Wait two minutes. 4. Turn on the modem router and wait two minutes. <p>If network problems still occur, make sure that your ISP does not require you to use the MAC address of the computer that was used to initially register the ISP account. If your ISP does require that you do this, you must change the modem router MAC address that the modem router uses. For more information, see Manually Set Up the Internet Connection on page 45.</p>

Table 4. Quick tips for troubleshooting

Problem	Possible Solution
Your cannot connect over an Ethernet cable to the modem router.	<ul style="list-style-type: none"> • Make sure that the Ethernet cables are securely plugged in. • Make sure that your computer or device does not use a static IP address but is configured to receive an IP address automatically with DHCP. (For most devices, DHCP is the default setting.)
You cannot connect over WiFi to the modem router.	<ul style="list-style-type: none"> • Make sure that the WiFi settings in your WiFi device and modem router match exactly. For a device that is connected over WiFi, the WiFi network name (SSID) and WiFi security settings of the modem router and WiFi computer must match exactly. The default SSID and password are on the product label (see <i>Bottom Panel Product Label</i> on page 14). • Make sure that your WiFi device supports the security that you are using for your WiFi network (WEP, WPA, or WPA2). For information about WiFi security settings, see <i>Manage the Basic WiFi Settings and WiFi Security of the Main Network</i> on page 73. • Make sure that the modem router is not too far from your WiFi device or too close: <ul style="list-style-type: none"> - Move your WiFi device near the modem router but at least 6 feet (1.8 meters) away and see if the signal strength improves. - Make sure that the WiFi signal is not blocked by objects between the modem router and your WiFi device. • Make sure that the WiFi LED on the modem router is not off. If this LED is off, both WiFi radios might be disabled. For more information about the WiFi radios, see <i>Control the WiFi Radios</i> on page 88. • Make sure that the modem router's SSID broadcast is not disabled. If the modem router's SSID broadcast is disabled, the WiFi network name is hidden and does not display in your WiFi device's scanning list. To connect to a hidden network, you must enter the network name and the WiFi password. For more information about the SSID broadcast, see <i>Manage the Basic WiFi Settings and WiFi Security of the Main Network</i> on page 73. • Make sure that your WiFi device does not use a static IP address but is configured to receive an IP address automatically with DHCP. (For most devices, DHCP is the default setting.)

Troubleshoot with the LEDs

When you turn on the power, the LEDs light as described here.

1. When power is first applied, all LEDs light for about one second.
2. The Power LED lights solid amber  for about 20 seconds, turns off for about 10 seconds (no LEDs are lit), and then lights solid amber again for about 30 seconds.
3. After approximately one minute, the DSL LED blinks green  to indicate that the modem router is negotiating the best possible speed on the DSL line. If the negotiation completes and a DSL link is established, the LED turns solid green. If you do not use a DSL modem but a cable or fiber modem, the LED remains blinking.

4. About 10 seconds after the DSL LED starts blinking, the following occurs:
 - The Power LED lights solid green , indicating that the startup procedure finished.
 - The Internet LED blinks amber . If an Internet connection is established, the Internet LED lights solid green .
5. Approximately one and a half minutes after you turned on the power, the WiFi LED lights solid blue .

Power LED Remains Solid Amber

When you turn on the modem router, the Power LED turns solid amber . After about one minute and 10 seconds, the Power LED lights solid green , indicating that the startup procedure finished. If the LED does not turn green, a power-on self-test (POST) failure occurred or the modem router is malfunctioning.

If the Power LED does not turn green, do the following:

1. Turn off the power and back on to see if the modem router recovers.
2. If the Power LED still does not turn green, reset the modem router to factory default settings.

For more information, see *Use the Reset Button* on page 153.

If the error persists, a hardware problem might exist. For recovery instructions or help with a hardware problem, contact technical support at www.netgear.com/support.

Power LED Is Off

If the Power LED  and other LEDs remain off when you turn on the modem router, do the following:

- Check that the **Power On/Off** button on the back is in the on position, that is, it is pushed in.
- Check that the power cord is correctly connected to your modem router and that the power supply adapter is correctly connected to a functioning power outlet.
- Check that you are using the 12 VDC 1.5A power adapter that NETGEAR supplied for this product.

If the error persists, a hardware problem might exist. For recovery instructions or help with a hardware problem, contact technical support at www.netgear.com/support.

WiFi LED Is Off

If the WiFi LED stays off , check to see if both radios on the modem router are disabled (see *Control the WiFi Radios* on page 88). By default, both radios are enabled and the WiFi LED lights solid blue.

You Cannot Log In to the Modem Router

If you are unable to log in to the modem router from a computer on your local network and use the web management interface, check the following:

- If you are using an Ethernet-connected computer, check the Ethernet connection between the computer and the modem router.
- If the computer is set to a static or fixed IP address (this setting is uncommon), either change the computer to obtain an IP address automatically from the modem router through DHCP, or change the IP address of the computer to a static or fixed IP address in the 192.168.0.2–192.168.0.254 range.
- Make sure that your computer can reach the modem router’s DHCP server. Recent versions of Windows and Mac OS generate and assign an IP address if the computer cannot reach a DHCP server. These autogenerated addresses are in the range of 169.254.x.x. If your IP address is in this range, check the connection from the computer to the modem router and reboot your computer.
- If your modem router’s IP address was changed and you do not know the current IP address, use an IP scanner application to detect the IP address. If you still cannot find the IP address, clear the modem router’s configuration to factory defaults. This sets the modem router’s IP address to 192.168.0.1. For more information, see *Return the Modem Router to Its Factory Default Settings* on page 153 and *Factory Settings* on page 218.
- Make sure that Java, JavaScript, or ActiveX is enabled in your browser. If you are using Internet Explorer, click the **Refresh** button to be sure that the Java applet is loaded.
- Try quitting the browser and launching it again.
- Make sure that you are using the correct login information. The user name is **admin**, and the default password is **password**. Make sure that Caps Lock is off when you enter this information.
- If you are attempting to set up your modem router behind an existing router in your network, set up the modem router as a WiFi access point (see *Use the Modem Router as a WiFi Access Point* on page 95).
- If you are attempting to set up your modem router as a replacement for an ADSL gateway in your network, the modem router cannot perform many gateway services. For example, the modem router cannot convert ADSL or cable data into Ethernet networking information. NETGEAR does not support such a configuration.

Troubleshoot the Internet Connection

If your modem router cannot access the Internet, check the DSL connection, then the WAN TCP/IP connection.

Troubleshoot the DSL Link

If your modem router is unable to access the Internet, first determine whether the DSL link with the service provider is working. The DSL LED indicates the state of this connection.

DSL LED Is Green

If the DSL link LED lights green  , the ADSL connection is good. You can be confident that the service provider connected your line correctly and that your wiring is correct.

DSL LED Is Blinking Green

If the DSL LED is blinking green  , your modem router is attempting to make an ADSL connection with the service provider. If the modem router establishes an ADSL connection, the DSL LED turns solid green. This connection process generally lasts several minutes.

If the DSL LED does not turn solid green, disconnect all telephones on the line. If this solves the problem, reconnect the telephones one at a time, being sure to use a microfilter on each telephone. If the microfilters are connected correctly, you can connect all your telephones.

If disconnecting telephones does not result in a green DSL LED, a problem with your wiring might exist. If the telephone company tested the ADSL signal at your network interface device (NID), then wiring in your house might be of poor quality.

DSL LED Is Off or Internet LED Is Off

If the DSL LED is off  , the Internet LED is off  , or both are off, disconnect all telephones on the line. If this solves the problem, reconnect the telephones one at a time, being sure to use a microfilter on each telephone. If the microfilters are connected correctly, you can connect all your telephones.

If disconnecting telephones does not result in a green DSL LED, check the following:

- Check that the telephone company made the connection to your line and tested it.
- Verify that you are connected to the correct telephone line. If more than one phone line is installed, be sure that you are connected to the line with the ADSL service. It might be necessary to use a swapper if your ADSL signal is on pins 1 and 4 or the RJ-11 jack. The modem router uses pins 2 and 3.

Internet LED Is Off

If the Internet LED is off , the modem router cannot connect to the Internet. Verify the following:

- Check that your login credentials are correct or that the information you entered for the ISP connection is correct (see *Manually Set Up the Internet Connection* on page 45).
- Check if your ISP is experiencing a problem—it might not be that the modem router cannot connect to the Internet, but rather that your ISP cannot provide an Internet connection.

Obtain an Internet IP Address

If the modem router cannot access the Internet but the Internet LED is green , see if the modem router can obtain an Internet IP address from the ISP. Unless the modem router is assigned a static IP address, the modem router requests an IP address from the ISP. You can determine whether the request was successful using the web management interface.

➤ **To check the Internet IP address:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type **http://www.routerlogin.net**.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, check that the IP Address field shows a valid IP address.

If the field shows 0.0.0.0, your modem router did not obtain an IP address from your ISP.

If your modem router cannot obtain an IP address from the ISP, the problem might be one of the following:

- Your Internet service provider (ISP) might require a login program. Ask your ISP whether they require PPP over Ethernet (PPPoE) or some other type of login.
- If you selected a login program, the service name, user name, or password might be incorrectly set.

For more information, see *Troubleshoot PPPoE or PPPoA* on page 212.

- Your ISP might check for your computer's host name. Assign the computer host name of your ISP account as the account name. For more information, see *Manually Set Up the Internet Connection* on page 45.
- If your ISP allows only one Ethernet MAC address to connect to Internet and checks for your computer's MAC address, do one of the following:
 - Inform your ISP that you bought a new network device and ask them to use the modem router's MAC address.
 - Configure your modem router to clone your computer's MAC address. For more information, see *Manually Set Up the Internet Connection* on page 45.

Troubleshoot PPPoE or PPPoA

If you use a PPPoE or PPPoA connection to your ISP, make sure that the connection works.

➤ **To verify that your PPPoE or PPPoA connection is working:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.
A login screen displays.
3. Enter the user name and password for the modem router.
The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.
4. Click the **OK** button.
The BASIC Home screen displays.
5. Select **ADVANCED > ADVANCED Home**.
The ADVANCED Home screen displays.
6. In the Internet Port pane, check that the IP Address field shows a valid IP address and that the Connection field shows PPPoE or PPPoA.
7. In the Internet Port pane, click the **Connection Status** button.
The Connection Status screen displays.
8. Check the following:
 - The Connection Status field shows Connected.
 - The Connection Time field does not show 00:00:00.

If all of the information is correct, your PPPoE or PPPoA connection is working.

➤ **To reconnect if your PPPoE or PPPoA connection does not function:**

1. Launch an Internet browser from a computer or WiFi device that is connected to the network.
2. Type <http://www.routerlogin.net>.

A login screen displays.

3. Enter the user name and password for the modem router.

The user name is **admin**. The default password is **password**. The user name and password are case-sensitive.

4. Click the **OK** button.

The BASIC Home screen displays.

5. Select **ADVANCED > ADVANCED Home**.

The ADVANCED Home screen displays.

6. In the Internet Port pane, click the **Connection Status** button.

The Connection Status screen displays.

7. Click the **Connect** button.

The modem router attempts to reconnect.

If you cannot connect after several minutes, you might be using an incorrect service name, user name, or password. Or your ISP might not be able to provide an Internet connection.

Unless you connect manually, the modem router does not authenticate using PPPoE or PPPoA until data is transmitted to the network.

Troubleshoot Internet Browsing

If your modem router can obtain an IP address but your computer is unable to load any web pages from the Internet, it might be for one of the following reasons:

- The traffic meter is enabled, and the limit was reached.

By configuring the traffic meter not to block Internet access when the traffic limit is reached, you can resume Internet access (see *Unblock the Traffic Meter After the Traffic Limit Is Reached* on page 174). If your ISP sets a usage limit, they might charge you for the overage.

- Your computer might not recognize any DNS server addresses.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP provides the addresses of one or two DNS servers for your use. If you entered a DNS address when you set up the modem router, reboot your computer and verify the DNS address. Alternatively, you can configure your computer manually with DNS addresses, as explained in your operating system documentation.

- The modem router might not be configured as the TCP/IP router on your computer.

For information about TCP/IP problems, see *Troubleshoot Your Network Using the Ping Utility* on page 215.

If your computer obtains its information from the modem router by DHCP, reboot the computer and verify the modem router address.

Changes Are Not Saved

If the modem router does not save the changes that you make in the web management interface, do the following:

- When entering configuration settings, always click the **Apply** button before moving to another screen or tab or your changes are lost.
- Click the **Refresh** or **Reload** button in the web browser. It is possible that the changes occurred but that the old settings remain in the web browser's cache.

Troubleshoot the WiFi Connectivity

If you are experiencing trouble connecting over WiFi to the modem router, try to isolate the problem:

- Make sure that the WiFi settings in your WiFi device and modem router match exactly. For a device that is connected over WiFi, the WiFi network name (SSID) and WiFi security settings of the modem router and WiFi computer must match exactly. The default SSID and password are on the product label (see *Bottom Panel Product Label* on page 14).
- Does the WiFi device that you are using find your WiFi network? If not, check the WiFi LED on the front of the modem router. If this LED is off, both WiFi radios might be disabled. For more information about the WiFi radios, see *Control the WiFi Radios* on page 88.
- If you disabled the modem router's SSID broadcast, your WiFi network is hidden and does not display in your WiFi client's scanning list. (By default, SSID broadcast is enabled.) For more information, see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73.
- Does your WiFi device support the security that you are using for your WiFi network (WEP, WPA, or WPA2)? For information about changing the WiFi security, see *Manage the Basic WiFi Settings and WiFi Security of the Main Network* on page 73.

Tip: If you want to change the WiFi settings of the modem router's main network, use a wired connection to avoid being disconnected when the new WiFi settings take effect.

If your WiFi device finds your network but the signal strength is weak, check these conditions:

- Is your modem router too far from your WiFi device or too close? Place your WiFi device near the modem router but at least 6 feet (1.8 meters) away and see whether the signal strength improves.
- Are objects between the modem router and your WiFi device blocking the WiFi signal?

Troubleshoot Your Network Using the Ping Utility

Most network devices and routers contain a ping utility that sends an echo request packet to the designated device. The device then responds with an echo reply. You can easily troubleshoot a network using the ping utility in your computer or workstation.

Test the LAN Path to Your Modem Router

You can ping the modem router from your computer to verify that the LAN path to your modem router is set up correctly.

- **To ping the modem router from a Windows computer:**
 1. From the Windows taskbar, click the **Start** button and select **Run**.
 2. In the field provided, enter **ping** followed by the IP address of the modem router, as in this example:
ping 192.168.0.1
 3. Click the **OK** button.

A message such as the following one displays:

Pinging <IP address> with 32 bytes of data

If the path is working, you see this message:

Reply from < IP address >: bytes=32 time=NN ms TTL=xxx

If the path is not working, you see this message:

Request timed out

If the path is not functioning correctly, one of the following problems might be occurring:

- Wrong physical connections

For a wired connection, make sure that the numbered LAN port LED is lit for the port to which you are connected.

Check that the appropriate LEDs are on for your network devices. If your modem router and computer are connected to a separate Ethernet switch, make sure that the link LEDs are lit for the switch ports that are connected to your computer and modem router.

- Wrong network configuration

Verify that the Ethernet card driver software and TCP/IP software are both installed and configured on your computer.

Verify that the IP address for your modem router and your computer are correct and that the addresses are on the same subnet.

Test the Path from Your Computer to a Remote Device

After you verify that the LAN path works correctly, test the path from your computer to a remote device:

1. From the Windows toolbar, click the **Start** button and select **Run**.
2. In the field provided, enter

```
ping -n 10 IP address
```

where *IP address* is the IP address of a remote device such as your ISP's DNS server.

If the path is functioning correctly, replies as described in *Test the LAN Path to Your Modem Router* on page 215 display. If you do not receive replies, do the following:

- Check that the IP address of your modem router is listed as the default router in your computer. If the IP configuration of your computer is assigned by DHCP, this information is not visible in your computer's Network Control Panel. Verify that the IP address of the modem router is listed as the default router.
- Check that the network address of your computer (the portion of the IP address specified by the netmask) is different from the network address of the remote device.
- If your ISP assigned a host name to your computer, enter that host name as the account name (see *Manually Set Up the Internet Connection* on page 45).
- Your ISP might be rejecting the Ethernet MAC addresses of all but one of your computers.

Many broadband ISPs restrict access by allowing traffic only from the MAC address of your modem, but some additionally restrict access to the MAC address of a single computer connected to that modem. In this case, configure your modem router to clone or spoof the MAC address from the authorized computer (see *Manually Set Up the Internet Connection* on page 45).

Supplemental Information

A

This appendix covers the following topics:

- *Factory Settings*
- *Technical Specifications*

Factory Settings

You can reset the modem router to the factory default settings that are shown in the following table.

For more information about resetting the modem router to its factory settings, see *[Return the Modem Router to Its Factory Default Settings](#)* on page 153.

Table 5. D6100 modem router factory default settings

Feature	Default Behavior
Router login	
User login URL	www.routerlogin.net (or www.routerlogin.com or 192.168.0.1)
User name (case-sensitive)	admin
Login password (case-sensitive)	password
Internet connection	
WAN MAC address	Use default hardware address
WAN MTU size	1500
Port speed	Autosensing
Local network (LAN)	
LAN IP address	192.168.0.1
Subnet mask	255.255.255.0
DHCP server	Enabled
DHCP range	192.168.0.2 to 192.168.0.254
DHCP starting IP address	192.168.0.2
DHCP ending IP address	192.168.0.254
DMZ	Disabled
Time zone	<ul style="list-style-type: none"> North America: Pacific Standard Time Europe: GMT Other continents: Varies by region
Time adjusted for daylight saving time	Disabled
Main WiFi network	
WiFi communication	Enabled
SSID name	See product label
Security	WPA2-PSK (AES)
WiFi network key (passphrase)	See product label

Table 5. D6100 modem router factory default settings (continued)

Feature	Default Behavior
Country/region	<ul style="list-style-type: none"> North America: United States Europe: Europe Other continents: Varies by region
RF channel	Auto. The available channels depend on the region.
Transmission speed	Auto ¹
Operating mode	<ul style="list-style-type: none"> Up to 300 Mbps at 2.4 GHz Up to 867 Mbps at 5 GHz
Transmit power	100%
Video network on the 5 GHz band	Disabled
Guest WiFi network	
WiFi communication	Disabled
SSID name	<ul style="list-style-type: none"> 2.4 GHz band: NETGEAR_Guest 5 GHz band: NETGEAR-5G_Guest
Security	None (open network)
Allow guests to access main network	Disabled
Video network on the 5 GHz band	Disabled
General WiFi settings	
Radio transmission power	100 percent
20/40 MHz coexistence	Enabled
Fragmentation length	2346
CTS/RTS threshold	2347
Preamble mode	Automatic

1. Maximum WiFi signal rate derived from IEEE Standard 802.11 specifications. Actual throughput can vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, and network overhead, lower actual data throughput rate.

Technical Specifications

Table 6. D6100 modem router specifications

Feature	Description
Data and routing protocols	TCP/IP, RIP-1, RIP-2, DHCP, PPPoE, PPTP, Bigpond, Dynamic DNS, UPnP, and SMB
Power adapter	<ul style="list-style-type: none"> North America: 120V, 60 Hz, input UK, Australia: 240V, 50 Hz, input Europe: 230V, 50 Hz, input All regions: 12V @ 1.5 A output
Dimensions	Dimensions: 179 mm x 167 mm x 59 mm (7.0 in. x 6.6 in. x 2.3 in.)
Weight	Weight: 362 g (0.8 lb)
Operating temperature	0° to 40°C (32° to 104°F)
Operating humidity	90% maximum relative humidity, noncondensing
Electromagnetic emissions	<ul style="list-style-type: none"> EN 55022:2010/AC:2011, Class B CISPR 22:2008, Class B AS/NZS CISPR 22:2009/Amdt 1:2010, Class B
LAN	Two RJ-45 ports supporting 10BASE-T, 100BASE-TX, and 1000BASE-T
WAN	One RJ-45 port supporting 10BASE-T, 100BASE-TX, and 1000BASE-T
ADSL	One RJ-11 asynchronous DSL (ADSL) port
WiFi	Maximum WiFi signal rate complies with the IEEE 802.11 standard. See the footnote for the table in <i>Factory Settings</i> on page 218.
Radio data rates	Auto-rate sensing
Data encoding standards	<ul style="list-style-type: none"> IEEE 802.11ac 2.0 IEEE 802.11n version 2.0 IEEE 802.11n 256QAM IEEE 802.11g, IEEE 802.11b 2.4 GHz IEEE 802.11n, IEEE 802.11a 5.0 GHz
Maximum computers per WiFi network	Limited by the amount of WiFi network traffic generated by each node (typically 50–70 nodes).

Table 6. D6100 modem router specifications (continued)

Feature	Description
Operating frequency range	<ul style="list-style-type: none"> • 2.4 GHz band <ul style="list-style-type: none"> - US: 2.412–2.462 GHz - Europe: 2.412–2.472 GHz - Australia: 2.412–2.472 GHz - Japan: 2.412–2.472 GHz • 5 GHz band <ul style="list-style-type: none"> - US: 5.18–5.24 + 5.745–5.825 GHz and DFS (5.25–5.35 + 5.50–5.70) - Europe: 5.18–5.24 GHz and DFS (5.25–5.35 + 5.50–5.70) - Australia: 5.18–5.24 + 5.745–5.825 GHz and DFS (5.25–5.35 + 5.50–5.70) - Japan: 5.18–5.24 GHz and DFS (5.25–5.35 + 5.50–5.70)
802.11 security	WPA2-PSK, WPA/WPA2, WPA/WPA2 Enterprise, and WEP