



Clear and Simple Quick Start Guide

ZTE Fanfare 2




Getting to know your ZTE Fanfare™ 2



*To exchange the positions of the Back key and Recent apps key, tap > > **Settings** > **Navigation key** and select an option.

Phone setup

- Place your finger in the slot at the bottom of the back cover to lift and remove the cover.
- Hold the micro-SIM card with the cut corner as shown and slide it into the card slot.
- Insert a microSDHC™ card with gold-colored contacts facing down.
- Align the back cover with the back of the phone and press the cover into place. Ensure that all the tabs are secure and there are no gaps around the cover.




WARNING! To avoid damage to the phone, do not use any other kind of SIM card or any non-standard micro-SIM card cut from a SIM card. You can get a standard micro-SIM card from your service provider.

Touch screen

Navigating your phone

- Press and hold the screen to unlock.
- Use your fingertip to lightly touch the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or a Gallery image.
- To return to the previous screen, tap the **Back key**.
- Tap the **Home key** at any time to return to the main home screen. Press and hold the **Home key** to access Google Now™.
- Tap the **Recent apps key** to access recently viewed apps.
- Tap **Apps** to access applications on your phone.



Notifications panel

- Tap the top of the screen and drag your finger down to see the Notifications panel.
- Tap to expand the quick settings menu.
- Tap to turn Battery Saver on.
- Tap to access the settings menu.
- Tap to change position of icons on the Notifications panel.
- Swipe right or left to clear individual notifications or tap to clear all.

Personalize

Set wallpaper


- To change your home screen wallpaper, press and hold a blank part of the home screen and tap **Wallpapers**.
- Tap a wallpaper to set it. You can also tap image **GALLERY** or **LIVE WALLPAPER** for additional options.

Add to home screen

- Tap **Apps** , press and hold the desired app, and drag it to the home screen.
- Press and hold a blank part of the screen and tap **Widgets**. Press and hold the desired widget and drag it to the home screen.
- Press and hold a blank part of the screen and then tap **Themes** or **Effects** to change the theme or home screen transition effect.

Organize home screens

- To move an icon, press and hold it and drag it to a new location. To delete it, drag it to **Remove** .
- Press and hold an icon and drag it to **Folder** . To keep your stuff together just how you like, drag additional icons to add them to an existing folder.
- To rename a folder, tap it, and then tap the folder name. Enter a name and then tap **Done**.



Calls and voicemail

Make a call

- From the home screen, tap **Phone** .
- Type the name or phone number of a contact in the search box at the top of the screen. Or, tap and enter a phone number. Tap the matching contact or tap to place the call.


Check voicemail

- From the home screen, tap **Phone** , then tap .
- Press and hold the **1 key** .

Use call waiting

- Call waiting helps you answer or hold a call while you are on an existing call.
- While on a call, you will hear a tone if another call comes in. Tap **Hold current and answer**.
 - Tap to merge calls or tap to switch between active calls.

Note: To access Call Settings, tap **Menu** from the dialer screen.



More information

On the web

Detailed support information, including device specifications and troubleshooting, is available at www.cricketwireless.com/support/devices.

On the phone

- Call Customer Care at **1-855-246-2461** or
- Dial **611** from your cell phone.

Accessories

For more information concerning accessories, please visit your local Cricket store location or go to www.cricketwireless.com/shop/accessories.



Note: Store and online inventories may vary.

Product meets FCC Radio Frequency Exposure Guidelines—FCC ID SRQ-Z815. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2016 Cricket Wireless LLC. All rights reserved. Cricket and the Cricket logo are registered trademarks under license to Cricket Wireless LLC. Other marks are the property of their respective owners. microSDHC™ logo is a trademark of SD-3C, LLC. The Bluetooth™ word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories. Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission.

© 2016 ZTE CORPORATION. All rights reserved. No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation. The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.




XXXXXXXXXX

Printed in USA

Text and picture messaging


Send a text message

- From the home screen, tap **Messaging** .
- Tap **New message** to start a new text message.
- In the **To** field, enter a number or a contact name or tap **Contacts** to access your contacts.
- Tap the **Type message** field and enter your message.
- Tap **Send** to send the message.



Send a picture message



- Follow steps 1-4 above.
- Tap the **Paperclip** .
- Tap **Picture** and select desired picture.
- Tap **Send** to send the message.



Email

Email setup (Gmail™, Yahoo!®, etc.)

- From the home screen, tap **Apps** > **Email** .
- Select an account type, enter your email address and password, and then tap **Next**.
- Confirm email account settings and tap **Next**.
- Name the account, enter your name as it will appear on outgoing messages, and tap **Next**. Your email will begin to synchronize with your phone.



Note: To set up corporate email, contact your IT administrator.

Create and send an email message

- From the home screen, tap **Apps** > **Email** .
- To compose a new message, tap **Compose** .
- Tap the **To** field and enter email address or name, or tap **Contacts** to access your contacts.
- Enter a subject and email message.
- To attach files to the email message, tap **Menu** , then tap **Attach file** and make your selection.
- Tap **Send** to send the message.

Value-added services

Cricket Services

These services make using Cricket even better and easier.

My Cricket: Access billing, make a quick payment, view usage and access support from the palm of your hand.

Cricket Wi-Fi Manager: Helps you save your high-speed data by seeking out free and open Wi-Fi™ hotspots whenever you're near them. Also remembers your favorite Wi-Fi hotspots and connects you automatically. Cricket does the searching so you can do the saving.

Visual Voicemail: Quickly view, access and play back your voicemail messages. Easily save important numbers to your Favorites list and respond to messages by calling back or texting.

Deezer: Listen on-the-go with ad-free streaming music, download your favorites to your phone, and get customized playlists based on your preferences.

Additional Value-Added Services

Selfie: Take selfies quickly and easily. Access the front-facing camera from the lock screen or from the Apps menu to capture the moment instantly without switching between camera modes.

AskMD: Get personalized health consultation that helps identify what's bothering you and organizes your health information, enabling you to have a more effective doctor's visit.

Apps on Google Play™

The Fanfare 2 is preloaded with great apps to take your experience to the next level. To find additional apps to make your phone experience even better, check out Google Play.


Access Google Play

- From the home screen, tap **Play Store** .
- Enter your existing Google account or create one following the steps on the screen.

Navigate Google Play

From Play Store, you will have multiple ways to search for apps, games, and more.

- Tap a category to browse popular apps, games, movies, and music organized by popularity or category.
- Tap **Search** to search the Play Store for a specific game or app.
- To install, tap the app and follow instructions. Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating the app in **Apps** .



Camera and video

With the Fanfare 2 choose from 3 different modes (manual, auto, and fun) to satisfy every type of photographer!

Take a picture

- From the home screen, tap **Camera** .
- Zoom in and out by pinching with your fingers or by using the **Volume key**.
- Tap the **Shutter button** to take a photo.
- Tap > **CAMERA** to adjust your camera settings.




Take a video

- In camera mode, tap **Start recording** to start, tap **Pause recording** to pause, tap **Resume recording** to resume, and tap **Stop recording** to stop recording video.
- Tap > **VIDEO** to adjust your camcorder settings.



Share a picture or video

- From the home screen, tap **Apps** > **Gallery** .
- Tap an album and then tap a photo or video.
- Tap and select an option for sharing.



Note: A payment method, such as Google Wallet™, is required to purchase apps.

Note: See user manual for additional photo features and settings.