



Your **definitive** source
for quality pre-owned
equipment.

Artisan Technology Group

(217) 352-9330 | sales@artisanTG.com | artisanTG.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Digital Lightwave NIC 10G* at our website: [Click HERE](#)

SCPI COMMAND REFERENCE GUIDE (NIC and NAA IV)

MARCH 2003
(Rel 3.2)

Document No. CO 004383F



15550 Lightwave Drive • Clearwater, Florida 33760 • United States
T: 727.442.6677 • F: 727.442.5660 • Toll Free: 800.548.9283 or 877.275.3445
info@lightwave.com • <http://www.lightwave.com>

Copyright	<p>Copyright © 2001-2003 Digital Lightwave[®], Inc. All rights reserved.</p> <p>This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose. For conditions of use and permission to use these materials for publication in other than the English language, contact Digital Lightwave, Inc.</p> <p>Digital Lightwave, Inc. reserves the right to revise and improve its product as it sees fit. This publication describes the state of this product at the time of its publication and may not represent the product at all times in the future.</p>
Patent Information	<p>The Network Information Computer[®] (NIC[®]) and Network Access Agent[®] (NAA[®]) described in this publication may be protected by one or more patents on file with the United States Patent Office.</p>
Trademarks	<p>Digital Lightwave; the rectangular logo; Technology to Reach Inside the Light; Network Information Computer; NIC; ASA 312; AnyBit; and Anytime, Anywhere, AnyBit are registered trademarks of Digital Lightwave, Inc. in the United States and/or other countries. Lightwave Management, Network Access Agent, Network Protocol Processor, NIC 2.5G, NIC 10G, NIC 622M, NIC GigE, NIC ONA, NIC Plus, DCA 425, NAA and NPP are trademarks of Digital Lightwave, Inc. for which application has been made.</p>
Technical Support	<p>Technical Support is available by calling toll free (in the US) 1.877.929.HELP (4357) 24 hours/day 7 days/week. Outside of the US, call 727.519.2860.</p>
Return Shipping Instructions	<p>If it is necessary to return the unit, obtain a Return Material Authorization (RMA) number and Return Shipping Address by contacting Technical Support between 8:00 a.m. and 6:30 p.m. EST, Monday through Friday.</p> <p>Please enclose a letter that briefly describes the reason for returning the unit and include the following information:</p> <ul style="list-style-type: none"> • Unit Serial Number • Customer Name and Shipping Address • Customer Contact Name and Telephone Number • Secondary Customer Contact Name and Telephone Number • Customer Supplied Purchase Order Number (if applicable)

If the original shipping container (box) is available, place the unit (and letter that describes the reason for the return) into the canvas carry bag, and pack it into the original Digital Lightwave, Inc. shipping container. **Do not include personal items such as jumper cords or connectors. Digital Lightwave, Inc. will not be responsible for these items.** Use the original foam inserts to protect all six sides of the unit.

Securely seal the shipping container, and mark **FRAGILE** on the container to ensure careful handling.

Include the **RMA number** on the outside of the shipping container.

If the original shipping container is not available, pack the unit (and letter that describes the reason for the return) into the canvas carry bag, and use the following general instructions to repack the unit using commercially available materials:

- Use a strong shipping container, similar to the original unit shipping box. Verify that the substitute container is rated at **350 lbs. per square inch** pressure durable.
- Make sure that the unit is satisfactorily protected by using a layer of ESD Protected short absorbing foam material. The foam padding must be 3- to 4-inches in thickness (70- to 100-mm) and applied to all six sides of the unit to provide adequate protection. Make sure that the canvas bag and unit cannot move or shift within the container.
- Securely seal the shipping container, and mark **FRAGILE** on the container to ensure careful handling.
- Include the **RMA number** on the outside of the shipping container.

Contact Technical Support for the Repair Department's Return Shipping Address.

When service is complete, your unit will be returned to you postage paid if the shipment is within the United States. You are responsible for paying all shipping charges, duties, taxes, and other charges for products returned to Digital Lightwave, Inc. from any location within or outside of the United States.

Safety Guidelines for Portable Products

The following safety precautions are provided to avoid injury and prevent damage to this product or any products connected to it during normal operation. Only qualified maintenance personnel should perform service procedures.

Use Proper Power Cord: To avoid fire hazard, only use the power cord specified for this instrument. For use in North America, use a power cord (maximum 6-foot length) with a type SJT, 18 AWG, two conductor with ground, IEC 320 connector on one end and a NEMA 5-15 connector on the other end.

For use outside of North America, use an HO5VV-F power cord with a 1-mm², two conductor plus ground, IEC 320 connector on one end, and a wall-socket plug on the other end that is certified for use in the country of installation.

NOTE | ►

The entire cordset must be certified for use in the country of installation. ◀

Avoid Electric Overload: This unit is designed to be powered from 100–120 and 200–240 VAC, 50–60 Hz.

Ground the Instrument: The unit is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the instrument, ensure that the product is properly grounded.

Do Not Operate in Hazardous Conditions: To avoid injury or fire hazard, do not operate this instrument in wet, damp, or other hazardous conditions. Do not operate this instrument in an explosive atmosphere. This instrument is not intended for outdoor use.

Eye Protection: Users should never stare into unterminated connectors or broken fibers. In addition, fiber cables and interfaces should always be handled as if they were emitting laser light. Always leave protective covers on optical connectors to prevent damage and prevent laser emissions.

Field Service: This equipment is not intended to be serviced in the field. All service is intended to be completed by Digital Lightwave, Inc.

WARNING

This is a class A product per EN55022. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. ◀

Sicherheitshinweise Zur Vermeidung von Verletzungen und Beschädigungen dieses Produktes oder angeschlossener Geräte während des normalen Betriebs sollten die folgenden Sicherheitshinweise beachtet werden. Reparaturarbeiten dürfen nur von qualifizierten Fachkräften durchgeführt werden.

Richtiges Stromkabel verwenden: Zur Vermeidung einer Brandgefahr sollte ausschließlich das für dieses Instrument vorgegebene Stromkabel verwendet werden. Spezifikationen für Nordamerika: Stromkabel (maximale Länge 1,82 m) der Bauart SJT, 3-adrig, Größe 18 AWG (zwei Leiter, ein Schutzleiter) sowie einem IEC 320-Steckverbinder an einem Ende und einem NEMA 5-15-Steckverbinder am anderen Ende.

Spezifikationen für Länder außerhalb der USA: Stromkabel der Bauart HO5VV-F, 3-adrig (zwei Leiter, ein Schutzleiter, 1 mm²) sowie einem IEC 320-Steckverbinder an einem Ende und einem für die Verwendung in dem jeweiligen Land zugelassenen Netzstecker am anderen Ende.

Hinweis:

Der gesamte Kabelsatz muss für die Verwendung im jeweiligen Land zugelassen bzw. zertifiziert sein. ◀

Elektrische Überlastungen vermeiden. Dieses Gerät ist für eine Stromversorgung von 100–120 und 200–240 VAC, 50–60 Hz ausgeführt. Zur Vermeidung von elektrischen Schlägen, Brandgefahr und Beschädigungen des Instruments darf keine höhere Spannung angelegt werden.

Das Instrument muss geerdet werden. Das Gerät ist durch den Schutzleiter des Stromkabels geerdet. Zur Vermeidung von elektrischen Schlägen muss der Schutzleiter mit der Erdung verbunden sein. Vor dem Anschluss an den Ein- oder Ausgangsklemmen des Instruments muss sichergestellt werden, dass das Produkt richtig geerdet ist.

Das Gerät darf nicht unter gefährlichen Bedingungen eingesetzt werden. Zur Vermeidung von Verletzungen oder Brandgefahr das Gerät nicht in nasser, feuchter oder anderweitig gefährlicher Umgebung betreiben. Das Gerät nicht in explosionsgefährdeten Bereichen verwenden.

Augen schützen. Benutzer sollten niemals in abgetrennte Steckverbinder oder getrennte LWL-Kabel blicken. Bei LWL-Kabeln und Anschlüssen sollte als Vorsichtsmaßnahme stets angenommen werden, dass sie Laserlicht ausstrahlen. Die LWL-Anschlüsse sollten immer mit den Schutzabdeckungen verschlossen gehalten werden, um Beschädigungen und

Laserausstrahlungen zu vermeiden.

Kundenseitige Reparaturen: Dieses Gerät darf nicht kundenseitig repariert werden. Alle Reparaturarbeiten müssen von Digital Lightwave, Inc. durchgeführt werden.

Warnung:

Dieses ist ein Gerät der Klasse A nach EN55022. In einem Wohngebiet kann dieses Gerät Funkstörungen verursachen. In diesem Fall muss der Benutzer entsprechende Abhilfemaßnahmen unternehmen. Die verwendeten Kabel dürfen nicht länger als 3 m sein, um die Anforderungen der EMV-Richtlinien zu erfüllen. ◀


Umweltschutz: Dieses Produkt kann bleihaltiges Lötmaterial und eine Lithiumbatterie für die Computerunterstützung enthalten. Senden Sie bitte alle Digital Lightwave Produkte zur vorschriftsmäßigen Entsorgung an das Werk zurück. Der Betrieb dieses Produktes hat keine schädlichen Auswirkungen auf die Umwelt.

Lasersicherheit: Dieses Produkt enthält Lasergeräte der Klasse 1 (21 CFR 1040.10 und 1040.11 konform; EN60825-1: 1993 +A11+A2). Niemals in das abgetrennte LWL-Kabel blicken. Wenn das LWL-Kabel nicht an den LWL-Anschlüssen angeschlossen ist, sollten immer die Staubschutzkappen auf den LWL-Anschlussöffnungen angebracht sein. CDRH-Zugriffszahl: 0021615.

Laserprodukt der Klasse 1

HINWEIS

Nicht angeschlossene LWL-Verbinder können Laserstrahlen emittieren. Nicht mit optischen Instrumenten betrachten.



Class 1 Laser Product

NOTICE

Unterminated optical connectors may emit laser radiation. Do not view with optical instruments.


Bei Verwendung von nicht in diesem Dokument spezifizierten Steuerungen, Einstellungen oder Verfahren besteht die Gefahr einer gefährlichen Strahlenaussetzung.

**Safety Guidelines
for Rackmount
Products**

Read and follow all warnings, cautions, and instructions marked on the product and included in this document. Only qualified personnel should perform installation or service.

This unit is designed to be NEBS Level 3 Conformant per Telcordia/Bellcore GR-1089-CORE and GR-63-CORE.

1. Always wear an ESD wriststrap and follow appropriate ESD procedures when installing or servicing the unit and its components.
2. The unit is suitable for connection to intra-building or non-exposed cabling only per Telcordia/Bellcore NEBS GR-1089-CORE.
3. Turn off the unit's subpanel circuit breakers when making power input connections.
4. Verify that the input power requirements (-42 VDC to -56 VDC) are correct before installing the unit. This product is intended to operate from a -48 VDC source derived from batteries, SELV, or an NEC Class II device.
5. Do not attempt to lift and install the unit alone. A fully configured unit can weigh up to 58 pounds (26.31 kgs.).
6. The unit is configured and shipped to mount into a 23- or 19-inch rack. A minimum of four mounting screws are required to attach the unit to a rack's mounting rails. Eight mounting screws are recommended. Mounting screws are the responsibility of the customer.
7. Always make sure that a component is installed into the correct slot. (Use the label, visible when components are removed, to verify the slot position.)
8. An empty slot should never be exposed. Always have an empty slot covered by the appropriate blank faceplate when a component is removed for any period of time. This is required for NEBS GR-1089-CORE and EMC conformance.
9. The circuit packs contain Class 1 laser devices (21 CFR 1040.10 and 1040.11 Compliant; EN60825-1:1993+A11+A2). Never look into an unterminated fiber. Always place shutters on the optical ports when fiber is not attached to the optical ports. CDRH Accession Number: 9922616.



Class 1 Laser Product

NOTICE

Unterminated optical connectors may emit laser radiation. Do not view with optical instruments.

Sicherheitshinweise Lesen und befolgen Sie bitte alle Warn- und Vorsichtshinweise sowie alle Anweisungen auf dem Produkt und in diesem Dokument. Installation und Reparatur dürfen nur von qualifizierten Fachkräften durchgeführt werden.

Dieses Gerät ist für NEBS Level 3 Konformität nach Telcordia/Bellcore GR-1089-CORE und GR-63-CORE ausgeführt.

1. Zur Installation oder Wartung des Gerätes sollte immer ein Antistatik-Armband getragen und die entsprechenden ESE-Verfahren beachtet werden.
2. Das Gerät eignet sich für den Anschluss an gebäudeinterne oder nicht freiliegende Kabel, sofern die Anforderungen nach Telcordia/Bellcore NEBS GR-1089-CORE erfüllt werden.
3. Vor dem Anschluss an die Leistungseingänge müssen die Leistungsschutzschalter auf der Unterverteilungsschalttafel des Gerätes ausgeschaltet werden.
4. Vor der Installation des Geräts ist zu prüfen, ob die Eingangsleistungsanforderungen (-42 VDC bis -56 VDC) erfüllt sind. Dieses Gerät ist für den Betrieb mit einer -48 VDC Batteriestromquelle, SELV oder einem NEC-Gerät der Klasse II bestimmt.
5. Das Gerät sollte keinesfalls von einer Person alleine gehoben und installiert werden. Voll konfiguriert kann es bis zu 26,3 kg wiegen.
6. Das Gerät wird für die Montage in einem 58,4 cm oder 48,3 cm Rack konfiguriert und geliefert. Zur Befestigung an den Rackschienen müssen mindestens vier Befestigungsschrauben verwendet werden. Acht Schrauben werden empfohlen. Die Befestigungsschrauben müssen kundenseitig gestellt werden.
7. Es ist wichtig, darauf zu achten, dass jede Komponente in den richti-


gen Steckplatz installiert wird. (Die Steckplatzposition kann bei ausgebauten Komponenten anhand der Etikettierung bestätigt werden.)

8. Freie Steckplätze dürfen nicht ungeschützt freiliegen. Wenn eine Komponente für längere Zeit entfernt wird, sollte der leere Steckplatz mit einer passenden Abdeckplatte abgedeckt werden. Die Steckplatzabdeckung ist zur Aufrechterhaltung der NEBS GR-1089-CORE- und EMV-Konformität notwendig.
9. Die Baugruppen enthalten Lasergeräte der Klasse 1 (21 CFR 1040.10 und 1040.11 konform; EN60825-1:1993 +A11+A2). Niemals in das abgetrennte LWL-Kabel blicken. Wenn das LWL-Kabel nicht an den LWL-Anschlüssen angeschlossen ist, sollten die LWL-Anschlussöffnungen immer mit Klappen abgedeckt werden. CDRH-Zugriffszahl: 9922616.

Laserprodukt der Klasse 1

HINWEIS

Nicht angeschlossene LWL-Verbinder können Laserstrahlen emittieren. Nicht mit optischen Instrumenten betrachten.



Class 1 Laser Product

NOTICE

Unterminated optical connectors may emit laser radiation. Do not view with optical instruments.

Bei Verwendung von nicht in diesem Dokument spezifizierten Steuerungen, Einstellungen oder Verfahren besteht die Gefahr einer gefährlichen Strahlenaussetzung.

Contents

1 Introducing SCPI Commands

Overview	1-1
SCPI Command Menu Hierarchy	1-1
Configuring the Unit for SCPI Command Mode	1-1
SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 1	1-2
SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 2	1-3
SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 3	1-4
SCPI Configuration when using the EMS	1-5
Verifying Connectivity	1-5
Opening a SCPI Session	1-6
Multisession SCPI Overview	1-8
Long and Short SCPI Command Formats	1-9
Query and Set SCPI Commands	1-9

2 Standard SCPI Commands

Overview	2-1
“STAR” Commands	2-2
SYSTem Commands	2-2
STATus Commands	2-5
Miscellaneous Commands: INITiate, ABORT, INSTrument, and ROUTE Commands	2-7

3 Extended SCPI Commands

Overview	3-1
Extended SCPI Commands	3-1
RES (Fetch) Branch	3-1
TX (SOURce) Branch	3-20
RX (Sense) Branch	3-40
GET Branch	3-51

4 ATM SCPI Commands

Overview	4-1
Supported ATM SCPI Commands	4-1

RES (Fetch) Branch	4-1
TX (SOURce) Branch	4-7
ATMVCC Branch	4-13
ATMSCAN Branch	4-19
ATMSYS Branch	4-20
SVCSETUP Branch	4-22
SVCCFG Branch	4-29
TXRX Branch	4-34
RX (Sense) Branch	4-36
5 Gigabit Ethernet SCPI Commands	
Overview	5-1
Supported GigE SCPI Commands	5-1
RES (Fetch) Branch	5-1
TX (SOURce) Branch	5-3
RFC2544 Branch	5-4
Packet Branch	5-6
GET Branch	5-12
6 OSA SCPI Commands	
Overview	6-1
Supported OSA SCPI Commands	6-1
RX (Sense) Branch	6-1
7 Error Codes	
Overview	7-1
8 Register Definitions	
Overview	8-1
*STB?	
Status Byte (Immediate Response Queue)	8-1
*ESR?	
Standard Event Status Register (Immediate Response Queue)	8-1
STATus:QUES?	
Questionable Register	8-2
STATus:OPER:TCON?	
Telecom Configuration Register (TCON)	8-2
DS1 Registers	
STAT:QUES:DS1@1? and STAT:QUES:DS1@2	8-3
DS3 Register	

STAT:QUES:DS3?	8-3
E1 Registers	
STAT:QUES:E1@1? and STAT:QUES:E1@2.	8-4
E3 Register	
STAT:QUES:E3?.....	8-5
E4 Register	
STAT:QUES:E4?.....	8-5
SDH/SONET Register	
STAT:QUES:SDH? or STAT:QUES:SONET?.....	8-6

1

Introducing SCPI Commands

Overview

Digital Lightwave products support automated programming and remote control using the **Standard Commands for Programmable Instruments (SCPI)** protocol. This protocol consists of standard and extended SCPI commands, which are listed in this reference guide.

SCPI commands can be issued over a variety of hardware interfaces, such as GPIB and serial, and software interfaces, such as Ethernet.

This reference guide lists Standard and Extended SCPI commands, Error Codes, and Register Definitions supported by the configured unit. You may not have access to all commands based on the product configuration you purchased. SCPI commands are fully compatible across all DLI NIC and NAA IV products.

SCPI Command Menu Hierarchy

The following is a hierarchal view of the SCPI Command menu.




Figure 1-1. SCPI Command Menu Hierarchy

Configuring the Unit for SCPI Command Mode

Before you can issue SCPI commands to the unit, you must first decide on a hardware or software interface to use, and then configure the unit for that interface. The following sections describe how to configure the unit for SCPI command operation when using either a portable unit's touch screen, the Remote Control GUI, or the EMS software. Methods 1, 2, and 3 vary based the unit's software version. Use the method that matches the I/O Settings screens that appear on your unit.

SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 1

The I/O Settings screen appears by selecting the **System** tab and then the **I/O Settings** button. **Units with feature set 3.2 or greater display the following I/O Settings screen:**



If your unit displays this screen, use the following procedures to configure the unit for SCPI operation.

1. Select **SYSTEM**. This appears on the unit’s touch screen or Remote Control GUI.
2. Select **I/O Settings**. The **Ethernet Configuration** functions appear.

NOTE >

Select **Serial** or **GPIB** if using the the serial or GPIB ports. <

3. Select **Port Assignment** and select **SCPI** to assign SCPI operations to the port.

If it is necessary to change port parameters, refer to the unit’s online help file for more information.

This concludes the unit’s SCPI port configuration using either the touch screen or Remote Control GUI.

SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 2

The I/O Settings screen appears by selecting the **System** tab and then the **I/O Settings** button. **Some units may display the following I/O Settings screen:**

The screenshot shows the 'I/O Settings' screen with the following sections:

- Ethernet Configuration:**
 - Obtain an IP address from a DHCP server
 - Specify an IP address
 - IP Address: 0.0.0.0
 - Subnet Address: 0.0.0.0
 - Router: 0.0.0.0
- RAS Configuration:**
 - Allow remote clients to request a predetermined IP address
 - Start IP Address: 0.0.0.0
 - End IP Address: 0.0.0.0
- Serial Configuration:**
 - Baud Rate: 9600
 - Parity: n
 - Data Bits: 7
 - Stop Bits: 1
- GPIB Configuration:**
 - GPIB Port: 0
- Communication Port Assignments:**
 - Serial: None
 - Ethernet: None
 - GPIB: None

If your unit displays this screen, use the following procedures to configure the unit for SCPI operation.

1. Select **SYSTEM**. This appears on the unit’s touch screen or Remote Control GUI.
2. Select **I/O Settings**. The **Communication Port Assignments** functions appear.

The close-up shows the 'Communication Port Assignments' section with the following options:

- Serial** None
- Ethernet** None
- GPIB** None


3. Select a port (**Serial**, **Ethernet**, or **GPIB**) to assign to SCPI operation.

If it is necessary to change port parameters, refer to the unit’s online help file for more information.

This concludes the unit’s SCPI port configuration using either the touch screen or Remote Control GUI.

SCPI Configuration when using a Touch Screen or Remote Control GUI - Method 3

The I/O Settings screen appears by selecting the **System** tab and then the **I/O Settings** button. **Some units may display the following I/O Settings screen:**




If your unit displays this screen, use the following procedures to configure the unit for SCPI operation.

1. Select **SYSTEM**. This appears on the unit’s touch screen or Remote Control GUI.
2. Select **I/O Settings**. The **Communication Ports** functions appear.



3. Select **SCPI Port**. The SCPI port options appear.




4. Select the connection method you will use to send SCPI commands to and from the unit.

This concludes the unit’s SCPI port configuration using either the touch screen or Remote Control GUI.

SCPI Configuration when using the EMS

1. Select the **Tools** function menu.
2. Select **Setup**.
3. Select **System Properties**. The System Settings window appears.
4. Select the **Comm** tab. The communications parameters appear.



5. Select and set the communications port that you will use to send SCPI commands to and from the unit.
6. Select **OK**.

This concludes the unit's SCPI port configuration using the EMS.

Verifying Connectivity

You can connect the unit directly to a PC (using the Serial port) or remotely using the Ethernet port. You must have a terminal emulation package (for example, HyperTerminal) or a terminal protocol, such as Telnet, as an interface for issuing SCPI commands.

After configuring the unit for SCPI operation, perform the following quick test to verify connectivity between the unit and your terminal software.

1. Open your terminal software, make sure it is properly configured for the unit's SCPI port settings, and connect to the unit.

NOTE | >

Use port number **8090** if you are using Ethernet or a Telnet application to issue SCPI commands to the unit. <

2. Verify connectivity by sending the **SCPI?** command (Identification) to the unit. This command queries the unit for its identification sequence. For example,

Type: **SCPI?**

Press: Enter

A **YES** message indicates that you can communicate with the unit.

To continue using SCPI commands, you must log in and open a SCPI session.

Opening a SCPI Session

The following procedures describe how to log in, retrieve a product inventory, and select a specific test unit (protocol processor).

1. Use the **LOGIN** command to open a SCPI session. For example,

Type: **LOGIN Admin Admin1**

(Admin = default user ID; Admin1 = default password)

Press: Enter

2. Use the **GET:PROTOCOLS?** command to retrieve an inventory of protocol processors installed in the unit.

Type: **GET:PROTO?**

Press: Enter

The information returned appears using the following format:

W X Y Z; W X Y Z; ... W X Y Z;

where

W = chassis ID (only appears for NAA IV and NIC Plus)

X = slot ID (only appears for NAA IV and NIC Plus)

Y = card ID (only appears for NAA IV and NIC Plus)

Z = protocol processor

3. Use the **INST** command to select a protocol processor.

For example, when using a NIC 10G or NIC 2.5G portable unit:

Type: **INST X**

where *X* = OC192, OC48, OC12, OC192Q@N, STM64, STM16, STM4, STM64Q@N, E1@N, E3, E4, DS3, DS@N, or ATM

Press: Enter

When using an NAA IV or NIC Plus:

Type: **INST X Z**

where

X = slot ID

NOTE | ►

The slot ID is only required when multiple circuit packs of the same type

(for example, two 2.5G circuit packs) are installed in the unit.

For a 19-inch NAA IV chassis, slots 1-5 and 7-10 can be selected. Slot 6 is reserved for the System Controller circuit pack.

For a 23-inch NAA IV chassis, slots 1-6 and 8-13 can be selected. Slot 7 is reserved for the System Controller circuit pack. ◀

Z = OC192, OC48, OC12, OC192Q@N, STM64, STM16, STM4, STM64Q@N, E1@N, E3, E4, DS3, DS1@N, ATM, or GIGE@N

Press: Enter

When using an NAA IV or NIC Plus with multiple Gigabit Ethernet circuit packs:

Type: INST W X Y Z

where

W = chassis ID

X = slot ID

NOTE ▶

The slot ID is only required when multiple circuit packs of the same type are installed in the unit. ◀

Y = card ID

NOTE ▶

The card ID is required when multiple Gigabit Ethernet circuit packs are installed in the unit. ◀

Z = GIGE@N

where N is 1 (Port 1) or 2 (Port 2)

NOTE ▶

All SCPI commands issued will be sent to the selected protocol processor. This is true until a new protocol processor is selected using the INST command. ◀


SCPI commands can now be issued to the selected protocol processor. An error message is returned if you enter a SCPI command that is not applicable for the selected protocol processor.

- To close a SCPI session, use the **LOGOUT** command.


Multisession SCPI Overview

A NIC portable unit can support up to five simultaneous SCPI users, and an NAA IV unit can support up to 10 simultaneous SCPI users. This is known as multisession SCPI. The following guidelines apply to multisession SCPI:

- The first user to select a circuit pack in the unit will automatically lock all associated circuit packs. This grouping of circuit packs is known as a Test Set. When a Test Set is locked, other users cannot access these circuit packs while the first user is logged on.
- A Test Set is a series of adjacent circuit packs (based on a circuit pack’s internal addressing and starting from the highest to the lowest speed) that are installed in a unit.



A unit can contain multiple circuit packs of the same type (for example, two 10 Gbps circuit packs).



When this type of configuration occurs, the first instance of the higher speed circuit pack is considered a test set (Test Set #1). Any lower speed circuit packs adjacent to this card are included in the test set. When the second instance of the higher speed circuit pack is encountered, it is considered the beginning of the second test set (Test Set #2). Likewise, any subsequent lower speed circuit packs are included as part of the second test set.

- The user, who has the Test Set locked, can unlock the Test Set and still remain logged on by issuing the **INST NONE** SCPI command.

Long and Short SCPI Command Formats

SCPI commands for the units are not case sensitive and can be entered using all upper-case characters, all lower-case characters, or a mixture of both.

SCPI commands can be issued using either the long-character format or the short-character format. In this reference guide:

- Upper-case characters indicate the minimum number of characters required for a successful command.
- Lower-case characters are optional.
- Parameters should be separated by a space, unless otherwise documented in the command.
- SCPI commands should be typed on one single line completed with a hard carriage return.
- Replies from SCPI commands have a carriage return appended.

The following examples show how the **SYSTEM:VERSion** query command is issued in both long-character and short-character formats:

To enter the **long-character** format of this command, type:

```
SYSTEM:VERSION?
```

The response `SCPI 1995.0` appears.

The same command can be entered using any of the following **short-character** formats:

```
SYST:VERS?
```

```
SYST:VERSI?
```

```
SYST:VERSIO?
```

```
SYST:VERSION?
```

```
SYSTEM:VERS?
```

```
SYSTEM:VERSI?
```

```
SYSTEM:VERSIO?
```

Query and Set SCPI Commands

In general, SCPI commands are query and set functions. A Query command interrogates the unit for the current value of the issued SCPI command. It is terminated with a question mark (?) and does not require a colon after the last parameter.

For example, to query the unit for the current selected protocol processor, type:

```
INST?
```

A Set command changes a command's value. The new command value is appended to the end of the command string. For example, to change the unit to the STM-16 protocol processor, type:

```
INST STM16
```


2

Standard SCPI Commands

Overview

This chapter lists the Standard SCPI commands supported by the configured unit. You may not have access to all commands based on the product configuration you purchased. SCPI commands are fully compatible across all DLI products.

Standard SCPI Commands

These commands are from the SCPI standard. SCPI commands for the configured unit are not case sensitive; therefore, both upper and lower cases can be used for the short version of a command. SCPI commands should be typed on one single line completed with a hard carriage return.

For example, the System Error Query command can be sent to the register queue by typing any of the following formats:

SYSTEM:ERROR?

syst:err?

SYST:ERROR?

system:erro?

Pattern Setting and Reporting

Patterns can be a user-specified bit pattern, or can be a character string, describing the pattern. Patterns are specified with one of these formats:

NNNNNN	(Decimal Integer)
#Bbbbbbbbb	(Binary Integer)
#Hhhhhhhhhh	(Hexadecimal Integer)
xxxxxxxxxxxx	(Predefined pattern description string)

For pattern queries, the Binary format is always returned.

For specifying patterns that can be variable size, the binary format must be used. The number of characters after the #B shall dictate the length of the pattern.

The pattern description string must not begin with a decimal character or "#" to prevent it from being confused with the numeric bit patterns. For example:

127	(8-bit, user-defined bit pattern of 01111111)
#B000	(3-bit, all-zero user-defined bit pattern)
#H00FF010A	(4-byte, user-defined bit pattern)
PRBS23-1	(PRBS $2^{23}-1$ predefined pattern)
2_IN_1	(INVALID PATTERN - Begins with a numeral)

TWO_IN_1 (Predefined pattern)

This command changes the SONET/SDH overhead using Hex:

TX:OH:D1 #HFF

This command changes a pattern using a binary input:

TX:PATT #B10101010101010

This command is for an E1 CAS channel query using a decimal for channel:

TX:CAS 21?

"STAR" Commands

The "Star" commands are standard SCPI commands that are used to set or query a device's Status Byte Register.

The following commands are supported:

"Star" Command	Description
*CLS	Sets all SCPI registers to zero.
*IDN?	Identification Sequence. Queries the IEEE standard identification sequence of the unit. The following four values, each separated by commas, are returned for this command: Company Name, Product Model Name, Serial Number, Software Version.
*ESR?	Queries the Standard Event Status Register.
*RST	Resets to factory default settings.

SYSTEM Commands

The System commands affect the entire instrument, not just one protocol. These commands allow you to query and set basic system items such as ports, printing, and configuration. The following is a list of supported System commands.

SYSTEM Command	Description
SYSTEM:AUTOLOGIN:DETAILS <UserName Password>	Sets the unit's user name and password. These values are case sensitive. The user name must be 5 to 18 characters. The password must be 4 to 8 characters. User accounts entered using SCPI commands have Administrator permissions.
SYSTEM:AUTOLOGIN:VALUE <true or false>	Enables and disables Auto login. True = On. False = Off. These values are not case sensitive.
SYSTEM:AUTOLOGIN:VALUE?	Queries the Auto login status and returns a value of True, if Auto login is enabled, or False, if Auto login is disabled.
SYSTEM:AUTOLOGIN:USER?	Queries the Auto login user name as defined by the SYSTEM:AUTOLOGIN:DETAILS command.

SYSTEM Command	Description
SYSTEM:BACKLight <value> SYSTEM:BACKLight?	Sets or queries the intensity of a unit's screen. Values range from 0 (brightest setting) to 255 (dimmiest setting).
SYSTEM:COMMunicate:SERial: BAUD <value> SYSTEM:COMMunicate:SERial:BAUD?	Sets or queries the RS-232 baud rate. Valid baud rates are: 1200, 2400, 4800, 9600, 14400, and 19200.
SYSTEM:COMMunicate:SERial:BITS <value> SYSTEM:COMMunicate:SERial:BITS?	Sets or queries the RS-232 data bits. Valid data bit values are: 7 or 8.
SYSTEM:COMMunicate:SERial:PARity <value> SYSTEM:COMMunicate:SERial:PARity?	Sets or queries the RS-232 parity. Valid parity values are: EVEN, ODD, or NONE.
SYSTEM:COMMunicate:SERial:SBITs <value> SYSTEM:COMMunicate:SERial:SBITs?	Sets or queries the RS-232 stop bits. Valid stop bit values are: 1 or 2.
SYSTEM:COMMunicate:ETHERnet: ADDRESS <value>	Sets or queries the Ethernet IP address. (e.g., 208.143.235.123)
SYSTEM:COMMunicate:ETHERnet:ADDRESS?	
SYSTEM:COMMunicate:ETHERnet: SUBnet <value>	Sets or queries the Ethernet IP subnet mask. (e.g., 255.255.255.0)
SYSTEM:COMMunicate:ETHERnet:SUBnet?	
SYSTEM:COMMunicate:ETHERnet: ROUTer <value>	Sets or queries the Ethernet IP router for this subnet. (e.g., 255.255.255.1)
SYSTEM:COMMunicate:ETHERnet:ROUTer?	
SYSTEM:DATE <MM,DD,YYYY> and SYSTEM:DATE?	Sets or queries the date on the system. Four digits are required for the year.
SYSTEM:DTESTUList?	Queries and displays a list of default test units and corresponding protocol processors. (For a description about test units, refer to the <i>Multisession SCPI Overview</i> section in Chapter 1.)
Note: This command reports the unit's inventory in relation to the default test unit grouping. It helps determine which protocol processors in a given test unit are locked when the INST command is used. The SYSTEM:LOCK:OWNER? command reports which user owns the test lock.	<p>Returned format string guidelines:</p> <ul style="list-style-type: none"> ■ When more than one protocol processor is associated with a default test unit, a comma (,) delimiter is used. ■ When multiple default test units are present, a colon (:) delimiter is used. ■ For NIC Plus portable and NAA IV rackmount products, the default test unit name, chassis number, slot number, card ID, and protocol processor ID appear. ■ For NIC portable products, the default test unit name and protocol processor ID appear. <p>Example output for NIC Plus and NAA IV products: Default1 1 1 0 OC192, 1 1 0 STM64, 1 2 0 OC48, 1 2 0 STM16: Default2 1 5 0 E4, 1 5 0 E3, 1 5 0 DS3, 1 5 0 E1@1, 1 5 0 DS1@1</p> <p>Example output for NIC products: Default1 OC192, STM64, OC48, STM16: Default2 E4, E3, DS3, E1@1, DS1@1</p>

SYSTEM Command	Description						
SYSTEM:ERRor?	Queries the first error waiting in the error queue, and removes that one error from the queue.						
SYSTEM:ERRor:CODE? SYSTEM:ERRor:CODE:NEXT? SYSTEM:ERRor:NEXT?	Queries the first error waiting in the error queue, and removes that one error from the queue.						
SYSTEM:ERRor:CODE:LAST?	Queries the last error waiting in the error queue, and empties the queue in the process.						
SYSTEM:ERRor:COUNt?	Queries the number of errors waiting in the error queue. Valid error values are: 0 to 79.						
SYSTEM:ERRor:LAST?	Queries the last error waiting in the error queue, and empties the queue in the process.						
SYSTEM:LEGACYR?	Queries the system for its current error code reporting format. Refer to Chapter 5, Error Codes for a list of error codes and descriptions. True = Error code number only. False = Error code number and definition.						
SYSTEM:LEGACYR <format>	Sets the error code format. Valid values for <format> are: Valid values for <format> are: <table border="0"> <thead> <tr> <th><u>Format</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>TRUE</td> <td>Only the error code number is returned. For example, 101. This is the old error code format.</td> </tr> <tr> <td>FALSE</td> <td>The error code number and description are returned. For example, 101, "Object not initialized." This is the new error code format. False is the factory default value.</td> </tr> </tbody> </table>	<u>Format</u>	<u>Description</u>	TRUE	Only the error code number is returned. For example, 101. This is the old error code format.	FALSE	The error code number and description are returned. For example, 101, "Object not initialized." This is the new error code format. False is the factory default value.
<u>Format</u>	<u>Description</u>						
TRUE	Only the error code number is returned. For example, 101. This is the old error code format.						
FALSE	The error code number and description are returned. For example, 101, "Object not initialized." This is the new error code format. False is the factory default value.						
SYSTEM:LOCK:OWNER?	Queries and reports a list of locked protocol processors and the lock owner. NONE is reported if no protocol processors are locked. Returned format string guidelines: <ul style="list-style-type: none"> ■ A colon delimiter is used to separate multiple protocol processors installed in a unit. ■ For NIC Plus portable and NAA IV rackmount products, the chassis number, slot number, card ID, protocol processor ID, and lock owner appear. ■ For NIC portable products, the default test unit name and protocol processor ID appear. Example output for NIC Plus and NAA IV products: 1 1 0 OC192_STM64 Admin: 1 2 0 E3_DS3 JOE Example output for NIC products: OC192_STM64 Admin: E3_DS3 JOE						
SYSTEM:OSCillator <value> SYSTEM:OSCillator?	Sets or queries the Oscillator Value. This command is used to set the unit's internal clock frequency. The value can be adjusted in 255 steps, where 0 is the lowest frequency, 128 is the center frequency, and 255 is the highest frequency.						
SYSTEM:PORT:SCPI <value> SYSTEM:PORT:SCPI?	Sets or queries which port accepts SCPI commands. Valid ports are: GPIB, SERIAL, 232MODEM, PCMCIA, ETHERNET, or NONE.						

SYSTem Command	Description
SYSTem:RESPonse <setting>	Sets the command response setting to one of ALWAYS or STANDARD. STANDARD is the default and behaves per the SCPI standard where only queries return a response. ALWAYS means that every command returns a response of +0 or an error code.
SYSTem:RESPonse?	Queries the current response setting, ALWAYS or STANDARD.
SYSTem:RUNTIME?	Returns the system runtime ODOMETER as three integers: Days, Hours, and Minutes, separated by commas.
SYSTem:SPEAKer <value> SYSTem:SPEAKer?	Sets or queries the unit's speaker volume. Values range from 0 to 15.
SYSTem:TIME <HH,MM,SS> SYSTem:TIME?	Sets or queries the time on the system, as Hours, Minutes and Seconds.
SYSTem:VERSion?	Queries the version number of the SCPI code. Format is "NN.NN.NN".
SYSTem:WHOAMI?	Queries and displays the user name and number associated with the current logged session using the following format: UserId/Session where, Session is TCP n (n is an integer greater than 0), RS232, or GPIB. For example: Admin/TCP2 The current session is owned by the user Admin and is connected to the SCPI Proxy using TCP/IP connection #2.

STATus Commands

The Status Branch commands allow you to query and set commands for functions in the OPERATION and QUESTIONable registers.

The following is a list of supported Status Branch commands. **The contents of these registers are described in [Chapter 8, Register Definitions](#).**

STATus Command	Description
STATus:OPERation:TCON? STATus:OPERation:TELECOM? STATus:OPERation:TCON:EVENT? STATus:OPERation:TELECOM:EVENT? STATus:OPERation:TCON:CONDition? STATus:OPERation:TELECOM:CONDition?	Queries the Telecom Configuration register. Register definitions are in this document.
STATus:OPERation:TCON:ENABLE? STATus:OPERation:TELECOM:ENABLE? STATus:OPERation:TCON:ENABLE <MASK> STATus:OPERation:TELECOM:ENABLE <MASK>	Queries and sets the TCON register mask.
STATus:QUESTionable? STATus:QUESTionable:CONDition?	Queries the standard QUESTIONable register. Register definitions are in this document.

STATUS Command	Description
STATUS:QUESTIONABLE:EVENT?	Queries a latched version of the standard QUESTIONABLE register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent.
STATUS:QUESTIONABLE:ENABLE? STATUS:QUESTIONABLE:ENABLE <MASK>	Queries and sets the QUESTIONABLE register mask.
STATUS:QUESTIONABLE:DS1@N? STATUS:QUESTIONABLE:DS1@N:CONDITION?	Queries the DS1 register. Register definitions are in this document (N = 1 or 2).
STATUS:QUESTIONABLE:DS1@N:EVENT?	Queries a latched version of the DS1 register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent (N = 1 or 2).
STATUS:QUESTIONABLE:DS1@N:ENABLE? STATUS:QUESTIONABLE:DS1@N:ENABLE <MASK>	Queries and sets the DS1 register mask (N = 1 or 2).
STATUS:QUESTIONABLE:E1@N? STATUS:QUESTIONABLE:E1@N:CONDITION?	Queries the E1 register. Register definitions are in this document (N = 1 or 2).
STATUS:QUESTIONABLE:E1@N:EVENT?	Queries a latched version of the E1 register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent (N = 1 or 2).
STATUS:QUESTIONABLE:E1@N:ENABLE? STATUS:QUESTIONABLE:E1@N:ENABLE <MASK>	Queries and sets the E1 register mask (N = 1 or 2).
STATUS:QUESTIONABLE:E3? STATUS:QUESTIONABLE:E3:CONDITION?	Queries the E3 register. Register definitions are in this document.
STATUS:QUESTIONABLE:E3:EVENT?	Queries a latched version of the E3 register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent.
STATUS:QUESTIONABLE:E3:ENABLE? STATUS:QUESTIONABLE:E3:ENABLE <MASK>	Queries and sets the E3 register mask.
STATUS:QUESTIONABLE:E4? STATUS:QUESTIONABLE:E4:CONDITION?	Queries the E4 register. Register definitions are in this document.
STATUS:QUESTIONABLE:E4:EVENT?	Queries a latched version of the E4 register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent.
STATUS:QUESTIONABLE:E4:ENABLE? STATUS:QUESTIONABLE:E4:ENABLE <MASK>	Queries and sets the E4 register mask.
STATUS:QUESTIONABLE:SDH? STATUS:QUESTIONABLE:SDH:CONDITION?	Queries the SDH/SONET register. Register definitions are in this document.
STATUS:QUESTIONABLE:SDH:EVENT?	Queries a latched version of the SDH/SONET register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent.
STATUS:QUESTIONABLE:SDH:ENABLE? STATUS:QUESTIONABLE:SDH:ENABLE <MASK>	Queries and sets the SDH/SONET register mask.
STATUS:QUESTIONABLE:SONET? STATUS:QUESTIONABLE:SONET:CONDITION?	Queries the SDH/SONET register. Register definitions are in this document.
STATUS:QUESTIONABLE:SONET:EVENT?	Queries a latched version of the SDH/SONET register. Register definition is the same as unlatched. Latched bits are cleared when INIT command is sent.

STATus Command	Description
STATus:QUEStionable:SONET:ENABle? STATus:QUEStionable:SONET:ENABle <MASK>	Queries and sets the SDH/SONET register mask.

Miscellaneous Commands: INITiate, ABORT, INSTRument, and ROUTe Commands

The following commands can start and stop basic unit functionality. In addition, these commands perform a number of miscellaneous commands that control unit settings.

Command	Description
ABORT <protocol processor or blank>	<i>Protocols Supported: ALL</i> Stops data acquisition for the selected protocol processor(s).
Note: A protocol processor has not been selected if error code -224 appears. Use the INST command to select a protocol.	Note: If one of the protocol processors listed below has other protocol processors associated with it (for example, a drop/insert configuration), then those protocol processors are also stopped. For example, if the ROUTE S3 command is in effect, the ABORT STM4 command will also stop the E3/DS3 protocol processor.
	Valid protocol processor values are:
	<u>Protocol Processor</u>
<blank>	Stops the protocol processor currently selected by the INST command. Error code -224 appears if no instrument is selected.
STM64	Stops the STM-64 protocol processor
STM16	Stops the STM-16 protocol processor
STM4	Stops the STM-4 protocol processor
OC192	Stops the OC-192 protocol processor
OC48	Stops the OC-48 protocol processor
OC12	Stops the OC-12 protocol processor
E4	Stops the E4 protocol processor
E3	Stops the E3 protocol processor
E1@N	Stops the E1@N protocol processor
DS3	Stops the DS3 protocol processor
DS1@N	Stops the DS1@N protocol processor
ATM	Stops the ATM protocol processor
ALL	Stops all protocol processors Note: Although the ALL parameter is currently supported in SCPI release 2.0.51, it may not be supported for future major releases. If an error code appears when using the ALL parameter, then it is not supported in your SCPI release.

Command	Description																																
AUTOCONfig <type or blank>	<p><i>Protocols Supported:</i> ALL</p> <p>Automatically configures settings to match the signal being received. When configuring tributaries, the first non-idle/unequipped tributary is used. If all are idle or all unequipped, no further tributary examination is done.</p> <p>TYPE is one of the following:</p> <table border="1"> <thead> <tr> <th>Type</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>MASTER or <blank></td> <td>Configure all, including tributaries, starting with SDH/SONET highest speed</td> </tr> <tr> <td>STM4</td> <td>Configure STM-4 and tributaries</td> </tr> <tr> <td>STM16</td> <td>Configure STM-16 only, no tributaries</td> </tr> <tr> <td>STM64</td> <td>Configure STM64 only, no tributaries</td> </tr> <tr> <td>OC192</td> <td>Configure OC192 only, no tributaries</td> </tr> <tr> <td>OC48</td> <td>Configure OC48 only, no tributaries</td> </tr> <tr> <td>OC12</td> <td>Configure OC12 and tributaries</td> </tr> <tr> <td>E4T</td> <td>Configure E4 and tributaries</td> </tr> <tr> <td>E4</td> <td>Configure E4 only, no tributaries</td> </tr> <tr> <td>E3T</td> <td>Configure E3 and tributaries</td> </tr> <tr> <td>E3</td> <td>Configure E3 only</td> </tr> <tr> <td>E1@N</td> <td>Configure E1@N only</td> </tr> <tr> <td>DS3T</td> <td>Configure DS3 and tributaries</td> </tr> <tr> <td>DS3</td> <td>Configure DS3 only, no tributaries</td> </tr> <tr> <td>DS1@N</td> <td>Configure DS1@N only</td> </tr> </tbody> </table>	Type	Meaning	MASTER or <blank>	Configure all, including tributaries, starting with SDH/SONET highest speed	STM4	Configure STM-4 and tributaries	STM16	Configure STM-16 only, no tributaries	STM64	Configure STM64 only, no tributaries	OC192	Configure OC192 only, no tributaries	OC48	Configure OC48 only, no tributaries	OC12	Configure OC12 and tributaries	E4T	Configure E4 and tributaries	E4	Configure E4 only, no tributaries	E3T	Configure E3 and tributaries	E3	Configure E3 only	E1@N	Configure E1@N only	DS3T	Configure DS3 and tributaries	DS3	Configure DS3 only, no tributaries	DS1@N	Configure DS1@N only
Type	Meaning																																
MASTER or <blank>	Configure all, including tributaries, starting with SDH/SONET highest speed																																
STM4	Configure STM-4 and tributaries																																
STM16	Configure STM-16 only, no tributaries																																
STM64	Configure STM64 only, no tributaries																																
OC192	Configure OC192 only, no tributaries																																
OC48	Configure OC48 only, no tributaries																																
OC12	Configure OC12 and tributaries																																
E4T	Configure E4 and tributaries																																
E4	Configure E4 only, no tributaries																																
E3T	Configure E3 and tributaries																																
E3	Configure E3 only																																
E1@N	Configure E1@N only																																
DS3T	Configure DS3 and tributaries																																
DS3	Configure DS3 only, no tributaries																																
DS1@N	Configure DS1@N only																																
DELAY <milliseconds>	<p><i>Protocols Supported:</i> SYSTEM</p> <p>Waits an integer number of milliseconds before processing next command.</p>																																
DURation <minutes>	<p><i>Protocols Supported:</i> ALL</p> <p>Set the duration of the specified test to an integer number of minutes or "CONTINUOUS." No practical maximum.</p>																																
DURation?	<p><i>Protocols Supported:</i> ALL</p> <p>Returns the duration of the specified test as an integer (minutes), or "CONTINUOUS."</p>																																
ELAPSEdtime?	<p><i>Protocols Supported:</i> ALL</p> <p>Returns the time the specified test has been running in seconds.</p>																																
PROTOCOL <protocol mode>	<p><i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1</p> <p>Selects a protocol processor mode.</p> <table border="1"> <thead> <tr> <th>Protocol Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SDH</td> <td>Enables SDH mode</td> </tr> <tr> <td>SONET</td> <td>Enables SONET mode</td> </tr> </tbody> </table> <p>Note: The following protocols are only available on products that contain both SONET/SDH and PDH hardware.</p> <table border="1"> <thead> <tr> <th>Protocol Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SDH_DS1_DS3</td> <td>Enables SDH, DS1 and DS3 modes</td> </tr> <tr> <td>SDH_E1_DS3</td> <td>Enables SDH, E1, and DS3 modes</td> </tr> <tr> <td>SDH_E1_E3</td> <td>Enables SDH, E1, and E3 modes</td> </tr> <tr> <td>SONET_DS1_DS3</td> <td>Enables SONET, DS1, and DS3 modes</td> </tr> <tr> <td>SONET_E1_DS3</td> <td>Enables SONET, E1, and DS3 modes</td> </tr> </tbody> </table>	Protocol Mode	Description	SDH	Enables SDH mode	SONET	Enables SONET mode	Protocol Mode	Description	SDH_DS1_DS3	Enables SDH, DS1 and DS3 modes	SDH_E1_DS3	Enables SDH, E1, and DS3 modes	SDH_E1_E3	Enables SDH, E1, and E3 modes	SONET_DS1_DS3	Enables SONET, DS1, and DS3 modes	SONET_E1_DS3	Enables SONET, E1, and DS3 modes														
Protocol Mode	Description																																
SDH	Enables SDH mode																																
SONET	Enables SONET mode																																
Protocol Mode	Description																																
SDH_DS1_DS3	Enables SDH, DS1 and DS3 modes																																
SDH_E1_DS3	Enables SDH, E1, and DS3 modes																																
SDH_E1_E3	Enables SDH, E1, and E3 modes																																
SONET_DS1_DS3	Enables SONET, DS1, and DS3 modes																																
SONET_E1_DS3	Enables SONET, E1, and DS3 modes																																

Command	Description
PROTOCOL?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the protocol processor for its current mode of operation.
REMAINingtime?	<i>Protocols Supported:</i> ALL Returns the time remaining of the specified test in seconds. For a test that is running and has a finite duration (not CONTINUOUS), this time is the duration minus the elapsed time. A value of zero indicates the protocol processor is stopped. A value of "CONTINUOUS" indicates there is no end to the test.
INITiate <protocol processor or blank>	<i>Protocols Supported:</i> ALL Starts data acquisition for the selected protocol processor(s). When the INIT command is issued, it automatically stops the protocol processor and then starts data acquisition. There is no need to issue the ABORT command before using the INIT command. Note: If one of the protocol processors listed below has other protocol processors associated with it (for example, a drop/insert configuration), then those protocol processors are also started. For example, if the ROUTE S3 command is in effect, the INIT STM4 command will also initialize the E3/DS3 protocol processor. Valid protocol processor values are: <u>Protocol Processor</u> <blank> Starts the protocol processor currently selected by the INST command. Error code -224 appears if no instrument is selected. STM64 Starts the STM-64 protocol processor STM16 Starts the STM-16 protocol processor STM4 Starts the STM-4 protocol processor OC192 Starts the OC-192 protocol processor OC48 Starts the OC-48 protocol processor OC12 Starts the OC-12 protocol processor E4 Starts the E4 protocol processor E3 Starts the E3 protocol processor E1@N Starts the E1@N protocol processor DS3 Starts the DS3 protocol processor DS1@N Starts the DS1@N protocol processor ATM Starts the ATM protocol processor ALL Starts all protocol processors. Note: Although the ALL parameter is currently supported in SCPI release 2.0.51, it may not be supported for future major releases. If an error code appears when using the ALL parameter, then it is not supported in your SCPI release.
Note: A protocol processor has not been selected if error code -224 appears. Use the INST command to select a protocol. When using the ALL parameter, refer to the description listed to the right.	

Command	Description
INSTRument <protocol processor> (for all portable and rackmount products)	<i>Protocols Supported: ALL</i> Selects a specific circuit pack card installed in a unit. Additional parameters can be used when multiple circuit packs of the same class or type are installed.
INSTRument <slot ID*> <protocol processor> (for NIC Plus portable and NAA IV rackmount products)	For example, if two 2.5G circuit packs are installed in an NAA IV, one in slot 4 and one in slot 9, then one of the following commands must be used to select and control the second circuit pack installed in slot 9: INST 9 STM16 or INST 1 9 0 STM16
INSTRument <chassis ID**> <slot ID> <card ID**> <protocol processor> (for rackmount products only)	Chassis ID (optional) 0 = Chassis ID for a NIC Plus 1 = Chassis ID for an NAA IV
	Slot ID (optional) For a 23-inch NAA IV chassis, slots 1-6 and 8-13 can be selected. Slot 7 is reserved for the System Controller circuit pack. For a 19-inch NAA IV chassis, slots 1-5 and 7-10 can be selected. Slot 6 is reserved for the System Controller circuit pack.
* The slot ID parameter is only required when multiple circuit packs of the same type (for example two 2.5G circuit packs) are installed in a NIC Plus portable or NAA IV rackmount unit. If a slot ID is not specified, the command will default to the first circuit pack installed.	
** The chassis ID and card ID parameters are always optional and only applicable for NIC Plus portable and NAA IV rackmount products.	
Note: Use the GET:PROTOcols? command to view an inventory of all protocol processors (which includes the chassis ID, slot ID, and card ID) installed in the unit. This command is useful when multiple circuit packs of the same type are installed. Refer to the GET:PROTO? command for more information.	
	Card ID (optional) Card ID. Selects the circuit pack, within a slot, by its card number. This parameter is required when multiple Gigabit Ethernet circuit packs are installed. Use the GET:PROTO? command to determine a circuit pack's chassis, slot, and card IDs.
	Protocol Processor (required)
	NONE No protocol processor is selected.
	GIGE@N Selects the Gigabit Ethernet protocol processor and port (N= 1 or 2. N defaults to 1.)
	STM64Q@N Selects STM-64 Quad RX protocol processor (N=1, 2, 3, or 4. N automatically defaults to 1; therefore, STM64Q = STM64Q@1.)
	STM64 Selects STM-64 protocol processor
	STM16 Selects STM-16 protocol processor
	STM4 Selects STM-4 protocol processor
	OC192Q@N Selects OC-192 Quad RX protocol processor (N=1, 2, 3, or 4. N automatically defaults to 1; therefore, OC192Q = OC192Q@1.)
	OC192 Selects OC-192 protocol processor
	OC48 Selects OC-48 protocol processor
	OC12 Selects OC-12 protocol processor
	OSA Selects the Optical Spectrum Analyzer protocol processor
	E4 Selects E4 protocol processor
	E3 Selects E3 protocol processor
	E1@N Selects E1@N protocol processor (N=1 or 2)
	DS3 Selects DS3 protocol processor
	DS1@N Selects DS1@N protocol processor (N=1 or 2)
	ATM ATM protocol processor
	JITT12 Selects the OC-12 Jitter protocol processor

Command	Description																														
INSTRument? Note: A protocol processor has not been selected if error code -224 appears. Use the INST command to select a protocol.	<i>Protocols Supported:</i> ALL Queries which protocol is selected. Note: If issued for an NAA IV or NIC Plus product, the chassis ID, slot ID, and card ID are also returned. For example, 1 9 0 STM16.																														
LOGIN <ID> <password>	<i>Protocols Supported:</i> SYSTEM Logs in with a user ID and password, which contain only alphanumeric characters.																														
LOGOUT	<i>Protocols Supported:</i> SYSTEM Ends a remote session initiated by LOGIN.																														
REPORT:PRINT	<i>Protocols Supported:</i> ALL Print Results report for a protocol over the already assigned port.																														
ROUTe <preset>	<i>Protocols Supported:</i> ALL Chooses one of these preset routing configurations: <table border="1"> <thead> <tr> <th>Preset</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>S10L</td> <td>STM64/OC192 to Line Interface</td> </tr> <tr> <td>S10S</td> <td>STM64/OC192 to STM16/OC48 Drop/Insert</td> </tr> <tr> <td>S10SL</td> <td>STM64/OC192 to STM16/OC48 Line Interface Drop/Insert</td> </tr> <tr> <td>S2.5L</td> <td>STM16/OC48 to Line Interface (no STM64/OC192 Drop/Insert)</td> </tr> <tr> <td>S2.5S</td> <td>STM-16 to STM-4 Drop/Insert</td> </tr> <tr> <td>SL</td> <td>STM-4/OC-12 to Line Interface</td> </tr> <tr> <td>S1@N</td> <td>STM-4/OC-12 Drop/Insert to E1/DS1 protocol processor instance N</td> </tr> <tr> <td>S3</td> <td>STM-4/OC-12 Drop/Insert to E3/DS3 protocol processor</td> </tr> <tr> <td>S4</td> <td>STM-4/OC-12 Drop/Insert to E4 protocol processor</td> </tr> <tr> <td>43</td> <td>E4 Line Interface to E3 Line interface</td> </tr> <tr> <td>4L</td> <td>E4 Line Interface to E4 Processor</td> </tr> <tr> <td>31@N</td> <td>E3/DS3 Line Interface to E1/DS1 processor instance N</td> </tr> <tr> <td>3L</td> <td>E3/DS3 Line Interface to E3/DS3 processor</td> </tr> <tr> <td>1L@N</td> <td>E1/DS1 Line Interface to E1/DS1 processor instance N</td> </tr> </tbody> </table>	Preset	Description	S10L	STM64/OC192 to Line Interface	S10S	STM64/OC192 to STM16/OC48 Drop/Insert	S10SL	STM64/OC192 to STM16/OC48 Line Interface Drop/Insert	S2.5L	STM16/OC48 to Line Interface (no STM64/OC192 Drop/Insert)	S2.5S	STM-16 to STM-4 Drop/Insert	SL	STM-4/OC-12 to Line Interface	S1@N	STM-4/OC-12 Drop/Insert to E1/DS1 protocol processor instance N	S3	STM-4/OC-12 Drop/Insert to E3/DS3 protocol processor	S4	STM-4/OC-12 Drop/Insert to E4 protocol processor	43	E4 Line Interface to E3 Line interface	4L	E4 Line Interface to E4 Processor	31@N	E3/DS3 Line Interface to E1/DS1 processor instance N	3L	E3/DS3 Line Interface to E3/DS3 processor	1L@N	E1/DS1 Line Interface to E1/DS1 processor instance N
Preset	Description																														
S10L	STM64/OC192 to Line Interface																														
S10S	STM64/OC192 to STM16/OC48 Drop/Insert																														
S10SL	STM64/OC192 to STM16/OC48 Line Interface Drop/Insert																														
S2.5L	STM16/OC48 to Line Interface (no STM64/OC192 Drop/Insert)																														
S2.5S	STM-16 to STM-4 Drop/Insert																														
SL	STM-4/OC-12 to Line Interface																														
S1@N	STM-4/OC-12 Drop/Insert to E1/DS1 protocol processor instance N																														
S3	STM-4/OC-12 Drop/Insert to E3/DS3 protocol processor																														
S4	STM-4/OC-12 Drop/Insert to E4 protocol processor																														
43	E4 Line Interface to E3 Line interface																														
4L	E4 Line Interface to E4 Processor																														
31@N	E3/DS3 Line Interface to E1/DS1 processor instance N																														
3L	E3/DS3 Line Interface to E3/DS3 processor																														
1L@N	E1/DS1 Line Interface to E1/DS1 processor instance N																														
SCPI?	<i>Protocols Supported:</i> SYSTEM Queries the SCPI processor to see if it is attached to the port used. Returns "YES" if the SCPI processor is attached to that port and is processing commands.																														
TEST:EXECute <test name> Note: This command is only valid when tests have been defined using the Element Management System software.	<i>Protocols Supported:</i> ALL Executes a test. Use the TEST:NAMeS? command to display a list of defined test configurations stored on the system.																														
TEST:NAMeS? Note: This command is only valid when tests have been defined using the Element Management System software.	<i>Protocols Supported:</i> ALL Queries which test names are available in the system. A test configuration contains the duration, criteria, and protocol processors used to perform a test. The test configurations are stored on the system and are assigned a test name.																														
TEST:PROTOcols <test name>? Note: This command is only valid when tests have been defined using the Element Management System software.	<i>Protocols Supported:</i> ALL Queries which protocol processors are associated with the entered test name.																														

Command	Description
TEST:STOP <test name> Note: This command is only valid when tests have been defined using the Element Management System software.	<i>Protocols Supported: ALL</i> Stops a test. Use the TEST:NAMES? command to display a list of defined test configurations stored on the system.

3

Extended SCPI Commands

Overview

This chapter lists the Standard SCPI commands supported by the configured unit. You may not have access to all commands based on the product configuration you purchased. SCPI commands are fully compatible across all DLI products.

The majority of commands listed in this chapter are intended for the OC-192, OC-48, OC-1/3/12, STM-64, STM-16, STM-0/1/4, E4, E3, E1, DS3, and DS1 protocol processors. ALL indicates that the command is supported by all of the previously listed protocol processors.

- n For ATM-specific commands, refer to **Chapter 4**, ATM SCPI Commands
- n For GigE-specific commands, refer to **Chapter 5**, Gigabit Ethernet SCPI Commands
- n For OSA-specific commands, refer to **Chapter 6**, OSA SCPI Commands

Extended SCPI Commands

These commands are extensions to the SCPI command set. These commands are adapted to the configured unit and are unique to each protocol processor. SCPI commands should be typed on one single line completed with a hard carriage return. These commands require zero or one parameters, and return zero or one values.

RES (Fetch) Branch

The RES branch is used to retrieve results. Alternatively, each command can be sent using the "FETC" or "FETCH" keyword instead of the "RES" keyword.

The following is a list of supported RESULT commands.

RESULT Command	Description
RES:AIS:Secs?	<i>Protocols Supported:</i> E1, E3, E4, DS3, D1 Seconds for which there was an AIS alarm.
RES:AIS:HP:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Seconds for which there was an HP-AIS alarm.
RES:AIS:LINE:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Seconds for which there was a Line AIS alarm.
RES:AIS:MS:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Seconds for which there was an MS-AIS alarm.
RES:AIS:PATH:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Seconds for which there was a Path AIS alarm.
RES:AIS:TU:Secs?	<i>Protocols Supported:</i> STM-4 Seconds for which there was a TU-AIS alarm.

RESULT Command	Description																																																																																													
RES:AIS:VT:Secs?	Protocols Supported: OC-12 Seconds for which there was a VT-AIS alarm.																																																																																													
RES:ALarm:<alarm type>?	<p><i>Protocols Supported: ALL</i> Queries and reports the state (On or Off) of the selected alarm LED.</p> <table border="1"> <thead> <tr> <th><u>Alarm Type</u></th> <th><u>Protocol Processors</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>AIS</td> <td>E1, E3, E4, DS3, DS1</td> <td>Alarm Indication Signal</td> </tr> <tr> <td>AISL</td> <td>OC-12, OC-48, OC-192</td> <td>Line Alarm Indication Signal</td> </tr> <tr> <td>AISP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Alarm Indication Signal</td> </tr> <tr> <td>AISV</td> <td>OC-12</td> <td>VT Alarm Indication Signal</td> </tr> <tr> <td>IDLE</td> <td>DS1, DS3</td> <td>Idle alarm</td> </tr> <tr> <td>LOS</td> <td>E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3</td> <td>Loss of Signal</td> </tr> <tr> <td>LOF</td> <td>E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</td> <td>Loss of Frame</td> </tr> <tr> <td>LOPP</td> <td>OC-12, OC-48, OC-192</td> <td>Loss of Pointer Path</td> </tr> <tr> <td>OOF</td> <td>DS1, DS3</td> <td>Out of Frame</td> </tr> <tr> <td>RAI</td> <td>E1, E3, E4</td> <td>Remote Alarm Indication</td> </tr> <tr> <td>YELLOW</td> <td>DS1, DS3</td> <td>Yellow alarm (RAI)</td> </tr> <tr> <td>RDIL</td> <td>OC-12, OC-48, OC-192</td> <td>Line Remote Defect Indication</td> </tr> <tr> <td>RDIP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Remote Defect Indication</td> </tr> <tr> <td>RDIV</td> <td>OC-12</td> <td>VT Remote Defect Indication</td> </tr> <tr> <td>RFIV</td> <td>OC-12</td> <td>VT RFI</td> </tr> <tr> <td>RMFAI</td> <td>E1</td> <td>Remote Multi-Frame Alarm Indicator</td> </tr> <tr> <td>CASMFL</td> <td>E1</td> <td>Channel-Associated Signaling Multi Frame Loss</td> </tr> <tr> <td>MSAIS</td> <td>STM-4, STM-16, STM-64</td> <td>MS-AIS</td> </tr> <tr> <td>MSRDI</td> <td>STM-4, STM-16, STM-64</td> <td>MS-RDI</td> </tr> <tr> <td>AUAIS</td> <td>STM-4, STM-16, STM-64</td> <td>AU-AIS</td> </tr> <tr> <td>AULOP</td> <td>STM-4, STM-16, STM-64</td> <td>AU-LOP</td> </tr> <tr> <td>HPUNEQ</td> <td>STM-4, STM-16, STM-64</td> <td>HP-UNEQ</td> </tr> <tr> <td>HPRDI</td> <td>STM-4, STM-16, STM-64</td> <td>HP-RDI</td> </tr> <tr> <td>TUAIS</td> <td>STM-4</td> <td>TU-AIS</td> </tr> <tr> <td>TULOP</td> <td>STM-4</td> <td>TU-Loss of Pointer</td> </tr> <tr> <td>LPUNEQ</td> <td>STM-4</td> <td>LP-Unequipped</td> </tr> <tr> <td>LPRDI</td> <td>STM-4</td> <td>LP-RDI</td> </tr> <tr> <td>LPRFI</td> <td>STM-4</td> <td>LP-RFI</td> </tr> <tr> <td>UNEQP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Unequipped</td> </tr> <tr> <td>UNEQV</td> <td>OC-12</td> <td>VT Unequipped</td> </tr> </tbody> </table>	<u>Alarm Type</u>	<u>Protocol Processors</u>	<u>Meaning</u>	AIS	E1, E3, E4, DS3, DS1	Alarm Indication Signal	AISL	OC-12, OC-48, OC-192	Line Alarm Indication Signal	AISP	OC-12, OC-48, OC-192	Path Alarm Indication Signal	AISV	OC-12	VT Alarm Indication Signal	IDLE	DS1, DS3	Idle alarm	LOS	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3	Loss of Signal	LOF	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192	Loss of Frame	LOPP	OC-12, OC-48, OC-192	Loss of Pointer Path	OOF	DS1, DS3	Out of Frame	RAI	E1, E3, E4	Remote Alarm Indication	YELLOW	DS1, DS3	Yellow alarm (RAI)	RDIL	OC-12, OC-48, OC-192	Line Remote Defect Indication	RDIP	OC-12, OC-48, OC-192	Path Remote Defect Indication	RDIV	OC-12	VT Remote Defect Indication	RFIV	OC-12	VT RFI	RMFAI	E1	Remote Multi-Frame Alarm Indicator	CASMFL	E1	Channel-Associated Signaling Multi Frame Loss	MSAIS	STM-4, STM-16, STM-64	MS-AIS	MSRDI	STM-4, STM-16, STM-64	MS-RDI	AUAIS	STM-4, STM-16, STM-64	AU-AIS	AULOP	STM-4, STM-16, STM-64	AU-LOP	HPUNEQ	STM-4, STM-16, STM-64	HP-UNEQ	HPRDI	STM-4, STM-16, STM-64	HP-RDI	TUAIS	STM-4	TU-AIS	TULOP	STM-4	TU-Loss of Pointer	LPUNEQ	STM-4	LP-Unequipped	LPRDI	STM-4	LP-RDI	LPRFI	STM-4	LP-RFI	UNEQP	OC-12, OC-48, OC-192	Path Unequipped	UNEQV	OC-12	VT Unequipped
<u>Alarm Type</u>	<u>Protocol Processors</u>	<u>Meaning</u>																																																																																												
AIS	E1, E3, E4, DS3, DS1	Alarm Indication Signal																																																																																												
AISL	OC-12, OC-48, OC-192	Line Alarm Indication Signal																																																																																												
AISP	OC-12, OC-48, OC-192	Path Alarm Indication Signal																																																																																												
AISV	OC-12	VT Alarm Indication Signal																																																																																												
IDLE	DS1, DS3	Idle alarm																																																																																												
LOS	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3	Loss of Signal																																																																																												
LOF	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192	Loss of Frame																																																																																												
LOPP	OC-12, OC-48, OC-192	Loss of Pointer Path																																																																																												
OOF	DS1, DS3	Out of Frame																																																																																												
RAI	E1, E3, E4	Remote Alarm Indication																																																																																												
YELLOW	DS1, DS3	Yellow alarm (RAI)																																																																																												
RDIL	OC-12, OC-48, OC-192	Line Remote Defect Indication																																																																																												
RDIP	OC-12, OC-48, OC-192	Path Remote Defect Indication																																																																																												
RDIV	OC-12	VT Remote Defect Indication																																																																																												
RFIV	OC-12	VT RFI																																																																																												
RMFAI	E1	Remote Multi-Frame Alarm Indicator																																																																																												
CASMFL	E1	Channel-Associated Signaling Multi Frame Loss																																																																																												
MSAIS	STM-4, STM-16, STM-64	MS-AIS																																																																																												
MSRDI	STM-4, STM-16, STM-64	MS-RDI																																																																																												
AUAIS	STM-4, STM-16, STM-64	AU-AIS																																																																																												
AULOP	STM-4, STM-16, STM-64	AU-LOP																																																																																												
HPUNEQ	STM-4, STM-16, STM-64	HP-UNEQ																																																																																												
HPRDI	STM-4, STM-16, STM-64	HP-RDI																																																																																												
TUAIS	STM-4	TU-AIS																																																																																												
TULOP	STM-4	TU-Loss of Pointer																																																																																												
LPUNEQ	STM-4	LP-Unequipped																																																																																												
LPRDI	STM-4	LP-RDI																																																																																												
LPRFI	STM-4	LP-RFI																																																																																												
UNEQP	OC-12, OC-48, OC-192	Path Unequipped																																																																																												
UNEQV	OC-12	VT Unequipped																																																																																												
RES:APS:Secs?	<p><i>Protocols Supported: STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</i> Seconds for which there was an APS alarm (event). Also known as a K1K2 alarm.</p>																																																																																													

RESULT Command	Description
RES:APS:LOG:?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries the log of the last 15 APS commands received. Commands are returned in comma-delimited format, similar to the <i>TX:APS:SEQ</i> command. Each has three values: K1, K2, Frames. If frames is zero for a row, then that indicates no entry for that row (this will happen if there are less than 15 commands received in the log). The log is refreshed at restart. 65535 in the number of frames indicates continuous, or a larger number of frames than 65534.
RES:APS:STATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current status of the automatic protection switch (APS) function. The following values can be returned for this command: APS STOP:Indicates that the APS function is stopped. ARMED APS SINGLE:Indicates that the APS test is configured for single round-trip delay operation. RUNNING APS SINGLE: Indicates that an APS test is in progress using the single round-trip delay configuration. ARMED APS CONTINUOUS: Indicates that the APS test is configured for continuous round-trip delay operation. RUNNING APS CONTINUOUS: Indicates that an APS test is in progress using the continuous round-trip delay configuration.
RES:APS:TIME:LAST?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current/last APS duration (measured in seconds) of an APS test.
RES:APS:TIME:MIN?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the fastest APS (in seconds) measured during the APS test.
RES:APS:TIME:MAX?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the slowest APS (in seconds) measured during the APS test.
RES:APS:FRAME:LAST?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current/last frame count of an APS test.
RES:APS:FRAME:MIN?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the frame count for the fastest APS measured during the APS test.
RES:APS:FRAME:MAX?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the frame count for the slowest APS measured during the APS test.
RES:B1:AVERage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the average B1 error rate.
RES:B1:COUNT?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the B1 error count.
RES:B1:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the current B1 error rate.
RES:B1:BBE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the B1 background block error count.
RES:B1:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds there were B1 Errors using ANSI rules.

RESULT Command	Description
RES:B1:ES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B1 errors using G.821 rules.
RES:B1:ES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B1 errors using G.826 rules.
RES:B1:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of B1 Severely Errored Seconds using ANSI rules.
RES:B1:SES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B1 severely errored seconds using G.821 rules.
RES:B1:SES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B1 severely errored seconds using G.826 rules.
RES:B2:AVERage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the average B2 error rate.
RES:B2:COUNt?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the B2 error count.
RES:B2:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the current B2 error rate.
RES:B2:BBE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the B2 background block error count.
RES:B2:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds there were B2 Errors using ANSI rules.
RES:B2:ES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B2 errors using G.821 rules.
RES:B2:ES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B2 errors using G.826 rules.
RES:B2:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of B2 Severely Errored Seconds using ANSI rules.
RES:B2:SES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B2 severely errored seconds using G.821 rules.
RES:B2:SES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B2 severely errored seconds using G.826 rules.
RES:B2:UAS:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of B2 Unavailable Seconds using ANSI rules.
RES:B2:UAS:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B2 unavailable seconds using G.821 rules.
RES:B2:UAS:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B2 unavailable seconds using G.826 rules.
RES:B3:AVERage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the average B3 error rate.
RES:B3:COUNt?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the B3 error count.
RES:B3:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the current B3 error rate.
RES:B3:BBE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the B3 background block error count.
RES:B3:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds there were B3 Errors using ANSI rules.

RESULT Command	Description
RES:B3:ES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B3 errors using G.821 rules.
RES:B3:ES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were B3 errors using G.826 rules.
RES:B3:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of B3 Severely Errored Seconds using ANSI rules.
RES:B3:SES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B3 severely errored seconds using G.821 rules.
RES:B3:SES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B3 severely errored seconds using G.826 rules.
RES:B3:UAS:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of B3 Unavailable Seconds using ANSI rules.
RES:B3:UAS:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B3 unavailable seconds using G.821 rules.
RES:B3:UAS:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of B3 unavailable seconds using G.826 rules.
RES:BIP:LP:AVERage?	<i>Protocols Supported:</i> STM-4 Queries and reports the average LP-BIP error rate.
RES:BIP:LP:COUNt?	<i>Protocols Supported:</i> STM-4 Queries the LP-BIP error count.
RES:BIP:LP:RATE?	<i>Protocols Supported:</i> STM-4 Queries and reports the current LP-BIP error rate.
RES:BIP:LP:BBE?	<i>Protocols Supported:</i> STM-4 Queries the current LP-BIP background block error count.
RES:BIP:LP:ES:821?	<i>Protocols Supported:</i> STM-4 Queries the number of seconds there were LP-BIP errors using G.821 rules.
RES:BIP:LP:ES:826?	<i>Protocols Supported:</i> STM-4 Queries the number of seconds there were LP-BIP errors using G.826 rules.
RES:BIP:LP:SES:821?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-BIP severely errored seconds using G.821 rules.
RES:BIP:LP:SES:826?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-BIP severely errored seconds using G.826 rules.
RES:BIP:LP:UAS:821?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-BIP unavailable seconds using G.821 rules.
RES:BIP:LP:UAS:826?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-BIP unavailable seconds using G.826 rules.
RES:BIP:VT:AVERage?	Queries and reports the average VT-BIP error rate.
RES:BIP:VT:COUNt?	<i>Protocols Supported:</i> OC-12 Queries the VT-BIP error count.
RES:BIP:VT:RATE?	<i>Protocols Supported:</i> OC-12 Queries the current VT-BIP error rate.
RES:BIP:VT:ES:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of seconds there were VT-BIP errors using ANSI rules.

RESULT Command	Description
RES:BIP:VT:SES:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of VT-BIP severely errored seconds using ANSI rules.
RES:BIP:VT:UAS:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of VT-BIP unavailable seconds using ANSI rules.
RES:BIT:AVERage?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the average bit error rate.
RES:BIT:COUNt?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the bit error count.
RES:BIT:RATE?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the bit error rate.
RES:BIT:BBE?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of bit background block errors.
RES:BIT:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192, DS3, DS1 Queries the number of seconds there were BIT Errors using ANSI rules.
RES:BIT:ES:821?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of seconds there were bit errors using G.821 rules.
RES:BIT:ES:826?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of seconds there were bit errors using G.826 rules.
RES:BIT:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192, DS3, DS1 Queries the number of BIT Severely Errored Seconds using ANSI rules.
RES:BIT:SES:821?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of bit severely errored seconds using G.821 rules.
RES:BIT:SES:826?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of bit severely errored seconds using G.826 rules.
RES:BIT:UAS:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192, DS3, DS1 Queries the number of BIT Unavailable Seconds using ANSI rules.
RES:BIT:UAS:821?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of bit unavailable seconds using G.821 rules.
RES:BIT:UAS:826?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64 Queries the number of bit unavailable seconds using G.826 rules.
RES:BPV:AVERage?	<i>Protocols Supported:</i> E1, E3, STM-4, DS3, DS1, OC-12 Queries and reports the average bipolar violation error rate.
RES:BPV:COUNt?	<i>Protocols Supported:</i> E1, E3, STM-4, DS3, DS1, OC-12 Queries the bipolar violation count.
RES:BPV:RATE?	<i>Protocols Supported:</i> E1, E3, STM-4, DS3, DS1, OC-12 Queries the bipolar violation error rate.
RES:CLOCK:Secs?	<i>Protocols Supported:</i> DS3, DS1 Queries and reports the number of seconds that there was a loss of clock alarm.
RES:CPPAR:AVERage?	<i>Protocols Supported:</i> DS3 Queries and reports the average CP-bit parity error rate.
RES:CPPAR:COUNt?	<i>Protocols Supported:</i> DS3 Queries the CP-bit parity error count.

RESULT Command	Description
RES:CPPAR:RATE?	<i>Protocols Supported:</i> DS3 Queries the current CP-bit parity error rate.
RES:CRC:AVERage?	<i>Protocols Supported:</i> E1, DS1 Queries and reports the average CRC error rate.
RES:CRC:COUNt?	<i>Protocols Supported:</i> E1, DS1 Queries the current CRC error count.
RES:CRC:RATE?	<i>Protocols Supported:</i> E1, DS1 Queries the current CRC error rate.
RES:CRC:BBE?	<i>Protocols Supported:</i> E1 Queries the number of CRC background block errors.
RES:CRC:ES:821?	<i>Protocols Supported:</i> E1 Queries the number of seconds there were CRC errors using G.821 rules.
RES:CRC:ES:826?	<i>Protocols Supported:</i> E1 Queries the number of seconds there were CRC errors using G.826 rules.
RES:CRC:SES:821?	<i>Protocols Supported:</i> E1 Queries the number of CRC severely errored seconds using G.821 rules.
RES:CRC:SES:826?	<i>Protocols Supported:</i> E1 Queries the number of CRC severely errored seconds using G.826 rules.
RES:CRC:UAS:821?	<i>Protocols Supported:</i> E1 Queries the number of CRC unavailable seconds using G.821 rules.
RES:CRC:UAS:826?	<i>Protocols Supported:</i> E1 Queries the number of CRC unavailable seconds using G.826 rules.
RES:EXZ:AVERage?	<i>Protocols Supported:</i> DS1 Queries and reports the average error rate for excessive zero errors.
RES:EXZ:COUNt?	<i>Protocols Supported:</i> DS1 Queries and reports the excessive zeros error count.
RES:EXZ:RATE?	<i>Protocols Supported:</i> DS1 Queries and reports the current excessive zeros error rate.
RES:FEBE:AVERage?	<i>Protocols Supported:</i> E1, DS3 Queries and reports the average FEBE error rate.
RES:FEBE:COUNt?	<i>Protocols Supported:</i> E1, DS3 Queries the current FEBE count for PDH and DS3.
RES:FEBE:RATE?	<i>Protocols Supported:</i> E1, DS3 Queries the current PDH and DS3 FEBE error rate.
RES:FEBE:BBE?	<i>Protocols Supported:</i> E1 Queries the number of FEBE background block errors.
RES:FEBE:ES:821?	<i>Protocols Supported:</i> E1 Queries the number of seconds there were FEBE errors using G.821 rules.
RES:FEBE:ES:826?	<i>Protocols Supported:</i> E1 Queries the number of seconds there were FEBE errors using G.826 rules.
RES:FEBE:SES:821?	<i>Protocols Supported:</i> E1 Queries the number of FEBE severely errored seconds using G.821.
RES:FEBE:SES:826?	<i>Protocols Supported:</i> E1 Queries the number of FEBE severely errored seconds using G.826.
RES:FEBE:UAS:821?	<i>Protocols Supported:</i> E1 Queries the number of FEBE unavailable seconds using G.821.

RESULT Command	Description
RES:FEBE:UAS:826?	<i>Protocols Supported:</i> E1 Queries the number of FEBE unavailable seconds using G.826.
RES:FRAME:AVERage?	<i>Protocols Supported:</i> E1, E3, E4, DS3, DS1 Queries and reports the average frame error rate.
RES:FRAME:COUNt?	<i>Protocols Supported:</i> E1, E3, E4, DS3, DS1 Queries the current frame error count.
RES:FRAME:RATE?	<i>Protocols Supported:</i> E1, E3, E4, DS3, DS1 Queries the current frame error rate.
RES:FRAME:ES:821?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of seconds there were frame errors using G.821 rules.
RES:FRAME:ES:826?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of seconds there were frame errors using G.826 rules.
RES:FRAME:SES:821?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of frame severely errored seconds using G.821 rules.
RES:FRAME:SES:826?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of frame severely errored seconds using G.826 rules.
RES:FRAME:UAS:821?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of frame unavailable seconds using G.821 rules.
RES:FRAME:UAS:826?	<i>Protocols Supported:</i> E1, E3, E4 Queries the number of frame unavailable seconds using G.826 rules.
RES:IDLE:Secs?	<i>Protocols Supported:</i> DS3, DS1 Queries and reports the number of seconds that there was an Idle alarm.
RES:LCV:AVERage?	<i>Protocols Supported:</i> E4 Queries and reports the average Line Code Violation error rate.
RES:LCV:COUNt?	<i>Protocols Supported:</i> E4 Queries the Line Code Violation count.
RES:LCV:RATE?	<i>Protocols Supported:</i> E4 Queries the Line Code Violation error rate.
RES:LOF:Secs?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the number of seconds a loss of frame was present.
RES:LOP:AU:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds an AU Loss of pointer alarm was present.
RES:LOP:STS:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds an STS (Path) Loss of pointer alarm was present.
RES:LOP:TU:Secs?	<i>Protocols Supported:</i> STM-4 Queries the number of seconds a TU Loss of pointer alarm was present.
RES:LOP:VT:Secs?	<i>Protocols Supported:</i> OC-12 Queries the number of seconds a VT Loss of pointer alarm was present.
RES:LOS:Secs?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1, Jitter Queries the number of seconds a loss of signal was present.
RES:NDF:AU?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the AU NDF count.

RESULT Command	Description
RES:NDF:TU?	<i>Protocols Supported:</i> STM-4 Returns the TU NDF count.
RES:NDF:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the STS NDF count.
RES:NDF:VT?	<i>Protocols Supported:</i> OC-12 Returns the VT NDF count.
RES:NDFERRor:AU:AVERage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries and reports the average SDH AU-NDF error rate.
RES:NDFERRor:AU:COUNT?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the SDH AU-NDF error count.
RES:NDFERRor:AU:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the SDH AU-NDF error rate.
RES:NDFERRor:STS:AVERage?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries and reports the average SONET STS-NDF Error Rate.
RES:NDFERRor:STS:COUNT?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the SONET STS-NDF Error Count.
RES:NDFERRor:STS:RATE?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the SONET STS-NDF Error Rate.
RES:NDFERRor:TU:AVERage?	<i>Protocols Supported:</i> STM-4 Queries and reports the average SDH TU-NDF error rate.
RES:NDFERRor:TU:COUNT?	<i>Protocols Supported:</i> STM-4 Queries the SDH TU-NDF error count.
RES:NDFERRor:TU:RATE?	<i>Protocols Supported:</i> STM-4 Queries the SDH TU-NDF error rate.
RES:NDFERRor:VT:AVERage?	<i>Protocols Supported:</i> OC-12 Queries and reports the average SONET VT-NDF error rate.
RES:NDFERRor:VT:COUNT?	<i>Protocols Supported:</i> OC-12 Queries the SONET VT-NDF error count.
RES:NDFERRor:VT:RATE?	<i>Protocols Supported:</i> OC-12 Queries the SONET VT-NDF error rate.
RES:NPJC:AU?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the number of negative AU Pointer justifications.
RES:NPJC:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the number of negative STS Pointer justifications.
RES:NPJC:TU?	<i>Protocols Supported:</i> STM-4 Returns the number of negative TU Pointer justifications.
RES:NPJC:VT?	<i>Protocols Supported:</i> OC-12 Returns the number of negative VT Pointer justifications.
RES:OOF:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, DS3, DS1 Out of frame seconds.
RES:PATsync:Secs?	<i>Protocols Supported:</i> ALL Seconds for which there was loss of pattern.
RES:PJCS:AU?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the number of seconds there was a negative or positive AU Pointer justification.

RESULT Command	Description
RES:PJCS:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the number of seconds there was a negative or positive STS Pointer justification.
RES:PJCS:TU?	<i>Protocols Supported:</i> STM-4 Returns the number of seconds there was a negative or positive TU Pointer justification.
RES:PJCS:VT?	<i>Protocols Supported:</i> OC-12 Returns the number of seconds there was a negative or positive VT Pointer justification.
RES:PLM:HP:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the number of HP Label Mismatch seconds.
RES:PLM:LP:Secs?	<i>Protocols Supported:</i> STM-4 Returns the number of LP Label Mismatch seconds.
RES:PLM:PATH:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Path Label Mismatch seconds.
RES:PLM:PATH:VT:Secs?	<i>Protocols Supported:</i> OC-12 VT Label Mismatch seconds.
RES:PPAR:AVeRage?	<i>Protocols Supported:</i> DS3 Queries and reports the average P-bit parity error rate.
RES:PPAR:COUNt?	<i>Protocols Supported:</i> DS3 Queries the P-bit parity error count.
RES:PPAR:RAte?	<i>Protocols Supported:</i> DS3 Queries the P-bit parity error rate.
RES:PPJC:Au?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the number of positive AU Pointer justifications.
RES:PJCS:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the number of seconds there was a negative or positive STS Pointer justification.
RES:PPJC:TU?	<i>Protocols Supported:</i> STM-4 Returns the number of positive TU Pointer justifications.
RES:PPJC:VT?	<i>Protocols Supported:</i> OC-12 Returns the number of positive VT Pointer justifications.
RES:RDI:HP:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Seconds for which there was an HP-RDI alarm.
RES:RDI:LINE:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Seconds for which there was an RDI-L alarm.
RES:RDI:LP:Secs?	<i>Protocols Supported:</i> STM-4 Seconds for which there was an LP-RDI alarm.
RES:RDI:MS:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Seconds for which there was an MS-RDI alarm.
RES:RDI:PATH:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Seconds for which there was an RDI-P alarm.
RES:RDI:VT:Secs?	<i>Protocols Supported:</i> OC-12 Seconds for which there was an RDI-VT alarm.
RES:REI:HP:AVeRage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the average HP-REI error rate.

RESULT Command	Description
RES:REI:HP:COUNt?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the HP-REI error count.
RES:REI:HP:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the HP-REI error rate.
RES:REI:HP:BBE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the HP-REI background block error count.
RES:REI:HP:ES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were HP-REI errors using G.821 rules.
RES:REI:HP:ES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were HP-REI errors using G.826 rules.
RES:REI:HP:SES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP-REI severely errored seconds using G.821 rules.
RES:REI:HP:SES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP-REI severely errored seconds using G.826 rules.
RES:REI:HP:UAS:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP-REI unavailable seconds using G.821 rules.
RES:REI:HP:UAS:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP-REI unavailable seconds using G.826 rules.
RES:REI:LINE:AVERage?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the average LINE-REI rate.
RES:REI:LINE:COUNt?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the current LINE-REI count using ANSI rules.
RES:REI:LINE:RATE?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the current LINE-REI error rate.
RES:REI:LINE:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds there were LINE-REI Errors.
RES:REI:LINE:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of LINE-REI Severely Errored Seconds.
RES:REI:LINE:UAS:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of LINE-REI Unavailable Seconds.
RES:REI:LP:AVERage?	<i>Protocols Supported:</i> STM-4 Queries the average LP-REI error rate.
RES:REI:LP:COUNt?	<i>Protocols Supported:</i> STM-4 Queries the LP-REI error count.
RES:REI:LP:RATE?	<i>Protocols Supported:</i> STM-4 Queries the LP-REI error rate.
RES:REI:LP:BBE?	<i>Protocols Supported:</i> STM-4 Queries the LP-REI background block error count.
RES:REI:LP:ES:821?	<i>Protocols Supported:</i> STM-4 Queries the number of seconds there were LP-REI errors using G.821 rules.
RES:REI:LP:ES:826?	<i>Protocols Supported:</i> STM-4 Queries the number of seconds there were LP-REI errors using G.826 rules.

RESULT Command	Description
RES:REI:LP:SES:821?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-REI severely errored seconds using G.821 rules.
RES:REI:LP:SES:826?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-REI severely errored seconds using G.826 rules.
RES:REI:LP:UAS:821?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-REI unavailable seconds using G.821 rules.
RES:REI:LP:UAS:826?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-REI unavailable seconds using G.826 rules.
RES:REI:MS:AVERage?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the average MS-REI error rate.
RES:REI:MS:COUNT?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the current MS-REI count.
RES:REI:MS:RATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the current MS-REI error rate.
RES:REI:MS:BBE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the MS-REI background block error count.
RES:REI:MS:ES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were MS-REI errors using G.821 rules.
RES:REI:MS:ES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of seconds there were MS-REI errors using G.826 rules.
RES:REI:MS:SES:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of MS-REI severely errored seconds using G.821 rules.
RES:REI:MS:SES:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of MS-REI severely errored seconds using G.826 rules.
RES:REI:MS:UAS:821?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of MS-REI unavailable seconds using G.821 rules.
RES:REI:MS:UAS:826?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of MS-REI unavailable seconds using G.826 rules.
RES:REI:PATH:AVERage?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the average PATH-REI error rate.
RES:REI:PATH:COUNT?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the current PATH-REI count.
RES:REI:PATH:RATE?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the current PATH-REI error rate.
RES:REI:PATH:ES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of seconds there were PATH-REI Errors using ANSI rules.
RES:REI:PATH:SES:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of PATH-REI Severely Errored Seconds using ANSI rules.
RES:REI:PATH:UAS:ANSI?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Queries the number of PATH-REI Unavailable Seconds using ANSI rules.

RESULT Command	Description
RES:REI:VT:AVERage?	<i>Protocols Supported:</i> OC-12 Queries and reports the average VT-REI error rate.
RES:REI:VT:COUNT?	<i>Protocols Supported:</i> OC-12 Queries the current VT-REI count.
RES:REI:VT:RATE?	<i>Protocols Supported:</i> OC-12 Queries the current VT-REI error rate.
RES:REI:VT:ES:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of seconds there were VT-REI errors using ANSI rules.
RES:REI:VT:SES:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of VT-REI severely errored seconds using ANSI rules.
RES:REI:VT:UAS:ANSI?	<i>Protocols Supported:</i> OC-12 Queries the number of VT-REI unavailable seconds using ANSI rules.
RES:RFI:LP:Secs?	<i>Protocols Supported:</i> STM-4 Queries the number of LP-RFI alarm seconds.
RES:RFI:VT:Secs?	<i>Protocols Supported:</i> OC-12 Queries the duration of a detected VT-RFI alarm.
RES:RTD:STATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current status of the round-trip delay (RTD) function. The following values can be returned for this command: RTD STOP: Indicates that the round-trip delay function is stopped. ARMED RTD SINGLE: Indicates that the RTD test is configured for single round-trip delay operation. RUNNING RTD SINGLE: Indicates that an RTD test is in progress using the single round-trip delay configuration. ARMED RTD CONTINUOUS: Indicates that the RTD test is configured for continuous round-trip delay operation. RUNNING RTD CONTINUOUS: Indicates that an RTD test is in progress using the continuous round-trip delay configuration.
RES:RTD:TIME:LAST?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current/last RTD duration (measured in seconds) of an RTD test.
RES:RTD:TIME:MIN?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the fastest RTD (in seconds) measured during the RTD test.
RES:RTD:TIME:MAX?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the slowest RTD (in seconds) measured during the RTD test.
RES:RTD:FRAME:LAST?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current/last frame count of an RTD test.
RES:RTD:FRAME:MIN?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the frame count for the fastest RTD measured during the RTD test.
RES:RTD:FRAME:MAX?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the frame count for the slowest RTD measured during the RTD test.
RES:SEF:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Severely Errored Frame seconds.

RESULT Command	Description
RES:SPM?	ax REI-V/LP-REI errors seconds
(continued)	ay LOM-V/TU-LOM alarm seconds
	az NDF-V/TU-NDF errors seconds
	ba AIS-V/TU-AIS alarm seconds
	bb LOP-V/TU-LOP alarm seconds
	bc UNEQ-V/TU-UNEQ alarm seconds
	bd PLM-V/LP-PLM alarm seconds
	be RDI-V/LP-RDI alarm seconds
	bf TIM-V/LP-TIM alarm seconds
	bg RFI-V/LP-RFI alarm seconds
	bh PAT SYNC alarm seconds
	bi Power Loss alarm seconds
	bj PP Paused alarm seconds

For OC-1/3/12 and STM-0/1/4, the average error, error rate, and current error rate counts appear as follows:

B1 errors

da average error rate (in scientific notation, 0.00e+00)
 db error rate (in scientific notation, 0.00e+00)
 dc error count

B2 errors

dd average error rate (in scientific notation, 0.00e+00)
 de error rate (in scientific notation, 0.00e+00)
 df error count

REI-L/MS-REI errors

dg average error rate (in scientific notation, 0.00e+00)
 dh error rate (in scientific notation, 0.00e+00)
 di error count

B3 errors

dj average error rate (in scientific notation, 0.00e+00)
 dk error rate (in scientific notation, 0.00e+00)
 dl error count

REI-P/HP - REI errors

dm average error rate (in scientific notation, 0.00e+00)
 dn error rate (in scientific notation, 0.00e+00)
 do error count

BIP-V/LP-BIP errors

dp average error rate (in scientific notation, 0.00e+00)
 dq error rate (in scientific notation, 0.00e+00)
 dr error count

REI-V/LP-REI errors

ds average error rate (in scientific notation, 0.00e+00)
 dt error count
 du error count

BPV errors

du average error rate (in scientific notation, 0.00e+00)
 dv error count
 dw error count

RESULT Command	Description
RES:SPM? (continued)	BIT errors dx average error rate (in scientific notation, 0.00e+00) dy error rate (in scientific notation, 0.00e+00) dz error count NDF-P/AU-NDF errors ea average error rate (in scientific notation, 0.00e+00) eb error rate (in scientific notation, 0.00e+00) ec error count NDF-V/TU-NDF errors ed average error rate (in scientific notation, 0.00e+00) ee error rate (in scientific notation, 0.00e+00) ef error count

**For OC-48, OC-192, STM-16, and STM-64,
 alarm and error durations appear in seconds:**

aa	B1 errors
ab	B2 errors BPV errors
ac	REI-L/MS-REI errors
ad	B3 errors
ae	REI-P/HP-REI errors
af	BIT errors
ag	No NDF errors
ah	LOS alarm seconds
ai	LOF alarm seconds
aj	SEF/OOF alarm seconds
ak	LOP-P/AU-LOP alarm seconds
al	AIS-L/MS-AIS alarm seconds
am	AIS-P/AU-AIS alarm seconds
an	UNEQ-P/HP-UNEQ alarm seconds
ao	Pattern Loss alarm seconds
ap	RDI-L/MS-RDI alarm seconds
aq	APS-L/MS-APS alarm seconds
ar	PLM-P/HP-PLM alarm seconds
as	TIM-S alarm seconds
at	TIM-P/HP-TIM alarm seconds
au	APS Changes alarm seconds
av	Concatenation alarm seconds
aw	SS Bits Mismatch alarm seconds
ax	PP Paused alarm seconds
ay	Power Loss alarm seconds
az	TC-IEC errors
ba	TC-REI errors alarm seconds
bb	TC-OEI errors
bc	TC-RDI alarm seconds s
bd	TC-ODI alarm seconds s
be	TC-AIS alarm seconds
bf	TC-UNEQ alarm seconds
bg	TC-TIM alarm seconds
bh	TC-LOF alarm seconds

RESULT Command	Description
RES:SPM? (continued)	<p>For OC-48, OC-192, STM-16, and STM-64, the average error, error rate, and current error rate counts appear as follows:</p> <p>B1 errors</p> <p>da average error rate (in scientific notation, 0.00e+00)</p> <p>db error rate (in scientific notation, 0.00e+00)</p> <p>dc error count</p> <p>B2 errors</p> <p>dd average error rate (in scientific notation, 0.00e+00)</p> <p>de error rate (in scientific notation, 0.00e+00)</p> <p>df error count</p> <p>REI-L/MS-REI errors</p> <p>dg average error rate (in scientific notation, 0.00e+00)</p> <p>dh error rate (in scientific notation, 0.00e+00)</p> <p>di error count</p> <p>B3 errors</p> <p>dj average error rate (in scientific notation, 0.00e+00)</p> <p>dk error rate (in scientific notation, 0.00e+00)</p> <p>dl error count</p> <p>REI-P/HP-REI errors</p> <p>dm average error rate (in scientific notation, 0.00e+00)</p> <p>dn error rate (in scientific notation, 0.00e+00)</p> <p>do error count</p> <p>No NDF errors</p> <p>dp average error rate (in scientific notation, 0.00e+00)</p> <p>dq error rate (in scientific notation, 0.00e+00)</p> <p>dr error count</p> <p>BIT errors</p> <p>ds average error rate (in scientific notation, 0.00e+00)</p> <p>dt error rate (in scientific notation, 0.00e+00)</p> <p>du error count</p> <p>TC-IEC errors</p> <p>ea average error rate (in scientific notation, 0.00e+00)</p> <p>eb error rate (in scientific notation, 0.00e+00)</p> <p>ec error count</p> <p>TC-REI errors</p> <p>ed average error rate (in scientific notation, 0.00e+00)</p> <p>ee error rate (in scientific notation, 0.00e+00)</p> <p>ef error count</p> <p>TC-OEI errors</p> <p>eg average error rate (in scientific notation, 0.00e+00)</p> <p>eh error rate (in scientific notation, 0.00e+00)</p> <p>ei error count</p>

RESULT Command	Description																																																																								
RES:STSD?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Queries and reports all Trouble Scan results for SONET and SDH protocols. Use this command to retrieve any and all alarms or errors associated with a the current protocol processor.</p> <p>If no alarms or errors are detected, the following is returned: “No Errors or Alarms”</p> <p>If an alarm or error is detected, results are returned using the following format: TAG N, TAG N, TAG N,.... where, N is an integer number greater than 0, and TAG is one of the following:</p> <p>For OC-1/3/12 and STM-0/1/4:</p> <table> <tr><td>aa</td><td>SS Bits Mismatch alarm seconds</td></tr> <tr><td>ab</td><td>BPV errors</td></tr> <tr><td>ac</td><td>B3 errors</td></tr> <tr><td>ad</td><td>REI-P/HP-REI errors</td></tr> <tr><td>ae</td><td>NDF-P/AU-NDF errors</td></tr> <tr><td>af</td><td>BIT errors</td></tr> <tr><td>ag</td><td>LOS alarm seconds</td></tr> <tr><td>ah</td><td>LOF alarm seconds</td></tr> <tr><td>ai</td><td>SEF/OOF alarm seconds</td></tr> <tr><td>aj</td><td>TIM-S/RS-TIM alarm seconds</td></tr> <tr><td>ak</td><td>AIS-L/MS-AIS alarm seconds</td></tr> <tr><td>al</td><td>RDI-L/MS-RDI alarm seconds</td></tr> <tr><td>am</td><td>B1 errors</td></tr> <tr><td>an</td><td>B2 errors</td></tr> <tr><td>ao</td><td>REI-L/MS-REI errors</td></tr> <tr><td>ap</td><td>APS-L/MS-APS alarm seconds</td></tr> <tr><td>aq</td><td>AIS-P/AU-AIS alarm seconds</td></tr> <tr><td>ar</td><td>LOP-P/AU-LOP alarm seconds</td></tr> <tr><td>as</td><td>UNEQ-P/HP-UNEQ alarm seconds</td></tr> <tr><td>at</td><td>PLM-P/HP-PLM alarm seconds</td></tr> <tr><td>au</td><td>RDI-P/HP-RDI alarm seconds</td></tr> <tr><td>av</td><td>TIM-P/HP-TIM alarm seconds</td></tr> <tr><td>aw</td><td>BIP-V/LO-BIP errors</td></tr> <tr><td>ax</td><td>REI-V/LP-REI errors</td></tr> <tr><td>ay</td><td>LOM-V/TU-LOM alarm seconds</td></tr> <tr><td>az</td><td>NDF-V/TU-NDF errors</td></tr> <tr><td>ba</td><td>AIS-V/TU-AIS alarm seconds</td></tr> <tr><td>bb</td><td>LOP-V/TU-LOP alarm seconds</td></tr> <tr><td>bc</td><td>UNEQ-V/TU-UNEQ alarm seconds</td></tr> <tr><td>bd</td><td>PLM-V/LP-PLM alarm seconds</td></tr> <tr><td>be</td><td>RDI-V/LP-RDI alarm seconds</td></tr> <tr><td>bf</td><td>TIM-V/LP-TIM alarm seconds</td></tr> <tr><td>bg</td><td>RFI-V/LP-RFI alarm seconds</td></tr> <tr><td>bh</td><td>PAT SYNC alarm seconds</td></tr> <tr><td>bi</td><td>Power Loss alarm seconds</td></tr> <tr><td>bj</td><td>PP Paused alarm seconds</td></tr> </table>	aa	SS Bits Mismatch alarm seconds	ab	BPV errors	ac	B3 errors	ad	REI-P/HP-REI errors	ae	NDF-P/AU-NDF errors	af	BIT errors	ag	LOS alarm seconds	ah	LOF alarm seconds	ai	SEF/OOF alarm seconds	aj	TIM-S/RS-TIM alarm seconds	ak	AIS-L/MS-AIS alarm seconds	al	RDI-L/MS-RDI alarm seconds	am	B1 errors	an	B2 errors	ao	REI-L/MS-REI errors	ap	APS-L/MS-APS alarm seconds	aq	AIS-P/AU-AIS alarm seconds	ar	LOP-P/AU-LOP alarm seconds	as	UNEQ-P/HP-UNEQ alarm seconds	at	PLM-P/HP-PLM alarm seconds	au	RDI-P/HP-RDI alarm seconds	av	TIM-P/HP-TIM alarm seconds	aw	BIP-V/LO-BIP errors	ax	REI-V/LP-REI errors	ay	LOM-V/TU-LOM alarm seconds	az	NDF-V/TU-NDF errors	ba	AIS-V/TU-AIS alarm seconds	bb	LOP-V/TU-LOP alarm seconds	bc	UNEQ-V/TU-UNEQ alarm seconds	bd	PLM-V/LP-PLM alarm seconds	be	RDI-V/LP-RDI alarm seconds	bf	TIM-V/LP-TIM alarm seconds	bg	RFI-V/LP-RFI alarm seconds	bh	PAT SYNC alarm seconds	bi	Power Loss alarm seconds	bj	PP Paused alarm seconds
aa	SS Bits Mismatch alarm seconds																																																																								
ab	BPV errors																																																																								
ac	B3 errors																																																																								
ad	REI-P/HP-REI errors																																																																								
ae	NDF-P/AU-NDF errors																																																																								
af	BIT errors																																																																								
ag	LOS alarm seconds																																																																								
ah	LOF alarm seconds																																																																								
ai	SEF/OOF alarm seconds																																																																								
aj	TIM-S/RS-TIM alarm seconds																																																																								
ak	AIS-L/MS-AIS alarm seconds																																																																								
al	RDI-L/MS-RDI alarm seconds																																																																								
am	B1 errors																																																																								
an	B2 errors																																																																								
ao	REI-L/MS-REI errors																																																																								
ap	APS-L/MS-APS alarm seconds																																																																								
aq	AIS-P/AU-AIS alarm seconds																																																																								
ar	LOP-P/AU-LOP alarm seconds																																																																								
as	UNEQ-P/HP-UNEQ alarm seconds																																																																								
at	PLM-P/HP-PLM alarm seconds																																																																								
au	RDI-P/HP-RDI alarm seconds																																																																								
av	TIM-P/HP-TIM alarm seconds																																																																								
aw	BIP-V/LO-BIP errors																																																																								
ax	REI-V/LP-REI errors																																																																								
ay	LOM-V/TU-LOM alarm seconds																																																																								
az	NDF-V/TU-NDF errors																																																																								
ba	AIS-V/TU-AIS alarm seconds																																																																								
bb	LOP-V/TU-LOP alarm seconds																																																																								
bc	UNEQ-V/TU-UNEQ alarm seconds																																																																								
bd	PLM-V/LP-PLM alarm seconds																																																																								
be	RDI-V/LP-RDI alarm seconds																																																																								
bf	TIM-V/LP-TIM alarm seconds																																																																								
bg	RFI-V/LP-RFI alarm seconds																																																																								
bh	PAT SYNC alarm seconds																																																																								
bi	Power Loss alarm seconds																																																																								
bj	PP Paused alarm seconds																																																																								

RESULT Command	Description
RES:STSD? (continued)	For OC-48, OC-192, STM-16, and STM-64:
	aa B1 errors
	ab B2 errors BPV errors
Note: Select a protocol processor (using the INST command) before using this command. Error code 508 appears if a protocol processor is not selected.	ac REI-L/MS-REI errors
	ad B3 errors
	ae REI-P/HP-REI errors
	af BIT errors
	ag No NDF errors
	ah LOS alarm seconds
	ai LOF alarm seconds
	aj SEF/OOF alarm seconds
	ak LOP-P/AU-LOP alarm seconds
	al AIS-L/MS-AIS alarm seconds
	am AIS-P/AU-AIS alarm seconds
	an UNEQ-P/HP-UNEQ alarm seconds
	ao Pattern Loss alarm seconds
	ap RDI-L/MS-RDI alarm seconds
	aq APS-L/MS-APS alarm seconds
	ar PLM-P/HP-PLM alarm seconds
	as TIM-S alarm seconds
	at TIM-P/HP-TIM alarm seconds
	au APS Changes alarm seconds
	av Concatenation alarm seconds
	aw SS Bits Mismatch alarm seconds
	ax PP Paused alarm seconds
	ay Power Loss alarm seconds
	az TC-IEC errors
	ba TC-REI errors alarm seconds
	bb TC-OEI errors
	bc TC-RDI alarm seconds s
	bd TC-ODI alarm seconds s
	be TC-AIS alarm seconds
	bf TC-UNEQ alarm seconds
	bg TC-TIM alarm seconds
	bh TC-LOF alarm seconds
RES:TCM:API?	Queries and reports the value of the 16-byte Tandem Connection Monitoring (TCM) trace.
RES:TCM:IEC?	Queries and reports the number of TC-Incoming Error Counts (B3 errors) logged by the unit when configured for TCM mode.
RES:TCM:OEI?	Queries and reports the number of TC-Outgoing Error Indication error counts logged by the unit when configured for TCM mode.
RES:TCM:REI?	Queries and reports the number of TC-Remote Error Indication error counts logged by the unit when configured for TCM mode.
RES:TCM:AIS:Secs?	Queries and reports the number of seconds an AIS alarm was logged by the unit when configured for TCM mode.
RES:TCM:LOF:Secs?	Queries and reports the number of seconds an LOF alarm was logged by the unit when configured for TCM mode.
RES:TCM:ODI:Secs?	Queries and reports the number of seconds a TC-Outgoing Defect Indicator alarm was logged by the unit when configured for TCM mode.

RESULT Command	Description
RES:TCM:RDI:Secs?	Queries and reports the number of seconds an RDI alarm was logged by the unit when configured for TCM mode.
RES:TCM:TIM:Secs?	Queries and reports the number of seconds a TIM alarm was logged by the unit when configured for TCM mode.
RES:TCM:UNEQ:Secs?	Queries and reports the number of seconds an Unequipped alarm was logged by the unit when configured for TCM mode.
RES:TIM:HP:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP Trace Identifier Mismatch seconds.
RES:TIM:LP:Secs?	<i>Protocols Supported:</i> STM-4 Queries the number of TU Trace Identifier Mismatch seconds.
RES:TIM:PATH:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Path Trace Identifier Mismatch seconds.
RES:TIM:RS:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of RS Trace Identifier Mismatch seconds.
RES:TIM:SECTion:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Section Trace Identifier Mismatch seconds.
RES:TIM:VT:Secs?	<i>Protocols Supported:</i> OC-12 VT Trace Identifier Mismatch seconds
RES:UNEQ:HP:Secs?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the number of HP Unequipped seconds.
RES:UNEQ:LP:Secs?	<i>Protocols Supported:</i> STM-4 Queries the number of LP Unequipped seconds.
RES:UNEQ:PATH:Secs?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Path Unequipped seconds.
RES:UNEQ:VT:Secs?	<i>Protocols Supported:</i> OC-12 VT Unequipped seconds.
RES:YELLOW:Secs?	<i>Protocols Supported:</i> DS3, DS1 Queries and reports the number of seconds that there was a Yellow (RAI – Remote Alarm Indication) alarm.

TX (SOURce) Branch

The TX branch is used to set and retrieve Transmit settings. Alternatively, each command can be sent using the "SOUR" or "SOURCE" keyword instead of the "TX" keyword.

The following is a list of supported Transmit commands.

Transmit Command	Description
TX:ALarm:TYPE?	<i>Protocols Supported:</i> ALL Queries the current protocol processor for the alarm type it is generating. For a list of returned values, see the <i>TX:ALarm:TYPE < alarm ></i> command.

Transmit Command	Description																																																																																																
TX:ALarm:TYPE < alarm >	<p><i>Protocols Supported:</i> ALL</p> <p>Sets the alarm being generated. Valid parameters, meanings and protocol processors are:</p> <table border="1"> <thead> <tr> <th><u>Alarm</u></th> <th><u>Protocol Processors</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>ALL</td> <td>No alarm generation</td> </tr> <tr> <td>AIS</td> <td>E1, E3, E4, DS3, DS1</td> <td>Alarm Indication Signal</td> </tr> <tr> <td>AISL</td> <td>OC-12, OC-48, OC-192</td> <td>Line Alarm Indication Signal</td> </tr> <tr> <td>AISP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Alarm Indication Signal</td> </tr> <tr> <td>AISV</td> <td>OC-12</td> <td>VT Alarm Indication Signal</td> </tr> <tr> <td>IDLE</td> <td>DS1, DS3</td> <td>Idle alarm</td> </tr> <tr> <td>LOS</td> <td>E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3</td> <td>Loss of Signal</td> </tr> <tr> <td>LOF</td> <td>E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</td> <td>Loss of Frame</td> </tr> <tr> <td>LOPP</td> <td>OC-12, OC-48, OC-192</td> <td>Loss of Pointer Path</td> </tr> <tr> <td>OOF</td> <td>DS1, DS3</td> <td>Out of Frame</td> </tr> <tr> <td>RAI</td> <td>E1, E3, E4</td> <td>Remote Alarm Indication</td> </tr> <tr> <td>YELLOW</td> <td>DS1, DS3</td> <td>Yellow alarm (RAI)</td> </tr> <tr> <td>RDIL</td> <td>OC-12, OC-48, OC-192</td> <td>Line Remote Defect Indication</td> </tr> <tr> <td>RDIP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Remote Defect Indication</td> </tr> <tr> <td>RDIV</td> <td>OC-12</td> <td>VT Remote Defect Indication</td> </tr> <tr> <td>RFIV</td> <td>OC-12</td> <td>VT RFI</td> </tr> <tr> <td>RMFAI</td> <td>E1</td> <td>Remote Multi-Frame Alarm Indicator</td> </tr> <tr> <td>CASMFL</td> <td>E1</td> <td>Channel-Associated Signaling Multi Frame Loss</td> </tr> <tr> <td>MSAIS</td> <td>STM-4, STM-16, STM-64</td> <td>MS-AIS</td> </tr> <tr> <td>MSRDI</td> <td>STM-4, STM-16, STM-64</td> <td>MS-RDI</td> </tr> <tr> <td>AUAIS</td> <td>STM-4, STM-16, STM-64</td> <td>AU-AIS</td> </tr> <tr> <td>AULOP</td> <td>STM-4, STM-16, STM-64</td> <td>AU-LOP</td> </tr> <tr> <td>HPUNEQ</td> <td>STM-4, STM-16, STM-64</td> <td>HP-UNEQ</td> </tr> <tr> <td>HPRDI</td> <td>STM-4, STM-16, STM-64</td> <td>HP-RDI</td> </tr> <tr> <td>TUAIS</td> <td>STM-4</td> <td>TU-AIS</td> </tr> <tr> <td>TULOP</td> <td>STM-4</td> <td>TU-Loss of Pointer</td> </tr> <tr> <td>LPUNEQ</td> <td>STM-4</td> <td>LP-Unequipped</td> </tr> <tr> <td>LPRDI</td> <td>STM-4</td> <td>LP-RDI</td> </tr> <tr> <td>LPRFI</td> <td>STM-4</td> <td>LP-RFI</td> </tr> <tr> <td>UNEQP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Unequipped</td> </tr> <tr> <td>UNEQV</td> <td>OC-12</td> <td>VT Unequipped</td> </tr> </tbody> </table>	<u>Alarm</u>	<u>Protocol Processors</u>	<u>Meaning</u>	OFF	ALL	No alarm generation	AIS	E1, E3, E4, DS3, DS1	Alarm Indication Signal	AISL	OC-12, OC-48, OC-192	Line Alarm Indication Signal	AISP	OC-12, OC-48, OC-192	Path Alarm Indication Signal	AISV	OC-12	VT Alarm Indication Signal	IDLE	DS1, DS3	Idle alarm	LOS	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3	Loss of Signal	LOF	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192	Loss of Frame	LOPP	OC-12, OC-48, OC-192	Loss of Pointer Path	OOF	DS1, DS3	Out of Frame	RAI	E1, E3, E4	Remote Alarm Indication	YELLOW	DS1, DS3	Yellow alarm (RAI)	RDIL	OC-12, OC-48, OC-192	Line Remote Defect Indication	RDIP	OC-12, OC-48, OC-192	Path Remote Defect Indication	RDIV	OC-12	VT Remote Defect Indication	RFIV	OC-12	VT RFI	RMFAI	E1	Remote Multi-Frame Alarm Indicator	CASMFL	E1	Channel-Associated Signaling Multi Frame Loss	MSAIS	STM-4, STM-16, STM-64	MS-AIS	MSRDI	STM-4, STM-16, STM-64	MS-RDI	AUAIS	STM-4, STM-16, STM-64	AU-AIS	AULOP	STM-4, STM-16, STM-64	AU-LOP	HPUNEQ	STM-4, STM-16, STM-64	HP-UNEQ	HPRDI	STM-4, STM-16, STM-64	HP-RDI	TUAIS	STM-4	TU-AIS	TULOP	STM-4	TU-Loss of Pointer	LPUNEQ	STM-4	LP-Unequipped	LPRDI	STM-4	LP-RDI	LPRFI	STM-4	LP-RFI	UNEQP	OC-12, OC-48, OC-192	Path Unequipped	UNEQV	OC-12	VT Unequipped
<u>Alarm</u>	<u>Protocol Processors</u>	<u>Meaning</u>																																																																																															
OFF	ALL	No alarm generation																																																																																															
AIS	E1, E3, E4, DS3, DS1	Alarm Indication Signal																																																																																															
AISL	OC-12, OC-48, OC-192	Line Alarm Indication Signal																																																																																															
AISP	OC-12, OC-48, OC-192	Path Alarm Indication Signal																																																																																															
AISV	OC-12	VT Alarm Indication Signal																																																																																															
IDLE	DS1, DS3	Idle alarm																																																																																															
LOS	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS1, DS3	Loss of Signal																																																																																															
LOF	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192	Loss of Frame																																																																																															
LOPP	OC-12, OC-48, OC-192	Loss of Pointer Path																																																																																															
OOF	DS1, DS3	Out of Frame																																																																																															
RAI	E1, E3, E4	Remote Alarm Indication																																																																																															
YELLOW	DS1, DS3	Yellow alarm (RAI)																																																																																															
RDIL	OC-12, OC-48, OC-192	Line Remote Defect Indication																																																																																															
RDIP	OC-12, OC-48, OC-192	Path Remote Defect Indication																																																																																															
RDIV	OC-12	VT Remote Defect Indication																																																																																															
RFIV	OC-12	VT RFI																																																																																															
RMFAI	E1	Remote Multi-Frame Alarm Indicator																																																																																															
CASMFL	E1	Channel-Associated Signaling Multi Frame Loss																																																																																															
MSAIS	STM-4, STM-16, STM-64	MS-AIS																																																																																															
MSRDI	STM-4, STM-16, STM-64	MS-RDI																																																																																															
AUAIS	STM-4, STM-16, STM-64	AU-AIS																																																																																															
AULOP	STM-4, STM-16, STM-64	AU-LOP																																																																																															
HPUNEQ	STM-4, STM-16, STM-64	HP-UNEQ																																																																																															
HPRDI	STM-4, STM-16, STM-64	HP-RDI																																																																																															
TUAIS	STM-4	TU-AIS																																																																																															
TULOP	STM-4	TU-Loss of Pointer																																																																																															
LPUNEQ	STM-4	LP-Unequipped																																																																																															
LPRDI	STM-4	LP-RDI																																																																																															
LPRFI	STM-4	LP-RFI																																																																																															
UNEQP	OC-12, OC-48, OC-192	Path Unequipped																																																																																															
UNEQV	OC-12	VT Unequipped																																																																																															
TX:APS:ACTION <state>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Starts and stops the round-trip delay function. Valid <state> values are:</p> <table border="1"> <tbody> <tr> <td>SINGLE</td> <td>Monitors for a single APS event. If the event occurs, the duration is reported and the state returns to Inactive.</td> </tr> <tr> <td>STOP</td> <td>Stops APS monitoring. The state returns to Inactive.</td> </tr> <tr> <td>CONTInuos</td> <td>Constantly monitors for APS events and updates the Protection Switch Time durations.</td> </tr> </tbody> </table>	SINGLE	Monitors for a single APS event. If the event occurs, the duration is reported and the state returns to Inactive.	STOP	Stops APS monitoring. The state returns to Inactive.	CONTInuos	Constantly monitors for APS events and updates the Protection Switch Time durations.																																																																																										
SINGLE	Monitors for a single APS event. If the event occurs, the duration is reported and the state returns to Inactive.																																																																																																
STOP	Stops APS monitoring. The state returns to Inactive.																																																																																																
CONTInuos	Constantly monitors for APS events and updates the Protection Switch Time durations.																																																																																																

Transmit Command	Description
TX:APS:GOOD:TIME?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current setting of the APS's Consecutive Good Time Required function. This value indicates the duration of the number of valid frames that occur before the APS function is confirmed to be activated. Valid values for this command range from 0.125 msec to 2047.875 msec.
TX:APS:GOOD:TIME <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the value for the APS's Consecutive Good Time Required function. Valid values range from 0.125 msec to 2047.875 msec.
TX:APS:GOOD:FRAME?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current setting of the APS's Consecutive Good Frames Required function. This value indicates the number of valid frames that occur before the APS function is confirmed to be activated. Valid values for this command range from 1 to 16383 frames.
TX:APS:GOOD:FRAME <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the value for the APS's Consecutive Good Frames Required function. Value values range from 1 to 16383 frames.
TX:APS:SEQuence?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries the values of the K1/K2 bytes and frames used for APS sequencing. The K1 and K2 bytes appear in HEX notation. The frames appear in decimal notation.
TX:APS:SEQuence <commands>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Specifies 1 to 15 APS commands to be transmitted. Each command contains the K1 value, K2 value, and number of frames to transmit (1 to 65535). Format is comma-delimited, with 3 numeric values for each command. Example, containing 3 commands: TX:APS:SEQ 0, 0, 100, 5, 1, 20, 255, 255, 10
TX:AU:INSert?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Queries the current Foreground AU inserted.
TX:AU:INSert <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Sets the current Foreground AU inserted. A value can be numeric or "ALL." ALL indicates that all the AUs have the same contents (broadcast).
TX:AU:TYPe?	<i>Protocols Supported:</i> STM-4 Queries the current AU type generated.
TX:AU:TYPe <value>	<i>Protocols Supported:</i> STM-4 Sets the current AU type generated. Valid values are: AU-3, AU-4, AU-4-4C
TX:CAS:<channel>?	<i>Protocols Supported:</i> E1 Queries the E1 test for the value being transmitted in any of the 30 CAS channels. Channel must be a decimal integer from 1 to 30.
TX:CAS:<channel> <value>	<i>Protocols Supported:</i> E1 Sets the value generated in any of the 30 CAS channels. Channel must be a decimal integer from 1 to 30 or "ALL." If "ALL," the number specified in value will be applied to all 30 channels, or it is the channel number. Value can be any integer from 0 to 15 specified as integer, hex or binary.
TX:CLOCK:SYStem?	<i>Protocols Supported:</i> SYSTEM Queries the source of the external system clock (must be set the same for all protocols).

Transmit Command	Description																		
TX:CLOCK:SYStem <clock source value>	<i>Protocols Supported:</i> SYSTEM Sets the source of the external system clock for all processors BITS or SETS. Valid values are: BITS or SETS.																		
TX:CLOCK?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1, Jitter Queries the current test for its reference clock source.																		
TX:CLOCK <clock type>	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1, Jitter Sets the current protocol processor's reference clock (for determining how the transmitted signal will be clocked) to one of the following types based on the protocol processor selected. EXTERNAL sets it to BITS or SETS, depending on the TX:CLOCK:SYStem setting. Valid clock types and descriptions are: <table border="1"> <thead> <tr> <th><u>Clock Type</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>INT</td> <td>Internal Clock</td> </tr> <tr> <td>EXTERNAL</td> <td>External BITS or SETS reference clock input (not valid for Jitter)</td> </tr> <tr> <td>LOOP</td> <td>Received (Recovered) signal (not valid for Jitter)</td> </tr> <tr> <td>BITS</td> <td>Synchronizes the transmitted signal to the BITS (Building Integrated Timing Supply) clock input, which is 1.544 MHz. If this option is selected, but BITS clocking is not available, then this function defaults to Internal.</td> </tr> <tr> <td>SETS</td> <td>Synchronizes the transmitted signal to the SETS (Synchronous Equipment Timing Source) clock input, which is 2.048 MHz. If this option is selected, but SETS clocking is not available, then this function defaults to Internal.</td> </tr> <tr> <td>RECOVERED</td> <td>Jitter recovered signal (Jitter only)</td> </tr> <tr> <td>EXT10MHZ</td> <td>Derives Jitter timing from an external timing source attached to the unit's 10 MHz In reference clock connector.</td> </tr> <tr> <td>EXT2MHZ</td> <td>Derives Jitter timing from an external timing source attached to the unit's 2.048 MHz In reference clock connector.</td> </tr> </tbody> </table>	<u>Clock Type</u>	<u>Description</u>	INT	Internal Clock	EXTERNAL	External BITS or SETS reference clock input (not valid for Jitter)	LOOP	Received (Recovered) signal (not valid for Jitter)	BITS	Synchronizes the transmitted signal to the BITS (Building Integrated Timing Supply) clock input, which is 1.544 MHz. If this option is selected, but BITS clocking is not available, then this function defaults to Internal.	SETS	Synchronizes the transmitted signal to the SETS (Synchronous Equipment Timing Source) clock input, which is 2.048 MHz. If this option is selected, but SETS clocking is not available, then this function defaults to Internal.	RECOVERED	Jitter recovered signal (Jitter only)	EXT10MHZ	Derives Jitter timing from an external timing source attached to the unit's 10 MHz In reference clock connector.	EXT2MHZ	Derives Jitter timing from an external timing source attached to the unit's 2.048 MHz In reference clock connector.
<u>Clock Type</u>	<u>Description</u>																		
INT	Internal Clock																		
EXTERNAL	External BITS or SETS reference clock input (not valid for Jitter)																		
LOOP	Received (Recovered) signal (not valid for Jitter)																		
BITS	Synchronizes the transmitted signal to the BITS (Building Integrated Timing Supply) clock input, which is 1.544 MHz. If this option is selected, but BITS clocking is not available, then this function defaults to Internal.																		
SETS	Synchronizes the transmitted signal to the SETS (Synchronous Equipment Timing Source) clock input, which is 2.048 MHz. If this option is selected, but SETS clocking is not available, then this function defaults to Internal.																		
RECOVERED	Jitter recovered signal (Jitter only)																		
EXT10MHZ	Derives Jitter timing from an external timing source attached to the unit's 10 MHz In reference clock connector.																		
EXT2MHZ	Derives Jitter timing from an external timing source attached to the unit's 2.048 MHz In reference clock connector.																		
TX:COUPled?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the current protocol processor to see if Receive and Transmit are coupled or set independently. Returns string YES or NO																		
TX:COUPled <mode>	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Sets the current protocol processor to either couple Receive and Transmit setting or make Receive and Transmit setting operate independently. Valid modes are: YES or NO.																		
TX:DCC?	<i>Protocols Supported:</i> STM-4, OC-12 Returns values as in TX:DCC																		

Transmit Command	Description																												
TX:DCC < channel >	<p><i>Protocols Supported:</i> STM-4, OC-12</p> <p>Specifies the bit stream to be sent over one of the datacomm channels. For those bytes not used (or if the value is NONE) the single byte value in the Transmit Overhead specification is used. Valid values are:</p> <table border="1"> <thead> <tr> <th><u>Channel</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>Only use single byte values in the Transmit Overhead setting</td> </tr> <tr> <td>RSPRBS</td> <td>Insert PRBS 2^7-1 into RS DCC channel (D1-D3)</td> </tr> <tr> <td>RSPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into RS DCC channel (D1-D3)</td> </tr> <tr> <td>MSPRBS</td> <td>Insert PRBS 2^7-1 into MS DCC channel (D4-D12)</td> </tr> <tr> <td>MSPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into MS DCC channel (D4-D12)</td> </tr> <tr> <td>RSDCC</td> <td>Insert bit stream from DCC Port into RS DCC channel (D1-D3)</td> </tr> <tr> <td>MSDCC</td> <td>Insert bit stream from DCC Port into MS DCC channel (D4-D12)</td> </tr> <tr> <td>SECTionPRBS</td> <td>Insert PRBS 2^7-1 into Section DCC channel (D1-D3)</td> </tr> <tr> <td>SECTionPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)</td> </tr> <tr> <td>LINEPRBS</td> <td>Insert PRBS 2^7-1 into Line DCC channel (D4-D12)</td> </tr> <tr> <td>LINEPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)</td> </tr> <tr> <td>SECTionDCC</td> <td>Insert bit stream from DCC Port into Section DCC channel (D1-D3)</td> </tr> <tr> <td>LINEDCC</td> <td>Insert bit stream from DCC Port into Line DCC channel (D4-D12)</td> </tr> </tbody> </table>	<u>Channel</u>	<u>Description</u>	NONE	Only use single byte values in the Transmit Overhead setting	RSPRBS	Insert PRBS 2^7-1 into RS DCC channel (D1-D3)	RSPRBSINV	Insert PRBS 2^7-1 Inverted into RS DCC channel (D1-D3)	MSPRBS	Insert PRBS 2^7-1 into MS DCC channel (D4-D12)	MSPRBSINV	Insert PRBS 2^7-1 Inverted into MS DCC channel (D4-D12)	RSDCC	Insert bit stream from DCC Port into RS DCC channel (D1-D3)	MSDCC	Insert bit stream from DCC Port into MS DCC channel (D4-D12)	SECTionPRBS	Insert PRBS 2^7-1 into Section DCC channel (D1-D3)	SECTionPRBSINV	Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)	LINEPRBS	Insert PRBS 2^7-1 into Line DCC channel (D4-D12)	LINEPRBSINV	Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)	SECTionDCC	Insert bit stream from DCC Port into Section DCC channel (D1-D3)	LINEDCC	Insert bit stream from DCC Port into Line DCC channel (D4-D12)
<u>Channel</u>	<u>Description</u>																												
NONE	Only use single byte values in the Transmit Overhead setting																												
RSPRBS	Insert PRBS 2^7-1 into RS DCC channel (D1-D3)																												
RSPRBSINV	Insert PRBS 2^7-1 Inverted into RS DCC channel (D1-D3)																												
MSPRBS	Insert PRBS 2^7-1 into MS DCC channel (D4-D12)																												
MSPRBSINV	Insert PRBS 2^7-1 Inverted into MS DCC channel (D4-D12)																												
RSDCC	Insert bit stream from DCC Port into RS DCC channel (D1-D3)																												
MSDCC	Insert bit stream from DCC Port into MS DCC channel (D4-D12)																												
SECTionPRBS	Insert PRBS 2^7-1 into Section DCC channel (D1-D3)																												
SECTionPRBSINV	Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)																												
LINEPRBS	Insert PRBS 2^7-1 into Line DCC channel (D4-D12)																												
LINEPRBSINV	Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)																												
SECTionDCC	Insert bit stream from DCC Port into Section DCC channel (D1-D3)																												
LINEDCC	Insert bit stream from DCC Port into Line DCC channel (D4-D12)																												
TX:E13:INSert:@N?	<p><i>Protocols Supported:</i> E3, DS3</p> <p>Queries the inserted E1 channel on the E13 or DS3 Mux for instance N. Values returned are 1-16 (for E3) and 1-21 (for DS3) or "ALL," where "ALL" means "All Background" (Broadcast).</p>																												
TX:E13:INSert:@N <value>	<p><i>Protocols Supported:</i> E3, DS3</p> <p>Sets the E1 insert channel for instance N to one of the 16 E13 or 21 DS3 channels available. Values are 1 to 16 (for E3) and 1-21 (for DS3) or "ALL." "ALL" means "All Background" (Broadcast).</p>																												
TX:E34:INSert?	<p><i>Protocols Supported:</i> E4</p> <p>Queries the current inserted E3 channel on the E34 Mux. Values returned are 1-4 or "ALL," where "ALL" means "All Background" (Broadcast).</p>																												
TX:E34:INSert <value>	<p><i>Protocols Supported:</i> E4</p> <p>Sets the E3 insert channel to one of the 4 E34 channels. Values are 1 to 4 or "ALL." "ALL" means "All Background" (Broadcast).</p>																												
TX:EBITs?	<p><i>Protocols Supported:</i> E1</p> <p>Returns the transmitted E-bits as a 2-bit binary number.</p>																												
TX:EBITs <value>	<p><i>Protocols Supported:</i> E1</p> <p>Sets the transmitted E-bits per the value passed, ignoring all but the low-order 2 bits in "value."</p>																												

Transmit Command	Description																																																												
TX:ERR:RATE?	<i>Protocols Supported: ALL</i> Queries the error rate and returns the value as given in the command.																																																												
TX:ERR:RATE < rate >	<i>Protocols Supported: ALL</i> Sets the error rate. Valid values are: <table border="1" data-bbox="548 436 1360 667"> <thead> <tr> <th><u>Rate</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>N.NNe-NN</td> <td>where each N is a numeral</td> </tr> <tr> <td>0</td> <td>= OFF</td> </tr> <tr> <td>SINGLE</td> <td>Single error generation; does not change the current generation rate</td> </tr> <tr> <td>Special strings</td> <td>Future expansion; must begin with an alphabetic character, not a numeral.</td> </tr> </tbody> </table>	<u>Rate</u>	<u>Description</u>	N.NNe-NN	where each N is a numeral	0	= OFF	SINGLE	Single error generation; does not change the current generation rate	Special strings	Future expansion; must begin with an alphabetic character, not a numeral.																																																		
<u>Rate</u>	<u>Description</u>																																																												
N.NNe-NN	where each N is a numeral																																																												
0	= OFF																																																												
SINGLE	Single error generation; does not change the current generation rate																																																												
Special strings	Future expansion; must begin with an alphabetic character, not a numeral.																																																												
TX:ERR:TYPE?	<i>Protocols Supported: ALL</i> Queries the error type selected for the current protocol processor.																																																												
TX:ERR:TYPE <error>	<i>Protocols Supported: ALL</i> Sets the error type for the current protocol processor to one of the following types: <table border="1" data-bbox="548 844 1360 1640"> <thead> <tr> <th><u>Error</u></th> <th><u>Protocol(s)</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>ALL</td> <td>Stops Error Generation</td> </tr> <tr> <td>BIT</td> <td>ALL</td> <td>Errors in the payload pattern</td> </tr> <tr> <td>BPV</td> <td>E1, E3, STM-4, DS3, DS1, OC-12</td> <td>Bipolar violations</td> </tr> <tr> <td>FRAME</td> <td>E1, E3, E4, DS3, DS1</td> <td>Framing errors</td> </tr> <tr> <td>CPAR</td> <td>DS3</td> <td>C-Parity Bit error</td> </tr> <tr> <td>CRC</td> <td>E1, DS1</td> <td>CRC errors</td> </tr> <tr> <td>FEBE</td> <td>E1</td> <td>Far End Block Errors</td> </tr> <tr> <td>B1</td> <td>STM-4, STM-16, STM-64 OC-12, OC-48, OC-192</td> <td>RS/Section BIP-8 Errors</td> </tr> <tr> <td>B2</td> <td>STM-4, STM-16, STM-64 OC-12, OC-48, OC-192</td> <td>MS/LINE BIP-8 Errors</td> </tr> <tr> <td>B3</td> <td>STM-4, STM-16, STM-64 OC-12, OC-48, OC-192</td> <td>HP/PATH BIP-8 Errors</td> </tr> <tr> <td>LCV</td> <td>E4</td> <td>Line Code Violations</td> </tr> <tr> <td>LPBIP</td> <td>STM-4</td> <td>LP-BIP-2 or LP-BIP-8 (depending on Mapping)</td> </tr> <tr> <td>MSREI</td> <td>STM-4, STM-16, STM-64</td> <td>MS-REI</td> </tr> <tr> <td>HPREI</td> <td>STM-4, STM-16, STM-64</td> <td>HP-REI</td> </tr> <tr> <td>LPREI</td> <td>STM-4</td> <td>LP-REI</td> </tr> <tr> <td>PPAR</td> <td>DS3</td> <td>P-Parity Bit error</td> </tr> <tr> <td>REIL</td> <td>OC-12, OC-48, OC-192</td> <td>Line Remote Error Indicator</td> </tr> <tr> <td>REIP</td> <td>OC-12, OC-48, OC-192</td> <td>Path Remote Error Indicator</td> </tr> <tr> <td>REIV</td> <td>OC-12</td> <td>VT Remote Error Indicator</td> </tr> </tbody> </table>	<u>Error</u>	<u>Protocol(s)</u>	<u>Description</u>	NONE	ALL	Stops Error Generation	BIT	ALL	Errors in the payload pattern	BPV	E1, E3, STM-4, DS3, DS1, OC-12	Bipolar violations	FRAME	E1, E3, E4, DS3, DS1	Framing errors	CPAR	DS3	C-Parity Bit error	CRC	E1, DS1	CRC errors	FEBE	E1	Far End Block Errors	B1	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	RS/Section BIP-8 Errors	B2	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	MS/LINE BIP-8 Errors	B3	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	HP/PATH BIP-8 Errors	LCV	E4	Line Code Violations	LPBIP	STM-4	LP-BIP-2 or LP-BIP-8 (depending on Mapping)	MSREI	STM-4, STM-16, STM-64	MS-REI	HPREI	STM-4, STM-16, STM-64	HP-REI	LPREI	STM-4	LP-REI	PPAR	DS3	P-Parity Bit error	REIL	OC-12, OC-48, OC-192	Line Remote Error Indicator	REIP	OC-12, OC-48, OC-192	Path Remote Error Indicator	REIV	OC-12	VT Remote Error Indicator
<u>Error</u>	<u>Protocol(s)</u>	<u>Description</u>																																																											
NONE	ALL	Stops Error Generation																																																											
BIT	ALL	Errors in the payload pattern																																																											
BPV	E1, E3, STM-4, DS3, DS1, OC-12	Bipolar violations																																																											
FRAME	E1, E3, E4, DS3, DS1	Framing errors																																																											
CPAR	DS3	C-Parity Bit error																																																											
CRC	E1, DS1	CRC errors																																																											
FEBE	E1	Far End Block Errors																																																											
B1	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	RS/Section BIP-8 Errors																																																											
B2	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	MS/LINE BIP-8 Errors																																																											
B3	STM-4, STM-16, STM-64 OC-12, OC-48, OC-192	HP/PATH BIP-8 Errors																																																											
LCV	E4	Line Code Violations																																																											
LPBIP	STM-4	LP-BIP-2 or LP-BIP-8 (depending on Mapping)																																																											
MSREI	STM-4, STM-16, STM-64	MS-REI																																																											
HPREI	STM-4, STM-16, STM-64	HP-REI																																																											
LPREI	STM-4	LP-REI																																																											
PPAR	DS3	P-Parity Bit error																																																											
REIL	OC-12, OC-48, OC-192	Line Remote Error Indicator																																																											
REIP	OC-12, OC-48, OC-192	Path Remote Error Indicator																																																											
REIV	OC-12	VT Remote Error Indicator																																																											

Transmit Command	Description																														
TX:FEAC:CODE <type>	<i>Protocols Supported:</i> DS3 Sets the transmitted FEAC code to one of the following:																														
	<table border="1"> <thead> <tr> <th><u>FEAC Type</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>SDS1LOS</td> <td>Single DS1 LOS/HBE</td> </tr> <tr> <td>MDS1LOS</td> <td>Multiple DS1 LOS/HBER</td> </tr> <tr> <td>DS1SA</td> <td>DS1 equipment failure SA</td> </tr> <tr> <td>DS1NSA</td> <td>DS1 equipment failure NSA</td> </tr> <tr> <td>DS3SA</td> <td>DS3 equipment failure SA</td> </tr> <tr> <td>DS3NSA</td> <td>DS3 equipment failure NSA</td> </tr> <tr> <td>DS3LOS</td> <td>DS3 LOS/HBER</td> </tr> <tr> <td>IDLE</td> <td>DS3 idle received</td> </tr> <tr> <td>OOF</td> <td>DS3 Out of Frame</td> </tr> <tr> <td>AIS</td> <td>DS3 AIS received</td> </tr> <tr> <td>LPUP</td> <td>DS3 NIU loop up</td> </tr> <tr> <td>LPDN</td> <td>DS3 NIU loop down</td> </tr> <tr> <td>COMSA</td> <td>Com equipment failure NSA</td> </tr> <tr> <td>000001–111111</td> <td>Unassigned value ranging from 000001 to 111111</td> </tr> </tbody> </table>	<u>FEAC Type</u>	<u>Description</u>	SDS1LOS	Single DS1 LOS/HBE	MDS1LOS	Multiple DS1 LOS/HBER	DS1SA	DS1 equipment failure SA	DS1NSA	DS1 equipment failure NSA	DS3SA	DS3 equipment failure SA	DS3NSA	DS3 equipment failure NSA	DS3LOS	DS3 LOS/HBER	IDLE	DS3 idle received	OOF	DS3 Out of Frame	AIS	DS3 AIS received	LPUP	DS3 NIU loop up	LPDN	DS3 NIU loop down	COMSA	Com equipment failure NSA	000001–111111	Unassigned value ranging from 000001 to 111111
<u>FEAC Type</u>	<u>Description</u>																														
SDS1LOS	Single DS1 LOS/HBE																														
MDS1LOS	Multiple DS1 LOS/HBER																														
DS1SA	DS1 equipment failure SA																														
DS1NSA	DS1 equipment failure NSA																														
DS3SA	DS3 equipment failure SA																														
DS3NSA	DS3 equipment failure NSA																														
DS3LOS	DS3 LOS/HBER																														
IDLE	DS3 idle received																														
OOF	DS3 Out of Frame																														
AIS	DS3 AIS received																														
LPUP	DS3 NIU loop up																														
LPDN	DS3 NIU loop down																														
COMSA	Com equipment failure NSA																														
000001–111111	Unassigned value ranging from 000001 to 111111																														
TX:FEAC:CODE?	<i>Protocols Supported:</i> DS3 Returns the current value of the <i>TX:FEAC:CODE</i> command.																														
TX:FEAC:CYCLE <value>	<i>Protocols Supported:</i> DS3 Sets the number of FEAC cycles sent for Burst mode. Valid values range from 1 to 16.																														
TX:FEAC:CYCLE?	<i>Protocols Supported:</i> DS3 Returns the current setting for the number of FEAC cycles sent. Values returned range from 1 to 16.																														
TX:FEAC:RX:CODE?	<i>Protocols Supported:</i> DS3 Returns the value of the last FEAC code received.																														
TX:FEAC:RX:SECOnds?	<i>Protocols Supported:</i> DS3 Returns the number of seconds since a FEAC code was last received.																														
TX:FEAC:TX <value>	<i>Protocols Supported:</i> DS3 Starts or stops the FEAC. Valid values are BURST, CONTinuous, and OFF.																														
TX:FEAC:TX:?	<i>Protocols Supported:</i> DS3 Returns the current setting for FEAC transmission.																														
TX:FRAC_E1:MASK?	<i>Protocols Supported:</i> E1 Queries the Transmit fractional E1 mask, returned as a 32-bit integer.																														
TX:FRAC_E1:MASK < mask >	<i>Protocols Supported:</i> E1 Sets the 32-bit Transmit fractional E1 mask by which DS0s are enabled.																														
TX:FRAC_T1:MASK?	<i>Protocols Supported:</i> DS1 Queries the Transmit fractional DS1 mask, returned as a 32-bit integer.																														
TX:FRAC_T1:MASK < mask >	<i>Protocols Supported:</i> DS1 Sets the 32-bit Transmit fractional DS1 mask by which DS0s are enabled.																														
TX:FRAMing:BG?	<i>Protocols Supported:</i> E3, E4, DS3 Queries the current protocol processor for the background framing it is transmitting.																														

Transmit Command	Description																																				
TX:FRAMing:BG	<p><i>Protocols Supported:</i> E3, E4, DS3, DS1</p> <p>Sets the background framing in the MUX to one of the following types:</p> <table border="1"> <thead> <tr> <th><u>Framing</u></th> <th><u>Protocol(s)</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>UNframed</td> <td>DS1, E1, E3</td> <td>Unframed</td> </tr> <tr> <td>ESF</td> <td>DS1</td> <td>Extended Super Frame</td> </tr> <tr> <td>D4/SF</td> <td>DS1</td> <td>D4/Super Frame</td> </tr> <tr> <td>C-BIT</td> <td>DS3</td> <td>C-Bit Frame</td> </tr> <tr> <td>M13</td> <td>DS3</td> <td>M13 Frame</td> </tr> <tr> <td>PCM30</td> <td>E1</td> <td>Framed E1, with CAS but no CRC</td> </tr> <tr> <td>PCM31</td> <td>E1</td> <td>Framed E1, without CAS or CRC</td> </tr> <tr> <td>PCM30CRC</td> <td>E1</td> <td>Framed E1, with CAS and CRC</td> </tr> <tr> <td>PCM31CRC</td> <td>E1</td> <td>Framed E1, without CAS but with CRC</td> </tr> <tr> <td>FRamed</td> <td>E3</td> <td>Framed</td> </tr> </tbody> </table>	<u>Framing</u>	<u>Protocol(s)</u>	<u>Description</u>	UNframed	DS1, E1, E3	Unframed	ESF	DS1	Extended Super Frame	D4/SF	DS1	D4/Super Frame	C-BIT	DS3	C-Bit Frame	M13	DS3	M13 Frame	PCM30	E1	Framed E1, with CAS but no CRC	PCM31	E1	Framed E1, without CAS or CRC	PCM30CRC	E1	Framed E1, with CAS and CRC	PCM31CRC	E1	Framed E1, without CAS but with CRC	FRamed	E3	Framed			
<u>Framing</u>	<u>Protocol(s)</u>	<u>Description</u>																																			
UNframed	DS1, E1, E3	Unframed																																			
ESF	DS1	Extended Super Frame																																			
D4/SF	DS1	D4/Super Frame																																			
C-BIT	DS3	C-Bit Frame																																			
M13	DS3	M13 Frame																																			
PCM30	E1	Framed E1, with CAS but no CRC																																			
PCM31	E1	Framed E1, without CAS or CRC																																			
PCM30CRC	E1	Framed E1, with CAS and CRC																																			
PCM31CRC	E1	Framed E1, without CAS but with CRC																																			
FRamed	E3	Framed																																			
TX:FRAMing?	<p><i>Protocols Supported:</i> E1, E3, E4, DS3, DS1</p> <p>Queries the current protocol processor for the framing it is transmitting.</p>																																				
TX:FRAMing < frame >	<p><i>Protocols Supported:</i> E1, E3, E4, DS3</p> <p>Sets the transmitter of the current protocol processor to one of the following framing types:</p> <table border="1"> <thead> <tr> <th><u>Framing</u></th> <th><u>Protocol(s)</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>ESF</td> <td>DS1</td> <td>ESF framing for DS1</td> </tr> <tr> <td>SF/D4</td> <td>DS1</td> <td>SF/D4 framing for DS1</td> </tr> <tr> <td>SLC96</td> <td>DS1</td> <td>SLC-96 framing for DS1</td> </tr> <tr> <td>M13</td> <td>DS3</td> <td>M13 framing for DS3</td> </tr> <tr> <td>C-BIT</td> <td>DS3</td> <td>C-Bit framing for DS3</td> </tr> <tr> <td>UNframed</td> <td>E1, E3, E4, DS3, DS1</td> <td>Unframed</td> </tr> <tr> <td>FRamed</td> <td>E3, E4</td> <td>Framed</td> </tr> <tr> <td>PCM30</td> <td>E1</td> <td>Framed E1, with CAS but no CRC</td> </tr> <tr> <td>PCM31</td> <td>E1</td> <td>Framed E1, without CAS or CRC</td> </tr> <tr> <td>PCM30CRC</td> <td>E1</td> <td>Framed E1, with CAS and CRC</td> </tr> <tr> <td>PCM31CRC</td> <td>E1</td> <td>Framed E1, without CAS but with CRC</td> </tr> </tbody> </table>	<u>Framing</u>	<u>Protocol(s)</u>	<u>Description</u>	ESF	DS1	ESF framing for DS1	SF/D4	DS1	SF/D4 framing for DS1	SLC96	DS1	SLC-96 framing for DS1	M13	DS3	M13 framing for DS3	C-BIT	DS3	C-Bit framing for DS3	UNframed	E1, E3, E4, DS3, DS1	Unframed	FRamed	E3, E4	Framed	PCM30	E1	Framed E1, with CAS but no CRC	PCM31	E1	Framed E1, without CAS or CRC	PCM30CRC	E1	Framed E1, with CAS and CRC	PCM31CRC	E1	Framed E1, without CAS but with CRC
<u>Framing</u>	<u>Protocol(s)</u>	<u>Description</u>																																			
ESF	DS1	ESF framing for DS1																																			
SF/D4	DS1	SF/D4 framing for DS1																																			
SLC96	DS1	SLC-96 framing for DS1																																			
M13	DS3	M13 framing for DS3																																			
C-BIT	DS3	C-Bit framing for DS3																																			
UNframed	E1, E3, E4, DS3, DS1	Unframed																																			
FRamed	E3, E4	Framed																																			
PCM30	E1	Framed E1, with CAS but no CRC																																			
PCM31	E1	Framed E1, without CAS or CRC																																			
PCM30CRC	E1	Framed E1, with CAS and CRC																																			
PCM31CRC	E1	Framed E1, without CAS but with CRC																																			
TX:FREQOFF:LINE?	<p><i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1</p> <p>Returns the current transmitted line frequency offset as a decimal number with one digit.</p>																																				
TX:FREQOFF:LINE < offset >	<p><i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1</p> <p>Sets the transmitted line frequency offset. Valid values are -100.0 to 100.0 in increments of 0.1.</p>																																				
TX:FREQOFF:AU?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Returns the current transmitted AU Frequency offset as a decimal number with one digit.</p>																																				
TX:FREQOFF:AU < offset >	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Sets the transmitted AU frequency offset. Valid values are -100.0 to 100.0 in increments of 0.1.</p>																																				
TX:FREQOFF:SPE? < offset >	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Returns the current transmitted SPE Frequency offset as a decimal number with one digit.</p>																																				

Transmit Command	Description																														
TX:FREQOFF:SPE < offset >	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Sets the transmitted SPE frequency offset. Valid offset values are -100.0 to 100.0 in increments of 0.1.																														
TX:FREQOFF:TU?	<i>Protocols Supported:</i> STM-4 Returns the current transmitted TU Frequency offset as a decimal number with one digit.																														
TX:FREQOFF:TU < offset >	<i>Protocols Supported:</i> STM-4 Sets the transmitted TU frequency offset. Valid values are -100.0 to 100.0 in increments of 0.1.																														
TX:FREQOFF:VT?	<i>Protocols Supported:</i> OC-12 Returns the current transmitted VT frequency offset as a decimal number with one digit.																														
TX:FREQOFF:VT <offset>	<i>Protocols Supported:</i> OC-12 Sets the transmitted VT frequency offset. Valid values are -100.0 to 100.0 in increments of 0.1.																														
TX:INTerface?	<i>Protocols Supported:</i> STM-4, OC-12, Jitter Queries the type of transmit interface.																														
TX:INTerface <interface value>	<i>Protocols Supported:</i> STM-4, OC-12, Jitter Sets the transmit interface speed and type (optical or electrical). Valid interface values are: <table border="1" data-bbox="516 968 1201 1283"> <thead> <tr> <th><u>Interface</u></th> <th><u>Protocol(s)</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>STM0E</td> <td>STM-4</td> <td>52 Mbps electrical interface</td> </tr> <tr> <td>STM1E</td> <td>STM-4</td> <td>155 Mbps electrical interface</td> </tr> <tr> <td>STM0</td> <td>STM-4, Jitter</td> <td>52 Mbps optical interface</td> </tr> <tr> <td>STM1</td> <td>STM-4, Jitter</td> <td>155 Mbps optical interface</td> </tr> <tr> <td>STM4</td> <td>STM-4, Jitter</td> <td>622 Mbps optical interface</td> </tr> <tr> <td>STSX1</td> <td>OC-12</td> <td>52 Mbps electrical interface</td> </tr> <tr> <td>OC1</td> <td>OC-12, Jitter</td> <td>52 Mbps optical interface</td> </tr> <tr> <td>OC3</td> <td>OC-12, Jitter</td> <td>155 Mbps optical interface</td> </tr> <tr> <td>OC12</td> <td>OC-12, Jitter</td> <td>622 Mbps optical interface</td> </tr> </tbody> </table>	<u>Interface</u>	<u>Protocol(s)</u>	<u>Description</u>	STM0E	STM-4	52 Mbps electrical interface	STM1E	STM-4	155 Mbps electrical interface	STM0	STM-4, Jitter	52 Mbps optical interface	STM1	STM-4, Jitter	155 Mbps optical interface	STM4	STM-4, Jitter	622 Mbps optical interface	STSX1	OC-12	52 Mbps electrical interface	OC1	OC-12, Jitter	52 Mbps optical interface	OC3	OC-12, Jitter	155 Mbps optical interface	OC12	OC-12, Jitter	622 Mbps optical interface
<u>Interface</u>	<u>Protocol(s)</u>	<u>Description</u>																													
STM0E	STM-4	52 Mbps electrical interface																													
STM1E	STM-4	155 Mbps electrical interface																													
STM0	STM-4, Jitter	52 Mbps optical interface																													
STM1	STM-4, Jitter	155 Mbps optical interface																													
STM4	STM-4, Jitter	622 Mbps optical interface																													
STSX1	OC-12	52 Mbps electrical interface																													
OC1	OC-12, Jitter	52 Mbps optical interface																													
OC3	OC-12, Jitter	155 Mbps optical interface																													
OC12	OC-12, Jitter	622 Mbps optical interface																													
TX:LABel:HP?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns HP Signal Label, as an 8-bit binary string.																														
TX:LABel:HP <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Sets the 8-bit HP signal label to any value from 0 to 255.																														
TX:LABel:LP?	<i>Protocols Supported:</i> STM-4 Returns LP signal label, as an 8-bit binary string.																														
TX:LABel:LP <value>	<i>Protocols Supported:</i> STM-4 Sets the 8-bit LP signal label to any value from 0 to 255.																														
TX:LABel:PATH?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns PATH signal label, as an 8 bit binary string.																														
TX:LABel:PATH <value>	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Sets the 8-bit PATH signal label to any value from 0 to 255.																														
TX:LABel:VT?	<i>Protocols Supported:</i> OC-12 Returns VT-Path signal label as an 8-bit binary string.																														
TX:LABel:VT <value>	<i>Protocols Supported:</i> OC-12 Sets the 8-bit VT-Path signal label to any value from 0 to 255.																														

Transmit Command	Description																
TX:LASER?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, GIGE, Jitter Returns ON, OFF depending on whether laser is on or off.																
TX:LASER <mode>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, GIGE, Jitter Turns the laser on or off. Valid modes are: ON or OFF.																
TX:LASERTYPE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Returns 1310 or 1550 depending on which laser is selected.																
TX:LASERTYPE <laser>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Selects the laser to use for dual laser systems. Valid lasers are: 1310 or 1550.																
TX:LCODE <mode>	<i>Protocols Supported:</i> E1, DS1 Sets the line coding. Valid modes are: AMI, HDB3, B8ZS.																
TX:LCODE?	<i>Protocols Supported:</i> E1, DS1 Queries the line code transmitted.																
TX:LOOPback:ACTivate <value>	<i>Protocols Supported:</i> DS3 Transmits loopback activation for DS3. Valid values are BURST, CONTinuous, and OFF.																
TX:LOOPback:AUTO	<i>Protocols Supported:</i> DS1 Sets the Auto Response setting to ON or OFF.																
TX:LOOPback:AUTO?	<i>Protocols Supported:</i> DS1 Returns the current auto response setting.																
TX:LOOPback:CODE <value>	<i>Protocols Supported:</i> DS1 Sets the loopback type. The user-defined value is 16 binary bits. The first 8 bits are the loopup code, the second 8 bits are the loopdown code. For example, 0000000011111111, where 00000000 is the loopup code and 11111111 is the loopdown code.																
	<table border="1"> <thead> <tr> <th><u>Parameter</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>PAYLOAD</td> <td>OUT-OF-BAND</td> </tr> <tr> <td>SMARTJACK</td> <td>OUT-OF-BAND</td> </tr> <tr> <td>OUTLINE</td> <td>OUT-OF-BAND</td> </tr> <tr> <td>4BIT</td> <td>IN-BAND</td> </tr> <tr> <td>5BIT</td> <td>IN-BAND</td> </tr> <tr> <td>INLINE</td> <td>IN-BAND</td> </tr> <tr> <td><user-defined></td> <td>IN-BAND</td> </tr> </tbody> </table>	<u>Parameter</u>	<u>Description</u>	PAYLOAD	OUT-OF-BAND	SMARTJACK	OUT-OF-BAND	OUTLINE	OUT-OF-BAND	4BIT	IN-BAND	5BIT	IN-BAND	INLINE	IN-BAND	<user-defined>	IN-BAND
<u>Parameter</u>	<u>Description</u>																
PAYLOAD	OUT-OF-BAND																
SMARTJACK	OUT-OF-BAND																
OUTLINE	OUT-OF-BAND																
4BIT	IN-BAND																
5BIT	IN-BAND																
INLINE	IN-BAND																
<user-defined>	IN-BAND																
TX:LOOPback:CODE?	<i>Protocols Supported:</i> DS1 Returns the current setting for the loopback code. For user-defined values, it returns the 16 binary bits.																
TX:LOOPback:CYCle <value>	<i>Protocols Supported:</i> DS3 Sets the number of loopback cycles that are sent for Burst mode. A value from 1 to 16 can be entered.																
TX:LOOPback:CYCle?	<i>Protocols Supported:</i> DS3 Returns the current setting of the TX:LOOPBACK:CYCLE command.																
TX:LOOPback:DEACTivate <value>	<i>Protocols Supported:</i> DS3 Transmits loopback activation for DS3. Valid values are BURST, CONTinuous, and OFF.																
TX:LOOPback:DOWNcode?	<i>Protocols Supported:</i> DS1 Returns the binary image of the loopdown code set in Type and Code.																

Transmit Command	Description																								
TX:LOOPback:LINE <value>	<i>Protocols Supported:</i> DS1 Sets the Tester Line Looped setting to UP or DOWN.																								
TX:LOOPback:LINE?	<i>Protocols Supported:</i> DS1 Returns the current Tester Line Looped setting.																								
TX:LOOPback:PAYload <value>	<i>Protocols Supported:</i> DS1 Sets the Tester payload Looped setting to UP or DOWN.																								
TX:LOOPback:PAYload?	<i>Protocols Supported:</i> DS1 Returns the current Tester Payload Looped setting.																								
TX:LOOPback:RX:LINE?	<i>Protocols Supported:</i> DS3 Returns the last loopback value received. The value returned is from the TX:LOOPBACK:ACTIVATE or TX:LOOPBACK:DEACTIVATE command.																								
TX:LOOPback:RX:SECOnds?	<i>Protocols Supported:</i> DS3 Returns the number of seconds since a loopback Activate or Deactivate command has been received.																								
TX:LOOPback:RX:TYPE?	<i>Protocol Supported:</i> DS3 Returns the value of the last loopback type received. If 1 is returned, the last loopback type received is Activate. If 2 is returned, the last loopback type received is Deactivate.																								
TX:LOOPback:SEND <value>	<i>Protocols Supported:</i> DS1 Transmits loopback activation. Argument values are UP or DOWN. This takes several seconds to take effect when an IN-BAND type is sent. The TX:LOOP:STATus command can be used to determine when it has taken effect.																								
TX:LOOPback:TYPE <value>	<i>Protocols Supported:</i> E1, DS3, DS1 Sets the loopback type.																								
	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Protocol(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>IN</td> <td>DS1</td> <td>IN-BAND</td> </tr> <tr> <td>OUT</td> <td>DS1</td> <td>OUT-OF-BAND (ESF Framing)</td> </tr> <tr> <td>NONE</td> <td>E1</td> <td>No loopback</td> </tr> <tr> <td>LINE</td> <td>E1</td> <td>Line Loopback</td> </tr> <tr> <td>PAYLOAD</td> <td>E1</td> <td>Payload Loopback</td> </tr> <tr> <td>1 to 28</td> <td>DS3</td> <td>Part of signal looped</td> </tr> <tr> <td>ALL</td> <td>DS3</td> <td>Entire signal</td> </tr> </tbody> </table>	Parameter	Protocol(s)	Description	IN	DS1	IN-BAND	OUT	DS1	OUT-OF-BAND (ESF Framing)	NONE	E1	No loopback	LINE	E1	Line Loopback	PAYLOAD	E1	Payload Loopback	1 to 28	DS3	Part of signal looped	ALL	DS3	Entire signal
Parameter	Protocol(s)	Description																							
IN	DS1	IN-BAND																							
OUT	DS1	OUT-OF-BAND (ESF Framing)																							
NONE	E1	No loopback																							
LINE	E1	Line Loopback																							
PAYLOAD	E1	Payload Loopback																							
1 to 28	DS3	Part of signal looped																							
ALL	DS3	Entire signal																							
TX:LOOPback:TYPE?	<i>Protocols Supported:</i> E1, DS3, DS1 Returns the current loopback type.																								
TX:LOOPback:UPcode?	<i>Protocols Supported:</i> DS1 Returns the binary image of the loopup code set in TYPE and CODE.																								
TX:M13:INSert:@N?	<i>Protocols Supported:</i> DS3 Queries the inserted DS1 channel for instance N on the M13 Mux. Values returned are 1-28 or "ALL," where "ALL" means "All Background" (Broadcast).																								
TX:M13:INSert:@N <value>	<i>Protocols Supported:</i> DS3 Sets the DS1 insert channel for instance N to one of the 28 M13 channels available. Values are 1 to 28 or "ALL." "ALL" means "All Background" (Broadcast).																								

Transmit Command	Description																																																																																										
TX:MAPping?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E1, E3, E4, DS3, DS1 Queries the protocol processor for the mapping it is transmitting.																																																																																										
TX:MAPping <mapping>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E1, E3, E4, DS3, DS1 Sets the transmitter to one of the following mappings.																																																																																										
	<table border="1"> <thead> <tr> <th><u>Mapping</u></th> <th><u>Protocol(s)</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr><td>STS192CBULK</td><td>OC-192</td><td>STS-192c Bulk Fill</td></tr> <tr><td>STS48</td><td>OC-192</td><td>STS-48 Drop/Insert</td></tr> <tr><td>AU464CBULK</td><td>STM-64</td><td>AU-4-64c Bulk Fill</td></tr> <tr><td>AU416C</td><td>STM-64</td><td>AU-4-16c Drop/Insert</td></tr> <tr><td>AU416CBULK</td><td>STM-16</td><td>AU-4-16c Bulk Fill</td></tr> <tr><td>AU44C</td><td>STM-16</td><td>AU-4-4c Drop/Insert</td></tr> <tr><td>STS48CBULK</td><td>OC-48</td><td>STS-48c Bulk Fill</td></tr> <tr><td>STS12</td><td>OC-48</td><td>STS-12 Drop/Insert</td></tr> <tr><td>C44CBULK</td><td>STM-4</td><td>C4-4c Bulk Fill</td></tr> <tr><td>C4BULK</td><td>STM-4</td><td>C-4 Bulk Fill</td></tr> <tr><td>E4</td><td>STM-4</td><td>E4 Drop/Insert</td></tr> <tr><td>E3</td><td>STM-4, E4</td><td>E3 Drop/Insert</td></tr> <tr><td>DS3</td><td>STM-4, OC-12</td><td>DS3 Drop/Insert</td></tr> <tr><td>C3BULK</td><td>STM-4</td><td>C-3 Bulk Fill</td></tr> <tr><td>C2BULK</td><td>STM-4</td><td>C-2 Bulk Fill</td></tr> <tr><td>C12BULK</td><td>STM-4</td><td>C-12 Bulk Fill</td></tr> <tr><td>C11BULK</td><td>STM-4</td><td>C-11 Bulk Fill</td></tr> <tr><td>E1</td><td>STM-4, E3, OC-12, DS3</td><td>E1 Drop/Insert</td></tr> <tr><td>FRACTIONal</td><td>E1</td><td>Fractional E1</td></tr> <tr><td>DS1</td><td>STM-4, OC-12, DS3</td><td>DS1 Drop/Insert</td></tr> <tr><td>STS12CBULK</td><td>OC-12</td><td>STS-12c Bulk Fill</td></tr> <tr><td>STS3CBULK</td><td>OC-12</td><td>STS-3c Bulk Fill</td></tr> <tr><td>STS1BULK</td><td>OC-12</td><td>STS1 Bulk Fill</td></tr> <tr><td>VT6BULK</td><td>OC-12</td><td>VT6 Bulk Fill</td></tr> <tr><td>VT2BULK</td><td>OC-12</td><td>VT2 Bulk Fill</td></tr> <tr><td>VT15BULK</td><td>OC-12</td><td>VT1.5 Bulk Fill</td></tr> <tr><td>BULK</td><td>E1, E3, E4, DS1, DS3</td><td>Bulk Fill</td></tr> <tr><td>56KFRACTIONal</td><td>DS1</td><td>Fractional T1, 56K</td></tr> <tr><td>64KFRACTIONal</td><td>DS1</td><td>Fractional T1, 64K</td></tr> </tbody> </table>	<u>Mapping</u>	<u>Protocol(s)</u>	<u>Meaning</u>	STS192CBULK	OC-192	STS-192c Bulk Fill	STS48	OC-192	STS-48 Drop/Insert	AU464CBULK	STM-64	AU-4-64c Bulk Fill	AU416C	STM-64	AU-4-16c Drop/Insert	AU416CBULK	STM-16	AU-4-16c Bulk Fill	AU44C	STM-16	AU-4-4c Drop/Insert	STS48CBULK	OC-48	STS-48c Bulk Fill	STS12	OC-48	STS-12 Drop/Insert	C44CBULK	STM-4	C4-4c Bulk Fill	C4BULK	STM-4	C-4 Bulk Fill	E4	STM-4	E4 Drop/Insert	E3	STM-4, E4	E3 Drop/Insert	DS3	STM-4, OC-12	DS3 Drop/Insert	C3BULK	STM-4	C-3 Bulk Fill	C2BULK	STM-4	C-2 Bulk Fill	C12BULK	STM-4	C-12 Bulk Fill	C11BULK	STM-4	C-11 Bulk Fill	E1	STM-4, E3, OC-12, DS3	E1 Drop/Insert	FRACTIONal	E1	Fractional E1	DS1	STM-4, OC-12, DS3	DS1 Drop/Insert	STS12CBULK	OC-12	STS-12c Bulk Fill	STS3CBULK	OC-12	STS-3c Bulk Fill	STS1BULK	OC-12	STS1 Bulk Fill	VT6BULK	OC-12	VT6 Bulk Fill	VT2BULK	OC-12	VT2 Bulk Fill	VT15BULK	OC-12	VT1.5 Bulk Fill	BULK	E1, E3, E4, DS1, DS3	Bulk Fill	56KFRACTIONal	DS1	Fractional T1, 56K	64KFRACTIONal	DS1	Fractional T1, 64K
<u>Mapping</u>	<u>Protocol(s)</u>	<u>Meaning</u>																																																																																									
STS192CBULK	OC-192	STS-192c Bulk Fill																																																																																									
STS48	OC-192	STS-48 Drop/Insert																																																																																									
AU464CBULK	STM-64	AU-4-64c Bulk Fill																																																																																									
AU416C	STM-64	AU-4-16c Drop/Insert																																																																																									
AU416CBULK	STM-16	AU-4-16c Bulk Fill																																																																																									
AU44C	STM-16	AU-4-4c Drop/Insert																																																																																									
STS48CBULK	OC-48	STS-48c Bulk Fill																																																																																									
STS12	OC-48	STS-12 Drop/Insert																																																																																									
C44CBULK	STM-4	C4-4c Bulk Fill																																																																																									
C4BULK	STM-4	C-4 Bulk Fill																																																																																									
E4	STM-4	E4 Drop/Insert																																																																																									
E3	STM-4, E4	E3 Drop/Insert																																																																																									
DS3	STM-4, OC-12	DS3 Drop/Insert																																																																																									
C3BULK	STM-4	C-3 Bulk Fill																																																																																									
C2BULK	STM-4	C-2 Bulk Fill																																																																																									
C12BULK	STM-4	C-12 Bulk Fill																																																																																									
C11BULK	STM-4	C-11 Bulk Fill																																																																																									
E1	STM-4, E3, OC-12, DS3	E1 Drop/Insert																																																																																									
FRACTIONal	E1	Fractional E1																																																																																									
DS1	STM-4, OC-12, DS3	DS1 Drop/Insert																																																																																									
STS12CBULK	OC-12	STS-12c Bulk Fill																																																																																									
STS3CBULK	OC-12	STS-3c Bulk Fill																																																																																									
STS1BULK	OC-12	STS1 Bulk Fill																																																																																									
VT6BULK	OC-12	VT6 Bulk Fill																																																																																									
VT2BULK	OC-12	VT2 Bulk Fill																																																																																									
VT15BULK	OC-12	VT1.5 Bulk Fill																																																																																									
BULK	E1, E3, E4, DS1, DS3	Bulk Fill																																																																																									
56KFRACTIONal	DS1	Fractional T1, 56K																																																																																									
64KFRACTIONal	DS1	Fractional T1, 64K																																																																																									
TX:NDF:AU?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns YES or NO, depending on the value of the AU New Data Flag.																																																																																										
TX:NDF:AU <mode>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Sets the AU New Data Flag. Valid modes are: YES or NO.																																																																																										
TX:NDF:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns YES, NO depending on the value of the STS New Data Flag.																																																																																										
TX:NDF:STS <mode>	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Set the STS New Data Flag. Valid modes are: YES or NO.																																																																																										
TX:NDF:TU?	<i>Protocols Supported:</i> STM-4 Returns YES, NO depending on the value of the TU New Data Flag.																																																																																										
TX:NDF:TU <value>	<i>Protocols Supported:</i> STM-4 Sets the TU New Data Flag. Valid modes are: YES or NO.																																																																																										

Transmit Command	Description
TX:NDF:VT?	<i>Protocols Supported:</i> OC-12 Returns YES, NO depending on the value of the VT New Data Flag.
TX:NDF:VT <value>	<i>Protocols Supported:</i> OC-12 Sets the VT New Data Flag. Valid modes are: YES or NO.
TX:OH:<OH BYTE>?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the currently transmitted SDH/SONET overhead byte or trace. J0 Trace is returned as quoted 15-byte string (CRC-7 byte is removed). J1 and J2 traces are returned as quoted 62-byte strings, with the last two bytes truncated (Carriage Return, Line Feed). If all ones, a trace will be returned as ALLONES, without any quotes. Other overhead bytes are returned in Hexadecimal format (#Hxx).
TX:OH:<OH BYTE> <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the currently transmitted SDH/SONET overhead byte or trace. J0 is specified as a 15-byte string. J1 and J2 traces are specified as quoted 0 to 62 byte strings. If set as all ones, a trace should be specified as ALLONES, without any quotes. Carriage Return and Line Feed are always added to the specified string for a trace. Other overhead bytes may be specified in any numeric integer format. Valid two-character strings for OH BYTE specification are: <u>SOH (SDH) / TOH (SONET):</u> A1, A2, J0, Z0 E1, F1 D1, D2, D3 K1, K2 D4, D5, D6 D7, D8, D9 D10, D11, D12 S1, Z2, E2 <u>9 Byte HP (SDH) / Path (SONET):</u> C2, G1, F2, F3, K3, N1, J1, H4 <u>9 Byte TU-3 LP (SDH):</u> LPC2, LPG1, LPF2, LPF3, LPK3, LPN1 <u>4 Byte LP (SDH) / VT (SONET):</u> J2, N2, K4
TX:OH:INTRusive: <group>?	<i>Protocols Supported:</i> STM64, OC192 Queries whether a group of overhead bytes is changed or not. Only used when in passthru mode, although the setting and query is valid when not in passthru mode, and no error should be returned if set or queried when not in passthru mode.

Transmit Command	Description
TX:OH:INTRusive:<group> <mode>	<p><i>Protocols Supported:</i> STM64, OC192</p> <p>Only used when in passthru mode, although the setting and query is valid when not in passthru mode, and no error should be returned if set or queried when not in passthru mode. Valid modes are: YES or NO.</p> <p>When Passthru mode is ON, it must be specified whether the overhead bytes are obtained from the received signal (passed thru), or if they are modified according to the TX:OH settings. These can be done only in groups, which are:</p> <p>A1 A2 J0Z0 (J0 or Z0 byte) B1 E1 F1 D1D3 (D1, D2, D3) H1H3 (H1, H2, H3) D3D12 (D3 through D12) B2 K1 K2 S1Z1 (S1 or Z1 byte) M1Z2 (M1 or Z2 byte) E2</p> <p>The Group name is passed as part of the command, followed by a value of YES or NO. YES means the bytes in that group are being passed through without change (intrusion). Example: TX:OH:INTR:D3D12 YES</p>
TX:ORDER?	<p><i>Protocols Supported:</i> STM-4, OC-12</p> <p>Returns values as in TX:ORDER.</p>
TX:ORDER <value>	<p><i>Protocols Supported:</i> STM-4, OC-12</p> <p>Sets the orderwire add. Parameter values are as follows:</p> <p>E1 Insert bit stream from orderwire into E1 (E2 single byte, as in TX OH settings).</p> <p>E2 Insert bit stream from orderwire into E2 (E1 single byte, as in TX OH settings).</p> <p>NONE E1 and E2 single bytes, as in TX OH settings.</p>
TX:PASSthru?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E3</p> <p>Returns the pass-thru (thru-mode) setting.</p>
TX:PASSthru <mode>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E3</p> <p>Sets the pass-thru (thru-mode) setting. NO is the same as OFF. Valid modes for STM-4 are: INTRusive, INTRusive, AddDrop, NONINTRusive. Valid modes for STM-16 are: YES or NO.</p>
TX:PATtern:AU:BG?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Returns the 8-bit pattern in background AUs as a 8-bit binary integer.</p>

Transmit Command	Description
TX:PATtern:AU:BG <pattern>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Sets the pattern in background AUs. This is an 8-bit pattern.
TX:PATtern:BG?	<i>Protocols Supported:</i> E1, E3, E4, DS3, DS1 Returns the pattern in the payload of background frames.
TX:PATtern:BG <pattern>	<i>Protocols Supported:</i> E1, E3, E4, DS3, DS1 Sets the pattern in the payload of background frames.
TX:PATtern:STS:BG?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the 8 bit pattern in background STS's as an 8-bit binary integer.
TX:PATtern:STS:BG <pattern>	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Sets the pattern in background STS's. This is an 8-bit pattern.
TX:PATtern:TU:BG?	<i>Protocols Supported:</i> STM-4 Returns the 8-bit pattern in background TU's as an 8-bit binary integer.
TX:PATtern:TU:BG <pattern>	<i>Protocols Supported:</i> STM-4 Sets the pattern in background TU's. This is an 8-bit pattern.
TX:PATtern:VT:BG?	<i>Protocols Supported:</i> OC-12 Returns the 8-bit pattern in background VT's as an 8-bit pattern.
TX:PATtern:VT:BG <pattern>	<i>Protocols Supported:</i> OC-12 Sets the pattern in background VT's. This is an 8-bit pattern.
TX:PATtern?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the current protocol processor for the (foreground) pattern it is sending. Returns a binary pattern for user-defined bit string, or a predefined pattern. See <i>TX:PATtern</i> for Predefined Patterns.

Transmit Command	Description	
TX:PATtern <pattern>	<p><i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1</p> <p>Sets the (foreground) transmit pattern. Pattern parameter can be a numeric value for a user-defined bit pattern, or a predefined pattern. See Chapter 2-1, <i>Pattern Setting and Reporting</i>, for more specific examples. Valid predefined patterns, protocols, and descriptions are:</p>	
	<u>Pattern</u>	<u>Protocol(s)</u>
	PRBS6	DS1
	PRBS9	E1, E3, STM-4, OC-12, DS1
	PRBS9INV	E1, E3, STM-4, OC-12
	PRBS11	E1, E3, STM-4, OC-12, DS1
	PRBS11INV	E1, E3, STM-4, OC-12
	PRBS15	E1, E3, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1
	PRBS15INV	E1, E3, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3
	PRBS20	E1, E3, E4, STM-4, OC-12, DS3, DS1
	PRBS20INV	E1, E3, E4, STM-4, OC-12, DS3
	PRBS23	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1
	PRBS23INV	E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192
	PRBS31	STM-4, STM-16, STM-64, OC-12, OC-48, OC-192
	PRBS31INV	STM-4, STM-16, STM-64, OC-12, OC-48, OC-192
	ALL ONES	DS3, DS1
	ALL ZEROS	DS3, DS1
	QRSS	DS1
	3in24	DS1
	1in8	DS1
	1010	DS1
	55DLY	DS1
	T1-2	DS1
	T1-3	DS1
		<u>Description</u>
		2 ⁶ -1 PRBS pattern
		2 ⁹ -1 PRBS pattern
		2 ⁹ -1 Inverted PRBS pattern
		2 ¹¹ -1 PRBS pattern
		2 ¹¹ -1 Inverted PRBS pattern
		2 ¹⁵ -1 PRBS pattern
		2 ¹⁵ -1 Inverted PRBS pattern
		2 ²⁰ -1 PRBS pattern
		2 ²⁰ -1 Inverted PRBS pattern
		2 ²³ -1 PRBS pattern
		2 ²³ -1 Inverted PRBS pattern
		2 ³¹ -1 PRBS pattern
		2 ³¹ -1 Inverted PRBS pattern
		All Ones pattern
		All Zeros pattern
		QRSS pattern
		3 in 24 pattern
		1 in 8 pattern
		1010 pattern
		55 Octet Daly pattern
		T1-2 pattern (96 octet pattern)
		T1-3 pattern (54 octet pattern)

Transmit Command	Description												
TX:PATtern <pattern> (continued)	T1-4	DS1	T1-4 pattern (120 octet pattern)										
	T1-5	DS1	T1-5 pattern (53 octet pattern)										
	55-OCTET	DS1	55-Octet pattern										
	DDS-1	DS1	100 bytes of ALL ONES followed by 100 bytes of ALL ZEROS.										
	DDS-2	DS1	100 bytes of 01111110 followed by 100 bytes of ALL ZEROS.										
	DDS-3	DS1	01001100 transmitted continuously										
	DDS-4	DS1	00000010 transmitted continuously										
	DDS-5	DS1	DDS-1 four times, DDS-2 four times, DDS-3 once, DDS-4 once transmitted continuously.										
	DDS-6	DS1	11111110 repeated seven times followed by an octet of ALL ONES continuously.										
BRIDGE	DS1	21 pattern bridge tap sequence											
MULTI	DS1	5 pattern multi-pattern sequence											
TX:PTR:ADJ:AU <count>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Adjusts the AU pointer by either incrementing or decrementing it, rather than assigning it a "new" value, as is done in TX:PTR:AU. The <count> may be one of the following:</p> <table border="1"> <thead> <tr> <th>Count Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>single increment</td> </tr> <tr> <td>-1</td> <td>single decrement</td> </tr> <tr> <td>2 to 8</td> <td>increment burst of 2 to 8</td> </tr> <tr> <td>-2 to -8</td> <td>decrement burst of 2 to 8</td> </tr> </tbody> </table>			Count Type	Description	1	single increment	-1	single decrement	2 to 8	increment burst of 2 to 8	-2 to -8	decrement burst of 2 to 8
Count Type	Description												
1	single increment												
-1	single decrement												
2 to 8	increment burst of 2 to 8												
-2 to -8	decrement burst of 2 to 8												
TX:PTR:ADJ:STS <count>	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Adjusts the STS pointer by either incrementing or decrementing it, rather than assigning it a "new" value, as is done in TX:PTR:STS. Valid count types and descriptions are:</p> <table border="1"> <thead> <tr> <th>Count Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>single increment</td> </tr> <tr> <td>-1</td> <td>single decrement</td> </tr> <tr> <td>2 to 8</td> <td>increment burst of 2 to 8</td> </tr> <tr> <td>-2 to -8</td> <td>decrement burst of 2 to 8</td> </tr> </tbody> </table>			Count Type	Description	1	single increment	-1	single decrement	2 to 8	increment burst of 2 to 8	-2 to -8	decrement burst of 2 to 8
Count Type	Description												
1	single increment												
-1	single decrement												
2 to 8	increment burst of 2 to 8												
-2 to -8	decrement burst of 2 to 8												
TX:PTR:ADJ:TU <count>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Adjusts the TU pointer by either incrementing or decrementing it, rather than assigning it a "new" value, as is done in TX:PTR:TU. The <count> may be one of the following:</p> <table border="1"> <thead> <tr> <th>Count Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>single increment</td> </tr> <tr> <td>-1</td> <td>single decrement</td> </tr> <tr> <td>2 to 8</td> <td>increment burst of 2 to 8</td> </tr> <tr> <td>-2 to -8</td> <td>decrement burst of 2 to 8</td> </tr> </tbody> </table>			Count Type	Description	1	single increment	-1	single decrement	2 to 8	increment burst of 2 to 8	-2 to -8	decrement burst of 2 to 8
Count Type	Description												
1	single increment												
-1	single decrement												
2 to 8	increment burst of 2 to 8												
-2 to -8	decrement burst of 2 to 8												

Transmit Command	Description										
TX:PTR:ADJ:VT <count>	<p><i>Protocols Supported:</i> OC-12</p> <p>Adjusts the VT pointer by either incrementing or decrementing it, rather than assigning it a "new" value, as is done in TX:PTR:VT. The <count> may be one of the following:</p> <table border="1"> <thead> <tr> <th>Count Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>single increment</td> </tr> <tr> <td>-1</td> <td>single decrement</td> </tr> <tr> <td>2 to 8</td> <td>increment burst of 2 to 8</td> </tr> <tr> <td>-2 to -8</td> <td>decrement burst of 2 to 8</td> </tr> </tbody> </table>	Count Type	Description	1	single increment	-1	single decrement	2 to 8	increment burst of 2 to 8	-2 to -8	decrement burst of 2 to 8
Count Type	Description										
1	single increment										
-1	single decrement										
2 to 8	increment burst of 2 to 8										
-2 to -8	decrement burst of 2 to 8										
TX:PTR:AU?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Returns the AU Pointer value currently being transmitted. Valid range is 0 to 782.</p>										
TX:PTR:AU <value>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64</p> <p>Sets a new AU pointer. Valid values are 0 to 782.</p>										
TX:PTR:STS?	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Returns STS Pointer value currently being transmitted. Valid range is 0 to 782.</p>										
TX:PTR:STS <value>	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Sets a new STS pointer. Valid values are 0 to 782.</p>										
TX:PTR:TU?	<p><i>Protocols Supported:</i> STM-4</p> <p>Returns the TU Pointer value currently being transmitted.</p>										
TX:PTR:TU <value>	<p><i>Protocols Supported:</i> STM-4</p> <p>Sets a new TU pointer. Valid range depends on the TU type.</p> <table border="1"> <thead> <tr> <th>TU Type</th> <th>Range</th> </tr> </thead> <tbody> <tr> <td>TU-3</td> <td>0-764</td> </tr> <tr> <td>TU-2</td> <td>0-427</td> </tr> <tr> <td>TU-12</td> <td>0-139</td> </tr> <tr> <td>TU-11</td> <td>0-103</td> </tr> </tbody> </table>	TU Type	Range	TU-3	0-764	TU-2	0-427	TU-12	0-139	TU-11	0-103
TU Type	Range										
TU-3	0-764										
TU-2	0-427										
TU-12	0-139										
TU-11	0-103										
TX:PTR:VT?	<p><i>Protocols Supported:</i> OC-12</p> <p>Returns VT pointer value currently being transmitted.</p>										
TX:PTR:VT <value>	<p><i>Protocols Supported:</i> OC-12</p> <p>Sets a new VT pointer. Valid values are 0 to 139 for VT2 and 0 to 103 for VT1.5.</p>										
TX:RTD:ACTION <state>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Starts and stops the round-trip delay function. Valid <state> values are:</p> <table border="1"> <tbody> <tr> <td>SINGLE</td> <td>Monitors for a single RTD event. If the event occurs, the duration is reported and the state returns to Inactive.</td> </tr> <tr> <td>STOP</td> <td>Stops RTD monitoring. The state returns to Inactive.</td> </tr> <tr> <td>CONTInuos</td> <td>Constantly monitors for RTD events and updates the Round Trip Delay Time durations.</td> </tr> </tbody> </table>	SINGLE	Monitors for a single RTD event. If the event occurs, the duration is reported and the state returns to Inactive.	STOP	Stops RTD monitoring. The state returns to Inactive.	CONTInuos	Constantly monitors for RTD events and updates the Round Trip Delay Time durations.				
SINGLE	Monitors for a single RTD event. If the event occurs, the duration is reported and the state returns to Inactive.										
STOP	Stops RTD monitoring. The state returns to Inactive.										
CONTInuos	Constantly monitors for RTD events and updates the Round Trip Delay Time durations.										
TX:RTD:GOOD:TIME?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Queries and reports the current setting of the RTD's Consecutive Good Time Required function. This value indicates the duration of the number of valid frames that occur before the round-trip delay function is confirmed to be activated. Valid values for this command range from 0.125 msec to 2047.875 msec.</p>										

Transmit Command	Description																		
TX:RTD:GOOD:TIME <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the value for the RTD's Consecutive Good Time Required function. Valid values range from 0.125 msec to 2047.875 msec.																		
TX:RTD:GOOD:FRAME?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries and reports the current setting of the RTD's Consecutive Good Frames Required function. This value indicates the number of valid frames that occur before the round-trip delay function is confirmed to be activated. Valid values for this command range from 1 to 16383 frames.																		
TX:RTD:GOOD:FRAME <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the value for the RTD's Consecutive Good Frames Required function. Value values range from 1 to 16383 frames.																		
TX:SIGLEVel?	<i>Protocols Supported:</i> E1, DS3, DS1 Queries the current protocol processor for the signal level it is transmitting.																		
TX:SIGLEVel <value>	<i>Protocols Supported:</i> E1, DS3, DS1 Sets the transmitter of the current protocol processor to one of the following signal levels: <table border="0" style="margin-left: 40px;"> <tr> <td>0DB</td> <td>for 0 dBdsx</td> <td>E1, DS1</td> </tr> <tr> <td>-7.5DB</td> <td>for -7.5 dBdsx</td> <td>E1, DS1</td> </tr> <tr> <td>-15DB</td> <td>for -15 dBdsx</td> <td>E1, DS1</td> </tr> <tr> <td>DSX3</td> <td>for DSX-3</td> <td>DS3 only</td> </tr> <tr> <td>DS3H</td> <td>for DS3 High</td> <td>DS3 only</td> </tr> <tr> <td>DS3L</td> <td>for DS3 Low</td> <td>DS3 only</td> </tr> </table>	0DB	for 0 dBdsx	E1, DS1	-7.5DB	for -7.5 dBdsx	E1, DS1	-15DB	for -15 dBdsx	E1, DS1	DSX3	for DSX-3	DS3 only	DS3H	for DS3 High	DS3 only	DS3L	for DS3 Low	DS3 only
0DB	for 0 dBdsx	E1, DS1																	
-7.5DB	for -7.5 dBdsx	E1, DS1																	
-15DB	for -15 dBdsx	E1, DS1																	
DSX3	for DSX-3	DS3 only																	
DS3H	for DS3 High	DS3 only																	
DS3L	for DS3 Low	DS3 only																	
TX:SLOT?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Returns the slot number for Transmit Overhead setting.																		
TX:SLOT <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets a slot number for the Transmit Overhead setting. For SDH, a slot is derived from the AU and TUG-3 number, and the STS number for SONET. Note: The slot specification for setting overhead can be different from the inserted Foreground STS or AU and TUG-3 combination.																		
TX:SPARE:BIT?	<i>Protocols Supported:</i> E1 Returns the spare bit number generated (first parameter in the TX:SPARE command).																		
TX:SPARE:VALUE?	<i>Protocols Supported:</i> E1 Returns the spare bit value generated (second parameter in the TX:SPARE command).																		
TX:SPARE:<SpareBit> <value>	<i>Protocols Supported:</i> E1 Sets the spare bits generated in the E1 FAS channel. If the <SpareBit> is 0, then the number in bits 5 to 8 of "value" is be applied to all spare bits. If the <SpareBit> is 4 to 8, then the number in "value" will be applied as an 8-bit stream to the SpareBit bit.																		
TX:SS?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Returns values as in TX:SS.																		

Transmit Command	Description
TX:SS <ss>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 The SS bits are the two bits of the H1 byte between the NDF flag and STS pointer. Valid values for <ss> are 0 to 3.
TX:STS:INSert?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the number of the current STS inserted, or "ALL" for broadcast mode. A.K.A. "SPE Under Test".
TX:STS:INSert <fg>	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Sets the Inserted STS to "ALL" (Broadcast mode) or numeric. Also known as "SPE Under Test".
TX:TCM:API?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries and reports the current value of the TCM Trace. Valid values that can appear for this command are: ALLONES, ALLZEROS, or any user defines string with a 15-character maximum value.
TX:TCM:API <trace>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Sets the transmitted TCM trace value. Valid <trace> values are: ALLONES Selects an All Ones pattern for the TCM Trace. ALLZEROS Selects an All Zeros pattern for the TCM Trace. User Defines Allows you to enter a user defined string from 1- to 15- characters in length.
TX:TCM:MODE?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries and reports the current status of the unit's TCM mode function. Enable appears if TCM mode is on. Disable appears if TCM mode is off.
TX:TCM:MODE <state>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Enables and disables TCM mode. Valid <state> values are: ENABLE Turns TCM mode on. DISABLE Turns TCM mode off.
TX:TU:INSert?	<i>Protocols Supported:</i> STM-4 Returns the number of the current TU inserted, or "ALL" for broadcast mode.
TX:TU:INSert <fg>	<i>Protocols Supported:</i> STM-4 Sets the Inserted TU and TUG-2 based on one of the following values: fg value Description ALL All TUs are inserted (broadcast) 1 to NN Numeric value of TU-11, TU-12, or TU-2 inserted <u>NN has the following values, depending on the container type and AU:</u> NN=1 if C4-16c, C4-4c, C-4, or AU-3 and C-3 NN=7 if C-2 NN=84 if C-12 NN=63 if C-11 NN=3 if AU-4 and C-3
TX:TUG3:INSert?	<i>Protocols Supported:</i> STM-4 Returns the number of the current TUG-3 inserted.
TX:TUG3:INSert <value>	<i>Protocols Supported:</i> STM-4 Sets the inserted TUG-3. Valid values are: 1, 2, or 3
TX:XBITS?	<i>Protocols Supported:</i> E1 Returns the first CAS byte in the transmitted 16-frame multiframe, with the non-X-bits in the byte set to 0. The byte is returned as an 8-bit binary number.

Transmit Command	Description						
TX:XBITs <value>	<i>Protocols Supported:</i> E1 Sets the X-bits in the first byte of the transmitted CAS multiframe. The non-X-bits are ignored.						
TX:VT:INSErt?	<i>Protocols Supported:</i> OC-12 Returns the number of the current VT channel inserted, or "ALL" for broadcast mode.						
TX:VT:INSErt <VT channel>	<i>Protocols Supported:</i> OC-12 Sets the inserted VT channel based on one of the following values: <table border="1"> <thead> <tr> <th><u>VT channel value</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>ALL</td> <td>All VTs are inserted (broadcast)</td> </tr> <tr> <td>1 to N</td> <td>Numeric value of VT2 or VT1.5 inserted, where N is 21 if VT2 or N is 28 if VT1.5</td> </tr> </tbody> </table>	<u>VT channel value</u>	<u>Description</u>	ALL	All VTs are inserted (broadcast)	1 to N	Numeric value of VT2 or VT1.5 inserted, where N is 21 if VT2 or N is 28 if VT1.5
<u>VT channel value</u>	<u>Description</u>						
ALL	All VTs are inserted (broadcast)						
1 to N	Numeric value of VT2 or VT1.5 inserted, where N is 21 if VT2 or N is 28 if VT1.5						

RX (Sense) Branch

The RX branch is used to set and retrieve Receive settings. Alternatively, each command can be sent using the "SENS" or "SENSE" keyword instead of the "RX" keyword.

SENSE Command	Description
RX:ABCD:<channel>?	<i>Protocols Supported:</i> E1 Queries E1 for the value received in any of the 30 4-bit CAS ABCD bits. Channel must be a decimal integer from 1 to 30. ABCD bits are in lower 4 bits of byte value returned.
RX:ABCD:DS0?	<i>Protocols Supported:</i> DS1 Returns the ABCD Signaling bits in the dropped DS0.
RX:APS:ABORT	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Aborts the APS protection switch measurement criteria.
RX:APS:CRITeria?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the APS protection switch measurement criteria.
RX:APS:CRITeria <criteria>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the APS protection switch measurement criteria. Valid criteria are: B1, SEF, AISL, AISP, or PRBS. AISL is Line AIS, and AISP is Path AIS.
RX:APS:FRAMES?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the APS protection switch measurement time in frames from the test last done. If none were done since booting, it returns 0. If measuring, returns 0.
RX:APS:START	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Starts the APS protection switch measurement criteria.
RX:APS:STATE?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the APS protection switch measurement state, either DONE or MEASURING.
RX:AU:DROp?	<i>Protocols Supported:</i> STM-4, STM-16 Queries the current AU dropped.
RX:AU:DROp <value>	<i>Protocols Supported:</i> STM-4, STM-16 Sets the current AU dropped. Value must be numeric.

SENSe Command	Description
RX:AU:TYPE?	<i>Protocols Supported:</i> STM-4 Queries the current AU Type received.
RX:AU:TYPE <value>	<i>Protocols Supported:</i> STM-4 Sets the current AU type received. Valid values are: AU-3, AU-4, AU-4-4C
RX:CALibrate:SAVE	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Saves calibration values just set. Requires permission for performing calibration to be set at login.
RX:CALibrate:<channel>:SAVE	<i>Protocols Supported:</i> STM-4, OC-12 Saves calibration values just set for Channel 1 or Channel 2. Channel parameter is entered as CH1 or CH2. Requires permission for performing calibration to be set at login.
RX:CALibrate:<type>?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries calibration values and returns an integer value. Type is one of the following power readings. Type (dBm) Description -20 -20 dBm Power Reading -10 -10 dBm Power Reading 0 0 dBm Power Reading
RX:CALibrate:<channel>:<type>?	<i>Protocols Supported:</i> STM-4, OC-12 Queries Channel 1 and Channel 2 calibration values, and returns an integer value. Channel parameter is entered as CH1 or CH2. Type is one of the following power readings. Channel Type (dBm) Description CH1 -10 -10 dBm Power Reading CH1 -5 -5 dBm Power Reading CH1 0 0 dBm Power Reading CH2 -30 -30 dBm Power Reading CH2 -10 -10 dBm Power Reading CH2 0 0 dBm Power Reading
RX:CALibrate:<type><value>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Sets calibration values. Type is one of the power readings listed below. Value is an integer value ranging from 0 to 32767. Type (dBm) Description -20 -20 dBm Power Reading -10 -10 dBm Power Reading 0 0 dBm Power Reading
RX:CALibrate:<channel>:<type> <value>	<i>Protocols Supported:</i> STM-4, OC-12 Sets Channel 1 and Channel 2 calibration values. Channel parameter is entered as CH1 or CH2. Type is one of the power readings listed below. Value is an integer value ranging from 0 to 32767. Channel Type (dBm) Description CH1 -10 -10 dBm Power Reading CH1 -5 -5 dBm Power Reading CH1 0 0 dBm Power Reading CH2 -30 -30 dBm Power Reading CH2 -10 -10 dBm Power Reading CH2 0 0 dBm Power Reading

SENSe Command	Description
RX:CALibrate:POSZ?	<i>Protocols Supported:</i> E1, DS1, E3, DS3 Queries the protocol processor for the Positive Signal Calibration's Zero Power Reading.
RX:CALibrate:POSZ <value>	<i>Protocols Supported:</i> E1, DS1, E3, DS3 Sets the Zero Power Reading value for the protocol processor's Positive Signal Calibration.
RX:CALibrate:POS5?	<i>Protocols Supported:</i> E1, DS1 Queries the protocol processor for the Positive Signal Calibration's 0.5 Volts Reading.
RX:CALibrate:POS5 <value>	<i>Protocols Supported:</i> E1, DS1 Sets the 0.5 Volts Reading value for the protocol processor's Positive Signal Calibration.
RX:CALibrate:POS2? (2.0 volts reading for E1 and DS1)	<i>Protocols Supported:</i> E1, DS1 Queries the protocol processor for the Positive Signal Calibration's 2.0 Volts Reading.
RX:CALibrate:POS2 <value> (2.0 volts reading for E1 and DS1)	<i>Protocols Supported:</i> E1, DS1 Sets the 2.0 Volts Reading value for the protocol processor's Positive Signal Calibration.
RX:CALibrate:POS2? (0.2 volts reading for E3 and DS3)	<i>Protocols Supported:</i> E3, DS3 Queries the protocol processor for the Positive Signal Calibration's 0.2 Volts Reading.
RX:CALibrate:POS2 <value> (0.2 volts reading for E3 and DS3)	<i>Protocols Supported:</i> E3, DS3 Sets the 0.2 Volts Reading value for the protocol processor's Positive Signal Calibration.
RX:CALibrate:POS8?	<i>Protocols Supported:</i> E3, DS3 Queries the protocol processor for the Positive Signal Calibration's 0.8 Volts Reading.
RX:CALibrate:POS8 <value>	<i>Protocols Supported:</i> E3, DS3 Sets the 0.8 Volts Reading value for the protocol processor's Positive Signal Calibration.
RX:CALibrate:POSBZ?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Positive Monitor (Bridged) Signal Calibration's Zero Power Reading.
RX:CALibrate:POSBZ <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the Zero Power Reading value for the protocol processor's Positive Monitor (Bridged) Signal Calibration.
RX:CALibrate:POSB5?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Positive Monitor (Bridged) Signal Calibration's 0.5 Volts Reading.
RX:CALibrate:POSB5 <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the 0.5 Volts Reading value for the protocol processor's Positive Monitor (Bridged) Signal Calibration.

SENSe Command	Description
RX:CALibrate:POSB2?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Positive Monitor (Bridged) Signal Calibration's 2.0 Volts Reading.
RX:CALibrate:POSB2 <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the 2.0 Volts Reading value for the protocol processor's Positive Monitor (Bridged) Signal Calibration.
RX:CALibrate:NEGZ?	<i>Protocols Supported:</i> E1, DS1, E3, DS3 Queries the protocol processor for the Negative Signal Calibration's Zero Power Reading.
RX:CALibrate:NEGZ <value>	<i>Protocols Supported:</i> E1, DS1, E3, DS3 Sets the Zero Power Reading value for the protocol processor's Negative Signal Calibration.
RX:CALibrate:NEG5?	<i>Protocols Supported:</i> E1, DS1 Queries the protocol processor for the Negative Signal Calibration's 0.5 Volt Reading.
RX:CALibrate:NEG5 <value>	<i>Protocols Supported:</i> E1, DS1 Sets the 0.5 Volts Reading value for the protocol processor's Negative Signal Calibration.
RX:CALibrate:NEG2?	<i>Protocols Supported:</i> E1, DS1 Queries the protocol processor for the Negative Signal Calibration's 2.0 Volt Reading.
RX:CALibrate:NEG2 <value>	<i>Protocols Supported:</i> E1, DS1 Sets the 2.0 Volts Reading value for the protocol processor's Negative Signal Calibration.
RX:CALibrate:NEGBZ?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Negative Monitor (Bridged) Signal Calibration's Zero Power Reading.
RX:CALibrate:NEGBZ <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the Zero Power Reading value for the protocol processor's Negative Monitor (Bridged) Signal Calibration.
RX:CALibrate:NEGB5?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Positive Monitor (Bridged) Signal Calibration's 0.5 Volts Reading.
RX:CALibrate:NEGB5 <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the 0.5 Volts Power Reading value for the protocol processor's Negative Monitor (Bridged) Signal Calibration.
RX:CALibrate:NEGB2?	<i>Protocols Supported:</i> E1@2, DS1@2 Queries the protocol processor for the Negative Monitor (Bridged) Signal Calibration's 2.0 Volts Reading.
RX:CALibrate:NEGB2 <value>	<i>Protocols Supported:</i> E1@2, DS1@2 Sets the 2.0 Volts Reading value for the protocol processor's Negative Monitor (Bridged) Signal Calibration.
RX:CALibrate:POSZ?	<i>Protocols Supported:</i> E3, DS3 Queries the protocol processor for the Positive Signal Calibration's Zero Power Reading.
RX:CALibrate:POSZ <value>	<i>Protocols Supported:</i> E3, DS3 Sets the Zero Power Reading value for the protocol processor's Positive Signal Calibration.

SENSe Command	Description																										
RX:CODEC?	<i>Protocols Supported:</i> E1, DS1 Returns CODEC encoding type.																										
RX:CODEC <setting>	<i>Protocols Supported:</i> E1, DS1 Sets CODEC encoding. Valid encoding settings are: ALAW or MULAW.																										
RX:COUPlEd?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the current protocol processor to see if Receive and Transmit are coupled or set independently. Returns string YES or NO.																										
RX:COUPlEd <mode>	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Sets the current protocol processor to either couple Receive and Transmit setting or make Receive and Transmit setting operate independently. Valid modes are: YES or NO.																										
RX:DCC?	<i>Protocols Supported:</i> STM-4, OC-12 Returns values as in RX:DCC.																										
RX:DCC < channel >	<i>Protocols Supported:</i> STM-4, OC-12 Specifies the expected bit stream to be received from one of the datacomm channels. Valid values are: <table border="0" style="margin-left: 40px;"> <tr> <td>NONE</td> <td>No bit streams processed from D1-D12</td> </tr> <tr> <td>RSPRBS</td> <td>Drop PRBS 2^7-1 to RS DCC channel (D1-D3)</td> </tr> <tr> <td>RSPRBSINV</td> <td>Drop PRBS 2^7-1 Inverted from RS DCC channel (D1-D3)</td> </tr> <tr> <td>MSPRBS</td> <td>Drop PRBS 2^7-1 from MS DCC channel (D4-D12)</td> </tr> <tr> <td>MSPRBSINV</td> <td>Drop PRBS 2^7-1 Inverted from MS DCC channel (D4-D12)</td> </tr> <tr> <td>RSDCC</td> <td>Drop bit stream to DCC Port from RS DCC channel (D1-D3)</td> </tr> <tr> <td>MSDCC</td> <td>Drop bit stream to DCC Port from MS DCC channel (D4-D12)</td> </tr> <tr> <td>SECTionPRBS</td> <td>Insert PRBS 2^7-1 into Section DCC channel (D1-D3)</td> </tr> <tr> <td>SECTionPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)</td> </tr> <tr> <td>LINEPRBS</td> <td>Insert PRBS 2^7-1 into Line DCC channel (D4-D12)</td> </tr> <tr> <td>LINEPRBSINV</td> <td>Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)</td> </tr> <tr> <td>SECTionDCC</td> <td>Insert bit stream from DCC Port into Section DCC channel (D1-D3)</td> </tr> <tr> <td>LINEDCC</td> <td>Insert bit stream from DCC Port into Line DCC channel (D4-D12)</td> </tr> </table>	NONE	No bit streams processed from D1-D12	RSPRBS	Drop PRBS 2^7-1 to RS DCC channel (D1-D3)	RSPRBSINV	Drop PRBS 2^7-1 Inverted from RS DCC channel (D1-D3)	MSPRBS	Drop PRBS 2^7-1 from MS DCC channel (D4-D12)	MSPRBSINV	Drop PRBS 2^7-1 Inverted from MS DCC channel (D4-D12)	RSDCC	Drop bit stream to DCC Port from RS DCC channel (D1-D3)	MSDCC	Drop bit stream to DCC Port from MS DCC channel (D4-D12)	SECTionPRBS	Insert PRBS 2^7-1 into Section DCC channel (D1-D3)	SECTionPRBSINV	Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)	LINEPRBS	Insert PRBS 2^7-1 into Line DCC channel (D4-D12)	LINEPRBSINV	Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)	SECTionDCC	Insert bit stream from DCC Port into Section DCC channel (D1-D3)	LINEDCC	Insert bit stream from DCC Port into Line DCC channel (D4-D12)
NONE	No bit streams processed from D1-D12																										
RSPRBS	Drop PRBS 2^7-1 to RS DCC channel (D1-D3)																										
RSPRBSINV	Drop PRBS 2^7-1 Inverted from RS DCC channel (D1-D3)																										
MSPRBS	Drop PRBS 2^7-1 from MS DCC channel (D4-D12)																										
MSPRBSINV	Drop PRBS 2^7-1 Inverted from MS DCC channel (D4-D12)																										
RSDCC	Drop bit stream to DCC Port from RS DCC channel (D1-D3)																										
MSDCC	Drop bit stream to DCC Port from MS DCC channel (D4-D12)																										
SECTionPRBS	Insert PRBS 2^7-1 into Section DCC channel (D1-D3)																										
SECTionPRBSINV	Insert PRBS 2^7-1 Inverted into Section DCC channel (D1-D3)																										
LINEPRBS	Insert PRBS 2^7-1 into Line DCC channel (D4-D12)																										
LINEPRBSINV	Insert PRBS 2^7-1 Inverted into Line DCC channel (D4-D12)																										
SECTionDCC	Insert bit stream from DCC Port into Section DCC channel (D1-D3)																										
LINEDCC	Insert bit stream from DCC Port into Line DCC channel (D4-D12)																										
RX:DS0:DR0P?	<i>Protocols Supported:</i> E1, DS1 Returns DS0 channel dropped to speaker and analysis.																										
RX:DS0:DR0P < 1 to NN >	<i>Protocols Supported:</i> E1, DS1 Sets DS0 channel dropped to speaker and analysis. Valid values for NN are: 1 to 31 for E1 (0 is FAS), 1 to 24 for DS1.																										

SENSe Command	Description																																				
RX:DS0:VALUE?	<i>Protocols Supported:</i> DS1 Returns DS0 value dropped (most recent 8-bit value).																																				
RX:E13:DROP:@N?	<i>Protocols Supported:</i> E3, DS3 Queries the current dropped channel on the E13 or DS3 Mux for instance N. Values returned are 1-16 (for E3) or 1- 21 (for DS3).																																				
RX:E13:DROP:@N <value>	<i>Protocols Supported:</i> E3, DS3 Sets the E1 drop channel for instance N to one of the 16 E13 or 21 DS3 channels available. Values are 1 to 16 (for E3) or 1- 21 (for DS3).																																				
RX:E34:DROP?	<i>Protocols Supported:</i> E4 Queries the current inserted E3 channel on the E34 Mux. Values returned are 0-4, where 0 means "All Background" (Broadcast).																																				
RX:E34:DROP <value>	<i>Protocols Supported:</i> E4 Sets the E3 insert channel to one of the four E34 channels available. Values are 0 to 4. The value 0 is used to mean "All Background" (Broadcast).																																				
RX:EBITs?	<i>Protocols Supported:</i> E1 Returns the received E-bits as a 2-bit binary number.																																				
RX:FRAC_E1:MASK < mask >	<i>Protocols Supported:</i> E1 Sets the 32-bit Receive fractional E1 mask.																																				
RX:FRAC_E1:MASK?	<i>Protocols Supported:</i> E1 Queries the Receive fractional E1 mask, returned as a 32-bit integer.																																				
RX:FRAC_T1:MASK < mask >	<i>Protocols Supported:</i> DS1 Sets the 32-bit Received fractional T1 mask.																																				
RX:FRAC_T1:MASK?	<i>Protocols Supported:</i> DS1 Queries the Receive fractional T1 mask, returned as a 32-bit integer.																																				
RX:FRAMing?	<i>Protocols Supported:</i> E1, E3, E4, DS1, DS3 Queries the current protocol processor for the framing it is trying to receive.																																				
RX:FRAMing < frame >	<i>Protocols Supported:</i> E1, E3, E4, DS1, DS3 Sets the receiver of the current protocol processor to one of the following framing types:																																				
	<table border="1"> <thead> <tr> <th>Framing</th> <th>Protocol(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>UNframed</td> <td>E1, E3, E4, DS3, DS1</td> <td>Unframed</td> </tr> <tr> <td>FRamed</td> <td>E3, E4</td> <td>Framed</td> </tr> <tr> <td>M13</td> <td>DS3</td> <td>M13 Framing for DS3</td> </tr> <tr> <td>C-BIT</td> <td>DS3</td> <td>C-Bit Framing for DS3</td> </tr> <tr> <td>ESF</td> <td>DS1</td> <td>ESF Framing for DS1</td> </tr> <tr> <td>SF/D4</td> <td>DS1</td> <td>SF/D4 Framing for DS1</td> </tr> <tr> <td>SLC96</td> <td>DS1</td> <td>SLC-96 Framing for DS1</td> </tr> <tr> <td>PCM30</td> <td>E1</td> <td>Framed E1, with CAS but no CRC</td> </tr> <tr> <td>PCM31</td> <td>E1</td> <td>Framed E1, without CAS or CRC</td> </tr> <tr> <td>PCM30CRC</td> <td>E1</td> <td>Framed E1, with CAS and CRC</td> </tr> <tr> <td>PCM31CRC</td> <td>E1</td> <td>Framed E1, without CAS but with CRC</td> </tr> </tbody> </table>	Framing	Protocol(s)	Description	UNframed	E1, E3, E4, DS3, DS1	Unframed	FRamed	E3, E4	Framed	M13	DS3	M13 Framing for DS3	C-BIT	DS3	C-Bit Framing for DS3	ESF	DS1	ESF Framing for DS1	SF/D4	DS1	SF/D4 Framing for DS1	SLC96	DS1	SLC-96 Framing for DS1	PCM30	E1	Framed E1, with CAS but no CRC	PCM31	E1	Framed E1, without CAS or CRC	PCM30CRC	E1	Framed E1, with CAS and CRC	PCM31CRC	E1	Framed E1, without CAS but with CRC
Framing	Protocol(s)	Description																																			
UNframed	E1, E3, E4, DS3, DS1	Unframed																																			
FRamed	E3, E4	Framed																																			
M13	DS3	M13 Framing for DS3																																			
C-BIT	DS3	C-Bit Framing for DS3																																			
ESF	DS1	ESF Framing for DS1																																			
SF/D4	DS1	SF/D4 Framing for DS1																																			
SLC96	DS1	SLC-96 Framing for DS1																																			
PCM30	E1	Framed E1, with CAS but no CRC																																			
PCM31	E1	Framed E1, without CAS or CRC																																			
PCM30CRC	E1	Framed E1, with CAS and CRC																																			
PCM31CRC	E1	Framed E1, without CAS but with CRC																																			
RX:FREQuency?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the line frequency, in Mhz, as a decimal number.																																				

SENSe Command	Description																														
RX:FREQOFFset:Hz?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries and reports the line frequency offset in Hz.																														
RX:FREQOFFset:Ppm?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries and reports the line frequency offset in ppm.																														
RX:INPUT?	<i>Protocols Supported:</i> E1, DS3, DS1 Returns the Input termination (protected monitor) type.																														
RX:INPUT <input termination value>	<i>Protocols Supported:</i> E1, DS3, DS1 Sets the Input Termination (protected monitor) type to one of these:																														
	<table border="1"> <thead> <tr> <th>Type</th> <th>Valid Protocols</th> </tr> </thead> <tbody> <tr> <td>TERMinated</td> <td>E1#1, DS3, DS1</td> </tr> <tr> <td>BRIDGED</td> <td>E1#2, DS1</td> </tr> <tr> <td>MONitor</td> <td>E1#1, E1#2, DS3, DS1</td> </tr> <tr> <td>TERM 100</td> <td>E1#2</td> </tr> <tr> <td>TERM120</td> <td>E1#2</td> </tr> </tbody> </table>	Type	Valid Protocols	TERMinated	E1#1, DS3, DS1	BRIDGED	E1#2, DS1	MONitor	E1#1, E1#2, DS3, DS1	TERM 100	E1#2	TERM120	E1#2																		
Type	Valid Protocols																														
TERMinated	E1#1, DS3, DS1																														
BRIDGED	E1#2, DS1																														
MONitor	E1#1, E1#2, DS3, DS1																														
TERM 100	E1#2																														
TERM120	E1#2																														
RX:INTErface?	<i>Protocols Supported:</i> STM-4, OC-12, Jitter Queries the type of receive interface.																														
RX:INTErface <interface value>	<i>Protocols Supported:</i> STM-4, OC-12, Jitter Sets the receive interface speed and type (optical or electrical). Valid <interface values> are:																														
	<table border="1"> <thead> <tr> <th>Interface</th> <th>Protocol(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>STM0E</td> <td>STM-4</td> <td>52 Mbps electrical interface</td> </tr> <tr> <td>STM1E</td> <td>STM-4</td> <td>155 Mbps electrical interface</td> </tr> <tr> <td>STM0</td> <td>STM-4, Jitter</td> <td>52 Mbps optical interface</td> </tr> <tr> <td>STM1</td> <td>STM-4, Jitter</td> <td>155 Mbps optical interface</td> </tr> <tr> <td>STM4</td> <td>STM-4, Jitter</td> <td>622 Mbps optical interface</td> </tr> <tr> <td>STSX1</td> <td>OC-12</td> <td>52 Mbps electrical interface</td> </tr> <tr> <td>OC1</td> <td>OC-12, Jitter</td> <td>52 Mbps optical interface</td> </tr> <tr> <td>OC3</td> <td>OC-12, Jitter</td> <td>155 Mbps optical interface</td> </tr> <tr> <td>OC12</td> <td>OC-12, Jitter</td> <td>622 Mbps optical interface</td> </tr> </tbody> </table>	Interface	Protocol(s)	Description	STM0E	STM-4	52 Mbps electrical interface	STM1E	STM-4	155 Mbps electrical interface	STM0	STM-4, Jitter	52 Mbps optical interface	STM1	STM-4, Jitter	155 Mbps optical interface	STM4	STM-4, Jitter	622 Mbps optical interface	STSX1	OC-12	52 Mbps electrical interface	OC1	OC-12, Jitter	52 Mbps optical interface	OC3	OC-12, Jitter	155 Mbps optical interface	OC12	OC-12, Jitter	622 Mbps optical interface
Interface	Protocol(s)	Description																													
STM0E	STM-4	52 Mbps electrical interface																													
STM1E	STM-4	155 Mbps electrical interface																													
STM0	STM-4, Jitter	52 Mbps optical interface																													
STM1	STM-4, Jitter	155 Mbps optical interface																													
STM4	STM-4, Jitter	622 Mbps optical interface																													
STSX1	OC-12	52 Mbps electrical interface																													
OC1	OC-12, Jitter	52 Mbps optical interface																													
OC3	OC-12, Jitter	155 Mbps optical interface																													
OC12	OC-12, Jitter	622 Mbps optical interface																													
RX:LABel:HP?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the expected HP Signal Label, as an 8-bit binary string.																														
RX:LABel:HP<value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Sets the expected 8-bit HP Signal Label to any value from 0 to 255.																														
RX:LABel:LP?	<i>Protocols Supported:</i> STM-4 Returns the expected LP Signal Label, as a 3- or 8-bit binary string (depending on the VC type).																														
RX:LABel:LP<value>	<i>Protocols Supported:</i> STM-4 Sets the expected 3- or 8-bit LP Signal Label to any value from 0 to 7 or 255 (depending on the VC type).																														
RX:LABel:PATH?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the expected Path Signal Label, as an 8 bit binary string.																														
RX:LABel:PATH<value>	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Sets the expected 8 bit Path Signal Label to any value from 0 to 255.																														
RX:LABel:VT?	<i>Protocols Supported:</i> OC-12 Returns the expected VT Signal Label, as a 3-bit binary string.																														

SENSe Command	Description
RX:LABEL:VT<value>	<i>Protocols Supported:</i> OC-12 Sets the expected 3-bit VT Signal Label to any value from 0 to 7.
RX:LCODE?	<i>Protocols Supported:</i> E1, DS1 Queries the line code being received. Returns AMI, HDB3, or B8ZS.
RX:M13:DROP:@N?	<i>Protocols Supported:</i> DS3 Returns the number of DS1 or E1 dropped for instance N.
RX:M13:DROP:@N [1 to NN]	<i>Protocols Supported:</i> DS3 Sets the DS1 or E1 drop channel for instance N to one of the NN mux channels. NN is 28 for DS3/DS1, 21 for DS3/E1, and 16 for E3.
RX:MAPping?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E1, E3, E4 Queries the protocol processor for the mapping it is receiving.
RX:MAPping < mapping >	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, E1, E3, E4 Sets the tributary mapping. See <i>TX:MAPping</i> for a list of mappings.
RX:OH:<OH BYTE>?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the received overhead byte. Byte is returned as a hexadecimal number (#Hxx), except for the J0 which is returned as a 15-byte string without the CRC byte, and, J1 or J2 traces, which are returned as a 62-byte string, without the Carriage Return and Line Feed at the end.
Valid two-character strings for OH BYTE specification are:	
<u>SOH (SDH) / TOH (SONET):</u>	
A1, A2, J0, Z0 B1, E1, F1 D1, D2, D3 H1, H2, H3 B2, K1, K2 D4, D5, D6 D7, D8, D9 D10, D11, D12 S1, Z2, E2	
<u>9 Byte HP (SDH) / Path (SONET):</u>	
J1, B3, C2, G1, F2, H4, F3, K3, N1	
<u>9 Byte TU-3 LP (SDH)</u>	
LPJ1, LPB3, LPC2, LPG1, LPF2, LPH4, LPF3, LPK3, LPN1	
<u>4 Byte LP (SDH STM-4 only):</u>	
V5, J2, N2, K4	
RX:OPP?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries the optical power in dBm for optical signals. Refer to <i>RX:ROPP?</i> for raw unit values.
RX:ORDER?	<i>Protocols Supported:</i> STM-4, OC-12 Returns the orderwire dropped configuration.

SENSe Command	Description
RX:ORDER <value>	<i>Protocols Supported:</i> STM-4, OC-12 Sets the orderwire drop. Parameter values are as follows: E1 Drop bit stream to orderwire from E1 E2 Drop bit stream to orderwire from E2 NONE No bit stream sent to orderwire output.
RX:PATtern?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Queries the current protocol processor for the expected receive pattern. Returns a binary pattern for user-defined bit string or a predefined pattern. See <i>RX:PATtern</i> and <i>TX:PATtern</i> for Predefined Patterns.
RX:PATtern <pattern>	<i>Protocols Supported:</i> E1, E3, E4, STM-4, STM-16, STM-64, OC-12, OC-48, OC-192, DS3, DS1 Sets the expected receive pattern. Pattern parameter can be a numeric value for a user-defined bit pattern, or a predefined pattern. Predefined Patterns are defined in <i>TX:PATtern</i> . "LIVE" is also allowed for <i>RX:PATtern</i> .
RX:PLM?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries whether PLM Alarm reporting is enabled.
RX:PLM <mode>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Enables (yes) or disables (no) PLM Alarm Reporting. Valid modes are: YES or NO.
RX:PNPV?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, OC-12, DS3, DS1 Queries the Peak negative pulse voltage in volts.
RX:PNPVR?	<i>Protocols Supported:</i> E1, E3, DS3, DS1 Queries the Peak negative pulse voltage in raw units.
RX:PPPV?	<i>Protocols Supported:</i> E1, E3, E4, STM-4, OC-12, DS3, DS1 Queries the Peak positive pulse voltage in volts.
RX:PPPVR?	<i>Protocols Supported:</i> E1, E3, DS3, DS1 Queries the Peak positive pulse voltage in raw units.
RX:PTR:AU?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64 Returns the AU pointer value received as a decimal number.
RX:PTR:STS?	<i>Protocols Supported:</i> OC-12, OC-48, OC-192 Returns the STS pointer value received as a decimal number.
RX:PTR:TU?	<i>Protocols Supported:</i> STM-4 Returns the TU pointer value received as a decimal number.
RX:PTR:VT?	<i>Protocols Supported:</i> OC-12 Returns the VT Pointer value received as a decimal number.
RX:SIGnaling?	<i>Protocols Supported:</i> DS1 Returns the Circuit Signaling value.

SENSe Command	Description																
RX:SIGnaling <type>	<p><i>Protocols Supported:</i> DS1</p> <p>Sets the Circuit Signaling to one of the following:</p> <table border="1"> <thead> <tr> <th><u>Type</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>UNK</td> <td>Unknown</td> </tr> <tr> <td>LS</td> <td>Loop-Start</td> </tr> <tr> <td>GS</td> <td>Ground-Start</td> </tr> <tr> <td>LRB</td> <td>Loop-Rev-Battery</td> </tr> <tr> <td>NET</td> <td>Network-Prov-Rev-Battery</td> </tr> <tr> <td>EM</td> <td>E&M</td> </tr> <tr> <td>CI</td> <td>CI-Prov-Loop-Start</td> </tr> </tbody> </table>	<u>Type</u>	<u>Description</u>	UNK	Unknown	LS	Loop-Start	GS	Ground-Start	LRB	Loop-Rev-Battery	NET	Network-Prov-Rev-Battery	EM	E&M	CI	CI-Prov-Loop-Start
<u>Type</u>	<u>Description</u>																
UNK	Unknown																
LS	Loop-Start																
GS	Ground-Start																
LRB	Loop-Rev-Battery																
NET	Network-Prov-Rev-Battery																
EM	E&M																
CI	CI-Prov-Loop-Start																
RX:SITE?	<p><i>Protocols Supported:</i> DS1</p> <p>Returns the Test Site value.</p>																
RX:SITE <type>	<p><i>Protocols Supported:</i> DS1</p> <p>Sets the Test Site to one of the following:</p> <table border="1"> <thead> <tr> <th><u>Type</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>UNK</td> <td>Unknown</td> </tr> <tr> <td>CN</td> <td>Customer <- Network</td> </tr> <tr> <td>NC</td> <td>Network <- Customer</td> </tr> </tbody> </table>	<u>Type</u>	<u>Description</u>	UNK	Unknown	CN	Customer <- Network	NC	Network <- Customer								
<u>Type</u>	<u>Description</u>																
UNK	Unknown																
CN	Customer <- Network																
NC	Network <- Customer																
RX:SLOT?	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Returns the slot number for Receive Overhead SCPI query (<i>RX:OH:xx?</i>).</p>																
RX:SLOT <value>	<p><i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192</p> <p>Sets a slot number for Receive Overhead SCPI query (<i>RX:OH:xx?</i>). A slot is derived from the AU and TUG-3 number for SDH, and the STS number for SONET. Note: The slot specification for setting overhead can be different from the Foreground AU and TUG-3 dropped (SDH) or STS number (SONET).</p>																
RX:SPARE?	<p><i>Protocols Supported:</i> E1</p> <p>Returns spare bit values received as eight-decimal integers. Bits 1 to 3 of each integer are set to zero, and the spare bits are in 4 to 8. The 8 integers are comma-delimited. Example: 0, 8, 248, 16, 24, 0, 0, 8.</p>																
RX:STS:DROP?	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Returns the number of the current STS dropped as a decimal number. For OC-48 this is an STS-12, and for OC-192 this is an STS-48.</p>																
RX:STS:DROP <value>	<p><i>Protocols Supported:</i> OC-12, OC-48, OC-192</p> <p>Sets the current SPE or STS dropped (under test).</p>																
RX:TCM:API?	<p><i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192</p> <p>Queries and reports the expected TCM Trace value.</p>																
RX:TCM:API <expected>	<p><i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192</p> <p>Sets the expected value for the receive TCM Trace. Valid <expected> values are:</p> <p>ALLONES Selects an All Ones pattern for the TCM Trace.</p> <p>ALLZEROS Selects an All Zeros pattern for the TCM Trace.</p> <p>User Defines Allows you to enter a user defined string from 1- to 15-characters in length.</p>																

SENSe Command	Description
RX:TCM:MODE?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries and reports the current status of the unit's receive TCM mode function. Enable appears if TCM mode is on. Disable appears if TCM mode is off.
RX:TCM:MODE <state>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Enables and disables receive TCM mode. Valid <state> values are: ENABLE Turns TCM mode on. DISABLE Turns TCM mode off.
RX:TCM:TIM:MODE?	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Queries and reports the current status of the unit's TCM-TIM mode setting. Values that appear are Enable or Disable.
RX:TCM:TIM:MODE <state>	<i>Protocols Supported:</i> STM-16, STM-64, OC-48, OC-192 Enables TCM TIM alarm reporting. This type of alarm occurs if the incoming TCM trace does not match the expected TCM trace. Valid <state> values are: ENABLE Turns TCM TIM alarm mode on. DISABLE Turns TCM TIM alarm mode off.
RX:TIM?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries whether TIM Alarm reporting is enabled.
RX:TIM <mode>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Enables or disables TIM Alarm Reporting. Valid modes are: YES or NO.
RX:TRACE:<type>?	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Queries what the expected J0, J1, or J2 trace is (set type to one of those 3).
RX:TRACE:<type> <value>	<i>Protocols Supported:</i> STM-4, STM-16, STM-64, OC-12, OC-48, OC-192 Sets the expect trace, where type is J0, J1 or J2. (See <i>TX:OH</i> for format of traces.)
RX:TU:DROP?	<i>Protocols Supported:</i> STM-4 Returns the number of the current TU, dropped as a decimal number.
RX:TU:DROP <value>	<i>Protocols Supported:</i> STM-4 Sets the dropped TU and TUG-2 based on one of the following values: 1 to NN Numeric value of TU-11, TU-12, or TU-2 dropped NN has the following values, depending on the container type and AU: NN=1 if C4-16c, C4-4c, C-4, or AU-3 and C-3 NN=7 if C-2 NN=21 if C-12 NN=28 if C-11 NN=3 if AU-4 and C-3
RX:TUG3:DROP?	<i>Protocols Supported:</i> STM-4 Returns the number of the current TUG-3s dropped.
RX:TUG3:DROP <value>	<i>Protocols Supported:</i> STM-4 Sets the dropped TUG-3. Valid values are 1, 2, or 3.

SENSe Command	Description
RX:XBITS?	<i>Protocols Supported:</i> E1 Returns the first CAS byte in the receive 16-frame multiframe, with the non-X-bits in the byte set to 0. The byte is returned as a decimal number.
RX:VT:DROP?	<i>Protocols Supported:</i> OC-12 Returns the number of the current VT channel dropped as a decimal number.
RX:VT:DROP <value>	<i>Protocols Supported:</i> OC-12 Sets the dropped VT channel.

GET Branch

The Get Branch SCPI commands act as batch commands by retrieving values for multiple unit parameters using a single SCPI command. This is similar to using the Transmit and Receive Function Group buttons to view various settings of the different protocol processors.

Many of the GET commands substitute a variable to report information about a specific test set. In this section, these commands are grouped together. Use the following table to locate a specific command.

Refer to this command...	For information about the following commands.
GET:PROTOcols?	<p><i>Protocols Supported:</i> SYSTEM</p> <p>Queries the types of protocol processors contained in the system. For example: STM4, E1 @ 1, E1 @ 2, etc.</p> <p>For Gigabit Ethernet, this command queries and reports the protocol processor ID, chassis ID, slot ID, and card ID for the Gigabit Ethernet protocol processor. This command is useful when multiple circuit packs are installed in the unit.</p> <p>For example, if a NIC Plus has two Gigabit Ethernet circuit packs installed, both circuit packs may appear as being installed in a single slot. To avoid this confusion, the GET:PROTO? command returns identity parameters for all circuit packs detected in the unit. Results for this command are returned in the following format:</p> <p>For circuit pack 1: 0 1 1 GIGE@1 0 1 1 GIGE@2 which means: Chassis ID 0, Slot 1, Card 1, GIGE Port 1; Chassis ID 0, Slot 1, Card 1, GIGE Port 2</p> <p>For circuit pack 2: 0 1 2 GIGE@1 0 1 2 GIGE@2 which means: Chassis ID 0, Slot 1, Card 2, GIGE Port 1; Chassis ID 0, Slot 1, Card 2, GIGE Port 2</p>

Refer to this command...	For information about the following commands.
GET:VERsion?	<p data-bbox="518 279 857 304"><i>Protocols Supported:</i> SYSTEM</p> <p data-bbox="518 310 1321 401">Queries the versions of software running in the system. Each is specified as the protocol name (similar to the GET:PROTOcols command) followed by "=" and the version in NN.NN.NN format.</p> <p data-bbox="518 436 902 462">For example: SC=1.0.1, SCPI=2.0.1</p> <p data-bbox="518 499 1321 558">System Controller software is indicated by SC, SCPI by SCPI, TL1 by TL1, GUI by GUI.</p>
GET:PARTnumbers?	<p data-bbox="518 573 857 598"><i>Protocols Supported:</i> SYSTEM</p> <p data-bbox="518 604 1321 663">Queries the part numbers for hardware and software in the system. Parts are returned in a comma-delimited string.</p>

4

ATM SCPI Commands

Overview

This chapter lists the ATM SCPI commands supported by the configured unit. You may not have access to all commands based on the product configuration you purchased.

Supported ATM SCPI Commands

These commands are extensions to the SCPI command set. These commands are adapted to the configured unit and are unique to each protocol processor. SCPI commands should be typed on one single line completed with a hard carriage return. These commands require zero or one parameters, and return zero or one values.

RES (Fetch) Branch

The RES branch is used to retrieve ATM results. Alternatively, each command can be sent using the "FETC" or "FETCH" keyword instead of the "RES" keyword.

The following is a list of supported RESULT commands.

RES Command	Description
RES:AAL0:TXCELLS?	Queries the AAL 0 transmitted cells count.
RES:AAL0:RXCELLS?	Queries the AAL 0 received cells count.
RES:AAL0:BANDwidth?	Queries the bandwidth used by AAL 0 connections
RES:AAL0:BIT:COUNT?	Queries the count of AAL 0 bit errors.
RES:AAL0:BIT:AVGRATE?	Queries the average rate of AAL 0 bit errors.
RES:AAL0:BIT:CURREATE?	Queries the current rate of AAL 0 bit errors.
RES:AAL0:PATSynch?	Queries the duration of loss of pattern synchronous alarm (LOPS) on AAL 0 connections.
RES:AAL1:TXCELLS?	Queries the AAL1 transmitted cells count.
RES:AAL1:RXCELLS?	Queries the AAL1 received cells count.
RES:AAL1:BANDwidth?	Queries the bandwidth used by AAL 1 connections.
RES:AAL1:BIT:COUNT?	Queries the count of AAL 1 bit errors.
RES:AAL1:BIT:AVGRATE?	Queries the average rate of AAL 1 bit errors.
RES:AAL1:BIT:CURREATE?	Queries the current rate of AAL 1 bit errors.
RES:AAL1:ERRsecs?	Queries the AAL1 errored seconds count.
RES:AAL1:PATSynch?	Queries the duration of loss of pattern synchronous alarm (LOPS) on AAL 1 connections.
RES:AAL1:SNPERRor:COUNT?	Queries the SNP error count for AAL 1 connections.

RES Command	Description
RES:AAL1:SNPERRor: AVGRATE?	Queries the average rate of SNP error for AAL 1 connections.
RES:AAL1:SNPERRor: CURRATE?	Queries the current rate of SNP error for AAL 1 connections.
RES:AAL1:LOSTcells:COUNT?	Queries the lost cells count for AAL 1 connections
RES:AAL1:LOSTcells: AVGRATE?	Queries the average rate of lost cells for AAL 1 connections.
RES:AAL1:LOSTcells: CURRATE?	Queries the current rate of missequenced cells for AAL 1 connections.
RES:AAL1:MISSEQcells: COUNT?	Queries the missequenced cells count for AAL 1 connections.
RES:AAL1:MISSEQcells: AVGRATE?	Queries the average rate of missequenced cells for AAL 1 connections.
RES:AAL1:MISSEQcells: CURRATE?	Queries the current rate of missequenced cells for AAL 1 connections.
RES:AAL5:RXPDUs?	Queries the AAL5 PDUs received count.
RES:AAL5:TXPDUs?	Queries the AAL 5 PDUs transmitted count.
RES:AAL5:RXCELLS?	Queries the AAL 5 received cells count.
RES:AAL5:BANDwidth?	Queries the bandwidth used by AAL 5 connections.
RES:AAL5:BIT:COUNT?	Queries the count of AAL 5 bit errors.
RES:AAL5:BIT:AVGRATE?	Queries the average rate of AAL 5 bit errors.
RES:AAL5:BIT:CURRATE?	Queries the current rate of AAL 5 bit errors.
RES:AAL5:ERRsecs?	Queries the AAL5 errored seconds count.
RES:AAL5:PATSynch?	Queries the duration of loss of pattern synchronous alarm (LOPS) on AAL 5 connections.
RES:AAL5:CRCError:COUNT?	Queries the count of AAL 5 CRC errors.
RES:AAL5:CRCError: AVGRATE?	Queries the average rate of AAL 5 CRC errors.
RES:AAL5:CRCError: CURRATE?	Queries the current rate of AAL 5 bit errors.
RES:AAL5:LENError:COUNT?	Queries the count of AAL 5 length errors.
RES:AAL5:LENError: AVGRATE?	Queries the average rate of AAL 5 length errors.
RES:AAL5:LENError: CURRATE?	Queries the current rate of AAL 5 length errors.
RES:AAL5PADerror:COUNT?	Queries the count of AAL 5 padding errors.
RES:AAL5:PADerror: AVGRATE?	Queries the average rate of AAL 5 padding errors.
RES:AAL5:PADerror: CURRATE?	Queries the current rate of AAL 5 padding errors.
RES:HECCorr:COUNT?	Queries the count of HEC correctable errors.
RES:HECCorr:AVGRATE?	Queries the average rate of HEC correctable errors.
RES:HECCorr:CURRATE?	Queries the current rate of HEC correctable errors.

RES Command	Description
RES:HECUncorr:COUNT?	Queries the count of HEC uncorrectable errors.
RES:HECUncorr:AVGRATE?	Queries the average rate of HEC uncorrectable errors.
RES:HECUncorr:CURRATE?	Queries the current rate of HEC uncorrectable errors.
RES:CELLsync:Secs?	Queries the duration of Loss of Cell synchronization alarm.
RES:IDLE:COUNT?	Queries the count of idle cells received.
RES:IDLE:BANDwidth?	Queries the bandwidth of idle cells received.
RES:DISCARD:COUNT?	Queries the count of discarded cells.
RES:DISCARD:BANDwidth?	Queries the bandwidth of discarded cells.
RES:OAM:VALID:COUNT?	Queries the count of valid OAM cells received.
RES:OAM:VALID:BANDwidth?	Queries the bandwidth of valid OAM cells received.
RES:OAM:ERR:COUNT?	Queries the count of errored OAM cells received.
RES:OAM:ERR:BANDwidth?	Queries the bandwidth of errored OAM cells received.
RES:TOTAL:COUNT?	Queries the total user cells received count.
RES:TOTAL:BANDwidth?	Queries the total bandwidth of user cells received.
RES:AIS:F5:Secs?	Queries the duration of a detected F5-AIS alarm.
RES:RDI:F5:Secs?	Queries the duration of a detected F5-RDI alarm.
RES:OAM:F5:CCcells?	Queries the F5 OAM continuity check cells received.
RES:OAM:F5:LPBKcells?	Queries the F5 OAM loopback cells received.
RES:AIS:F4:Secs?	Queries the duration of a detected F4-AIS alarm.
RES:RDI:F4:Secs?	Queries the duration of a detected F4-RDI alarm.
RES:OAM:F4:CCcells?	Queries the F4 OAM continuity check cells received.
RES:OAM:F4:LPBKcells?	Queries the F4 OAM loopback cells received.
RES:SCNRsecs?	Queries the duration of an SCNR (Selected Cells Not Received) condition.
RES:FEBEerr:COUNT?	Queries the count of PLCP FEBE errors.
RES:FEBEerr:AVGRATE?	Queries the average rate of PLCP FEBE errors.
RES:FEBEerr:CURRATE?	Queries the current rate of PLCP FEBE errors.
RES:B1BITerr:COUNT?	Queries the count of PLCP B1 BIT errors.
RES:B1BITerr:AVGRATE?	Queries the average rate of PLCP B1 BIT errors.
RES:B1BITerr:CURRATE?	Queries the current rate of PLCP B1 BIT errors.
RES:B1BLOCKerr:COUNT?	Queries the count of PLCP B1 Block errors.
RES:B1BLOCKerr:AVGRATE?	Queries the average rate of PLCP B1 Block errors.
RES:B1BLOCKerr:CURRATE?	Queries the current rate of PLCP B1 Block errors.
RES:FRAMINGerr:COUNT?	Queries the count of PLCP Framing errors.
RES:FRAMINGerr:AVGRATE?	Queries the average rate of PLCP Framing errors.
RES:FRAMINGerr:CURRATE?	Queries the current rate of PLCP Framing errors.
RES:POIerr:COUNT?	Queries the count of PLCP POI errors.
RES:POIerr:AVGRATE?	Queries the average rate of PLCP POI errors.
RES:POIerr:CURRATE?	Queries the current rate of PLCP POI errors.
RES:PLCPYEL:SECS?	Queries the duration of PLCP Yellow alarms detected.
RES:PLCPOOF:SECS?	Queries the duration of PLCP OOF alarms detected.
RES:PLCPLOF:SECS?	Queries the duration of PLCP LOF alarms detected.

RES Command	Description
RES:SVC:CALLSTAT:TOTAL?	Queries the total number of Switch Virtual Circuits (SVC) set up by the user.
RES:SVC:CALLSTAT:ACTIVE?	Queries the number of active SVCs.
RES:SVC:CALLSTAT:TX:ATTEMPT?	Queries the number of TX calls attempted.
RES:SVC:CALLSTAT:TX:CONNECT?	Queries the number of TX calls connected.
RES:SVC:CALLSTAT:TX:REJECT?	Queries the number of TX calls rejected.
RES:SVC:CALLSTAT:TX:CLRD?	Queries the number TX calls cleared.
RES:SVC:CALLSTAT:TX:CAUSE?	Queries the last transmitted Cause value.
RES:SVC:CALLSTAT:TX:DGN?	Queries the last transmitted diagnostic value.
RES:SVC:CALLSTAT:RX:RCVD?	Queries the number of RX calls received.
RES:SVC:CALLSTAT:RX:ACCPT?	Queries the number of RX calls accepted.
RES:SVC:CALLSTAT:RX:REJECT?	Queries the number of RX calls rejected.
RES:SVC:CALLSTAT:RX:CLRD?	Queries the number of RX calls cleared.
RES:SVC:CALLSTAT:RX:CAUSE?	Queries the last received Cause value.
RES:SVC:CALLSTAT:RX:DGN?	Queries the last received diagnostic value.
RES:SVC:CALLSTAT:AVGSETUP?	Queries the average setup time for the SVCs.
RES:SVC:CALLSTAT:MINSETUP?	Queries the minimum setup time for the SVCs.
RES:SVC:CALLSTAT:MAXSETUP?	Queries the maximum setup time for the SVCs.
RES:SVC:CALLSTAT:AVGREL?	Queries the average release time for the SVCs.
RES:SVC:CALLSTAT:MINREL?	Queries the minimum release time for the SVCs.
RES:SVC:CALLSTAT:MAXREL?	Queries the maximum release time for the SVCs.
RES:SVC:ERRSTAT:PROTDECR?	Queries the count of Q.93B signaling message protocol discriminator errors.
RES:SVC:ERRSTAT:CREFFMT?	Queries the count of Q.93B signaling message call reference format errors.
RES:SVC:ERRSTAT:CREFVAL?	Queries the count of Q.93B signaling message invalid call reference value errors.
RES:SVC:ERRSTAT:MSGTYPE?	Queries the count of Q.93B signaling message invalid message type errors.

RES Command	Description
RES:SVC:ERRSTAT:MSGLEN?	Queries the count of Q.93B signaling message invalid message length errors.
RES:SVC:ERRSTAT:IEMISS?	Queries the count of Q.93B signaling message mandatory IE missing errors.
RES:SVC:ERRSTAT:IECONTENT?	Queries the count of Q.93B signaling message invalid IE content errors.
RES:SVC:ERRSTAT:IEUNRECOG?	Queries the count of Q.93B signaling message unrecognized IE errors.
RES:SVC:ERRSTAT:PDULEN?	Queries the count of Q.SAAL PDU length errors.
RES:SVC:ERRSTAT:PDUTYPE?	Queries the count of Q.SAAL PDU type errors.
RES:SVC:ERRSTAT:PDUALIGN?	Queries the count of Q.SAAL PDU alignment errors.
RES:VCC:QOS:CER?	Queries the cell error ratio for the current VCC entry.
RES:VCC:QOS:CLR?	Queries the cell loss ratio for the current VCC entry.
RES:VCC:QOS:CMR?	Queries the cell misinsertion rate for the current VCC entry.
RES:VCC:QOS:SECBR?	Queries the severely errored cell block ratio for the current entry.
RES:VCC:QOS:NONCOMP1?	Queries the count of cells non-compliant to GCRA-1 for the current entry.
RES:VCC:QOS:NONCOMP2?	Queries the count of cells non-compliant to GCRA-2 for the current entry.
RES:VCC:QOS:STATUS?	Queries the quality of service (QOS) status for the current entry. Status = 1 if cells with CLP = 1 are received on the VCC.
RES:VCC:QOS:STATECS?	Queries the duration of STA conditions for the current entry.
RES:VCC:QOS:CLP1?	Queries the count of CLP1 cells received for the current entry.
RES:VCC:AAL:TXCELLS?	Queries the transmitted cell count for the current entry.
RES:VCC:AAL:RXCELLS?	Queries the received cell count for the current entry.
RES:VCC:AAL:RXPDU:COUNT?	Queries the received PDU count for the current entry. Note: This command is only available for AAL 5.
RES:VCC:AAL:RXPDU:RATE?	Queries the received PDU rate (represented as the number of PDUs per second) for the current entry. Note: This command is only available for AAL 5.
RES:VCC:AAL:BANDwidth?	Queries the bandwidth used by the current entry.
RES:VCC:AAL:BIT:COUNT?	Queries the count of bit errors for the current entry.
RES:VCC:AAL:BIT:RATE?	Queries the rate of bit errors for the current entry.
RES:VCC:AAL:PATSynch?	Queries the duration of loss of pattern synchronization for the current entry.
RES:VCC:AAL:SNPERRor:COUNT?	Queries the AAL 1 SNP error count for the current entry.
RES:VCC:AAL:SNPERRor:RATE?	Queries the AAL 1 SNP error rate for the current entry.
RES:VCC:AAL:LOSTcells:COUNT?	Queries the AAL 1 lost cells count for the current entry.
RES:VCC:AAL:LOSTcells:RATE?	Queries the AAL 1 lost cells rate for the current entry.
RES:VCC:AAL:MISSEQcells:COUNT?	Queries the AAL 1 missequenced cells count for the current entry.

RES Command	Description
RES:VCC:AAL:MISSEQcells:RATE?	Queries the AAL 1 missequenced cells rate for the current entry.
RES:VCC:AAL:CRCErrors:COUNT?	Queries the count of AAL 5 CRC errors for the current entry.
RES:VCC:AAL:CRCErrors:RATE?	Queries the rate of AAL 5 CRC errors for the current entry.
RES:VCC:AAL:LENErrors:COUNT?	Queries the count of AAL 5 length errors for the current entry.
RES:VCC:AAL:LENErrors:RATE?	Queries the rate of AAL 5 length errors for the current entry.
RES:VCC:AAL:PADErrors:COUNT?	Queries the count of AAL 5 padding errors for the current entry.
RES:VCC:AAL:PADErrors:RATE?	Queries the rate of AAL 5 padding errors for the current entry.
RES:VCC:AAL:ERRFlag?	Queries the AAL error flag for the current VCC entry.
RES:VCC:AAL:O191:MINCTD?	Queries the minimum CTD value for the current VCC entry. The value is reported in nano-seconds.
RES:VCC:AAL:O191:MAXCTD?	Queries the maximum CTD value for the current VCC entry. The value is reported in nano-seconds.
RES:VCC:AAL:O191:MEANCTD?	Queries the average CTD value for the current VCC entry. The value is reported in nano-seconds.
RES:VCC:AAL:O191:MISINS?	Queries the misinserted cell count.
RES:VCC:AAL:O191:LOST?	Queries the lost cell count.
RES:VCC:AAL:O191:ERR?	Queries the errored cell count.
RES:VCC:AAL:O191:AVAIL?	Queries the availability ratio.
RES:VCC:AAL:O191:CLR?	Queries the cell loss ratio.
RES:VCC:AAL:O191:CMR?	Queries the cell misinsertion rate.
RES:VCC:AAL:O191:CER	Queries the cell error ratio.
RES:VCC:AAL:O191:SECBR?	Queries the severely errored cell block ratio.
RES:VCC:AAL:O191:MTBO?	Queries the mean time between outages. This is reported in seconds.
RES:VCC:AIS:F5:Secs?	Queries the duration of F5-AIS alarm detected for the current entry.
RES:VCC:RDI:F5:Secs?	Queries the duration of F5-RDI alarm detected for the current entry.
RES:VCC:OAM:F5:CCcells?	Queries the F5 OAM continuity check cells received for the current entry.
RES:VCC:OAM:F5:LPBKcells?	Queries the F5 OAM loopback cells received for the current entry.
RES:VCC:AIS:F4:Secs?	Queries the duration of detected F4-AIS alarm for the current entry.
RES:VCC:RDI:F4:Secs?	Queries the duration of detected F4-RDI alarm for the current entry.
RES:VCC:OAM:F4:CCcells?	Queries the F4 OAM continuity check cells received for the current entry.
RES:VCC:OAM:F4:LPBKcells?	Queries the F4 OAM loopback cells received for the current entry.

TX (SOURce) Branch

The TX branch is used to set and retrieve ATM Transmit settings. Alternatively, each command can be sent using the "SOUR" or "SOURCE" keyword instead of the "TX" keyword.

The following is a list of supported Transmit commands.

TX Command	Description																																							
TX:ALarm:DEFECTtype: <octet>	Sets the defect type octet to be sent in the OAM AIS/RDI cell payload. This can be specified in either binary, Hexadecimal, or decimal formats.																																							
TX:ALarm:DEFECTtype?	Queries the defect type octet for the OAM AIS/RDI cells.																																							
TX:ALarm:DURation?	Queries the ATM test set for the duration of the alarm it is generating.																																							
TX:ALarm:DURation: <seconds>	Sets the duration (in seconds) for the alarm currently configured for the ATM protocol processor. The alarm starts after the duration is entered. The duration values range from 0 seconds to 32765 seconds or it can be set to CONTINUOUS generation.																																							
TX:ALarm:SCOPE?	Queries the ATM test set for the scope of the alarm it is generating.																																							
TX:ALarm:SCOPE: <vpi,vci>	Sets the scope of the alarm generated by the ATM test set. Default scope or for alarm generation is <0,0>. Values can be specified in either Hexadecimal or decimal formats. For physical layer alarms (Cell Sync and PLCPYEL), the scope must be set to <0,0>, which are invalid VPI/VCI values.																																							
TX:ALarm:TYPE?	Queries the current protocol processor for the alarm type it is generating. For a list of returned values, see the <i>TX:ALarm:TYPE < alarm ></i> command.																																							
TX:ALarm:TYPE <alarm>	Sets the alarm being generated. Valid parameters, meanings and protocol processors are:																																							
	<table border="1"> <thead> <tr> <th><u>Alarm</u></th> <th><u>Protocol Processors</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>ATM</td> <td>No alarm generation</td> </tr> <tr> <td>AISF4S</td> <td>ATM</td> <td>F4 Segment Alarm Indication Signal (AIS)</td> </tr> <tr> <td>AISF4E</td> <td>ATM</td> <td>F4 End AIS</td> </tr> <tr> <td>AISF5S</td> <td>ATM</td> <td>F5 Segment AIS</td> </tr> <tr> <td>AISF5E</td> <td>ATM</td> <td>F5 End AIS</td> </tr> <tr> <td>RDIF4S</td> <td>ATM</td> <td>F4 Segment RDI</td> </tr> <tr> <td>RDIF4E</td> <td>ATM</td> <td>F4 End RDI</td> </tr> <tr> <td>RDIF5S</td> <td>ATM</td> <td>F5 Segment RDI</td> </tr> <tr> <td>RDIF5E</td> <td>ATM</td> <td>F5 End RDI</td> </tr> <tr> <td>CELLSYNC</td> <td>ATM</td> <td>Cell Sync</td> </tr> <tr> <td>PLCPYEL</td> <td>ATM</td> <td>PLCP Yellow Alarm</td> </tr> <tr> <td>LOPS</td> <td>ATM</td> <td>Loss of Pattern Synchronization Alarm</td> </tr> </tbody> </table>	<u>Alarm</u>	<u>Protocol Processors</u>	<u>Meaning</u>	OFF	ATM	No alarm generation	AISF4S	ATM	F4 Segment Alarm Indication Signal (AIS)	AISF4E	ATM	F4 End AIS	AISF5S	ATM	F5 Segment AIS	AISF5E	ATM	F5 End AIS	RDIF4S	ATM	F4 Segment RDI	RDIF4E	ATM	F4 End RDI	RDIF5S	ATM	F5 Segment RDI	RDIF5E	ATM	F5 End RDI	CELLSYNC	ATM	Cell Sync	PLCPYEL	ATM	PLCP Yellow Alarm	LOPS	ATM	Loss of Pattern Synchronization Alarm
<u>Alarm</u>	<u>Protocol Processors</u>	<u>Meaning</u>																																						
OFF	ATM	No alarm generation																																						
AISF4S	ATM	F4 Segment Alarm Indication Signal (AIS)																																						
AISF4E	ATM	F4 End AIS																																						
AISF5S	ATM	F5 Segment AIS																																						
AISF5E	ATM	F5 End AIS																																						
RDIF4S	ATM	F4 Segment RDI																																						
RDIF4E	ATM	F4 End RDI																																						
RDIF5S	ATM	F5 Segment RDI																																						
RDIF5E	ATM	F5 End RDI																																						
CELLSYNC	ATM	Cell Sync																																						
PLCPYEL	ATM	PLCP Yellow Alarm																																						
LOPS	ATM	Loss of Pattern Synchronization Alarm																																						
TX:BGRND:SEQNUM <sequence number>	Sets the sequence number for background traffic generation. The sequence number can vary from 1 to 4. Up to four sequences can be defined for background traffic with each one identified by the sequence number. Note: All sequence related commands (SEQNUM, SEQHDR, SEQPAYLD) are referenced to the sequence number used by this command.																																							
TX:BGRND:SEQNUM?	Queries the current sequence number.																																							

TX Command	Description
TX:BGRND:SEQHDR <ATM cell header>	Sets the header for the current sequence.
TX:BGRND:SEQHDR?	Queries the header for the current sequence.
TX:BGRND:SEQPAYLD <payload octet>	Sets the payload octet for the current sequence.
TX:BGRND:SEQPAYLD?	Queries the payload octet for the current sequence.
TX:BGRND:BURST <burst>	Sets the burst count for the current sequence. Valid values range from 1 to 255.
TX:BGRND:BURST?	Queries the burst count for the current sequence.
TX:BGRND:SKIP <skip>	Sets the skip count for the current sequence. Valid values range from 1 to 1000.
TX:BGRND:SKIP?	Queries the skip count for the current sequence.
TX:BGRND:SEQSTAT <enable / disable>	Enables or disables the current sequence.
TX:BGRND:SEQSTAT?	Queries the status of the current sequence.
TX:BGRND:TRAF <on / off>	Starts or stops generation of background traffic on all enabled sequences.
TX:BGRND:TRAF?	Queries the status of background traffic generation.
TX:BGRND:SEQCNT?	Queries the number of sequences defined currently for background traffic generation.
TX:BURST: SCOPE <vpi,vci>	Sets the scope for burst traffic generation. Default scope for burst traffic generation is <0,0>. Values can be entered in Hexadecimal or decimal formats.
TX:BURST:SCOPE?	Queries the scope for burst cell/PDU generation.
TX:BURST:BURST <count>	Sets the burst count for burst cell/PDU generation. Valid values are 1 to 1000. Note: The burst scope must be set using the <i>TX:BURST:SCOPE <vpi,vci></i> command before using the <i>TX:BURST:BURST <count></i> command.
TX:BURST:BURST?	Queries the burst count for burst cell/PDU generation. For AAL0 and AAL1 connections, the count returned is for cells sent and or AAL5 connections, the count returned is for PDUs sent.
TX:ERRor:BURST <count>	Sets the burst count for the current error type. This command is not valid for BIT, SN, or SNP errors. Valid values are 1 to 10.
TX:ERRor:BURST?	Queries the burst count for the current error setting.
TX:ERRor:DURation <seconds>	Sets the duration, in seconds, of the error being generated by the ATM protocol processor. Valid values range from 0 to 32767 seconds or it can be set to CONTINUOUS generation.
TX:ERRor:DURation?	Queries the protocol processor for the duration of the error being generated.
TX:ERRor:RATE?	Queries the error rate.

TX Command	Description																																				
TX:ERRor:RATE <rate>	<p>Sets the error rate. Valid values are:</p> <table border="1"> <thead> <tr> <th>Rate</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>= OFF</td> </tr> <tr> <td>N.Ne-N</td> <td>where each N is a numeral from 1 to 9</td> </tr> </tbody> </table> <p>Note: This error rate format is not valid for BIT, SN, SNP, O.191 SN, or O.191 CRC errors. For these errors, only the following error rates are valid: 1.0e-2, 1.0e-3, 1.0e-4, 1.0e-5, 1.0e-6, 1.0e-7, 1.0e-8, and 1.0e-9.</p>	Rate	Description	0	= OFF	N.Ne-N	where each N is a numeral from 1 to 9																														
Rate	Description																																				
0	= OFF																																				
N.Ne-N	where each N is a numeral from 1 to 9																																				
TX:ERRor:SCOPE <vpi,vci>	<p>Sets the VPI and VCI for the ATM error. Default scope or for error generation is <0,0>. Values can be specified in either Hexadecimal or decimal formats. For physical layer errors (HEC correctable and HEC uncorrectable), the scope must be set to <0,0>, which are invalid VPI/VCI values.</p>																																				
TX:ERRor:SCOPE?	<p>Queries the protocol processor for the scope of the current error generated.</p>																																				
TX:ERRor:TYPE?	<p>Queries the error type selected for the current protocol processor.</p>																																				
TX:ERRor:TYPE <error>	<p>Note: The error generation scope must be set using the <i>TX:ERRor:SCOPE</i> command before using the <i>TX:ERR:TYPE <error></i> command.</p> <p>Sets the error type for the current protocol processor to one of the following types:</p> <table border="1"> <thead> <tr> <th>Error</th> <th>Protocol(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>ATM</td> <td>Stops error generation</td> </tr> <tr> <td>BIT</td> <td>ATM</td> <td>BIT errors</td> </tr> <tr> <td>HECC</td> <td>ATM</td> <td>HEC correctable error</td> </tr> <tr> <td>HECU</td> <td>ATM</td> <td>HEC uncorrectable error</td> </tr> <tr> <td>CRC</td> <td>ATM</td> <td>AAL5 CRC error</td> </tr> <tr> <td>LEN</td> <td>ATM</td> <td>AAL5 length error</td> </tr> <tr> <td>PAD</td> <td>ATM</td> <td>AAL5 padding error</td> </tr> <tr> <td>O191SN</td> <td>ATM</td> <td>O.191 SN error</td> </tr> <tr> <td>O191CRC</td> <td>ATM</td> <td>O.191 CRC error</td> </tr> <tr> <td>SN</td> <td>ATM</td> <td>AAL1 SN error</td> </tr> <tr> <td>SNP</td> <td>ATM</td> <td>AAL1 SNP error</td> </tr> </tbody> </table>	Error	Protocol(s)	Description	NONE	ATM	Stops error generation	BIT	ATM	BIT errors	HECC	ATM	HEC correctable error	HECU	ATM	HEC uncorrectable error	CRC	ATM	AAL5 CRC error	LEN	ATM	AAL5 length error	PAD	ATM	AAL5 padding error	O191SN	ATM	O.191 SN error	O191CRC	ATM	O.191 CRC error	SN	ATM	AAL1 SN error	SNP	ATM	AAL1 SNP error
Error	Protocol(s)	Description																																			
NONE	ATM	Stops error generation																																			
BIT	ATM	BIT errors																																			
HECC	ATM	HEC correctable error																																			
HECU	ATM	HEC uncorrectable error																																			
CRC	ATM	AAL5 CRC error																																			
LEN	ATM	AAL5 length error																																			
PAD	ATM	AAL5 padding error																																			
O191SN	ATM	O.191 SN error																																			
O191CRC	ATM	O.191 CRC error																																			
SN	ATM	AAL1 SN error																																			
SNP	ATM	AAL1 SNP error																																			
TX:LPBK:CLEARcount	<p>Clears the loopback count.</p>																																				
TX:LPBK:DURation <seconds>	<p>Sets the duration, in seconds, of the loopback generated by the ATM protocol processor. The valid range is 0 to 32767.</p>																																				
TX:LPBK:DURation?	<p>Queries the duration of OAM loopback generation.</p>																																				
TX:LPBK:SCOPE <vpi, vci>	<p>Sets the scope of the loopback being generated by the ATM protocol processor. Default scope for loopback generation is <0,0>. Values can be specified in either Hexadecimal or decimal formats.</p>																																				
TX:LPBK:SCOPE?	<p>Queries the scope of the OAM loopback generation setting.</p>																																				
TX:LPBK:SINGLoopback	<p>Starts a single loopback test.</p> <p>Note: The loopback scope (using the <i>TX:LPBK:SCOPE <vpi, vci></i> command) and type (using the <i>TX:LPBK:TYPE <type></i> command) must be set prior to using this command.</p>																																				

TX Command	Description																														
TX:LPBK:TYPE <type>	<p>Sets the loopback type. Note: The loopback generation scope must be set using the <i>TX:LPBK:SCOPE <scope></i> command before using the <i>TX:LPBK:TYPE <type></i>.</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>Invalid type</td> </tr> <tr> <td>F4SEG</td> <td>F4 Segment loopback</td> </tr> <tr> <td>F4ETE</td> <td>F4 End to End loopback</td> </tr> <tr> <td>F5SEG</td> <td>F5 Segment loopback</td> </tr> <tr> <td>F5ETE</td> <td>F5 End to End loopback</td> </tr> </tbody> </table>	Parameter	Description	NONE	Invalid type	F4SEG	F4 Segment loopback	F4ETE	F4 End to End loopback	F5SEG	F5 Segment loopback	F5ETE	F5 End to End loopback																		
Parameter	Description																														
NONE	Invalid type																														
F4SEG	F4 Segment loopback																														
F4ETE	F4 End to End loopback																														
F5SEG	F5 Segment loopback																														
F5ETE	F5 End to End loopback																														
TX:LPBK:TYPE?	Returns the current loopback type.																														
TX:NWIMPairment:SCOPE <vpi,vci>	<p>Sets the scope of the network impairment being generated by the protocol processor. These values can be entered using Hexadecimal or decimal formats. The scope must be set to <0,0> (invalid VPI/VCI values) for the following types of network impairments: Cell error generation; cell loss; cell misinsertion; cell delay variation; and cell reordering</p>																														
TX:NWIMPairment:SCOPE?	Queries the scope of the network impairment setting.																														
TX:NWIMPairment:TYPE <type>	<p>Note: The network impairment generation scope must be set using the <i>TX:NWIMP:SCOPE</i> command before using the <i>TX:NWIMP:TYPE <type></i> command. Sets the network impairment type for the current protocol processor to one of the following types:</p> <table border="1"> <thead> <tr> <th>Error</th> <th>Protocol(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>ATM</td> <td>Stops network impairment</td> </tr> <tr> <td>CEG</td> <td>ATM</td> <td>Cell error generation</td> </tr> <tr> <td>CLOS</td> <td>ATM</td> <td>Cell loss</td> </tr> <tr> <td>CMIS</td> <td>ATM</td> <td>Cell Misinsertion</td> </tr> <tr> <td>CDV</td> <td>ATM</td> <td>Cell delay variation</td> </tr> <tr> <td>CREO</td> <td>ATM</td> <td>Cell recording</td> </tr> <tr> <td>REMAP</td> <td>ATM</td> <td>VPI,VCI remapping</td> </tr> <tr> <td>CLPTG</td> <td>ATM</td> <td>CLP tagging</td> </tr> <tr> <td>CISSET</td> <td>ATM</td> <td>CI setting</td> </tr> </tbody> </table>	Error	Protocol(s)	Description	NONE	ATM	Stops network impairment	CEG	ATM	Cell error generation	CLOS	ATM	Cell loss	CMIS	ATM	Cell Misinsertion	CDV	ATM	Cell delay variation	CREO	ATM	Cell recording	REMAP	ATM	VPI,VCI remapping	CLPTG	ATM	CLP tagging	CISSET	ATM	CI setting
Error	Protocol(s)	Description																													
NONE	ATM	Stops network impairment																													
CEG	ATM	Cell error generation																													
CLOS	ATM	Cell loss																													
CMIS	ATM	Cell Misinsertion																													
CDV	ATM	Cell delay variation																													
CREO	ATM	Cell recording																													
REMAP	ATM	VPI,VCI remapping																													
CLPTG	ATM	CLP tagging																													
CISSET	ATM	CI setting																													
TX:NWIMPairment:TYPE?	Queries the current network impairment type setting.																														
TX:NWIMPairment:ERRMask <mask>	Sets the error mask octet (one byte) for cell error generation. Error mask can be specified in either binary, Hexadecimal, or decimal formats.																														
TX:NWIMPairment:ERRMask?	Queries the error mask octet for cell error generation.																														
TX:NWIMPairment:OCTET Select <octet number>	Sets the octet to be errored for cell error generation. Valid values range from 1 to 53.																														
TX:NWIMPairment:OCTET Select?	Queries the octet to be errored for cell error generation.																														
TX:NWIMPairment:HDRSelect <hrd>	Sets the header select (32-bit). Header select can be specified in either Hexadecimal or decimal formats. Header select is valid for the following network impairment types: Cell error generation; cell loss; CI setting; and CLP tagging.																														

TX Command	Description						
TX:NWIMPairment: HDRSelect?	Queries the header select.						
TX:NWIMPairment: HDRMask <mask>	Sets the header mask (32-bit). Header select can be specified in either Hexadecimal or decimal formats. Header select is valid for the following network impairment types: Cell error generation; cell loss; CI setting; and CLP tagging.						
TX:NWIMPairment: HDRMask?	Queries the header mask. This command is valid for the network impairment types mentioned in the <i>TX:NWIMPairment:HDRMask <mask></i> command.						
TX:NWIMPairment:BURST <count>	Sets the burst count for the current network impairment setting (1-10). Header select is valid for the following types: Cell error generation; cell loss; CI setting; CLP tagging; cell misinsertion; and cell delay variation.						
TX:NWIMPairment: BURST?	Queries the burst count for the current network impairment setting. It is valid for the following types: Cell error generation; cell loss; CI setting; CLP tagging; cell misinsertion; and cell delay variation.						
TX:NWIMPairment: RATE <rate>	Sets the rate for network impairment generation. It is valid for the following types: Cell error generation; cell loss; CI setting; CLP tagging; cell misinsertion; and cell delay variation. Valid rate values are: <table border="1" data-bbox="548 890 1136 982"> <thead> <tr> <th><u>Rate</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>N.Ne-N</td> <td>where each N is a numeral from 1 to 9</td> </tr> <tr> <td>0</td> <td>= OFF</td> </tr> </tbody> </table>	<u>Rate</u>	<u>Description</u>	N.Ne-N	where each N is a numeral from 1 to 9	0	= OFF
<u>Rate</u>	<u>Description</u>						
N.Ne-N	where each N is a numeral from 1 to 9						
0	= OFF						
TX:NWIMPairment:RATE?	Sets the rate for network impairment generation. It is valid for the following types: Cell error generation; cell loss; CI setting; CLP tagging; cell misinsertion; and cell delay variation.						
TX:NWIMPairment: DURation <seconds>	Sets the duration (in seconds) for the network impairment currently generated for the ATM protocol processor. The duration values range from 0 seconds to 32765 seconds or it can be set to CONTINUOUS generation.						
TX:NWIMPairment: DURation?	Queries the duration of the network impairment being generated by the ATM test set.						
TX:NWIMPairment: MISINSHeader <hdr>	Sets the misinserted cell's header (32-bit) for Cell Misinsertion network impairment. This can be specified in either Hexadecimal or decimal formats.						
TX:NWIMPairment: MISINSHeader?	Queries the misinserted cell's header for Cell misinsertion network impairment.						
TX:NWIMPairment: PAYLoadoctet <octet>	Sets the payload octet (one byte) of the misinserted cell. This can be specified in either binary, Hexadecimal, or decimal formats.						
TX:NWIMPairment: PAYLoadoctet?	Queries the payload octet of the misinserted cell.						
TX:NWIMPairment: REMAPHeader <ATM header>	Sets the ATM header for remapping. Refer to the ATMVCC Branch for ATM header information.						
TX:NWIMPairment: REMAPHeader?	Queries the ATM header for remapping.						
TX:NWIMPairment: REORDER	Reorders a pair of cells matching the header select and header mask set earlier.						

TX Command	Description										
TX:PMOAM:SCOPE <vpi,vci>	Sets the scope for PM-OAM cell generation. The default scope is <0,0>. The scope has to be set to the VPI/VCI of the VCC on which the PM-OAM has been enabled. The VPI/VCI can be entered using either Hexadecimal or decimal formats.										
TX:PMOAM:SCOPE?	Queries the scope for the PM-OAM cell generation.										
TX:FWMON [ENABLE, DISABLE] {<blksize>}	Enables or disables the generation of Forward Monitoring PM-OAM cells on the VCC indicated by the scope. When enabling the generation of FW PM-OAM cells only, the block size must be specified. The block size specifies the number of user cells after which a FM PM-OAM cell is inserted. The block size can take any one of the following values: 128, 256, 512, 1024, 2048, 4096, 8192, 16384, or 32768. Note: PM-OAM can be enabled or disabled only when the VCC is not transmitting or receiving cells.										
TX:BWREP [ENABLE, DISABLE]	Enables or disables the generation of Backward Reporting PM-OAM cells on the VCC indicated by the scope. Once enabled, a backward reporting PM-OAM cell is sent in response to each forward monitoring PM-OAM cell received. Note: PM-OAM can be enabled or disabled only when the VCC is not transmitting or receiving cells.										
TX:FWMON?	Queries the Forward Monitoring PM-OAM setting.										
TX:BWREP?	Queries the Backward Monitoring PM-OAM setting.										
TX:SVCTEST:TYPE <test type>	Sets the SVC load test type. The following are valid values: <table border="1"> <thead> <tr> <th>Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>No SVC test is set.</td> </tr> <tr> <td>CALLSETUP</td> <td>SVC call setup test. Setup - Connect ACK sequence</td> </tr> <tr> <td>CYCLIC</td> <td>SVC cyclic call test. Setup - Release Complete sequence</td> </tr> <tr> <td>CALLBURST</td> <td>SVC call burst test. SVCs are established with the specified burst and skip profile</td> </tr> </tbody> </table>	Type	Description	NONE	No SVC test is set.	CALLSETUP	SVC call setup test. Setup - Connect ACK sequence	CYCLIC	SVC cyclic call test. Setup - Release Complete sequence	CALLBURST	SVC call burst test. SVCs are established with the specified burst and skip profile
Type	Description										
NONE	No SVC test is set.										
CALLSETUP	SVC call setup test. Setup - Connect ACK sequence										
CYCLIC	SVC cyclic call test. Setup - Release Complete sequence										
CALLBURST	SVC call burst test. SVCs are established with the specified burst and skip profile										
TX:SVCTEST:TYPE?	Queries the SVC load test type.										
TX:SVCTEST:CALLRATE <rate>	Sets the call rate for the SVC load test. The call rate appears as number of calls per second. Valid values range from 1 to 256.										
TX:SVCTEST:CALLRATE?	Queries the call rate for the SVC load test.										
TX:SVCTEST:DUR <duration in seconds>	Sets the duration of the SVC load test. The duration should be set such that (call rate * duration) is less than or equal to 5000.										
TX:SVCTEST:DUR?	Queries the duration of the SVC load test.										
TX:SVCTEST:BURST <burst size>	Sets the burst size for Call Burst SVC load test. The burst is specified as number of seconds or as RANDOM. The burst parameter specifies the duration for which the SETUP messages are sent continuously.										
TX:SVCTEST:BURST?	Queries the burst size for the Call Burst SVC load test.										
TX:SVCTEST:SKIP <skip size>	Sets the skip size for Call Burst SVC load test. The skip is specified as number of seconds. The skip parameter specifies the duration for which no SETUP message are sent out.										
TX:SVCTEST:SKIP?	Queries the skip size for Call Burst SVC load test.										

ATMVCC Branch

The ATMVCC Branch contains SCPI commands that control functionality associated with the ATM VCC Table Function Group button.

- Allow you to create and edit VCC Table entries
- Query and change VCC Table entry

Using the ATMVCC Branch Commands

Before you can use an ATMVCC command, you must first select a VCC Table entry. For first-time ATM operation, create a VCC Table entry

1. Issue the *ATMSYS:INTERFACE?* command to determine if the ATM protocol processor is configured for NNI or UNI mode. (This determines how you enter the VCC Table header.)
2. To add a VCC Table entry, issue the *ATMVCC:TABLE:ADD* command.

For UNI, enter:

- One digit for the GFC value
- Two digits for the VPI value
- Four digits for the VCI value
- One digit for the PTI value
- One digit for the CLP value

an X represents a wildcard character and a single space is required between each value, for example

ATMVCC:TABLE:ADD x 12 0040 x x

For NNI, enter:

- Two digits for the VPI value
- Four digits for the VCI value
- One digit for the PTI value
- One digit for the CLP value

an X represents a wildcard character and a single space is required between each value, for example

ATMVCC:TABLE:ADD 21 0050 x x

3. Issue the *ATMVCC:TABLE:ENTRY?* command to verify that the entry was added to the VCC Table.

ATMVCC Command	Description								
ATMVCC:AAL?	Queries the current virtual channel for its AAL value.								
ATMVCC:AAL <type>	Sets the AAL type as specified for the current VCC table entry. Valid values are: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AAL0</td> </tr> <tr> <td>1</td> <td>AAL1</td> </tr> <tr> <td>5</td> <td>AAL5</td> </tr> </tbody> </table>	Type	Description	0	AAL0	1	AAL1	5	AAL5
Type	Description								
0	AAL0								
1	AAL1								
5	AAL5								

ATMVCC Command	Description																		
ATMVCC:AALPDU?	Returns the AAL PDU length for the current AAL5 VCC table entry.																		
ATMVCC:AALPDU <length>	Sets the AAL PDU length for the current VCC table entry to the value specified. The value ranges from 1 to 65512.																		
ATMVCC:CDVT?	Queries the CDVT parameter for the current VCC table entry.																		
ATMVCC:CDVT <value>	Sets the CDVT parameter (in number of cell slots) for the current VCC entry. Valid values range from 1 to 1047552.																		
ATMVCC:COUNT?	Queries the count of VCCs present in the VCC table.																		
ATMVCC:DELETE:CURrent	Deletes the current virtual channel from the VCC Table.																		
ATMVCC:DELETE:ALL	Deletes all virtual channels from the VCC table. Note: This command deletes the entire VCC table.																		
ATMVCC:HEADER:n?	Queries the ATM header (32-bit) for the N th entry in the VCC table.																		
ATMVCC:MBS?	Returns the maximum burst size (MBS) for the current VCC table entry. MBS is only valid for VBR connections.																		
ATMVCC:MBS <value>	Sets the MBS for the current VCC table entry. MBS is only valid for VBR connections.																		
ATMVCC:PCR?	Returns the peak cell rate (PCR) for the current VCC table entry.																		
ATMVCC:PCR <value>	Sets the PCR for the current VCC table entry.																		
ATMVCC:RX:PATtern?	Returns the pattern name as specified in the <i>ATMVCC:RX:PAT <pattern></i> command.																		
ATMVCC:RX:PATtern:<pattern>	Sets the value of the expected ATM receive pattern. The following values are valid: <table border="1" data-bbox="755 1327 1331 1638"> <thead> <tr> <th>Pattern</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>WORD <word></td> <td>User word (32-bit) pattern</td> </tr> <tr> <td>PRBS</td> <td>2¹⁵-1 PRBS pattern</td> </tr> <tr> <td>INVPRBS</td> <td>2¹⁵-1 inverted PRBS pattern</td> </tr> <tr> <td>O191_REV0</td> <td>O.191 Revision-0 test cell pattern</td> </tr> <tr> <td>O191_REV1</td> <td>O.191 Revision-1 test cell pattern</td> </tr> <tr> <td>ALLONES</td> <td>All 1s pattern</td> </tr> <tr> <td>ALLZEROS</td> <td>All 0s pattern</td> </tr> <tr> <td>1010</td> <td>Alternating 1 and 0s pattern</td> </tr> </tbody> </table> PDU<#of Bytes> <byte1>...<byteN> Full cell/PDU pattern. Note: Up to 100 bytes can be entered for a Full PDU pattern.	Pattern	Description	WORD <word>	User word (32-bit) pattern	PRBS	2 ¹⁵ -1 PRBS pattern	INVPRBS	2 ¹⁵ -1 inverted PRBS pattern	O191_REV0	O.191 Revision-0 test cell pattern	O191_REV1	O.191 Revision-1 test cell pattern	ALLONES	All 1s pattern	ALLZEROS	All 0s pattern	1010	Alternating 1 and 0s pattern
Pattern	Description																		
WORD <word>	User word (32-bit) pattern																		
PRBS	2 ¹⁵ -1 PRBS pattern																		
INVPRBS	2 ¹⁵ -1 inverted PRBS pattern																		
O191_REV0	O.191 Revision-0 test cell pattern																		
O191_REV1	O.191 Revision-1 test cell pattern																		
ALLONES	All 1s pattern																		
ALLZEROS	All 0s pattern																		
1010	Alternating 1 and 0s pattern																		
ATMVCC:RX:STATUS?	Returns the receive enable status of the current VCC table entry. Returned values are: DISABLE, MONITOR, or DETAIL.																		

ATMVCC Command	Description												
ATMVCC:RX:STATUS <status>	<p>Sets the receive enable status of the current VCC table entry. The following values are valid:</p> <table border="1"> <thead> <tr> <th>Status</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MONITOR</td> <td>Enables monitoring of the entry.</td> </tr> <tr> <td>DETAIL</td> <td>Enables detailed monitoring of the entry for a maximum of four entries.</td> </tr> <tr> <td>DISABLE</td> <td>Disables monitoring of the entry.</td> </tr> </tbody> </table>	Status	Description	MONITOR	Enables monitoring of the entry.	DETAIL	Enables detailed monitoring of the entry for a maximum of four entries.	DISABLE	Disables monitoring of the entry.				
Status	Description												
MONITOR	Enables monitoring of the entry.												
DETAIL	Enables detailed monitoring of the entry for a maximum of four entries.												
DISABLE	Disables monitoring of the entry.												
ATMVCC:RX:STATALL <status>	<p>Sets the receive enable status of all VCC table entries. The following values are valid:</p> <table border="1"> <thead> <tr> <th>Status</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MONITOR</td> <td>Enables monitoring of all entries.</td> </tr> <tr> <td>DISABLE</td> <td>Disables monitoring of all entries.</td> </tr> </tbody> </table>	Status	Description	MONITOR	Enables monitoring of all entries.	DISABLE	Disables monitoring of all entries.						
Status	Description												
MONITOR	Enables monitoring of all entries.												
DISABLE	Disables monitoring of all entries.												
ATMVCC:RX:TOGGLE?	Queries the value of the <i>ATMVCC:RX:TOGGLE <toggle></i> command.												
ATMVCC:RX:TOGGLE <toggle>	<p>Starts and stops monitoring on all enabled VCC table entries. Valid values are:</p> <table border="1"> <thead> <tr> <th>Toggle</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Monitors all enabled VCC table entries as specified (Monitor or Detail).</td> </tr> <tr> <td>OFF</td> <td>Stops monitoring all enabled VCC table entries.</td> </tr> </tbody> </table>	Toggle	Description	ON	Monitors all enabled VCC table entries as specified (Monitor or Detail).	OFF	Stops monitoring all enabled VCC table entries.						
Toggle	Description												
ON	Monitors all enabled VCC table entries as specified (Monitor or Detail).												
OFF	Stops monitoring all enabled VCC table entries.												
ATMVCC:SCR?	Returns the sustained cell rate (SCR) for the current VCC table entry. SCR is only valid for VBR connections.												
ATMVCC:SCR <value>	Sets the SCR for the current VCC table entry. SCR is only valid for VBR connections.												
ATMVCC:SHAPING?	Returns the traffic shaping for the current VCC table entry.												
ATMVCC:SHAPING <type>	<p>Sets the traffic shaping for the current VCC table entry. The following values are valid:</p> <table border="1"> <thead> <tr> <th>Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>RTVBR</td> <td>?Variable Bit Rate traffic shaping</td> </tr> <tr> <td>NRTVBR</td> <td>?Variable Bit Rate traffic shaping</td> </tr> <tr> <td>UBR</td> <td>Unspecified Bit Rate traffic shaping</td> </tr> <tr> <td>CBR</td> <td>Constant Bit Rate traffic shaping</td> </tr> <tr> <td>ABR</td> <td>Available Bit Rate traffic shaping</td> </tr> </tbody> </table>	Type	Description	RTVBR	?Variable Bit Rate traffic shaping	NRTVBR	?Variable Bit Rate traffic shaping	UBR	Unspecified Bit Rate traffic shaping	CBR	Constant Bit Rate traffic shaping	ABR	Available Bit Rate traffic shaping
Type	Description												
RTVBR	?Variable Bit Rate traffic shaping												
NRTVBR	?Variable Bit Rate traffic shaping												
UBR	Unspecified Bit Rate traffic shaping												
CBR	Constant Bit Rate traffic shaping												
ABR	Available Bit Rate traffic shaping												

ATMVCC Command	Description
ATMVCC:TABLE:ADD <header>	<p>Adds a virtual channel to the VCC Table. The ATM header contains the following parameters: Use the following guidelines to enter the VCC Header:</p> <ul style="list-style-type: none"> gfc — a single digit Hex value (0 to F) that represents the Generic Flow Control bit in a VCC Header. The GFC is used only for a UNI interface. It is not required for an NNI interface. vpi — a 2 digit hex value (for a UNI interface) or a 3 digit hex value (for an NNI interface) that represents the Virtual Path Identifier. vci — a 4 digit Hex value that represents the Virtual Channel Identifier. pti — a 2 digit binary value (0 or 1) that represents the Payload Type Indicator bits in a VCC Header. Enter values only for the 2nd and 3rd bit position. clp — a single digit binary value that represents the Cell Loss Priority bit in a VCC Header. <p>Note: Use a space to separate VCC Header parameters. For example, To enter a UNI VCC Header: ATMVCC:TABLE:ADD F 01 0040 11 0 To enter an NNI VCC Header: ATMVCC:TABLE:ADD 01 0040 11 X</p>
ATMVCC:TABLE:ENTRY?	<p>Returns the current VCC Table entry for its VCC Header. For a UNI VCC Header, the query may appear similar to the following: 0 0F 0040 0x0 x For an NNI VCC Header, the query may appear similar to the following: 00F 0040 0x0 x</p>
ATMVCC:TABLE:ENTRY <header>	<p>Sets the current VCC table entry (for GPIB/SCPI) to the entry specified. The ATM header contains the following parameters:</p> <ul style="list-style-type: none"> gfc — a single digit Hex value (0 to F) that represents the Generic Flow Control bit in a VCC Header. The GFC is used only for a UNI interface. It is not required for an NNI interface. vpi — a 2 digit hex value (for a UNI interface) or a 3 digit hex value (for an NNI interface) that represents the Virtual Path Identifier. vci — a 4 digit Hex value that represents the Virtual Channel Identifier. pti — a 2 digit binary value (0 or 1) that represents the Payload Type Indicator bits in a VCC Header. Enter values only for the 2nd and 3rd bit position. clp — a single digit binary value that represents the Cell Loss Priority bit in a VCC Header. <p>Note: The entry must exist in the VCC table; this entry is used for changes and deletion. If it does not exist, then the most recent entry added to the VCC table becomes the editable table.</p>

ATMVCC Command	Description
ATMVCC:TABLE:SEARCH <vpi,vci>	Searches the VCC table for a connection with the given VPI/VCI values. If a connection is found, its index (which starts at 1) in the VCC table is returned. If no connection is found, then -1 is returned.
ATMVCC:TABLE:ADDSVC [number of connections]	<p>Establishes and adds a specified number of SVCs in the VCC table. If no value is specified, then the default value of 1 is used. Valid values range from 1 to 256.</p> <p>Note: Before using this command, the SVC setup message parameters must be set. Refer to the SVCSETUP commands for more information.</p> <p>Any added entry uses PRBS pattern as the default Transmit and Receive patterns.</p> <p>The current VCC entry is set to the newly added connection. the VPI.VCI allocated for the SVC can be queried using the ATMVCC:TABLE:ENTRY? command.</p>
ATMVCC:TABLE:TURBOadd <N, header>	<p>Adds N entries to the VCC table. Valid values for N are 1 to 256. The ATM header contains the following parameters:</p> <ul style="list-style-type: none"> gfc — a single digit Hex value (0 to F) that represents the Generic Flow Control bit in a VCC Header. The GFC is used only for a UNI interface. It is not required for an NNI interface. vpi — a 2 digit hex value (for a UNI interface) or a 3 digit hex value (for an NNI interface) that represents the Virtual Path Identifier. vci — a 4 digit Hex value that represents the Virtual Channel Identifier. pti — a 2 digit binary value (0 or 1) that represents the Payload Type Indicator bits in a VCC Header. Enter values only for the 2nd and 3rd bit position. clp — a single digit binary value that represents the Cell Loss Priority bit in a VCC Header. <p>Note: The entry must exist in the VCC table; this entry is used for changes and deletion. If it does not exist, then the most recent entry added to the VCC table becomes the editable table.</p>
ATMVCC:TX:CSIbyte <octet>	Sets the AAL1 CSI octet for the current entry to the passed value. This can be specified in either binary, Hexadecimal, or decimal formats.
ATMVCC:TX:PATtern?	Returns the transmit pattern for the current VCC table entry.

ATMVCC Command	Description																		
ATMVCC:TX:PATtern <pattern>	<p>Sets the value of the ATM transmit pattern.</p> <p>The following values are valid:</p> <table border="1"> <thead> <tr> <th><u>Pattern</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>WORD <word></td> <td>User word (32-bit) pattern</td> </tr> <tr> <td>PRBS</td> <td>2¹⁵-1 PRBS pattern</td> </tr> <tr> <td>INVPRBS</td> <td>2¹⁵-1 inverted PRBS pattern</td> </tr> <tr> <td>O191_REV0</td> <td>O.191 Revision-0 test cell pattern</td> </tr> <tr> <td>O191_REV1</td> <td>O.191 Revision-1 test cell pattern</td> </tr> <tr> <td>ALLONES</td> <td>All 1s pattern</td> </tr> <tr> <td>ALLZEROS</td> <td>All 0s pattern</td> </tr> <tr> <td>1010</td> <td>Alternating 1 and 0s pattern</td> </tr> </tbody> </table> <p>PDU<#of Bytes> <byte1>...<byteN> Full cell/PDU pattern. Note: Up to 100 bytes can be entered for a Full PDU pattern.</p>	<u>Pattern</u>	<u>Description</u>	WORD <word>	User word (32-bit) pattern	PRBS	2 ¹⁵ -1 PRBS pattern	INVPRBS	2 ¹⁵ -1 inverted PRBS pattern	O191_REV0	O.191 Revision-0 test cell pattern	O191_REV1	O.191 Revision-1 test cell pattern	ALLONES	All 1s pattern	ALLZEROS	All 0s pattern	1010	Alternating 1 and 0s pattern
<u>Pattern</u>	<u>Description</u>																		
WORD <word>	User word (32-bit) pattern																		
PRBS	2 ¹⁵ -1 PRBS pattern																		
INVPRBS	2 ¹⁵ -1 inverted PRBS pattern																		
O191_REV0	O.191 Revision-0 test cell pattern																		
O191_REV1	O.191 Revision-1 test cell pattern																		
ALLONES	All 1s pattern																		
ALLZEROS	All 0s pattern																		
1010	Alternating 1 and 0s pattern																		
ATMVCC:TX:STATALL <status>	<p>Sets the receive enable status of all VCC table entries. The following values are valid:</p> <table border="1"> <thead> <tr> <th><u>Status</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>ENABLE</td> <td>Allows transmit to be turned on for all entries.</td> </tr> <tr> <td>DISABLE</td> <td>Allows transmit to be turned off for all entries.</td> </tr> </tbody> </table>	<u>Status</u>	<u>Description</u>	ENABLE	Allows transmit to be turned on for all entries.	DISABLE	Allows transmit to be turned off for all entries.												
<u>Status</u>	<u>Description</u>																		
ENABLE	Allows transmit to be turned on for all entries.																		
DISABLE	Allows transmit to be turned off for all entries.																		
ATMVCC:TX:STATUS?	Returns the transmit enable status of the current VCC table entry. Returned values are: ENABLE or DISABLE.																		
ATMVCC:TX:STATUS <status>	<p>Sets the receive enable status of the current VCC table entry. The following values are valid:</p> <table border="1"> <thead> <tr> <th><u>Status</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>ENABLE</td> <td>Allows transmit to be turned on for the entry.</td> </tr> <tr> <td>DISABLE</td> <td>Allows transmit to be turned off for the entry.</td> </tr> <tr> <td>ERR_ENABLE</td> <td>Allows transmit to be turned on for the entry with the capability to generate (1) Errors (2) Alarms (3) PM-OAM Cells (4) Loopback OAM Cells.</td> </tr> </tbody> </table>	<u>Status</u>	<u>Description</u>	ENABLE	Allows transmit to be turned on for the entry.	DISABLE	Allows transmit to be turned off for the entry.	ERR_ENABLE	Allows transmit to be turned on for the entry with the capability to generate (1) Errors (2) Alarms (3) PM-OAM Cells (4) Loopback OAM Cells.										
<u>Status</u>	<u>Description</u>																		
ENABLE	Allows transmit to be turned on for the entry.																		
DISABLE	Allows transmit to be turned off for the entry.																		
ERR_ENABLE	Allows transmit to be turned on for the entry with the capability to generate (1) Errors (2) Alarms (3) PM-OAM Cells (4) Loopback OAM Cells.																		
ATMVCC:TX:TOGGLE?	Queries the value of the <i>ATMVCC:TX:TOGGLE <toggle></i> command.																		
ATMVCC:TX:TOGGLE <toggle>	<p>Starts and stops monitoring on all enabled VCC table entries. Valid values are:</p> <table border="1"> <thead> <tr> <th><u>Toggle</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Monitors all enabled VCC table entries as specified (Monitor or Detail).</td> </tr> <tr> <td>OFF</td> <td>Stops monitoring all enabled VCC table entries.</td> </tr> </tbody> </table>	<u>Toggle</u>	<u>Description</u>	ON	Monitors all enabled VCC table entries as specified (Monitor or Detail).	OFF	Stops monitoring all enabled VCC table entries.												
<u>Toggle</u>	<u>Description</u>																		
ON	Monitors all enabled VCC table entries as specified (Monitor or Detail).																		
OFF	Stops monitoring all enabled VCC table entries.																		
ATMVCC:TX:UUfield?	Queries the AAL5 User-to-User (UU) indication for the current entry.																		
ATMVCC:TX:UUfield <octet>	Sets the AAL5 UU indication for the current entry. Any coding of an octet is valid for the UU field. Values can be specified in binary, Hexadecimal, or decimal formats.																		

ATMVCC Command	Description
ATMVCC:TYPE?	Queries the VCC type of the current entry in the VCC table. The response is either PVC or SVC.
ATMVCC:CREFValue?	Queries the call reference value of the current entry in the VCC table. The entry will be an SVC.
ATMVCC:CREFFlag?	Queries the call reference flag of the current entry in the VCC table. The entry will be an SVC.
ATMVCC:O191:BLKSIZE <block size>	Sets the O.191 block size for a VCC with O.191 as the receive pattern. Valid values for block size are: 128, 256, 512, 1024, 2048, 4096, 8192, 16384, or 32768.
ATMVCC:O191:BLKSIZE?	Queries the O.191 block size for a VCC with O.191 as the receive pattern.
ATMVCC:O191:FLOWtype <flow type>	Sets the CLP flow to be analyzed for a VCC with O.191 as the receive pattern. The flow type can be analyzed and set to any of the following values: CLP0, CLP1, or CLP01.
ATMVCC:O191:FLOWtype?	Queries the CLP flow to be analyzed for a VCC with O.191 as the receive pattern.

ATMSCAN Branch

The ATM Scan Branch SCPI commands support functionality associated with the Scan button. The Scan button is located under the ATM Functns Function Group button.

ATMSCAN Commands	Description
ATMSCAN:ADDVCC:N	Adds a specific VCC (that appears in the Scan table as a result of using the Scan function) to the ATM protocol processor's VCC Table. For example, <i>ATMSCAN:ADDVCC:3</i>
ATMSCAN:ADDVCC:ALL	Add all VCCs (that appear in the Scan table as a result of using the Scan function) to the ATM protocol processor's VCC Table.
ATMSCAN:CLEAR	Removes all elements from the Scan table
ATMSCAN:COUNT?	Queries the number of VCCs in the Scan table.
ATMSCAN:HDRS?	Queries the header select used for scanning.
ATMSCAN:HDRS <header select>	Sets the VCC header select (32-bit) for scanning. This value can be specified in Hexadecimal or decimal formats.
ATMSCAN:HDRM? (Protocol supported: ATM)	Queries the header mask used for scanning.
ATMSCAN:HDRM <header select>	Sets the VCC header mask (32-bit) for scanning. This value can be specified in Hexadecimal or decimal formats.
ATMSCAN:HEADER:n?	Queries a specific VCC (that appears in the Scan table as a result of using the Scan function) for its VPI and VCI values.

ATMSCAN Commands	Description
ATMSCAN:SEARCH <vpi,vci>	Searches the list of scanned VPI/VCI pairs for the given VPI/VCI values. If a present, the VPI/VCI pair's index (which starts at 1) in the scanned list is returned. If a VPI/VCI pair is not found, then -1 is returned.
ATMSCAN:START	Starts the VCC scan operation.
ATMSCAN:STOP	Stop the VCC scan operation.

ATMSYS Branch

The ATM System Branch SCPI commands support functionality associated with the **Settings** button. This button is located under the ATM Functns Function Group button.

ATMSYS Commands	Description										
ATMSYS:CELLRATE?	Queries the ATM cell rate's unit of measure.										
ATMSYS:CELLRATE <unit of measure>	<p>Determines how the ATM interface's bandwidth is represented in units of measure:</p> <table border="1"> <thead> <tr> <th><u>Unit of Measure</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>CPS</td> <td>Cells per second. (Default value) The bandwidth is entered and displayed as cells-per-second.</td> </tr> <tr> <td>BW</td> <td>Bandwidth percentage. The bandwidth is entered and displayed as a percentage ranging from 0.0 percent</td> </tr> <tr> <td>KB</td> <td>Kilobits per second. The bandwidth is entered and displayed as Kbps.</td> </tr> <tr> <td>MB</td> <td>Megabits per second. The bandwidth is entered and displayed as Mbps.</td> </tr> </tbody> </table>	<u>Unit of Measure</u>	<u>Description</u>	CPS	Cells per second. (Default value) The bandwidth is entered and displayed as cells-per-second.	BW	Bandwidth percentage. The bandwidth is entered and displayed as a percentage ranging from 0.0 percent	KB	Kilobits per second. The bandwidth is entered and displayed as Kbps.	MB	Megabits per second. The bandwidth is entered and displayed as Mbps.
<u>Unit of Measure</u>	<u>Description</u>										
CPS	Cells per second. (Default value) The bandwidth is entered and displayed as cells-per-second.										
BW	Bandwidth percentage. The bandwidth is entered and displayed as a percentage ranging from 0.0 percent										
KB	Kilobits per second. The bandwidth is entered and displayed as Kbps.										
MB	Megabits per second. The bandwidth is entered and displayed as Mbps.										
ATMSYS:INTERFACE?	Queries the ATM interface setting.										
ATMSYS:INTERFACE <interface>	<p>Sets the ATM interface. The following values are valid:</p> <table border="1"> <thead> <tr> <th><u>Interface</u></th> <th><u>Description</u></th> </tr> </thead> <tbody> <tr> <td>UNI</td> <td>User-Network Interface</td> </tr> <tr> <td>NNI</td> <td>Network-Network Interface</td> </tr> </tbody> </table>	<u>Interface</u>	<u>Description</u>	UNI	User-Network Interface	NNI	Network-Network Interface				
<u>Interface</u>	<u>Description</u>										
UNI	User-Network Interface										
NNI	Network-Network Interface										
ATMSYS:MAPping?	Queries the protocol processor for the ATM physical mapping.										

ATMSYS Commands	Description																																																																											
ATMSYS:MAPping <mapping>	<p>Sets the physical mapping for ATM. The following values are valid:</p> <p>Mapping:</p> <table> <tr><td>NONE</td><td></td><td></td></tr> <tr><td>E3_DIRECT</td><td>STM4_C4_4c</td><td>OC12_STS12c</td></tr> <tr><td>E3_PLCP</td><td>STM4_C4</td><td>OC12_STS3c</td></tr> <tr><td>E1_1_DIRECT</td><td>STM4_C3</td><td>OC12_FULLSPE</td></tr> <tr><td>E1_1_PLCP</td><td>STM4_C2</td><td>OC12_VT15</td></tr> <tr><td>E1_2_DIRECT</td><td>STM4_C12</td><td>OC12_VT2</td></tr> <tr><td>E1_2_PLCP</td><td>STM4_C11</td><td>OC12_VT6</td></tr> <tr><td>DS3_DIRECT</td><td>STM1_C4</td><td>OC3_STS3c</td></tr> <tr><td>DS3_PLCP</td><td>STM1_C3</td><td>OC3_FULLSPE</td></tr> <tr><td>DS1_1_DIRECT</td><td>STM1_C2</td><td>OC3_VT15</td></tr> <tr><td>DS1_1_PLCP</td><td>STM1_C12</td><td>OC3_VT2</td></tr> <tr><td>DS1_2_DIRECT</td><td>STM1_C11</td><td>OC3_VT6</td></tr> <tr><td>DS1_2_PLCP</td><td>STM0_C3</td><td>OC1_FULLSPE</td></tr> <tr><td></td><td>STM0_C2</td><td>OC1_VT15</td></tr> <tr><td></td><td>STM0_C12</td><td>OC1_VT2</td></tr> <tr><td></td><td>STM0_C11</td><td>OC1_VT6</td></tr> <tr><td></td><td>STM1e_C4</td><td>STS1_FULLSPE</td></tr> <tr><td></td><td>STM1e_C3</td><td>STS1_VT15</td></tr> <tr><td></td><td>STM1e_C2</td><td>STS1_VT2</td></tr> <tr><td></td><td>STM1e_C12</td><td>STS1_VT6</td></tr> <tr><td></td><td>STM1e_C11</td><td></td></tr> <tr><td></td><td>STM0e_C3</td><td></td></tr> <tr><td></td><td>STM0e_C2</td><td></td></tr> <tr><td></td><td>STM0e_C12</td><td></td></tr> <tr><td></td><td>STM0e_C11</td><td></td></tr> </table>	NONE			E3_DIRECT	STM4_C4_4c	OC12_STS12c	E3_PLCP	STM4_C4	OC12_STS3c	E1_1_DIRECT	STM4_C3	OC12_FULLSPE	E1_1_PLCP	STM4_C2	OC12_VT15	E1_2_DIRECT	STM4_C12	OC12_VT2	E1_2_PLCP	STM4_C11	OC12_VT6	DS3_DIRECT	STM1_C4	OC3_STS3c	DS3_PLCP	STM1_C3	OC3_FULLSPE	DS1_1_DIRECT	STM1_C2	OC3_VT15	DS1_1_PLCP	STM1_C12	OC3_VT2	DS1_2_DIRECT	STM1_C11	OC3_VT6	DS1_2_PLCP	STM0_C3	OC1_FULLSPE		STM0_C2	OC1_VT15		STM0_C12	OC1_VT2		STM0_C11	OC1_VT6		STM1e_C4	STS1_FULLSPE		STM1e_C3	STS1_VT15		STM1e_C2	STS1_VT2		STM1e_C12	STS1_VT6		STM1e_C11			STM0e_C3			STM0e_C2			STM0e_C12			STM0e_C11	
NONE																																																																												
E3_DIRECT	STM4_C4_4c	OC12_STS12c																																																																										
E3_PLCP	STM4_C4	OC12_STS3c																																																																										
E1_1_DIRECT	STM4_C3	OC12_FULLSPE																																																																										
E1_1_PLCP	STM4_C2	OC12_VT15																																																																										
E1_2_DIRECT	STM4_C12	OC12_VT2																																																																										
E1_2_PLCP	STM4_C11	OC12_VT6																																																																										
DS3_DIRECT	STM1_C4	OC3_STS3c																																																																										
DS3_PLCP	STM1_C3	OC3_FULLSPE																																																																										
DS1_1_DIRECT	STM1_C2	OC3_VT15																																																																										
DS1_1_PLCP	STM1_C12	OC3_VT2																																																																										
DS1_2_DIRECT	STM1_C11	OC3_VT6																																																																										
DS1_2_PLCP	STM0_C3	OC1_FULLSPE																																																																										
	STM0_C2	OC1_VT15																																																																										
	STM0_C12	OC1_VT2																																																																										
	STM0_C11	OC1_VT6																																																																										
	STM1e_C4	STS1_FULLSPE																																																																										
	STM1e_C3	STS1_VT15																																																																										
	STM1e_C2	STS1_VT2																																																																										
	STM1e_C12	STS1_VT6																																																																										
	STM1e_C11																																																																											
	STM0e_C3																																																																											
	STM0e_C2																																																																											
	STM0e_C12																																																																											
	STM0e_C11																																																																											
ATMSYS:RESTART	<p>Restarts the ATM protocol processor, all accumulated statistics, and any activities stopped by the <i>ATMSYS:STOP</i> command.</p> <p>Note: This command is usually issued after the <i>ATMSYS:STOP</i> command.</p>																																																																											
ATMSYS:SCRAMBLing?	Queries the ATM cell scrambling setting.																																																																											
ATMSYS:SCRAMBLing <scrambling>	<p>Sets the ATM protocol processor's cell scrambling mode. Valid values are:</p> <table> <thead> <tr> <th>Scrambling</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Enables ingress scrambling and egress descrambling</td> </tr> <tr> <td>OFF</td> <td>Disables ingress scrambling and egress descrambling</td> </tr> </tbody> </table>	Scrambling	Description	ON	Enables ingress scrambling and egress descrambling	OFF	Disables ingress scrambling and egress descrambling																																																																					
Scrambling	Description																																																																											
ON	Enables ingress scrambling and egress descrambling																																																																											
OFF	Disables ingress scrambling and egress descrambling																																																																											
ATMSYS:STOP	Stops the ATM protocol processor.																																																																											

SVCSETUP Branch

The Switched Virtual Circuit Setup Branch SCPI commands are used to

- n Set the information elements of the SETUP message internally in SCPI. These elements are used when trying to establish an SVC using the ATMVCC:TABLE:ADDSVC command.

The SVC setup parameters are initially set to the values taken from the default SVC setup parameter list. These can be optionally modified using the SVCSETUP commands. After ATMVCC:TABLE:ADDSVC command is issued, the SVC setup parameters will be set to the values from the default parameters list. Refer to the SVCCFG:DEFSETUP branch for setting and getting the default setup parameters.

- n Queries the information elements of the SETUP message for the current VCC table entry. For this operation, the current VCC table entry should be set to an existing SVC in the VCC table.
- n Queries the information elements of the SETUP message stored internally in SCPI. For this operation, the current VCC table entry should be set as INVALID.

SVCSETUP Commands	Description												
SVCSETUP:QOSCLASS:FWD <QOS class>	<p>Sets the forward QoS class for the SVC to be established. The QoS Class can be any one of the following:</p> <table border="1"> <thead> <tr> <th>QoS Class</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>CLASS0</td> <td>QoS class 0</td> </tr> <tr> <td>CLASS1</td> <td>QoS class 1</td> </tr> <tr> <td>CLASS2</td> <td>QoS class 2</td> </tr> <tr> <td>CLASS3</td> <td>QoS class 3</td> </tr> <tr> <td>CLASS4</td> <td>QoS class 4</td> </tr> </tbody> </table>	QoS Class	Meaning	CLASS0	QoS class 0	CLASS1	QoS class 1	CLASS2	QoS class 2	CLASS3	QoS class 3	CLASS4	QoS class 4
QoS Class	Meaning												
CLASS0	QoS class 0												
CLASS1	QoS class 1												
CLASS2	QoS class 2												
CLASS3	QoS class 3												
CLASS4	QoS class 4												
SVCSETUP:QOSCLASS:FWD?	Queries the forward QoS class setting for the SVC to be established.												
SVCSETUP:QOSCLASS:BWD <QOS class>	Sets the backward QoS class for the SVC to be established.												
SVCSETUP:QOSCLASS:BWD?	Queries the backward QoS class setting for the SVC to be established.												
SVCSETUP:CDPTY <called party address>	<p>Sets the ATM address of the called party (destination). The called party address has to be specified in one of the following formats:</p> <p>The ISO-NSAP ATM address format is: <NSAP, NetworkPrefix, ESI, SEL></p> <p>The E.164 Native ATM addressing format is: <E164, E.164 Address digits></p> <p>where, Network prefix is 13 octets ESI is 6 octets SEL is 1 octet E.164 address digits are 1-15 octets</p> <p>The network prefix, ESI and SEL octets or the E.164 addressing digits have to be specified in hexadecimal format.</p>												
SVCSETUP:CDPTY?	Queries the ATM address of the called party (destination).												
SVCSETUP:AALTYPE <AAL type>	<p>Sets the AAL type of the SVC to be established. Valid values are AAL0, AAL1 or AAL5.</p>												

SVCSETUP Commands	Description														
SVCSETUP:AALTYPE?	Queries the AAL type of the SVC to be established.														
SVCSETUP:MAXSDUSIZE:FWD <size>	Sets the forward maximum AAL5 CPCS SDU size.														
SVCSETUP:MAXSDUSIZE:FWD?	Queries the forward maximum AAL5 CPCS SDU size.														
SVCSETUP:MAXSDUSIZE:BWD <size>	Sets the backward maximum AAL5 CPCS SDU size.														
SVCSETUP:MAXSDUSIZE:BWD?	Queries the backward maximum AAL5 CPCS SDU size.														
SVCSETUP:TRAFDESCR:FWD:COMB <combination>	<p>Sets the forward traffic combination. The following combinations are valid:</p> <table border="1"> <thead> <tr> <th><u>Combination</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>COMB1</td> <td>PCR for CLP0 and CLP0+1 are specified.</td> </tr> <tr> <td>COMB2</td> <td>PCR for CLP0, CLP0+1 and tagging are specified.</td> </tr> <tr> <td>COMB3</td> <td>PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.</td> </tr> <tr> <td>COMB4</td> <td>PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.</td> </tr> <tr> <td>COMB5</td> <td>PCR for CLP0+1 is specified.</td> </tr> <tr> <td>COMB6</td> <td>PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.</td> </tr> </tbody> </table> <p>Note: The combination needs to be set prior to the setting of the individual traffic parameters associated with that combination.</p>	<u>Combination</u>	<u>Meaning</u>	COMB1	PCR for CLP0 and CLP0+1 are specified.	COMB2	PCR for CLP0, CLP0+1 and tagging are specified.	COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.	COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.	COMB5	PCR for CLP0+1 is specified.	COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.
<u>Combination</u>	<u>Meaning</u>														
COMB1	PCR for CLP0 and CLP0+1 are specified.														
COMB2	PCR for CLP0, CLP0+1 and tagging are specified.														
COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.														
COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.														
COMB5	PCR for CLP0+1 is specified.														
COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.														
SVCSETUP:TRAFDESCR:FWD:COMB?	Queries the forward traffic combination.														
SVCSETUP:TRAFDESCR:BWD:COMB <combination>	<p>Sets the backward traffic combination. The following combinations are valid:</p> <table border="1"> <thead> <tr> <th><u>Combination</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>COMB1</td> <td>PCR for CLP0 and CLP0+1 are specified.</td> </tr> <tr> <td>COMB2</td> <td>PCR for CLP0, CLP0+1 and tagging are specified.</td> </tr> <tr> <td>COMB3</td> <td>PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.</td> </tr> <tr> <td>COMB4</td> <td>PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.</td> </tr> <tr> <td>COMB5</td> <td>PCR for CLP0+1 is specified.</td> </tr> <tr> <td>COMB6</td> <td>PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.</td> </tr> </tbody> </table> <p>Note: The combination needs to be set prior to the setting of the individual traffic parameters associated with that combination.</p>	<u>Combination</u>	<u>Meaning</u>	COMB1	PCR for CLP0 and CLP0+1 are specified.	COMB2	PCR for CLP0, CLP0+1 and tagging are specified.	COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.	COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.	COMB5	PCR for CLP0+1 is specified.	COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.
<u>Combination</u>	<u>Meaning</u>														
COMB1	PCR for CLP0 and CLP0+1 are specified.														
COMB2	PCR for CLP0, CLP0+1 and tagging are specified.														
COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.														
COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.														
COMB5	PCR for CLP0+1 is specified.														
COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.														
SVCSETUP:TRAFDESCR:BWD:COMB?	Queries the backward traffic combination.														
SVCSETUP:TRAFDESCR:FWD:PCR0 <value>	Sets the forward PCR for CLP0.														
SVCSETUP:TRAFDESCR:FWD:PCR0?	Queries the forward PCR for CLP0.														
SVCSETUP:TRAFDESCR:BWD:PCR0 <value>	Sets the backward PCR for CLP0.														
SVCSETUP:TRAFDESCR:BWD:PCR0?	Queries the backward PCR for CLP0.														
SVCSETUP:TRAFDESCR:FWD:PCR01 <value>	Sets the forward PCR for CLP0+1.														

SVCSETUP Commands	Description
SVCSETUP:TRAFDESCR:FWD:PCR01?	Queries the forward PCR for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:PCR01 <value>	Sets the backward PCR for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:PCR01?	Queries the backward PCR for CLP0+1.
SVCSETUP:TRAFDESCR:FWD:SCR0 <value>	Sets the forward SCR for CLP0.
SVCSETUP:TRAFDESCR:FWD:SCR0?	Queries the forward SCR for CLP0.
SVCSETUP:TRAFDESCR:BWD:SCR0 <value>	Sets the backward SCR for CLP0.
SVCSETUP:TRAFDESCR:BWD:SCR0?	Queries the backward SCR for CLP0.
SVCSETUP:TRAFDESCR:FWD:SCR01 <value>	Sets the forward SCR for CLP0+1.
SVCSETUP:TRAFDESCR:FWD:SCR01?	Queries the forward SCR for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:SCR01 <value>	Sets the backward SCR for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:SCR01?	Queries the backward SCR for CLP0+1.
SVCSETUP:TRAFDESCR:FWD:MBS0 <value>	Sets the forward MBS for CLP0.
SVCSETUP:TRAFDESCR:FWD:MBS0?	Queries the forward MBS for CLP0.
SVCSETUP:TRAFDESCR:BWD:MBS0 <value>	Sets the backward MBS for CLP0.
SVCSETUP:TRAFDESCR:BWD:MBS0?	Queries the backward MBS for CLP0.
SVCSETUP:TRAFDESCR:FWD:MBS01 <value>	Sets the forward MBS for CLP0+1.
SVCSETUP:TRAFDESCR:FWD:MBS01?	Queries the forward MBS for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:MBS01 <value>	Sets the backward MBS for CLP0+1.
SVCSETUP:TRAFDESCR:BWD:MBS01?	Queries the backward MBS for CLP0+1.
SVCSETUP:TRAFDESCR:FWD: TAGging <requested/not-requested>	Sets the forward tagging requested parameter.
SVCSETUP:TRAFDESCR:FWD:TAGging?	Queries the forward tagging requested parameter.
SVCSETUP:TRAFDESCR:BWD:TAGging <requested/not-requested>	Sets the backward tagging requested parameter.
SVCSETUP:TRAFDESCR:BWD:TAGging?	Queries the backward tagging requested parameter.

SVCSETUP Commands	Description
SVCSETUP:EXTQOS:FWD:CDVACCeptable <value>	Sets the forward acceptable peak to peak CDV parameter. It has to be specified in terms of micro-secs. Note: The extended QoS parameters can be set only for the UNI 4.0 signalling protocol version.
SVCSETUP:EXTQOS:FWD:CDVACCeptable?	Queries the forward acceptable peak to peak CDV parameter.
SVCSETUP:EXTQOS:BWD:CDVACCeptable <value>	Sets the backward acceptable peak to peak CDV parameter. It has to be specified in terms of micro-secs.
SVCSETUP:EXTQOS:BWD:CDVACCeptable?	Queries the backward acceptable peak to peak CDV parameter.
SVCSETUP:EXTQOS:FWD:CDVCumulative <value>	Sets the forward cumulative peak to peak CDV parameter. It has to be specified in terms of micro-secs.
SVCSETUP:EXTQOS:FWD:CDVCumulative?	Queries the forward cumulative peak to peak CDV parameter.
SVCSETUP:EXTQOS:BWD:CDVCumulative <value>	Sets the backward cumulative peak to peak CDV parameter. It has to be specified in terms of micro-secs.
SVCSETUP:EXTQOS:BWD:CDVCumulative?	Queries the backward cumulative peak to peak CDV parameter.
SVCSETUP:EXTQOS:FWD:CLR <value>	Sets the forward Cell Loss Ratio exponent. It can take values from 1 to 15. The CLR is taken to be $10^{-\text{value}}$.
SVCSETUP:EXTQOS:FWD:CLR?	Queries the forward Cell Loss Ratio exponent.
SVCSETUP:EXTQOS:BWD:CLR <value>	Sets the backward Cell Loss Ratio exponent. It can take values from 1 to 15. The CLR is taken to be $10^{-\text{value}}$.
SVCSETUP:EXTQOS:BWD:CLR?	Queries the backward Cell Loss Ratio exponent.
SVCSETUP:ABR:FWD:ICR <value>	Sets the forward Initial Cell Rate for ABR traffic type. Note: The ABR setup parameter commands are applicable only for UNI4.0
SVCSETUP:ABR:FWD:ICR?	Queries the forward Initial Cell Rate for ABR traffic type.
SVCSETUP:ABR:BWD:ICR <value>	Sets the backward Initial Cell Rate for ABR traffic type.
SVCSETUP:ABR:BWD:ICR?	Queries the backward Initial Cell Rate for ABR traffic type.
SVCSETUP:ABR:FWD:RIF <value>	Sets the forward Rate Increase Factor for ABR traffic type. RIF can have a value in the range 0-15.
SVCSETUP:ABR:FWD:RIF?	Queries the forward Rate Increase Factor for ABR traffic type.
SVCSETUP:ABR:BWD:RIF <value>	Sets the backward Rate Increase Factor for ABR traffic type. RIF can have a value in the range 0-15.
SVCSETUP:ABR:BWD:RIF?	Queries the backward Rate Increase Factor for ABR traffic type.
SVCSETUP:ABR:FWD:RDF <value>	Sets the forward Rate Decrease Factor for ABR traffic type. RIF can have a value in the range 0-15.

SVCSETUP Commands	Description														
SVCSETUP:ABR:FWD:RDF?	Queries the forward Rate Decrease Factor for ABR traffic type.														
SVCSETUP:ABR:BWD:RDF <value>	Sets the backward Rate Decrease Factor for ABR traffic type. RIF can have a value in the range 0-15.														
SVCSETUP:ABR:BWD:RDF?	Queries the backward Rate Decrease Factor for ABR traffic type.														
SVCSETUP:TRAFTYPE <type>	Sets the traffic type. Valid traffic types are: RTVBR Real time Variable Bit Rate NRTVBR Non real time Variable Bit Rate UBR Unspecified Bit Rate CBR Constant Bit Rate ABR Available Bit Rate														
SVCSETUP:TRAFTYPE?	Queries the traffic type.														
SVCSETUP:CONNID <vpi, vci>	Command to specify the VPI/VCI of the SVC to be established. This is applicable only for UNI4.0 signalling protocol.														
SVCSETUP:CONNID?	Queries the VPI/VCI setting for the SVC to be established.														
SVCSETUP:ALTDESCR:FWD:COMB <combination>	Sets the forward traffic combination for Alternate ATM traffic descriptor IE. The following combinations are valid: <table border="1"> <thead> <tr> <th><u>Combination</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>COMB1</td> <td>PCR for CLP0 and CLP0+1 are specified.</td> </tr> <tr> <td>COMB2</td> <td>PCR for CLP0, CLP0+1 and tagging are specified.</td> </tr> <tr> <td>COMB3</td> <td>PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.</td> </tr> <tr> <td>COMB4</td> <td>PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.</td> </tr> <tr> <td>COMB5</td> <td>PCR for CLP0+1 is specified.</td> </tr> <tr> <td>COMB6</td> <td>PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.</td> </tr> </tbody> </table> Note: Alternate ATM traffic descriptor IE is valid only for UNI4.0 signalling protocol version.	<u>Combination</u>	<u>Meaning</u>	COMB1	PCR for CLP0 and CLP0+1 are specified.	COMB2	PCR for CLP0, CLP0+1 and tagging are specified.	COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.	COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.	COMB5	PCR for CLP0+1 is specified.	COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.
<u>Combination</u>	<u>Meaning</u>														
COMB1	PCR for CLP0 and CLP0+1 are specified.														
COMB2	PCR for CLP0, CLP0+1 and tagging are specified.														
COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.														
COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.														
COMB5	PCR for CLP0+1 is specified.														
COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.														
SVCSETUP:ALTDESCR:FWD:COMB?	Queries the forward traffic combination for Alternate ATM traffic descriptor IE.														

SVCSETUP Commands	Description
SVCSETUP:ALTDESCR:BWD:COMB <combination>	Sets the backward traffic combination for Alternate ATM traffic descriptor IE. The following combinations are valid: Combination Meaning COMB1 PCR for CLP0 and CLP0+1 are specified. COMB2 PCR for CLP0, CLP0+1 and tagging are specified. COMB3 PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified. COMB4 PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified. COMB5 PCR for CLP0+1 is specified. COMB6 PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.
SVCSETUP:ALTDESCR:BWD:COMB?	Queries the backward traffic combination for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:PCR0 <value>	Sets the forward PCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:PCR0?	Queries the forward PCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:PCR0 <value>	Sets the backward PCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:PCR0?	Queries the backward PCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:PCR01 <value> <value>	Sets the forward PCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:PCR01?	Queries the forward PCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:PCR01 <value>	Sets the backward PCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:PCR01?	Queries the backward PCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:SCR0 <value>	Sets the forward SCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:SCR0?	Queries the forward SCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:SCR0 <value>	Sets the backward SCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:SCR0?	Queries the backward SCR-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:SCR01 <value>	Sets the forward SCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:SCR01?	Queries the forward SCR-CLP0+1 for Alternate ATM traffic descriptor IE.

SVCSETUP Commands	Description
SVCSETUP:ALTDESCR:BWD:SCR01 <value>	Sets the backward SCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:SCR01?	Queries the backward SCR-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:MBS0 <value>	Sets the forward MBS-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:MBS0?	Queries the forward MBS-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:MBS0 <value>	Sets the backward MBS-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:MBS0?	Queries the backward MBS-CLP0 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:MBS01 <value>	Sets the forward MBS-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:MBS01?	Queries the forward MBS-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:MBS01 <value>	Sets the backward MBS-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:MBS01?	Queries the backward MBS-CLP0+1 for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:TAGging <requested /not requested>	Sets the forward tagging requested parameter for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:FWD:TAGging?	Queries the forward tagging requested parameter for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:TAGging <requested/not requested>	Sets the backward tagging requested parameter for Alternate ATM traffic descriptor IE.
SVCSETUP:ALTDESCR:BWD:TAGging?	Queries the backward tagging requested parameter for Alternate ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:PCR0 <value>	Sets the forward PCR-CLP0 for Minimum Acceptable ATM traffic descriptor IE. Note: Minimum acceptable ATM traffic descriptor IE is valid only for UNI4.0 signalling protocol.
SVCSETUP:MINDESCR:FWD:PCR0?	Queries the forward PCR-CLP0 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:PCR0 <value>	Sets the backward PCR-CLP0 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:PCR0?	Queries the backward PCR-CLP0 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:PCR01 <value>	Sets the forward PCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:PCR01?	Queries the forward PCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:PCR01 <value>	Sets the backward PCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.

SVCSETUP Commands	Description
SVCSETUP:MINDESCR:BWD:PCR01?	Queries the backward PCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:SCR01 <value>	Sets the forward SCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:SCR01?	Queries the forward SCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:SCR01 <value>	Sets the backward SCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:SCR01?	Queries the backward SCR-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:MBS01 <value>	Sets the forward MBS-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:FWD:MBS01?	Queries the forward MBS-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:MBS01 <value>	Sets the backward MBS-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:MINDESCR:BWD:MBS01?	Queries the backward MBS-CLP0+1 for Minimum Acceptable ATM traffic descriptor IE.
SVCSETUP:TRNST:MAX?	Queries the maximum transit delay. Note: End-to-End transit delay is applicable only for UNI4.0.
SVCSETUP:TRNST:MAX <delay>	Sets the maximum transit delay.
SVCSETUP:TRNST:CUM?	Queries the cumulative transit delay.
SVCSETUP:TRNST:CUM <delay>	Sets the cumulative transit delay.

SVCCFG Branch

The commands in this branch are related to configuring SVC parameters like UNI version, station address, default SETUP message parameters etc..

SVCCFG Commands	Description
SVCCFG:UNIVERsion <UNI signalling protocol version>	Selects the UNI signalling protocol version. Valid values are: UNI3.0 UNI3.1 and UNI4.0
SVCCFG:UNIVERsion?	Queries the UNI signalling protocol version.

SVCCFG Commands	Description																		
SVCCFG:ATMADDRESS <addressing format, ATM address>	<p>Sets the calling party ATM address. The ATM address can be specified in the following formats:</p> <table border="0"> <thead> <tr> <th><u>Format</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>NSAP</td> <td>ISO-NSAP Addressing format</td> </tr> <tr> <td>E.164</td> <td>E.164 Addressing format.</td> </tr> </tbody> </table> <p>ISO-NSAP ATM address format is: <NetworkPrefix, ESI, SEL> E.164 Native ATM addressing format is: < E.164 Address digits> where,</p> <table border="0"> <tbody> <tr> <td>Network prefix</td> <td>13 octets</td> </tr> <tr> <td>ESI</td> <td>6 octets</td> </tr> <tr> <td>SEL</td> <td>1 octet</td> </tr> <tr> <td>E.164 address digits</td> <td>1-15 decimal digits</td> </tr> </tbody> </table> <p>The network prefix, ESI and SEL octets have to be specified in hexadecimal format.</p>	<u>Format</u>	<u>Meaning</u>	NSAP	ISO-NSAP Addressing format	E.164	E.164 Addressing format.	Network prefix	13 octets	ESI	6 octets	SEL	1 octet	E.164 address digits	1-15 decimal digits				
<u>Format</u>	<u>Meaning</u>																		
NSAP	ISO-NSAP Addressing format																		
E.164	E.164 Addressing format.																		
Network prefix	13 octets																		
ESI	6 octets																		
SEL	1 octet																		
E.164 address digits	1-15 decimal digits																		
SVCCFG: ATMADDRESS?	Queries the calling party ATM address.																		
SVCCFG:SIGCONNECTION <bandwidth>	Sets the signalling connection's (VPI=0 and VCI=5) peak cell rate.																		
SVCCFG:SIGCONNECTION?	Queries the signalling connection's (VPI=0 and VCI=5) peak cell rate.																		
SVCCFG:SIGFILTER:TYPE <type>	<p>Sets signalling filters. Following are the valid signalling filter types:</p> <table border="0"> <thead> <tr> <th><u>Type</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>TYPE0</td> <td>No filters are set.</td> </tr> <tr> <td>TYPE1</td> <td>Filtering based on Call Reference Value</td> </tr> <tr> <td>TYPE2</td> <td>Filtering based on Call Reference Flag</td> </tr> <tr> <td>TYPE3</td> <td>Filtering based on Call Reference Value and Call Reference Flag.</td> </tr> <tr> <td>TYPE4</td> <td>Filtering based on signalling message types.</td> </tr> <tr> <td>TYPE5</td> <td>Filtering based on signalling message types and Call Reference Value.</td> </tr> <tr> <td>TYPE6</td> <td>Filtering based on signalling message types and Call Reference Flag.</td> </tr> <tr> <td>TYPE7</td> <td>Filtering based on signalling message types, Call Reference Value and Call Reference Flag.</td> </tr> </tbody> </table>	<u>Type</u>	<u>Meaning</u>	TYPE0	No filters are set.	TYPE1	Filtering based on Call Reference Value	TYPE2	Filtering based on Call Reference Flag	TYPE3	Filtering based on Call Reference Value and Call Reference Flag.	TYPE4	Filtering based on signalling message types.	TYPE5	Filtering based on signalling message types and Call Reference Value.	TYPE6	Filtering based on signalling message types and Call Reference Flag.	TYPE7	Filtering based on signalling message types, Call Reference Value and Call Reference Flag.
<u>Type</u>	<u>Meaning</u>																		
TYPE0	No filters are set.																		
TYPE1	Filtering based on Call Reference Value																		
TYPE2	Filtering based on Call Reference Flag																		
TYPE3	Filtering based on Call Reference Value and Call Reference Flag.																		
TYPE4	Filtering based on signalling message types.																		
TYPE5	Filtering based on signalling message types and Call Reference Value.																		
TYPE6	Filtering based on signalling message types and Call Reference Flag.																		
TYPE7	Filtering based on signalling message types, Call Reference Value and Call Reference Flag.																		
SVCCFG:SIGFILTER:TYPE?	Queries the signalling filter type setting.																		
SVCCFG:SIGFILTER:CALLREFVALUE <value>	Sets the Call Reference Value to be used in filtering signalling messages.																		
SVCCFG:SIGFILTER:CALLREFVALUE?	Queries the Call Reference Value to be used in filtering signalling messages.																		

SVCCFG Commands	Description																								
SVCCFG:SIGFILTER:CALLREFMask <value>	Sets the Call Reference Mask to be used in filtering signalling messages.																								
SVCCFG:SIGFILTER:CALLREFMask?	Queries the Call Reference Mask to be used in filtering signalling messages.																								
SVCCFG:SIGFILTER:CALLREFFlag <value>	Sets the Call reference flag for filtering. This can be either 0 or 1.																								
SVCCFG:SIGFILTER:CALLREFFlag?	Queries the Call reference flag for filtering.																								
SVCCFG:SIGFILTER:MSGTYPE <type1 type2...typeN>	<p>Sets the message type(s) for filtering. Following message types are valid for this command.</p> <table border="1"> <thead> <tr> <th>Type</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>SETUP</td> <td>Filter on SETUP message.</td> </tr> <tr> <td>CONN</td> <td>Filter on CONNECT message.</td> </tr> <tr> <td>CONNACK</td> <td>Filter on CONNECT ACKNOWLEDGE message.</td> </tr> <tr> <td>CALLPROC</td> <td>Filter on CALL PROCEEDING message.</td> </tr> <tr> <td>REL</td> <td>Filter on RELEASE message.</td> </tr> <tr> <td>RELCMP</td> <td>Filter on RELEASE COMPLETE message.</td> </tr> <tr> <td>STAT</td> <td>Filter on STATUS message.</td> </tr> <tr> <td>STATENQ</td> <td>Filter on STATUS ENQUIRY message.</td> </tr> <tr> <td>RST</td> <td>Filter on RESTART message.</td> </tr> <tr> <td>RSTACK</td> <td>Filter on RESTART ACKNOWLEDGE message.</td> </tr> <tr> <td>ALERT</td> <td>Filter on ALERT message.</td> </tr> </tbody> </table>	Type	Meaning	SETUP	Filter on SETUP message.	CONN	Filter on CONNECT message.	CONNACK	Filter on CONNECT ACKNOWLEDGE message.	CALLPROC	Filter on CALL PROCEEDING message.	REL	Filter on RELEASE message.	RELCMP	Filter on RELEASE COMPLETE message.	STAT	Filter on STATUS message.	STATENQ	Filter on STATUS ENQUIRY message.	RST	Filter on RESTART message.	RSTACK	Filter on RESTART ACKNOWLEDGE message.	ALERT	Filter on ALERT message.
Type	Meaning																								
SETUP	Filter on SETUP message.																								
CONN	Filter on CONNECT message.																								
CONNACK	Filter on CONNECT ACKNOWLEDGE message.																								
CALLPROC	Filter on CALL PROCEEDING message.																								
REL	Filter on RELEASE message.																								
RELCMP	Filter on RELEASE COMPLETE message.																								
STAT	Filter on STATUS message.																								
STATENQ	Filter on STATUS ENQUIRY message.																								
RST	Filter on RESTART message.																								
RSTACK	Filter on RESTART ACKNOWLEDGE message.																								
ALERT	Filter on ALERT message.																								
SVCCFG:SIGFILTER:MSGTYPE?	Queries the message type(s) selected for filtering signalling messages.																								
SVCCFG:DEFSETUP:CDPTY < addressing format, address>	<p>Sets the default called party ATM address. The ATM address can be specified in the following formats:</p> <table border="1"> <thead> <tr> <th>Format</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>NSAP</td> <td>ISO-NSAP Addressing format</td> </tr> <tr> <td>E.164</td> <td>E.164 Addressing format.</td> </tr> </tbody> </table> <p>ISO-NSAP ATM address format is: < NetworkPrefix, ESI, SEL></p> <p>E.164 Native ATM addressing format is: < E.164 Address digits></p> <table border="1"> <thead> <tr> <th>where,</th> <th></th> </tr> </thead> <tbody> <tr> <td>Network prefix</td> <td>13 octets</td> </tr> <tr> <td>ESI</td> <td>6 octets</td> </tr> <tr> <td>SEL</td> <td>1 octet</td> </tr> <tr> <td>E.164 address digits</td> <td>1-15 decimal digits</td> </tr> </tbody> </table> <p>The network prefix, ESI and SEL octets have to be specified in hexadecimal format.</p>	Format	Meaning	NSAP	ISO-NSAP Addressing format	E.164	E.164 Addressing format.	where,		Network prefix	13 octets	ESI	6 octets	SEL	1 octet	E.164 address digits	1-15 decimal digits								
Format	Meaning																								
NSAP	ISO-NSAP Addressing format																								
E.164	E.164 Addressing format.																								
where,																									
Network prefix	13 octets																								
ESI	6 octets																								
SEL	1 octet																								
E.164 address digits	1-15 decimal digits																								
SVCCFG:DEFSETUP:CDPTY?	Queries the default called party address setting.																								

SVCCFG Commands	Description
SVCCFG:DEFSETUP:AALTYPE <type>	Sets the default AAL type.
SVCCFG:DEFSETUP:AALTYPE?	Queries the default AAL type.
SVCCFG:DEFSETUP:QOSCLASS <default QoS class>	Sets the default QoS class (used in both forward and backward directions).
SVCCFG:DEFSETUP:QOSCLASS?	Queries the default QoS class
SVCCFG:DEFSETUP:MAXSDUSIZE <default Max CPCS SDU size>	Sets the default maximum AAL5-CPCS SDU size (used in both forward and backward directions).
SVCCFG:DEFSETUP:MAXSDUSIZE?	Queries the default maximum AAL5-CPCS SDU size
SVCCFG:DEFSETUP:PCR0 <value>	Sets the default PCR for CLP0 (used in both forward and backward directions).
SVCCFG:DEFSETUP:PCR0?	Queries the default PCR for CLP0.
SVCCFG:DEFSETUP:PCR01 <value>	Sets the default PCR for CLP0+1 (used in both forward and backward directions).
SVCCFG:DEFSETUP:PCR01?	Queries the default PCR for CLP0+1.
SVCCFG:DEFSETUP:SCR0 <value>	Sets the default SCR for CLP0 (used in both forward and backward directions).
SVCCFG:DEFSETUP:SCR0?	Queries the default SCR for CLP0.
SVCCFG:DEFSETUP:SCR01 <value>	Sets the default SCR for CLP0+1 (used in both forward and backward directions).
SVCCFG:DEFSETUP:SCR01?	Queries the default SCR for CLP0+1.
SVCCFG:DEFSETUP:MBS0 <value>	Sets the default MBS for CLP0 (used in both forward and backward directions).
SVCCFG:DEFSETUP:MBS0?	Queries the default MBS for CLP0.
SVCCFG:DEFSETUP:MBS01 <value>	Sets the default MBS for CLP0+1 (used in both forward and backward directions).
SVCCFG:DEFSETUP:MBS01?	Queries the default MBS for CLP0+1.
SVCCFG:DEFSETUP:TAGging <requested / not requested>	Sets the default tagging requested parameter to "Requested" or "Not Requested" for both forward and backward directions.
SVCCFG:DEFSETUP:TAGging?	Queries the default tagging requested parameter.

SVCCFG Commands	Description														
SVCCFG:DEFSETUP:COMBination <value>	<p>Sets the default traffic combination for both forward and backward directions.</p> <p>The following combinations are valid:</p> <table border="1"> <thead> <tr> <th><u>Combination</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>COMB1</td> <td>PCR for CLP0 and CLP0+1 are specified.</td> </tr> <tr> <td>COMB2</td> <td>PCR for CLP0, CLP0+1 and tagging are specified.</td> </tr> <tr> <td>COMB3</td> <td>PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.</td> </tr> <tr> <td>COMB4</td> <td>PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.</td> </tr> <tr> <td>COMB5</td> <td>PCR for CLP0+1 is specified.</td> </tr> <tr> <td>COMB6</td> <td>PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.</td> </tr> </tbody> </table>	<u>Combination</u>	<u>Meaning</u>	COMB1	PCR for CLP0 and CLP0+1 are specified.	COMB2	PCR for CLP0, CLP0+1 and tagging are specified.	COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.	COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.	COMB5	PCR for CLP0+1 is specified.	COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.
<u>Combination</u>	<u>Meaning</u>														
COMB1	PCR for CLP0 and CLP0+1 are specified.														
COMB2	PCR for CLP0, CLP0+1 and tagging are specified.														
COMB3	PCR for CLP0+1, SCR for CLP0 and MBS for CLP0 are specified.														
COMB4	PCR for CLP0+1, SCR for CLP0, MBS for CLP0 and tagging are specified.														
COMB5	PCR for CLP0+1 is specified.														
COMB6	PCR for CLP0+1, SCR for CLP0+1 and MBS for CLP0+1 are specified.														
SVCCFG:DEFSETUP:COMBination?	Queries the default traffic combination.														
SVCCFG:DEFSETUP:TRAFtype <value>	<p>Sets the default traffic type for both forward and backward directions.</p> <p>Valid traffic types are:</p> <table border="1"> <tbody> <tr> <td>RTVBR</td> <td>Real time Variable Bit Rate</td> </tr> <tr> <td>NRTVBR</td> <td>Non real time Variable Bit Rate</td> </tr> <tr> <td>UBR</td> <td>Unspecified Bit Rate</td> </tr> <tr> <td>CBR</td> <td>Constant Bit Rate</td> </tr> <tr> <td>ABR</td> <td>Available Bit Rate</td> </tr> </tbody> </table>	RTVBR	Real time Variable Bit Rate	NRTVBR	Non real time Variable Bit Rate	UBR	Unspecified Bit Rate	CBR	Constant Bit Rate	ABR	Available Bit Rate				
RTVBR	Real time Variable Bit Rate														
NRTVBR	Non real time Variable Bit Rate														
UBR	Unspecified Bit Rate														
CBR	Constant Bit Rate														
ABR	Available Bit Rate														
SVCCFG:DEFSETUP:TRAFtype?	Queries the default traffic type.														
SVCCFG:DEFSETUP:ICR <value>	Sets the default ICR value for ABR SVCs.														
SVCCFG:DEFSETUP:ICR?	Queries the default ICR value for ABR SVCs.														
SVCCFG:DEFSETUP:RIF <value>	Sets the default RIF for ABR SVCs.														
SVCCFG:DEFSETUP:RIF?	Queries the default RIF for ABR SVCs.														
SVCCFG:DEFSETUP:RDF <value>	Sets the default RDF for ABR SVCs.														
SVCCFG:DEFSETUP:RDF?	Queries the default RDF for ABR SVCs.														
SVCCFG:DEFSETUP:MCR <value>	Sets the default MCR (minimum cell rate) for ABR SVCs.														
SVCCFG:DEFSETUP:MCR?	Queries the default MCR (minimum cell rate) for ABR SVCs.														
SVCCFG:DEFSETUP:TBE <value>	<p>Sets the default TBE (Transient buffer exposure) for ABR SVCs.</p> <p>Valid range for TBE is 1 to (2²⁴ - 1).</p>														

SVCCFG Commands	Description																														
SVCCFG:DEFSETUP:TBE?	Queries the default TBE (Transient buffer exposure) for ABR SVCs.																														
SVCCFG:TIMER <timer> <value>	Sets the value for UNI signalling protocol timers. <table border="1"> <thead> <tr> <th><u>Timer</u></th> <th><u>Meaning</u></th> </tr> </thead> <tbody> <tr> <td>T301</td> <td>Timer for ALERT</td> </tr> <tr> <td>T303</td> <td>Timer for SETUP</td> </tr> <tr> <td>T308</td> <td>Timer for RELEASE</td> </tr> <tr> <td>T309</td> <td>Timer for Link Connection</td> </tr> <tr> <td>T310</td> <td>Timer for Call Proceeding Received</td> </tr> <tr> <td>T313</td> <td>Timer for CONNECT</td> </tr> <tr> <td>T316</td> <td>Timer for RESTART</td> </tr> <tr> <td>T317</td> <td>Timer for RESTART received</td> </tr> <tr> <td>T322</td> <td>Timer for STATUS</td> </tr> <tr> <td>POLL</td> <td>Timer for POLL pdu</td> </tr> <tr> <td>KEEPALIVE</td> <td>Timer for Keep Alive</td> </tr> <tr> <td>NORESP</td> <td>Timer between receipt of STAT pdu</td> </tr> <tr> <td>CC</td> <td>Timer between BGN and END pdu</td> </tr> <tr> <td>IDLE</td> <td>Idle timer period.</td> </tr> </tbody> </table>	<u>Timer</u>	<u>Meaning</u>	T301	Timer for ALERT	T303	Timer for SETUP	T308	Timer for RELEASE	T309	Timer for Link Connection	T310	Timer for Call Proceeding Received	T313	Timer for CONNECT	T316	Timer for RESTART	T317	Timer for RESTART received	T322	Timer for STATUS	POLL	Timer for POLL pdu	KEEPALIVE	Timer for Keep Alive	NORESP	Timer between receipt of STAT pdu	CC	Timer between BGN and END pdu	IDLE	Idle timer period.
<u>Timer</u>	<u>Meaning</u>																														
T301	Timer for ALERT																														
T303	Timer for SETUP																														
T308	Timer for RELEASE																														
T309	Timer for Link Connection																														
T310	Timer for Call Proceeding Received																														
T313	Timer for CONNECT																														
T316	Timer for RESTART																														
T317	Timer for RESTART received																														
T322	Timer for STATUS																														
POLL	Timer for POLL pdu																														
KEEPALIVE	Timer for Keep Alive																														
NORESP	Timer between receipt of STAT pdu																														
CC	Timer between BGN and END pdu																														
IDLE	Idle timer period.																														
SVCCFG:TIMER <timer>?	Queries the value of UNI signalling protocol timer specified.																														
SVCCFG:SIGNalling <enable / disable>	Enables or disables signalling.																														
SVCCFG:SIGNalling?	Queries the status of signalling.																														

TXRX Branch

The commands in this branch are related to configuring SVC parameters like UNI version, station address, default SETUP message parameters etc..

TXRX Commands	Description
TXRX:CAPTURE:SCOPE <vpi,vci>	Sets the scope of data capture. The default scope is <0,0>. The scope has to be set to the VPI/VCI of the VCC on which capture of data is to be done. VPI.VCI can be specified in either hexadecimal or decimal formats.
TXRX:CAPTURE:SCOPE?	Queries the scope of data capture.
TXRX:CAPTURE:ENABLE <number of bytes>	Starts data capture for the specified number of bytes. The VC on which the capture is to be done should have been set using TXRX:CAPTURE:SCOPE command before to this. The number of bytes to capture can vary from 1 to 4096 bytes.
TXRX:CAPTURE:DISABLE	Stops data capture

TXRX Commands	Description
TXRX:CAPTURE?	<p>Queries the status of data capture operation. Returned values are:</p> <p>ON Capture is proceeding on the VCC. OFF Capture is not set on the VCC. COMPLETE <bytes> Capture is complete with the specified number of bytes.</p>
TXRX:CAPTURE:DATA <offset, number of bytes>	<p>Queries the captured data. The command take the following parameters:</p> <p>Offset Byte offset from which to display the captured data. Number of bytes Number of bytes of captured data displayed from the specified offset.</p> <p>Valid values for Offset range from 1 to 4096. Valid number of bytes can range from 1 to 100.</p>
TXRX:CAPTURE:SEND <vpi,vci,number of bytes>	<p>Sends the captured and modified data on the specified VCC. The specified VCC should be a Transmit full PDU VCC in the VCC table.</p> <p>Note: The captured data can be optionally modified before sending using the <i>TXRX:CAPTURE:MODIFIED</i> command.</p>
TXRX:CAPTURE:SEND?	<p>Queries the status of the “captured and modified data send” operation. The return values could be any one of the following:</p> <p>ON Sending of captured and modified data on the VCC is going on. OFF Sending of captured and modified data on the VCC is completed.</p>
TXRX:CAPTURE:MODIFY <offset, number of bytes, byte 1, byte 2, ...byte n>	<p>Modifies the captured data. The bytes specified in the command are used to replace the bytes present in the captured data starting from the offset for the number of bytes.</p> <p>Valid values for offset range from 1 to 4096. Valid values for the number of bytes can range from 1 to 100.</p> <p>Note: The modified data is stored only internally in SCPI until the <i>TXRX:CAPTURE:SEND</i> command is issued. Once this command is issued, the modified data is sent to the ATM protocol processor for transmission.</p>
TXRX:CAPTURE:MODIFY <offset, number of bytes>?	<p>Queries the modified data.</p>

RX (Sense) Branch

The RX branch is used to set and retrieve Receive ATM settings. Alternatively, each command can be sent using the "SENS" or "SENSE" keyword instead of the "RX" keyword.

SENSe Command	Description								
RX:QOSANLYS: TYPE <type>	<p>Sets the QOS analysis test type. Valid values are:</p> <table border="1"> <thead> <tr> <th>Type</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NONE</td> <td>Invalid test type</td> </tr> <tr> <td>CDV</td> <td>1-point CDV analysis</td> </tr> <tr> <td>INTARRVL</td> <td>Cell inter-arrival time analysis</td> </tr> </tbody> </table>	Type	Description	NONE	Invalid test type	CDV	1-point CDV analysis	INTARRVL	Cell inter-arrival time analysis
Type	Description								
NONE	Invalid test type								
CDV	1-point CDV analysis								
INTARRVL	Cell inter-arrival time analysis								
RX:QOSANLYS:TYPE?	Queries the QOS analysis test type.								
RX:QOSANLYS: HDRS <header select>	Sets the header select for QOS analysis.								
RX:QOSANLYS:HDRS?	Selects the mask header for QOS analysis.								
RX:QOSANLYS: HDRM <header mask>	Sets the mask header for QOS analysis.								
RX:QOSANLYS:HDRM?	Queries the header mask for QOS analysis.								
RX:QOSANLYS: EXPCELLrate <cell rate>	Sets the expected cell rate. This is valid only for 1-point CDV analysis. The input format is based on the unit of measure for cell rates. Refer to the <i>ATMSYS:CELLRATE</i> command for setting the unit of measure.								
RX:QOSANLYS: EXPCELLrate?	Queries the expected cell rate. This is valid only for 1-point CDV analysis. The output format is based on the unit of measure for cell rates. Refer to the <i>ATMSYS:CELLRATE</i> command for unit of measure information.								
RX:QOSANLYS:START	Starts the QOS analysis test.								
RX:QOSANLYS:STOP	Stops the QOS analysis test.								
RX:QOSANLYS?	Queries the status of QOS analysis test. Returned values are START or STOP.								
RX:QOSANLYS:MINCDV?	Queries the minimum 1-point CDV measurement. The value reported is in nano-seconds.								
RX:QOSANLYS: MAXCDV?	Queries the maximum 1-point CDV measurement. The value reported is in nano-seconds.								
RX:QOSANLYS: MINARRVL?	Queries the minimum cell inter-arrival time measurement. The value reported is in nano-seconds.								
RX:QOSANLYS: MAXARRVL?	Queries the maximum cell inter-arrival time measurement. The value reported is in nano-seconds.								

5

Gigabit Ethernet SCPI Commands

Overview

This chapter describes the Gigabit Ethernet (GigE) SCPI commands supported by the configured unit. You may not have access to all commands based on the product configuration you purchased.

Supported GigE SCPI Commands

These commands are extensions to the SCPI command set. These commands are adapted to the configured unit and are unique to each protocol processor. SCPI commands should be typed on one single line completed with a hard carriage return. These commands require zero or one parameters, and return zero or one values.

RES (Fetch) Branch

The RES branch is used to retrieve Gigabit Ethernet results. Alternatively, each command can be sent using the "FETC" or "FETCH" keyword instead of the "RES" keyword.

The following is a list of supported RESULT commands.

RESULT Command	Description
RES:APS:AVG?	Queries and reports the average duration of an APS switch.
RES:APS:LAST?	Queries and reports the duration of the last APS switch.
RES:APS:MAX?	Queries and reports the duration of the longest APS switch.
RES:APS:MIN?	Queries and reports the duration of the shortest APS switch.
RES:APS:STATE?	Queries and reports the current APS switch state.
RES:BERT:BIT:AVGRATE?	Queries the average bit error rate.
RES:BERT:BIT:COUNT?	Queries the bit error count.
RES:BERT:BIT:CURRENTE?	Queries the current bit error rate.
RES:BERT:BIT:ES?	Queries and reports the number of seconds a bit error was present.
RES:BERT:CODE:COUNT?	Queries and reports the code error count.
RES:BERT:CODE:AVGRATE?	Queries and reports the average code error rate.
RES:BERT:CODE:CURRENTE?	Queries and reports the current code error rate.
RES:BERT:CODE:ES?	Queries and reports the number of seconds a code error was present.
RES:BERT:FCS:COUNT?	Queries and reports the Frame Check Sequence (FCS) error count.
RES:BERT:FCS:AVGRATE?	Queries and reports the FCS average error rate.
RES:BERT:FCS:CURRENTE?	Queries and reports the current FCS error rate.
RES:BERT:FCS:ES?	Queries and reports the number of seconds an FCS error was present.
RES:BERT:FRAMERX:COUNT?	Queries the number of frames received during a bit-error-rate test.
RES:BERT:FRAMETX:COUNT?	Queries the number of frames sent during a bit-error-rate test.

RESULT Command	Description
RES:BERT:PATSync:Secs?	Queries the number of seconds a loss of pattern was present.
RES:TXFRAMes?	Reports the total number of frames transmitted by the current Ethernet stream.
RES:RXFRAMes?	Reports the total number of frames received by the current Ethernet stream.
RES:TXBYTes?	Reports the total number of bytes transmitted by the current Ethernet stream.
RES:RXBYTes?	Reports the total number of bytes received by the current Ethernet stream.
RES:INVALid:FCS?	Reports the error count for invalid FCS errors.
RES:INVALid:IPCHECKsum?	Reports the error count for invalid IP checksum errors.
RES:UNDERsized?	Reports the error count for undersized frames.
RES:OVERsized?	Reports the error count for oversized frames.
RES:LOS:Secs?	Reports the LOS alarm seconds count.
RES:VLAN:TAGged?	Reports the number of received VLAN tagged frames.
RES:VLAN:QOS? <entry>	Reports the number of frames received for the selected QOS user priority level.
RES:PAUSE:FRAMes?	Reports the number of Pause packets received.
RES:PAUSE:QUANTas?	Reports the number of Pause Quantas received.
RES:PAUSE:ENDFRAMes?	Reports the number of Pause frames received with a Quantas value of 0.
RES:PACKets:IP?	Reports the number of IP packets received.
RES:PACKets:ICMP?	Reports the number of ICMP packets received.
RES:PACKets:UDP?	Reports the number of UDP packets received.
RES:PACKets:TCP?	Reports the number of TCP packets received.
RES:PACKets:BGP?	Reports the number of BGP packets received.
RES:PACKets:OSPF?	Reports the number of OSPF packets received.
RES:PACKets:IGMP?	Reports the number of IGMP packets received.
RES:PACKets:JUMBO?	Reports the number of Jumbo packets received.
RES:STRM:OUTofseq? <tgen> Note: <tgen> = traffic generator	Reports the number of out of sequence frames received by the Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:TXFRAMes? <tgen>	Reports the number of packets transmitted by the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:RXFRAMes? <tgen>	Reports the number of packets received by the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:TXBYTes? <tgen>	Reports the number of bytes transmitted by the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:RXBYTes? <tgen>	Reports the number of bytes received by the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:VLANtagged? <tgen>	Reports the number of VLAN tagged packets received by the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
RES:STRM:TXBW? <tgen>	Reports the number of bytes transmitted as a percentage of bandwidth. Valid <tgen> values are 1, 2, 3, or 4.

RESULT Command	Description
RES:STRM:RXBW? <tgen>	Reports the number of bytes received as a percentage of bandwidth. Valid <tgen> values are 1, 2, 3, or 4.

TX (SOURce) Branch

The TX branch is used to set and retrieve Gigabit Ethernet transmit settings. Alternatively, each command can be sent using the "SOUR" or "SOURCE" keyword instead of the "TX" keyword.

The following is a list of supported Transmit commands.

Transmit Command	Description
TX:APS:ACTION?	Queries and reports the current setting of the APS Action State function. Valid responses are Single, Stop, and Continuous.
TX:APS:ACTION <state>	Starts and stops Gigabit Ethernet APS mode. Valid <state> values are: SINGLE Monitors for a single APS event. If the event occurs, the duration is reported and the state returns to Inactive. STOP Stops APS monitoring. The state returns to Inactive. CONTInuos Constantly monitors for APS events and updates the Protection Switch Time durations.
TX:APS:BAD?	Queries and reports the Consecutive Bad Time Required value. The value that appears is in milliseconds.
TX:APS:BAD <value>	Sets a value for the Consecutive Bad Time Required for a Gigabit Ethernet APS test. Values range from 0.1 to 409.0.
TX:APS:GOOD?	Queries and reports the Consecutive Good Time Required value. The value that appears in milliseconds.
TX:APS:GOOD <value>	Sets a value for the Consecutive Good Time Required for a Gigabit Ethernet APS test. Values range from 0.1 to 409.0.
TX:BERT:ERR:RATE?	Queries the current bit error rate.
TX:BERT:ERR:RATE <rate>	Sets the error rate. Valid values for <rate> are: Rate Description 0 Off. Stops error generation SINGLE Single error generation; does not change the current generation rate N.NNe-NN where each N is a numeral
TX:BERT:ERR:TYPE?	Queries and reports the current type of error configured for the BERT test.
TX:BERT:ERR:TYPE <error>	Sets the error type for the BERT test to one of the following types: Error Description NONE Stops error generation. BIT Injects BIT errors into the payload pattern. FCS Injects Frame Check Sequence errors into the payload pattern.
TX:BERT:FRAMESIZE?	Queries the frame size in bytes.
TX:BERT:FRAMESIZE <packet size>	Sets the frame size in bytes. Valid values for <packet size> range from 64 bytes to 9216 bytes.
TX:BERT:FRAMING?	Queries the current framing parameter.
TX:BERT:FRAMING <frame>	Sets the framing parameter. Valid values for <frame> are UNFRAMED and FRAMED.

Transmit Command	Description
TX:BERT:PATtern?	Returns the current Gigabit Ethernet pattern value.
TX:BERT:PATtern <pattern>	Sets the expected Gigabit Ethernet receive pattern value. Valid values for <pattern> are: Pattern Description <word> Uses a user-defined 32-bit pattern. The pattern is entered using HEX notation. For example, TX:BERT:PATT #HFFFFFFF. PRBS Uses a PRBS pattern. INVPBS Uses an inverted PRBS pattern. LIVE User data is received; no pattern is used. This is a receive only function.
TX:BERT:TESTMode?	Queries the current Test mode parameter.
TX:BERT:TESTMode <mode>	Sets the Test mode parameter. Valid values for <mode> are: ON Starts a BERT test. It continues until the BERT test is turned off. OFF Stops a BERT test.

RFC2544 Branch

The RFC2544 branch is used to configure and operate the Gigabit Ethernet’s RFC 2544 functionality.

The following is a list of supported RFC2544 commands.

RFC 2544 Command	Description
RFC:THRUput:STREAMid?	Queries and reports which Ethernet stream is currently selected. Valid values that appear are 1, 2, 3, or 4.
RFC:THRUput:STREAMid <id>	Selects an existing Ethernet stream to use for the test. Valid <id> values are: 1 Stream ID 1 2 Stream ID 2 3 Stream ID 3 4 Stream ID 4 An error is returned if a stream ID, that does not exist, is entered. Note: Ethernet streams are created using the Packet Branch’s STRM:ADD command.
RFC:THRUput:DURation?	Queries and reports the duration set, or remaining, for the RFC 2544 Throughput test. The value that appears is in seconds.
RFC:THRUput:DURation <secs>	Sets the duration (in seconds) for the RFC 2544 Throughput test. Valid values for <secs> range from 1 to 600.
RFC:THRUput:LOSSrate?	Queries and reports the packet loss rate threshold for the RFC 2544 Throughput test. This value specifies how many packets can be lost without signifying a failure.
RFC:THRUput:LOSSrate <rate>	Sets the acceptable packet loss rate for an RFC 2544 Throughput test. When this value is exceeded, this portion of the test is considered a failure. Valid <rate> values range from 1 to 100.
RFC:THRUput:RESolutionrate?	Queries and reports the granularity specified for determining the exact passing rate of the RFC 2544 Throughput test.

RFC 2544 Command	Description
RFC:THRUpUt:RESolutionrate <rate>	Sets the granularity, or resolution rate, used to determine the passing rate of the RFC 2544 Throughput test. Valid values for <rate> range from 1 to 100.
RFC:THRUpUt:ACTivate?	Queries and reports the On/Off state of the RFC 2544 Throughput test. Values that appear are ON or OFF.
RFC:THRUpUt:ACTivate <state>	Starts and stops an RFC 2544 Throughput test. Valid <state> values are: ON Activates the test. OFF Deactivates the test.
RFC:THRUpUt:PASS? <size>	Returns the passing rate for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:THRUpUt:TX? <size>	Returns the number of transmitted packets for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:THRUpUt:RX? <size>	Returns the number of received packets for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:THRUpUt:MIN? <size>	Returns the minimum latency value for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:THRUpUt:MAX? <size>	Returns the maximum latency value for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:THRUpUt:AVG? <size>	Returns the average latency value for a specific packet size. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518.
RFC:FRAMEloss:TX? <size> <rate>	Reports the total number of frames transmitted for a specific packet size and rate in an RFC 2544 Frame Loss test. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518. Valid <rate> values are: 10, 20, 30, 40, 50, 60, 70, 80, 90, or 100.
RFC:FRAMEloss:RX? <size> <rate>	Reports the total number of frames received for a specific packet size and rate in an RFC 2544 Frame Loss test. Valid <size> values are: 64, 128, 256, 512, 1024, 1280, or 1518. Valid <rate> values are: 10, 20, 30, 40, 50, 60, 70, 80, 90, or 100.
RFC:FRAMEloss:ACTivate <state>	Starts and stops an RFC 2544 Frame Loss test. Valid <state> values are: ON Activates the test. OFF Deactivates the test.

Packet Branch

The Packet branch is used to configure and operate the Gigabit Ethernet's Packet functionality.

The following is a list of supported Stream commands.

Stream Command	Description
STRM:NUMber?	Queries and reports the number of configured Ethernet streams. The following values can be returned: 0, 1, 2, 3, or 4. Note: If 0 is returned, all STRM commands are disabled except for STRM:ADD .
STRM:ADD?	Queries and reports if an Ethernet stream can be added. The following values can appear: TRUE Indicates that a stream can be added using the STRM:ADD command. FALSE Indicates that no additional streams can be added until a stream is deleted. For example, if four Ethernet stream are currently defined, FALSE is returned. Another stream cannot be added unless one of the four existing stream is deleted (see STRM:DELeTe command).

Stream Command	Description
STRM:ADD <all fields>	<p>Creates an Ethernet stream. The <all fields> value contains 20 different parameters that define an Ethernet stream's profile.</p> <p>When adding a stream, use the following format guideline:</p> <p>STRM:ADD a, b, c, d, e, f, g, h, i, j, k, l, m, n, o, p, q, r, s, t,</p> <p>where,</p> <p>a = MAC source address mask, see STRM:SRC:MASK:MAC command b = MAC source address, see STRM:SRC:MAC command c = MAC destination address mask, see STRM:DEST:MASK:MAC command d = MAC destination address, see STRM:DEST:MAC command e = IP source address mask, see STRM:SRC:MASK:IP command f = IP source address, see STRM:SRC:IP command g = IP destination address mask, see STRM:DEST:MASK:IP command h = IP destination address, see STRM:DEST:IP command i = <i>Not implemented. Use a null character or blank space for this value.</i> j = Payload, see STRM:PAYload command k = Payload user data. A value is only required if Payload is set to USER. Otherwise, enter a blank space for this value. See STRM:PAYload command l = <i>Not implemented. Use a null character or blank for this value.</i> m = Frame length, see STRM:FRAMELENGTH command n = UDP source port, see STRM:SRC:PORT command o = UDP destination port, see STRM:DEST:PORT command p = Percent bandwidth, see STRM:BW command q = <i>Not implemented. Use a null character or blank space for this value.</i> r = VLAN tag, see STRM:VLAN:TAG command s = VLAN ID, see STRM:VLAN:ID command t = VLAN QOS, see STRM:VLAN:QOS command</p> <p>Note: If a value is not entered (a null character or blank space), the command's default value is used. For readability, use a blank space for items <i>i</i>, <i>l</i>, and <i>q</i> listed above. When entering values for items <i>a</i> through <i>t</i> listed above, do not use the <tgen> parameter that is listed in that command's description. Always place a comma after the last parameter.</p> <p>The following example illustrates how to create an Ethernet stream using the STRM:ADD command.</p> <p>STRM:ADD 16, 10-2b-3a-22-14-AA, 16, 10-2b-3a-22-14-FF, 8, 010.011.010.111, , , , ONES, , , 64, , , 3, , ON, 20, 7,</p>

Stream Command	Description
<p>STRM:UPDate <tgen>, <all fields></p> <p>Note: Use the STRM:GET? command to view the current parameter values for a selected Ethernet stream.</p>	<p>Updates the parameters of an existing Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. The <all fields> value contains 20 different parameters that define an Ethernet stream's profile. When updating an existing stream, use the following format guideline:</p> <p>STRM:UPDate <tgen>, a, b, c, d, e, f, g, h, i, j, k, l, m, n, o, p, q, r, s, t,</p> <p>where,</p> <p><tgen> = Stream's ID number (1, 2, 3, or 4). This is required.</p> <p>a = MAC source address mask, see STRM:SRC:MASK:MAC command</p> <p>b = MAC source address, see STRM:SRC:MAC command</p> <p>c = MAC destination address mask, see STRM:DEST:MASK:MAC command</p> <p>d = MAC destination address, see STRM:DEST:MAC command</p> <p>e = IP source address mask, see STRM:SRC:MASK:IP command</p> <p>f = IP source address, see STRM:SRC:IP command</p> <p>g = IP destination address mask, see STRM:DEST:MASK:IP command</p> <p>h = IP destination address, see STRM:DEST:IP command</p> <p>i = <i>Not implemented. Use a null character or blank space for this value.</i></p> <p>j = Payload, see STRM:PAYload command</p> <p>k = Payload user data. A value is only required if Payload is set to USER. Otherwise, enter a blank space for this value. See STRM:PAYload command</p> <p>l = <i>Not implemented. Use a null character or blank for this value.</i></p> <p>m = Frame length, see STRM:FRAMELENgth command</p> <p>n = UDP source port, see STRM:SRC:PORT command</p> <p>o = UDP destination port, see STRM:DEST:PORT command</p> <p>p = Percent bandwidth, see STRM:BW command</p> <p>q = <i>Not implemented. Use a null character or blank space for this value.</i></p> <p>r = VLAN tag, see STRM:VLAN:TAg command</p> <p>s = VLAN ID, see STRM:VLAN:ID command</p> <p>t = VLAN QOS, see STRM:VLAN:QOS command</p> <p>Note: If a value is not entered (null character or blank space), the command's default value is used. For readability, use a blank space for items <i>i</i>, <i>l</i>, and <i>q</i> listed above. When entering values for items <i>a</i> through <i>t</i> listed above, do not use the <tgen> parameter that is listed in that command's description. Always place a comma after the last parameter.</p> <p>The following example illustrates how to create an Ethernet stream using the STRM:UPDate command.</p> <p>STRM:UPD 2, 16, 10-2b-3a-22-14-AA, 16, 10-2b-3a-22-14-FF, 8, 010.011.010.111, , , , ONES, , , 64, , , 3, , ON, 20, 7,</p>
<p>STRM:GET? <tgen></p> <p>Note: <tgen> = traffic generator</p>	<p>Returns the parameter values of a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.</p>
<p>STRM:DELEte <tgen></p>	<p>Deletes the selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.</p>

Stream Command	Description
STRM:CONTROL <tgen> <state>	Starts and stops the transmission of a selected Ethernet stream. Valid <tgen> values are 0 – Selects all defined streams 1 – Stream ID #1 2 – Stream ID #2 3 – Stream ID #3 4 – Stream ID #4 Valid <state> values are ON or OFF.
STRM:CONTROL? <tgen>	Queries and reports the transmission state (On or Off) for the selected Ethernet stream. Valid <tgen> values are: 0 – Queries all defined streams 1 – Queries Stream ID #1 2 – Queries Stream ID #2 3 – Queries Stream ID #3 4 – Queries Stream ID #4 Note: An error is returned if the selected stream does not exist. The following is an example of what is returned by this command if only a single stream is defined and enabled: Stream ID#1 ON. If four streams are defined, but only Stream 2 is On, then the following is an example of what is returned by this command when the 0 tgen value is used: Stream ID#1 OFF, Stream ID#2 ON, Stream ID#3 OFF, Stream ID#4 ON.
STRM:SRC:MASK:MAC? <tgen>	Reports the mask that is configured for the MAC source address of a specific Ethernet stream.
STRM:SRC:MASK:MAC <tgen> <mask>	Creates an address mask for an Ethernet stream's MAC source address. The MAC address is a 6-byte HEX value. Valid <tgen> values are 1, 2, 3, or 4. Valid <mask> values are: 0 Fixed address value is used (default), i.e., 10-2b-3a-22-14-12 8 Last address element is a variable, i.e., 10-2b-3a-22-14-XX 16 Last two address elements are variables, i.e., 10-2b-3a-22-XX-XX 24 Last three address elements are variables, i.e., 10-2b-3a-XX-XX-XX 32 Last four address elements are variables, i.e., 10-2b-XX-XX-XX-XX
STRM:SRC:MAC? <tgen>	Reports the MAC source address for a selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:SRC:MAC <tgen> <addr>	Creates and edits the MAC source address for a specific Ethernet stream. Valid values for <tgen> are 1, 2, 3, or 4. The <addr> parameter is a 6-byte HEX value (ranging from 0 to FF) and entered using the following format: XX-XX-XX-XX-XX-XX (default value is 00-00-00-00-00-00).
STRM:DEST:MASK:MAC? <tgen>	Reports the mask that is configured for the MAC destination address of a specific Ethernet stream.

Stream Command	Description
STRM:DEST:MASK:MAC <tgen> <mask>	Creates an address mask for an Ethernet stream's MAC destination address. The MAC address is a 6-byte HEX value. Valid <tgen> values are 1, 2, 3, or 4. Valid <mask> values are: 0 Fixed address value is used (default), i.e., 10-2b-3a-22-14-12 8 Last address element is a variable, i.e., 10-2b-3a-22-14-XX 16 Last two address elements are variables, i.e., 10-2b-3a-22-XX-XX 24 Last three address elements are variables, i.e., 10-2b-3a-XX-XX-XX 32 Last four address elements are variables, i.e., 10-2b-XX-XX-XX-XX
STRM:DEST:MAC? <tgen>	Reports the MAC destination address for a selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:DEST:MAC <tgen> <addr>	Creates and edits the MAC destination address for a specific Ethernet stream. Valid values for <tgen> are 1, 2, 3, or 4. The <addr> parameter is a 6-byte HEX value (ranging from 0 to FF) and entered using the following format: XX-XX-XX-XX-XX-XX (default value is 00-00-00-00-00-00).
STRM:SRC:MASK:IP? <tgen>	Reports the Ethernet stream's IP source address. Valid <tgen> values are 1, 2, 3, or 4.
STRM:SRC:MASK:IP <tgen> <mask>	Creates an address mask for an Ethernet stream's IP source address. The IP address is an ASCII string entered using yyy.yyy.yyy.yyy format, where yyy is a value ranging from 0 to 255. Valid <tgen> values are 1, 2, 3, or 4. Valid <mask> values are: 0 Fixed address value is used (0.0.0.0 = default), i.e., 127.0.1.8 8 Last address element is a variable, i.e., 127.0.1.XXX 16 Last two address elements are variables, i.e., 127.0.XXX.XXX 24 Last three address elements are variables, i.e., 127.XXX.XXX.XXX
STRM:SRC:IP? <tgen>	Reports the IP source address for a specific Ethernet stream.
STRM:SRC:IP <tgen> <addr>	Creates and edits the IP source address for a specific Ethernet stream. Valid values for <tgen> are: 1, 2, 3, or 4. The <addr> value is an ASCII string entered using the following format: XXX.XXX.XXX.XXX where, XXX is a value ranging from 0 to 255. Default <addr> is 0.0.0.0.
STRM:DEST:MASK:IP? <tgen>	Reports the Ethernet stream's IP destination address. Valid <tgen> values are 1, 2, 3, or 4.
STRM:DEST:MASK:IP <tgen> <mask>	Creates an address mask for an Ethernet stream's IP destination address. The address mask is an ASCII string entered using yyy.yyy.yyy.yyy format, where yyy is a value ranging from 0 to 255. Valid <tgen> values are 1, 2, 3, or 4. Valid <mask> values are: 0 Fixed address value is used (0.0.0.0 = default), i.e., 127.0.1.8 8 Last address element is a variable, i.e., 127.0.1.XXX 16 Last two address elements are variables, i.e., 127.0.XXX.XXX 24 Last three address elements are variables, i.e., 127.XXX.XXX.XXX

Stream Command	Description
STRM:DEST:IP? <tgen> <addr>	Creates and edits the IP destination address for a specific Ethernet stream. Valid values for <tgen> are: 1, 2, 3, or 4. The <addr> value is an ASCII string entered using the following format: XXX.XXX.XXX.XXX where, XXX is a value ranging from 0 to 255. Default <addr> is 0.0.0.0.
STRM:DEST:IP <tgen>	Reports the IP destination address for a specific Ethernet stream.
STRM:PAYload? <tgen>	Reports the type of payload used for a specific Ethernet stream.
STRM:PAYload <tgen> <pattern> <hex value>	Creates and edits the pattern used for the Ethernet stream's payload. Valid <tgen> values are 1, 2, 3, or 4. Valid <pattern> values are: USER Allows a user defined hex value to be entered for the pattern. See <hex value> below for more information. ONES Uses and All Ones pattern ZEROS Uses an All Zeros pattern (default) Valid <hex value> values range from 0 to FFFFFFFF. The <hex value> parameter is only used when the <pattern> parameter is set to USER.
STRM:FRAMELENgth? <tgen>	Reports the frame size for a specific Ethernet stream.
STRM:FRAMELENgth <tgen> <length>	Sets the frame size for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <length> values range from 60 to 9220. (Default is 64.)
STRM:SRC:PORT? <tgen>	Reports the UDP source port value for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:SRC:PORT <tgen> <port>	Sets the UDP source port for a selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <port> values range from 0 to 65535. (Default is 0.)
STRM:DEST:PORT? <tgen>	Reports the UDP destination port value for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:DEST:PORT <tgen> <port>	Sets the UDP destination port value for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <port> values range from 0 to 65535. (Default is 0.)
STRM:BW? <tgen>	Reports the bandwidth value selected for a single Ethernet stream or the total bandwidth value for all configured Ethernet streams. Valid <tgen> values are: 1 Reports the bandwidth configured for stream 1. 2 Reports the bandwidth configured for stream 2. 3 Reports the bandwidth configured for stream 3. 4 Reports the bandwidth configured for stream 4. Note: If no <tgen> parameter is entered, then the command reports the total bandwidth used by all configured streams.
STRM:BW <tgen> <bw>	Sets the bandwidth percentage used for a selected Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <bw> values range from 3 to 100. (Default is 100 percent.)
STRM:VLAN:ID? <tgen>	Reports the VLAN ID assigned to a specific Ethernet stream.
STRM:VLAN:ID <tgen> <id>	Assigns a VLAN ID to a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <id> values range from 0 to 4095. (Default is 0.)

Stream Command	Description
STRM:VLAN:QOS? <tgen>	Reports the VLAN QOS value for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:VLAN:QOS <tgen> <qos>	Sets the VLAN QOS user priority level for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <qos> values range from 0 to 7. (Default is 0.)
STRM:VLAN:TAG? <tgen>	Reports the VLAN tag value for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4.
STRM:VLAN:TAG <tgen> <tag>	Enables and disables VLAN tagging for a specific Ethernet stream. Valid <tgen> values are 1, 2, 3, or 4. Valid <tag> values ON (enables VLAN tagging) or OFF (disables VLAN tagging). Default is OFF.

GET Branch

The Get Branch SCPI commands act as batch commands by retrieving values for multiple unit parameters using a single SCPI command. This is similar to using the Transmit and Receive Function Group buttons to view various settings of the different protocol processors.

Many of the GET commands substitute a variable to report information about a specific test set. In this section, these commands are grouped together. Use the following table to locate a specific command.

Refer to this command...	For information about the following commands.
GET:PROTOcols?	<p>Queries the types of protocol processors contained in the system. For example: STM4, E1@1, E1@2, etc.</p> <p>For Gigabit Ethernet, this command queries and reports the protocol processor ID, chassis ID, slot ID, and card ID for the Gigabit Ethernet protocol processor. This command is useful when multiple circuit packs are installed in the unit.</p> <p>For example, if a NIC Plus has two Gigabit Ethernet circuit packs installed, both circuit packs may appear as being installed in a single slot. To avoid this confusion, the GET:PROTO? command returns identity parameters for all circuit packs detected in the unit. Results for this command are returned in the following format:</p> <p>For circuit pack 1: 0 1 1 GIGE@1 0 1 1 GIGE@2 which means: Chassis ID 0, Slot 1, Card 1, GIGE Port 1; Chassis ID 0, Slot 1, Card 1, GIGE Port 2</p> <p>For circuit pack 2: 0 1 2 GIGE@1 0 1 2 GIGE@2 which means: Chassis ID 0, Slot 1, Card 2, GIGE Port 1; Chassis ID 0, Slot 1, Card 2, GIGE Port 2</p>

6

OSA SCPI Commands

Overview

This chapter describes the Optical Spectrum Analyzer (OSA) SCPI commands supported by the configured unit. You may not have access to all commands based on the product configuration you purchased.

Supported OSA SCPI Commands

These commands are extensions to the SCPI command set. These commands are adapted to the configured unit and are unique to each protocol processor. SCPI commands should be typed on one single line completed with a hard carriage return. These commands require zero or one parameters, and return zero or one values.

RX (Sense) Branch

The RX branch is used to set and retrieve OSA Receive settings. Alternatively, each command can be sent using the "SENS" or "SENSE" keyword instead of the "RX" keyword.

SENSe Command	Description								
RX:CBAND:SPACING?	Queries and reports the C-band channel spacing value.								
RX:CBAND:SPACINGS <spacing>	Sets the C-band channel spacing. Valid values for <spacing> are: <table border="1"><thead><tr><th>Spacing (GHz)</th><th>Description</th></tr></thead><tbody><tr><td>50</td><td>50 GHz spacing</td></tr><tr><td>100</td><td>100 GHz spacing</td></tr><tr><td>200</td><td>200 GHz spacing</td></tr></tbody></table>	Spacing (GHz)	Description	50	50 GHz spacing	100	100 GHz spacing	200	200 GHz spacing
Spacing (GHz)	Description								
50	50 GHz spacing								
100	100 GHz spacing								
200	200 GHz spacing								
RX:CBAND:CHTABLE?	Queries and returns C-band channel data. Data appears in a comma-delimited list, for example: A,B,C,D,E,F where, A is an C-band channel number which ranges from 1 to 80 (for example, C#3) B is the C-band Grid value C is the wavelength in nanometers (nm) D is the deviation value in picometers (pm) E is the channel power value F is the signal-to-noise ratio The following is an example of C-band channel data for a single channel: C#3,1570.40,1570.45,-100,-32.92,31.75 If multiple channels are listed, data is separated with a colon (:). For example: C#3,1570.40,1570.45,-100,-32.92,31.75:C#7,1470.40,1470.45,-90,-25.90,40.75								
Note: Error code -925 appears if no channel data is available.									
RX:LBAND:SPACING?	Queries and reports the L-band channel spacing value.								

SENSe Command	Description								
RX:LBAND:SPACINGS <spacing>	<p>Sets the L-band channel spacing. Valid values for <spacing> are:</p> <table border="1"> <thead> <tr> <th>Spacing (GHz)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>50</td> <td>50 GHz spacing</td> </tr> <tr> <td>100</td> <td>100 GHz spacing</td> </tr> <tr> <td>200</td> <td>200 GHz spacing</td> </tr> </tbody> </table>	Spacing (GHz)	Description	50	50 GHz spacing	100	100 GHz spacing	200	200 GHz spacing
Spacing (GHz)	Description								
50	50 GHz spacing								
100	100 GHz spacing								
200	200 GHz spacing								
RX:LBAND:CHTABLE?	<p>Queries and returns L-band channel data. Data appears in a comma-delimited list, for example: A,B,C,D,E,F where,</p> <p>A is an L-band channel number which ranges from 1 to 80 (for example, L#3) B is the L-band Grid value C is the wavelength in nanometers (nm) D is the deviation value in picometers (pm) E is the channel power value F is the signal-to-noise ratio</p> <p>The following is an example of L-band channel data for a single channel: L#3,1570.42,1570.33,-90,-33.25,35.82</p> <p>If multiple channels are listed, data is separated with a colon (:). For example: L#3,1570.42,1570.33,-90,-33.25,35.82:L#7,1584.53,1584.56,30,-32.74,36.46</p>								
RX:REPBAND?	<p>Queries and returns the type of band (C-band or L-band) that is being reported or monitored.</p>								
RX:REPBAND<band>	<p>Sets the type of band that is being reported or monitored. Valid values for <band> are: CBAND or LBAND</p>								

7

Error Codes

Overview

The error codes assist in debugging problems. These error codes can be returned from SCPI commands in request to a command or query that is invalid.

Error codes are returned in the following default format:

error code number, “definition”

If you have existing SCPI command scripts that require error codes to be returned using only the error code number, use the **SYST:LEGACYR TRUE** command for this type of formatting. Refer to the SYST:LEGACYR? command for additional information.

Error Code	Definition
101	“Object not initialized “
102	“File read/write failed”
103	“Insufficient memory “
104	“Unauthorized User”
105	“Invalid protocol processor index”
201	“User not found”
202	“User not logged-in”
203	“Failed to add user “
204	“Failed to delete user”
205	“Failed to lock user”
206	“Invalid login name”
207	“Invalid password”
208	“User cannot modify privilege”
209	“Maximum logged sessions reached”
210	“Upgrade in progress”
211	“User already logged-in”
301	“Failed to initialize system”
302	“Failed to reboot”
303	“Invalid test ID”
304	“Failed to configure TCP configuration””
305	“Failed to configure RS232 configuration”
306	“Invalid RS232 configuration parameters”
307	“Failed to CPLD”
308	“Invalid CPLD data”
309	“Invalid date-time”
310	“Serial port is busy “
311	“Sound card failed”

Error Code	Definition
312	“Invalid GPIB address”
313	“Invalid license key”
401	“Data manager, index out of range”
501	“Protocol manager, invalid PP type”
502	“Protocol manager, invalid CORBA-any”
503	“Protocol manager, invalid command type”
504	“Protocol manager, invalid preset command”
505	“Protocol manager, test unit active”
506	“Protocol manager, test unit locked”
507	“Protocol manager, user ID not found”
508	“Invalid protocol processor mode”
509	“Protocol processor not present”
601	“Invalid test unit ID”
602	“Invalid test ID”
603	“Invalid protocol processor lock attempt”
701	“Record not found”
702	“Duplicate record”
800	“Invalid registry key”
801	“Invalid registry entry”
802	“Incompatible versions”
803	“Failed to bind to CORBA”
804	“Invalid IP address”
900	“Unhandled internal error”
901	“Invalid Scrambling mode”
902	“Invalid unit of measure”
903	“Invalid for current scope”
904	“Invalid for current setting”
905	“Invalid for alarm type”
906	“Invalid error type”
907	“Invalid network impairment type”
908	“Invalid OAM type”
909	“Invalid AAL type”
910	“Invalid traffic type”
911	“Invalid receive status”
912	“Invalid transmit status”
913	“Invalid transmit/receive toggle (on/off) type”
914	“Transmit is on.”
915	“Transmit is off.”
916	“Receive is on.”
917	“Receive is off.”
918	“Invalid VCC table entry”

Error Code	Definition
919	“Invalid scope”
920	“Invalid PMOMA block size specified”
921	“Invalid interface”
922	“Invalid mapping”
923	“Invalid framing”
924	“Invalid pattern”
925	“No modified data captured”
926	“Invalid background sequence”
927	“Invalid for current UNI version”
928	“Invalid SVC test type”
929	“Invalid UNI version”
930	“Unhandled exception”
931	“Invalid results”
932	“Invalid settings”
933	“Invalid ATM address format”
934	“Invalid UNI timer”
935	“Invalid QOS class specified”
936	“Invalid signal filter type specified”
937	“Invalid call reference flag specified”
938	“Invalid SVC message type”
939	“VCC entry is not an SVC”
940	“VCC entry not valid for O.191 RX pattern”
941	“Invalid O.191 flow type”
942	“Invalid QOS test type”
997	“Instrument Locked”
998	“Unauthorized user”
999	“User already logged in”
-100	“Command error”
-104	“Data type error”
-108	“Parameter not allowed”
-109	“Missing parameters”
-120	“Numeric data error”
-200	“Execution error”
-203	“Command protected”
-213	“Init ignored”
-222	“Data out of range”
-224	“Illegal parameter value”
-256	“File name not found”
-300	“System controller exception”
-310	“System exception”
-350	“Queue overflow”

8

Register Definitions

Overview

The configured unit supports the following registers. The tables below define these registers.

*STB? Status Byte (Immediate Response Queue)

BIT	Value
0	TCON Summary
1	Latched version of bit 3 (Summary of STATUS: QUESTIONABLE:EVENT?)
2	Errors are in Queue
3	QUESTIONABLE Status Summary
4	MAV (Output available in its Queue)
5	Standard Event Status Register Summary
6	
7	

*ESR? Standard Event Status Register (Immediate Response Queue)

BIT	Value
0	Operation Pending (Always zero, indicating done)
1	Request Control (Always zero)
2	Query Error (Indicates an error in the error queue is from a query)
3	Device-Dependent Error (Indicates existence of a fault)
4	Execution error (Always zero)
5	Command error (Indicates an error in the error queue is from a command)
6	User Request (Always zero)
7	Power on (Always zero)

STATus:QUES? Questionable Register

Refer to the *Status Branch* section in Chapter 2 for more information about Status Branch commands.

BIT	Value
0	E1@1 Summary
1	E1@2 Summary
2	E3 Summary
3	E4 Summary
4	DS1@1 Summary
5	DS1@2 Summary
6	DS3 Summary
7	SDH Summary
8	
9	
10	
11	
12	
13	
14	
15	Not Used - Forbidden

STATus:OPER:TCON? Telecom Configuration Register (TCON)

Refer to the *Status Branch* section in Chapter 2 for more information about Status Branch commands.

BIT	Value
0	E1@1 Protocol Processor Selected
1	E1@2 Protocol Processor Selected
2	E3 Protocol Processor Selected
3	E4 Protocol Processor Selected
4	DS1 @ 1 Protocol Processor Selected
5	DS1 @ 2 Protocol Processor Selected
6	DS3 Protocol Processor Selected
7	SDH/SONET Protocol Processor Selected

BIT	Value
8	
9	
10	
11	
12	
13	
14	
15	Not Used - Forbidden

DS1 Registers

STAT:QUES:DS1@1? and STAT:QUES:DS1@2

BIT	Value
0	DS1 Clock Sync Alarm
1	DS1 Loss of Signal
2	DS1 Loss of Frame
3	DS1 Loss of Pattern
4	DS1 Alarm Indication Signal (AIS)
5	DS1 COFA
6	DS1 RAI
7	DS1 Idle
8	Looped Tester
9	Loop Up Detected
10	Loop Down Detected
11	
12	
13	
14	
15	Not Used - Forbidden

DS3 Register

STAT:QUES:DS3?

BIT	Value
0	DS3 Clock Sync Alarm
1	DS3 Loss of Signal

BIT	Value
2	DS3 Loss of Frame
3	DS3 Loss of Pattern
4	DS3 Alarm Indication Signal (AIS)
5	DS3 Idle
6	DS3 X-Bit Alarm
7	
8	
9	
10	
11	
12	
13	
14	
15	Not Used - Forbidden

E1 Registers

STAT:QUES:E1@1? and STAT:QUES:E1@2

BIT	Value
0	E1 Clock Sync Alarm
1	E1 Loss of Signal
2	E1 Loss of Frame
3	E1 Loss of Pattern (LSS)
4	E1 Alarm Indication Signal (AIS)
5	E1 CASMFL
6	E1 RAI
7	E1 RMFAI
8	E1 COFA
9	Payload Looped
10	Line Looped
11	
12	
13	
14	
15	Not Used - Forbidden

E3 Register STAT:QUES:E3?

BIT	Value
0	E3 Clock Sync Alarm
1	E3 Loss of Signal
2	E3 Loss of Frame
3	E3 Loss of Pattern
4	E3 Alarm Indication Signal (AIS)
5	E3 RDI (RAI)
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	Not Used - Forbidden

E4 Register STAT:QUES:E4?

BIT	Description / Value
0	E4 Clock Sync Alarm
1	E4 Loss of Signal
2	E4 Loss of Frame
3	E4 Loss of Pattern
4	E4 Alarm Indication Signal (AIS)
5	E4 RDI (RAI)
6	
7	
8	
9	
10	
11	
12	
13	

BIT	Description / Value
14	
15	Not Used - Forbidden

SDH/SONET Register

STAT:QUES:SDH? or STAT:QUES:SONET?

BIT	Value
0	Clock Sync
1	LOS
2	LOF
3	MS-AIS/AIS-L
4	MS-RDI/RDI-L
5	AU-AIS/AIS-P
6	AU-LOP/LOP-P
7	HP-UNEQ/UNEQ-P
8	HP-RDI/RDI-P
9	TU-AIS/AIS-V
10	TU-LOP/LOP-V
11	LP-UNEQ/UNEQ-V
12	LP-RDI/RDI-V
13	LP-RFI/RFI-V
14	Loss of Pat Sync
15	Not Used - Forbidden

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at artisanng.com for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisanng.com | artisanng.com

