

THE SOUND OF THE PROFESSIONALS"

# 222 HARTREY AVENUE EVANSTON, ILLINOIS 60202-3696 U.S.A. **PROFESSIONAL PRODUCTS**



### GENERAL

The FP31 is a portable electronic news gathering (ENG) electronic field production (EFP), or film production, mixer that provides the quality and features needed for remotes.

### FEATURES

### Inputs

- Three transformer-coupled, 3-socket XLR-connector inputs; each switchable to low-impedance microphone or line level
- Lo-Cut filters available at each input to reduce extraneous low-frequency interference
- (Phantom) simplex or A-B power for condenser microphones available at each microphone input
- Built-in tone oscillator for level checks or line tests
- Slate microphone with automatic gain control (AGC) for take identification or for emergency use
- Slate tone for identifying take locations during editing

### Outputs

- Two transformer-coupled, 3-pin XLR-connector outputs, each switchable either to low-impedance balanced microphone or to 600-ohm balanced line level
- Tape output to feed tape recorder input or other unbalanced Aux-level input
- Front and side panel stereo headphone jacks (8 to 2,000 ohms, ¼-inch and 3.5 mm jacks) with separate Phones level control. Either or both jacks can drive Aux or unbalanced line-level inputs. Four separate sources can be driven from these two headphone outputs.

### **Controls and Indicators**

- Active, feedback-type input gain controls permit direct input of high-level sources without input attenuators
- Built-in Limiter with adjustable threshold prevents output clipping of mixer or input overload of amplifier, telephone line or tape recorder
- LED indicator flashes with Limiter operation or to signal overload with Limiter defeated
- Professional VU meter, factory set for 0 VU = +4 dBm, internally adjustable for other VU levels
- VU lamp, stays illuminated while pushbutton is depressed, automatic 5-second turnoff after button is released.
- Battery check function with readout on VU meter
- Master gain controls level at Line/Mic and Tape outputs as well as tone oscillator level
- Phones level control adjusts output at both headphone jacks

### Power

- Mixer is powered by two standard 9V alkaline batteries that also supply simplex power for condenser microphones
- Extremely low battery drain provides 8-hour minimum battery life under normal conditions
- Separate 9V alkaline battery supplies A-B power for condenser microphones; third battery is not required if A-B power is not used
- Spring-loaded battery compartment prevents incorrect insertion of batteries; batteries available for replacement instantly when compartment door is opened
- Mixer can be powered from any 11 to 18 Vdc source such as: standard belt pack, automotive electrical system, video tape recorder, or ac power converter

### Mechanical characteristics

- Extremely rugged and durable construction
- Very small size and light weight
- Carrying case and detachable shoulder strap supplied
- All input and output connectors are professional standard types

### Performance

- Reliable operation under wide extremes of temperature and humidity
- Extremely low noise and low RF susceptibility permits use near microwave transmitters and in strong hum fields
- Wide, flat response, extremely low distortion, and up to +18 dBm output level provide studio-quality performance in a portable mixer

### SPECIFICATIONS

### Frequency Response

30 Hz to 20 kHz ± 2 dB

### Distortion

Less than 0.25% total harmonic distortion at  $\pm 4$  dBm, 50 Hz to 20 kHz

### Noise

Less than - 129 dBV equivalent input noise

### **Common Mode Rejection**

65 dB minimum at 100 Hz, - 30 dBV input

Inputs

	IMPEDAN	CE	Input Clipping
	For Use With	Actual	Level
Mic	19 to 600Ω*	1 kΩ	- 47 to - 17 dBV (4.5 to 141 mV)
Line	Less than 10 k $\Omega$	66 kΩ	+ 3 to + 33 dBV
			(1.4 to 44V)

\*Including simplex or A-B powered, and dynamic or ribbon microphones

### **Tone Oscillator**

1 kHz nominal at +4 dBm, Master at approx. 7

Slate Tone 400 Hz, 1 sec, each time button is depressed

### **Slate Microphone**

Electret condenser, omnidirectional, with AGC, activated while slate button is depressed

### Outputs

	IMPEDAN	ICE	Output Clipping
	For Use With	Actual	Level
Mic	Any low-Z mic	0.5Ω	- 34 dBV (20 mV)
	input		minimum into 150Ω
Line	600Ω	150Ω	+ 18 dBm minimum
			into 600Ω
Tape	8 kΩ or greater	2.5 kΩ	-6 dBV (0.5V RMS)
	high level input		into 47 kΩ
Phone	8Ω to 2 kΩ	180Ω	+4 dBV (1.6V RMS
			Max)
			into 200Ω

### Phase

3-pin Input & Output connectors in phase; pin 3 in phase with tip of phone & mini jacks

### Gain (at 1 kHz)

INPUT		OUTPUT	
	Mic	Line	Таре
Mic	40 dB	90 dB	68 dB
Line	— 10 dB	40 dB	18 dB

### Controls

CHANNEL GAIN: Active, feedback type, individual for each input; Channel 1 control pulls out to activate tone oscillator

MASTER GAIN: Controls Line/Mic and Tape outputs, and tone oscillator and slate levels

LOW-CUT FILTERS: 7 dB rolloff at 100 Hz, -6 dB/octave slope

PHONES LEVEL: Controls both headphone outputs LIMITER: Controls Line/Mic and Tape outputs; + 14 dBm factory-set threshold, internally screwdriver adjustable down to + 3 dBm; 3 msec attack, 500 msec recovery time typica! SIMPLEX/DYNAMIC/A-B SELECTORS: Individual for each input, supplies 11 to 18 Vdc Simplex (phantom) or 9 Vdc A-B power with Input in MIC position; supplies no power with Selector in DYN position (for dynamic or ribbon microphones) or with Input in LINE position

### **Control Interaction**

Less than 1 dB with any control combination

### **Output Isolation**

Shorting one output shall cause no more than 8 dB level drop at 1 kHz at other output

### **Overload and Shorting Protection**

Shorting outputs, even for prolonged periods, shall cause no damage. Microphone inputs will not be damaged by signals up to 3 volts.

### Indicators

POWER ON: Green LED flashes at approximately 1-second repetition rate as long as power switch is on

PEAK/OVERLOAD: Limiter IN – Red LED flashes to indicate onset of limiting; Limiter OUT – flashes 6 dB below output clipping level

BATTERY CHECK: Converts VU Meter to battery condition or circuit voltage indicator; 0 VU or higher indicates good batteries or adequate (11 to 18 Vdc) external power source

VU METER: Factory-set at 0 VU = +4 dBm; 0 VU level internally screwdriver adjustable

VU LAMP: Illuminates meter while button is depressed; automatic shufoff 5 seconds after release

### Power

MIXER AND SIMPLEX (PHANTOM) POWER: Supplied by two internal 9V standard alkaline batteries (Duracell MN1604 or equivalent) or external 11 to 18 Vdc supply; 8-hour battery life under normal operation

SIMPLEX POWER: 11 to 18 Vdc nominal through 6200

A-B POWER: Supplied by additional 9V standard alkaline battery

### Connectors

LINE/MIC INPUTS AND OUTPUTS: 3-pin XLR type

TAPE OUT: 3.5 mm mini jack

PHONES: Stereo jacks; one standard ¼-inch phone and one 3.5 mm mini

12 VDC EXTERNAL POWER: Single-pin dc power jack

### **Temperature Range**

OPERATING:  $-18 \text{ to } +57^{\circ}\text{C} (0 \text{ to } 135^{\circ}\text{F})$ STORAGE:  $-29 \text{ to } +71^{\circ}\text{C} (-20 \text{ to } +160^{\circ}\text{F})$ 

### Dimensions

48.3 mm H x 160 mm W x 135 mm D (1-7/8 x 6-5/16 x 5-5/16 in.)

### Net Weight (less batteries)

1 kg (2.2 lb)

### Supplied Accessories

Removable shoulder strap, carrying case


### OPERATION

### Line/Mic Inputs and Outputs

XLR-type 3-pin connectors, transformer-coupled balanced-line circuits; pins 2 and 3 are signal conductors; pin 1 is ground. All XLR connectors are in phase with one another.

### **Lo-Cut Filters**

Activated by In/Out switch above each Channel Gain Control to provide low-frequency rolloff as shown in Figure 1. Reduce undesirable low-frequency signals such as wind noise.



### LO-CUT FILTER ACTION FIGURE 1

### Channel Gain Controls

Determine preamplifier gain and provide preamplifier output attenuation. As gain is reduced, input clipping level increases for channel. Optimum signal-to-noise ratio occurs with Channel controls set as high as possible (consistent with maintaining adequate control range and input clipping level).

### **Tone Oscillator**

Activated by pulling out Channel 1 control knob; stable 1 kHz oscillator; level determined by Master gain control. Oscillator signal appears at all outputs. When not in use, Channel 1 control knob should be pushed in.

### Slate

Depressing Slate button activates 1-second 400 Hz tone and turns on Slate Microphone. Omnidirectional electret Slate Microphone remains on while button is depressed, can be used to identify recorded segments or as emergency field microphone. Slate Tone and AGC'd microphone audio levels are controlled by Master Gain Control.

### Master Gain Control

Determines output levels at Line/Mic and Tape outputs. Also sets Tone Oscillator level when Channel 1 knob is pulled out, and Slate-tone and -microphone level when Slate button is pushed.

### **Headphone Jacks**

Two stereo phone jacks: one mini 3.5 mm (front panel) and one 1/4-inch phone (side panel). Combined output, including Tone Oscillator, Slate Tone and Slate Microphone, appears at headphone jacks. Can be used to drive up to four headphones or Aux-level recorder or amplifier inputs. To wire either connector for two outputs, connect one conductor to tip; connect other conductor to ring; and connect shield(s) to sleeve of appropriate mating stereo plug. Tip and ring of headphone jacks in-phase with pin 3 of XLR Line/Mic input and output connectors.

### **Phones Control**

Sets output level at headphone jacks.

### Limiter

Limiter In/Out switch turns on fast-acting, peak-responding limiter circuit to cut overload distortion during loud program intervals without affecting normal program levels. Limiter switch In (operating) restricts maximum mixer output to approximately +14 dBm. Increasing individual Channel or Master gain controls increases both average output and amount of limiting. To change Limiter threshold, see section on Limiter Threshold Adjustment.

### Peak LED

Indicates Limiter operation with Limiter switch In. With switch Out, flashes at 6 dB below output clipping. Peak indicator responds much faster than meter, activated by even shortest transient peak, yet remains lit long enough to provide easy recognition.

### **VU Meter**

Factory calibrated for +4 dBm = 0 VU with 600-ohm load at Line output. (Microphone output levels are 50 dB below Line output.) Supplied 0 VU level is recommended for normal use to provide approximately 14 dB headroom between operating level and clipping level. To change 0 VU level, see section on VU Meter Adjustment.

### VU Lamp

Illuminates meter while button is depressed; automatically turns off 5 seconds after release to prevent battery drain.

### Tape Outputs

3.5 mm jack to feed unbalanced Aux-level input of tape recorder or amplifier. Tip of connector in phase with pin 3 of XLR connectors.

### **Telephone Lines**

In Line position, output transformer will operate with dc-biased "dialed up" telephone lines although there may be slight increase in distortion. When connecting FP31 to telephone line, use FCC-Registered\* interface adapter between mixer and telephone line.

### \*DOC-Certified in Canada

### **Condenser Microphone Power**


Condenser microphones, either 12 to 18 Vdc phantom (simplex) powered or 9 Vdc A-B(T) powered, can be supplied from any Mic input of FP31. Below batteries, inside battery compartment, are three 3-position switches. Center position is for dynamic microphones (no dc power supplied to Mic input); left position is for 9-Vdc A-B power, right position is for 11- to 18-Vdc phantom power.

NOTE: No power is supplied to any input with Line/Mic switch in Line position. No A-B power is supplied unless right-side battery is present.

### **Mixer Powering**

In ordinary portable use, the FP31 is powered by two standard 9-Vdc alkaline batteries installed in leftmost battery compartment positions. Phantom power is also supplied by these batteries.

The FP31 can also be powered by an 11 to 18 Vdc external source, such as an automotive battery, battery beltpack, Shure PS20 AC Adapter or other low-ripple ac power converter (see Figure 2), using the12 Vdc single-pin coaxial input connector in the left-side panel. To filter possible power-supply hum and noise, install a 100  $\Omega$  resistor on the "+" side of the dc output. The outside barrel of the mating connector is positive.



\*Wire with white stripe is 12 V+ Coaxial Power Plug

Cut off molded dc power plug of PS20 and wire new connector as shown

### POWERING FP31 FROM EXTERNAL AC ADAPTER FIGURE 2

### Parts Required:

- Shure PS20 AC Adapter or equivalent (dc output = 12 Vdc, 100 mA minimum)
- 1 100 Ω 1 W resistor
- 1 Coaxial dc power plug to fit FP31 external dc power jack (2.1 or 2.5 mm l.D.) Radio Shack #274-1567A

Batteries can be left in place as backup in case of failure of external source. Switchover to internal batteries is performed by disconnecting external plug.

### CAUTION

12 Vdc input circuit is not fused. Any external source should be provided with in-line fuse, 0.25 A, 250 V, as safety precaution.

### Battery Check

Depressing BATT button converts VU Meter to readout of battery condition (two mixer-powering batteries) or of supply voltage. Readings of 0 VU or higher indicate good batteries or adequate external supply.

### **VU METER ADJUSTMENT**

To set the VU Meter for a value different from the supplied 0 VU =  $\pm 4$  dBm, proceed as follows.

- 1. Connect a 600-ohm load to one of the Line outputs.
- 2. Connect an ac voltmeter (e.g., HP 400GL) in parallel with the load.
- 3. Pull out the Channel 1 knob to activate the Tone Oscillator.
- Adjust the Tone Oscillator level with the Master gain control until the ac voltmeter reading is at the level desired.
- With a screwdriver, adjust the VU Level trimpot (left of the A-B/DYN/SPLX Selector switches) until the VU Meter reads 0.

### LIMITER THRESHOLD ADJUSTMENT

To adjust the Limiter threshold for a value different from the supplied +14 dBm, proceed as follows.

- 1. Connect a 600-ohm load and an ac voltmeter to a Line output as described in steps 1 and 2 above.
- 2. Pull out the Channel 1 knob to activate the Tone Oscillator.
- With Limiter switch Out, adjust Master gain control until the ac voltmeter reading is at the level desired.
- Move the Limiter switch In, and adjust Limiter Threshold trimpot (left of the VU Level trimpot) until the level drops 0.5 dB.


### FURNISHED ACCESSORIES

Carrying Case	 . 95B8066
Shoulder Strap	 90BX2600


Ination         ment Kit         City.         Part No.           C104.          86Y628           C103.          86Y628           C130.          86Y629           C130.          86Y629           C130.          86T629           C130.          86A629           C120.          86A629           C154.          86A629           C154.          86A629           C154.          865629           C154.          865629           C154.          865629           C154.          865629           C154.          865629           C154.          865629           C154.          -           C154.          865629           C157.          865629           C156.          865629           C155.          865629           C155.          865629           C157.          864629           C15	Yy.         Part No.         Description           -         86Y628         Capacitor, Electrolytic,           -         86Y628         Capacitor, Electrolytic,           -         86T629         Capacitor, Electrolytic,           -         86AC629         Capacitor, Electrolytic,           -         86S628         Capacitor, Electrolytic,           -         86S629         Capacit	Commarcial Alternate Panasonic ECEB0JK220 Panasonic ECEB1EK4R7 Marcon CESSM1E4R7 Marcon CESSM1C471 Marcon CESSM1C471A LC.C. 336RSS010M LC.C. 336RSS010M LC.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1221 LC.C. 227RMP025M Marcon CESSM1A470
-     86Y628        -     86Y629        -     86T629        -     86T629        -     86A629        -     86A659        -<		Panasonic ECEBOJK220 Panasonic ECEB1EK4R7 Marcon CESSM1E4R7 Marcon CESSM1C471A Marcon CESSM1C471A L.C.C. 336RSS010M L.C.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1221 L.C.C. 227HMP025M Marcon CESSM1A470
-     867629        -     867629        -     86A0529        -     865629        -		Panasonic ECEB1E4R7 Marcon CESSM1E4R7 Marcon CESSM1C471 Marcon CESSM1C471A LC.C. 336RSS010M LC.C. 336RSS010M LC.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1221 LC.C. 227RMP025M Marcon CESSM1A470
86AG629         86AG629         865629         865629         865629         865629         865629         865629         865629         865629         865629         865629         865629         865629         865629         8646529         865629         865629         865629         865629         865629         865629         865629         865629         8654629         8654629         8654629         8654629         8654629		Marcon CESSM1E4R7 Marcon CESSM1C471A Marcon CESSM1C471A L.C.C. 336RSS010M L.C.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1221 L.C.C. 227RMP025M Marcon CESSM1A470
86A0629         865629         9654415         9654415	Capacitor, 470 µF, 160 470 µF, 160 Capacitor, 470 µF, 160 Capacitor, 33 µF, 100 Capacitor, 1 µF, 250 Capacitor, 250 µF, 160 Capacitor, 220 µF, 160 Capacitor, 257 Capacitor, 257 Capacitor, 257 Capacitor, 257 Capacitor, 100 Capacitor, 100 Capacitor	Marcon CESSM1C471 Marcon CESSM1C471A L.C.C. 336RSS010M Panasonic ECE81HK010 Marcon CESSM1C221 L.C.C. 227BMP025M Marcon CESSM1A470
865629         865629         865629         865629         865629         865629         865629         865629         865629         864629         864659         864659         864659         864659         864659         864659         864659         864659         864659         864659         864415         864415	Capacitor, 470 μF, 160 Capacitor, 33 μF, 10V Capacitor, 1 μF, 25V Capacitor, 220 μF, 16V Capacitor, 220 μF, 25V Capacitor, 47 μF, 10V Capacitor, 100 μF, 16V	Marcon CESSM1C471A I.C.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1C221 I.C.C. 227BMR025M Marcon CESSM1A470
86Y629         865528         865529         865629        -     865629        -     865629        -     865629        -     865629        -     865629        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     8646529        -     864415	Capacitor, 33 μF, 10V Capacitor, 1 μF, 25V Capacitor, 220 μF, 25V Capacitor, Capacitor, Capacitor, Capacitor, Capacitor, 100 μF, 10V	I.C.C. 336RSS010M Panasonic ECEB1HK010 Marcon CESSM1C221 I.C.C. 227HMP025M Marcon CESSM1A470
-     -     865628       -     -     867629       -     -     867829       -     -     867829       -     -     867829       -     -     867829       -     -     865829       -     -     865829       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     8648529       -     -     864455       -     -     864455       -     -     864455       -     -     8654659	Capacitor, 1 $\mu$ F, 25V Capacitor, 220 $\mu$ F, 16N Capacitor, 220 $\mu$ F, 25N Capacitor, Capacitor, Capacitor, Copacitor, Copacitor, Copacitor, Copacitor,	Panasonic ECEB1HK010 Marcon CESSM1C221 I.C.C. 227HMP025M Marcon CESSM1A470
-     86R629        -     86K629        -     86K629        -     86K629        -     86K629        -     86K629        -     86K629        -     86A6529        -     86A455        -     86A455	Capacitor, 220 μF, 16N Capacitor, 220 μF, 25N Capacitor, 47 μF, 10V Capacitor, 100 μF, 10N	Marcon CESSM1C221 I.C.C. 227HMP025M Marcon CESSM1A470
86X629        -     86Z629        -     86Z629        -     86A629        -     86A659        -     86A415       RKC19     4     86A405		I.C.C. 227RMR025M Marcon CESSM1A470
-     862629        -     8646529        -     8646529        -     8646529        -     864653        -     964415        -     864405       RKC19     4     86A405		Marcon CESSM1A470
~ -     -     B6W629        -     86A6529        -     86V629        -     86V629        -     86V629        -     86V629        -     86A415        -     86A415       FIKC19     4     86A405		
8646529            -         86V629            -         86V629            -         86V629            -         86A415            -         86A415            -         86A415            -         86A415		LC.C. 107RMH016M
86V629 86A415 86A415 RKC19 4 86A405	29 Capacitor, Electrolytic, 22 μF, 16V	I.C.C. 226RSS016M
86A415 RKC19 4 86A405		LC.C. 108RMR025M
D114, RKC19 4 86A405 D303,		TI 1N4148
D304, D305	5 Diode, Germanium, 30V	RCA 1N48, 1N60
D118, D119, RKC21 4 86A404 Si D205	4 Silicon Rectifier, 100V, ½ A	Matorala IN4002
D204 86A8405 Di	Diode, Light Emitting, Green	Rohm SLR34MG3
86B8405	Diode, Light Emitting, Red	Rohm SLR34OR3
J3 – – – 95A8060	Connector, Three Socket	ITT Cannon XLR-3-31-F77
95A8061	Connector, Three-Pin	ITT Cannon XLR-3-32-F77
J101, J301 95A8062 Pt 1463	Phone Jack, Miniature, 3.5mm	None
95A8064	Power Jack, Coaxial	None

# **REPLACEMENT PARTS LIST**

		ć			
Reference Designation	Replace. ment Kit	oty.	Parl No.	ty. Part No. Description	Commercial Alternate
L1-L10		Ι	80A250	Ferrite Bead Ring	Stackpole 57-0181
L201, L202 L301	1	ł	80A365	Ferrite Bead Ring	Stackpole 57-3425
M1	1	I	95A8068	VU Meter (Special VU Range)	None
MCI	1	Ļ	95A8069	Carlridge, Electret	Radio Shack 270-090
MP1-MP3	 	Ι	9508080	Knob, MIC 1-3	Nane
MP4	1	J	95B8080	Knob, MASTER	None
МР5	I I	I	9508081	Knob, PHONES	None
MP6	l I	I	90BW2600	Battery Cover	None
PL1	1	)	95 <b>A</b> 8070	Lamp. T1, 10V, .027A	Precision Lamp PL7218
0101	RKC89	4	86A350	Transistor, NPN	Molorola 2N5210
Q102, Q103, Q104, Q301	1	I	86A,349	Transistor, NPN	Farranti FST185L
Q302	RKC66	F	86A335	Transistor, PNP	TI TI593
R110 & S108	] 1	ł	46A8009	Potentiometer, 100k, with SPDT Switch	None
B122. B134	 	I	46A8010	Polentiometer, 100k	None
R138	4	Ι	46A8013	Polentiometer, 50k	None
H143		Ι	46A8008	Potentiometer, 100k	Piher PT10Lh(2.5)100k
B146	l	I	46A8011	Polentiometer, 50k	None
R153	1	t	46C8008	Polentiometer, 50k	Piher PT10Lh(2.5)50k
S101, S102, S103		I	55A8019	Switch, Slide, 4PDT	Alcoswitch MSS4200RG
S104, S105. S106	1	I	55A8022	Switch, Slide, DPTT	Alcoswitch SLS-230PC
S107, S207, S201-S205	 	I	55A8020	Switch, Slide. DPDT	None
S206, S301, S302	[ ]	í	55A8021	Switch, Pushbutton, SPDT	None
T101, T102, T103	} }	I	51D243	Transformer, Input	None
<b>T</b> 201	1	I	51A8015	Transformer, Outout	None
<b>U101</b> , U102	1	1	868608	Integrated Circuit, Quad Op Ampl (Selected for NF)	Raytheon RC4156N
<b>U10</b> 3, U104		Ι	96A8818	Integraled Circuit, Audio Power Amplifier	National Semiconductor LM386N-4
U105	1		86A8900	Opto-Isolator	None
U106	I	1	864808	Integrated Circuit, Quad Op Ampl	Raytheon RC4156N
<b>U2</b> 01	1		86A8819	Integrated Circuit, Dual Comparator	Motorola LM393N
U202	<b>k</b> 	I	86A8820	Integraled Circuit, 10V Regulator	TI UA78L10ACLP
U301		J	96A806	Integraled Circuit, Quad Comparator	Raytheon LM339DB
Parts listed as Kit humber is :	RKC Kits s shown will	houk be s	d be ordered hipped in R	Parts listed as RKC Kits should be ordered by that kit number. Orders received for piece parts where RKC Kit number is shown will be shipped in RKC quantities.	ived for piece parts where RKC



## **CIRCUIT DIAGRAM**



7

### The three 3-socket professional audio input connec-

tors are individually switchable to balanced 600-ohm line or low-impedance microphone level. In the MIC position, either simplex (phantom) or A-B power is available at each input for powering condenser microphones. Each input transformer is Mumetal shielded for maximum resistance to electrical hum. A single-pin coaxial 12 Vdc external power jack permits the mixer to be powered from an 11 to 18 volt source such as a video tape recorder, automotive electrical system or ac power converter. Such an external source will also provide simplex power to the microphone inputs, but a battery is still required for A-B power. The mixer requires 11 to 18 Vdc for operating power. Internal power is supplied by **two standard rectangular 9-volt alkaline batteries** (Duracell MN1604 or equivalent) which also provide simplex (phantom) power to the microphone inputs. Battery life is approximately 8 hours. IMPORTANT: Use only alkaline batteries.



When powering the mixer from an external source, the batteries may be left in place as backup in case of failure of the source. Switchover to battery power is performed by removing the plug from the 12 Vdc jack. To prevent the possibility of damage caused by leaking batteries, remove the batteries during any prolonged period of storage or nonuse.

The **Slate pushbutton** inserts a 1-second low-frequency tone (400 Hz) each time it is depressed, and it keeps the slate microphone on as long as it is depressed.

Individual Lo-Cut filter switches for each input reduce lowfrequency interference from air-conditioner or fan noise, wind, strong hum fields, or similar sources. The filters insert a 7 dB rolloff at 100 Hz with a slope of -6 dB per octave.

On **Channel 1, the Gain Control knob** pulls out to activate a 1 kHz tone oscillator that serves as a level-setting aid. The oscillator level is set with the Master control and is indicated on the VU Meter.

Each input channel has its own gain

control. The input clipping level for

microphones is from -47 to -17 dBV

depending on the channel control set-

ting. For line inputs, the clipping level

ranges from +3 to +33 dBV, again

depending on the control setting.

Using the On/Off switch to turn the power on starts the green Power On indicator LED flashing with a repetition rate of approximately 1 second. The LED continues to flash so long as the switch is on.

> The **VU Meter** is supplied set for 0 VU = +4 dBm. This level can be changed by an internal adjustment (see section on VU Meter Adjustment).

FP31 MIXER SLATE SHURE OUT IN OUT IN OUT IN OFF ON BATT LAMP

SOL SOL SOL SOL OUT IN 1 PULL 2 MIC 3 MASTER LIMITER PION

A built-in pushbutton-operated, electret condenser slate microphone can be used either for identifying recorded segments or as an emergency field microphone.

The **Master gain control** sets the output level at the Line/Mic and Tape Outputs. Gain is 40 dB from Mic In to Mic Out or from Line In to Line Out; 90 dB from Mic In to Line Out, 68 dB from Mic In to Tape Out, and 18 dB from Line In to Tape Out.

The **output Limiter** has a threshold of + 14 dBm at the 600-ohm Line output (4 dB below clipping), with comparable levels at the Mic and Tape outputs. The threshold can be internally adjusted down to + 3 dBm (see section on Limiter Threshold Adjustment). The Limiter attack time is 3 msec typical, with 500 msec typical recovery time, for unobtrusive operation.

The Limiter Threshold and VU Meter trimpots are located through screwdriver slots below the battery compartment and to the left of the A-B/Simplex switches.

The VU Lamp pushbutton momentarily illuminates the meter dial. An automatic timed release shuts off the lamp after 5 seconds. The lamp remains lit while the button is depressed.


The **red Peak LED** flashes to indicate the onset of limiting. When the Limiter is Out, the red LED acts as an overload indicator and begins flashing at 6 dB below output clipping level.

The **Battery check pushbutton** converts the VU Meter to a battery condition or circuit voltage indicator while the button is depressed.



A **3.5 mm mini jack** and a **quarter-inch phone jack** provide two stereo headphone outputs that can be used simultaneously. They are designed to drive mono or stereo headsets with impedances of 8 to 2,000 ohms. They can also be used to drive up to four Aux-level tape recorder or amplifier inputs.

A separate Phones volume control sets the level at the headphone outputs; maximum output is 1.6V RMS (+4 dBV) to 200 ohms. A third 9-volt battery is used to supply A-B power at each microphone input. When the input selector switch is in the Line position, the power is automatically off for that input.



A 3.5 mm mini jack provides an Aux-level Tape output with minimum clipping level of 0.5V RMS (-6 dBV).