


Quick Installation Guide

300Mbps Wireless N Access Point

MODEL NO. TL-WA901ND

Package Contents




System Requirement


- Windows 8 · Windows 7 · Windows Vista · Windows XP
- Mac OS · UNIX · Linux

1 Connecting the Device for Configuration

- 1 Connect to the Access Point with the Ethernet cable or via wireless. The default wireless network name (SSID) of the Access Point is TP-LINK_AP_XXXXXX. Please check the label at the bottom of the unit for more details.



- 2 Plug the provided power adapter into the power jack on the back of the Access Point, and the other end to a standard electrical wall socket. Then press the **ON/OFF** button to power on the device.



Note If the distance between the outlet and the Access Point is too long to supply the power, you can refer to the Power over Ethernet (PoE) solution in **Appendix 1: With PoE Setup**.

- 3 LED explanation:


LED	Status	Indication
Power	Off	Power off.
	On	Power on.
System	Off	The device has a system error.
	On	The device is initialising.
	Flashing	The device is working properly.
Port	Off	There is no device linked to the corresponding port.
	On	There is a device linked to the corresponding port but no activity.
	Flashing	There is an active device linked to the corresponding port.
Wireless	Off	The Wireless function is disabled.
	Flashing	The Wireless function is enabled.
WPS	Slow Flash	A wireless device is connecting to the network by WPS function. This process will last in the first 2 minutes.
	On	A wireless device has been successfully added to the network by WPS function.
	Quick Flash	A wireless device failed to be added to the network by WPS function.

Note If the LEDs display abnormally, please check to see if all the cable connectors (power adapter and Ethernet cable) are well connected to your device.


2 Configuring the Device

Please make sure that your wired device's IP address is set as **Obtain an IP address automatically** before configuring the device.

- 1 Open your web browser, type in <http://tplinkap.net> in the address bar and press **Enter**.
- 2 A dialog box will prompt you for the **User name** and **Password**. Enter the default values (both are **admin**) and click **OK**.



- 3 After successfully logging in, the Quick Setup page will display. Click **Next**.



- 4 Then you will see the Start page shown as below. Select your region and click **Next** to continue.




- 5 The Operation Mode page will appear then. The TL-WA901ND supports up to five operation modes. Please select the proper operation mode according to your needs and click **Next**.




a) Access Point Mode Introduction

In this mode, the product will act as a wireless central hub for your wireless LAN clients, giving a wireless extension for your current wired network.




Settings

1. Create an easy-to-remember name for your wireless network.
2. Select **WPA-PSK/WPA2-PSK (Recommended)** mode and enter a wireless password below to prevent unauthorized access to your AP.
3. Click **Next**.




b) Repeater (Range Extender) Mode Introduction

In this mode, the product can extend the coverage of another wireless Access Point or Router.



Settings

1. Select the repeater mode, **Universal Repeater** is recommended as for better compatibility. Click **Survey**.
2. The window displaying a list of available SSIDs will appear.
3. Find the SSID of the main Router/AP that you want to repeat, and then click **Connect** in the corresponding row.
4. You will then return to the previous page.
5. The security mode will be selected automatically, please confirm it and enter the password of your main Router/AP. Click **Next**.




Note The setup for **WDS Repeater** mode is similar to that of **Universal Repeater** mode.

2 Configuring the Device (continued)

c) Bridge with AP mode

Introduction

In this mode, the product can wirelessly connect two or more remote LANs together.



Settings

1. Click **Survey**.
2. Find the SSID of the main Router/AP that you want to bridge, and then click **Connect** in the corresponding row. You will then return to the previous page.
3. The security mode will be selected automatically, please confirm it and enter the password that is the same as on the remote AP.
4. Create a name for the Local Wireless Network.
5. Click **Next**.

d) Client Mode

Introduction

In this mode, the product will act as a wireless adapter to connect your wired devices (eg. IPTV Set-top-box, Smart TVs, Game Consoles, DVD and Blu-ray Players, etc.) to a wireless network.




Settings

1. Click **Survey**.
2. Find the SSID of the Access Point/Router or WISP, and click **Connect** in the corresponding row. You will then return to the previous page.
3. The security mode will be selected automatically, please confirm it and enter the password that is the same as on the main Router/AP.
4. Click **Next**.

e) Multi-SSID Mode

Introduction

In this mode, the product can be assigned up to four SSIDs to work with your VLAN.



Settings

1. Select **ON** to enable VLAN function for this access point.
2. Configure the SSID and its corresponding VLAN ID. You can create up to 4 SSIDs and rename them.
3. Configure the wireless security for each SSID.
4. Click **Next**.



For the configuration of VLAN, please refer to the User Guide on the Resource CD.

- 6 The Network Setting page will appear then. It is recommended that you keep the default settings on this page. Click **Next**.




For advanced configurations on this page, please refer to the User Guide on the Resource CD.

- 7 After Network Settings, the Finish page will appear. Check your settings and click **Save** to save your settings on your desktop for future reference. Click the **Finish** button to finish the configuration of the Access Point.

- 8 Wait until the device restarts successfully.

Appendix 1: With PoE Setup

1. Turn off all your network devices, including your computer(s), power injector and the AP.
2. Connect your computer to the **LAN** port on the power injector with an Ethernet Cable.
3. Connect your AP to the **POE** port on the power injector with an Ethernet Cable.
4. Plug the provided power adapter into the **DC** jack on the power injector, and the other end to a standard electrical wall socket.
5. Then you can configure the AP according to **2 Configuring the device**.



1. Passive PoE Injector supports a maximum cable length up to 30 meters due to the environment.
2. For longer powered cable up to 100 meters, please choose TP-LINK's 48V PoE adapters: TL-POE200 or TL-POE150S & TL-POE10R.

Product information can be found on our official website <http://www.tp-link.com>.


Appendix 2: Troubleshooting

T1. How do I restore my AP's configuration to its factory default settings?

With the Access Point powered on, use a pin to press and hold the WPS/RESET button on the rear panel for 5 to 8 seconds before releasing it.



Once the Access Point is reset, the current configuration settings will be lost and you will need to reconfigure the Access Point.



T2. What can I do if I forget my password?

- 1) Try to use the default user name and password: admin, admin;
- 2) Referring to the file that you have saved in **Finish** last time you configured the device, the file will show you the user name and password that you have configured.
- 3) If the password is still not the correct one, then you can try to restore the Access Point's configuration to its factory default settings referring to previous section **T1** and try to reconfigure your AP by following the instructions of this QIG.

T3. What can I do if I cannot access the web-based configuration page?

- 1) Make sure your wired device's IP address is set as "Obtain an IP address automatically".
- 2) Check to see if you have input the correct address <http://tplinkap.net> in the address bar of your browser.
- 3) Please make sure your hardware connection is OK. You can confirm this by the LAN LED on the front panel of TL-WA901ND. If the LED of the LAN port, which your Ethernet cable is connected to, is lighting green, your hardware connection is OK; otherwise, please check your hardware connection carefully.
- 4) If the problem still persists, please feel free to contact our technical support.

Technical Support

- For more troubleshooting help, go to: <http://www.tp-link.com/en/support/faq>
- To download the latest Firmware, Driver, Utility and User Guide, go to: <http://www.tp-link.com/en/support/download>
- For all other technical support, please contact us by using the following details:

Global Tel: +86 755 2650 4400 E-mail: support@tp-link.com Service time: 24hrs, 7 days a week	Singapore Tel: +65 6284 0493 E-mail: support.sg@tp-link.com Service time: 24hrs, 7 days a week
UK Tel: +44 (0) 845 147 0017 E-mail: support.uk@tp-link.com Service time: 24hrs, 7 days a week	USA/Canada Toll Free: +1 866 225 8139 E-mail: support.usa@tp-link.com Service time: 24hrs, 7 days a week
Turkey Tel: 0850 7244 488 (Turkish Service) E-mail: support.tr@tp-link.com Service time: 09:00 to 21:00 7 days a week	Italy Tel: +39 023 051 9020 E-mail: support.it@tp-link.com Service time: Monday to Friday 09:00 to 13:00; 14:00 to 18:00
Ukraine Tel: 0800 505 508 E-mail: support.ua@tp-link.com Service time: Monday to Friday 10:00 to 22:00	Malaysia Tel: 1300 88 875 465 Email: support.my@tp-link.com Service time: 24hrs, 7 days a week
Brazil Toll Free: 0800 608 9799 (Portuguese Service) E-mail: suporte.br@tp-link.com Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00	Poland Tel: +48 (0) 801 080 618 / +48 223 606 363 (if calls from mobile phone) E-mail: support.pl@tp-link.com Service time: Monday to Friday, 09:00 to 17:00. GMT+1 or GMT+2 (Daylight Saving Time)
Indonesia Tel: (+62) 021 6386 1936 E-mail: support.id@tp-link.com Service time: Monday to Friday 09:00 to 18:00 *Except public holidays	France Tel: +33 (0) 820 800 860 (French service) Email: support.fr@tp-link.com Fee: 0.118 EUR/min from France Service time: Monday to Friday, 09:00 to 18:00 *Except French Bank holidays
Australia/New Zealand Tel: AU 1300 87 5465 NZ 0800 87 5465 E-mail: support.au@tp-link.com (Australia) support.nz@tp-link.com (New Zealand) Service time: 24hrs, 7 days a week	Switzerland Tel: +41 (0) 848 800 998 (German Service) E-mail: support.ch@tp-link.com Fee: 4-8 Rp/min, depending on rate of different time Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 17:30. GMT+1 or GMT+2 (Daylight Saving Time)
Germany/Austria Tel: +49 1805 875 465 (German Service) +49 1805 TPLINK +43 820 820 360 E-mail: support.de@tp-link.com Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 17:30. GMT+1 or GMT+2 (Daylight Saving Time in Germany) *Except bank holidays in Hesse	Russian Federation Tel: 8 (499) 754 5560 8 (800) 250 5560 (toll-free call from any RF region) E-mail: support.ru@tp-link.com Service time: From 10:00 to 18:00 (Moscow time) *Except weekends and holidays in Russian Federation