



S7012

Version 1.1

Copyright

Copyright © 2009 MiTAC International Corporation. All rights reserved. TYAN® is a registered trademark of MiTAC International Corporation.

Trademark

All registered and unregistered trademarks and company names contained in this manual are property of their respective owners including, but not limited to the following.

TYAN® is a trademark of MiTAC International Corporation.

Intel® Nehalem-EP Series and combinations thereof are trademarks of Intel Corporation.

AMI, AMI BIOS are trademarks of AMI Technologies.

Microsoft, Windows are trademarks of Microsoft Corporation.

SuSE is a trademark of Novell.

IBM, PC, AT, and PS/2 are trademarks of IBM Corporation.










Notice

Information contained in this document is furnished by MiTAC International Corporation and has been reviewed for accuracy and reliability prior to printing. MiTAC assumes no liability whatsoever, and disclaims any express or implied warranty, relating to sale and/or use of TYAN products including liability or warranties relating to fitness for a particular purpose or merchantability. MiTAC retains the right to make changes to product descriptions and/or specifications at any time, without notice. In no event will MiTAC be held liable for any direct or indirect, incidental or consequential damage, loss of use, loss of data or other malady resulting from errors or inaccuracies of information contained in this document.

Table of Contents

Check the box contents!	3
Chapter 1: Introduction	
1.1 Congratulations	5
1.2 Hardware Specifications	5
1.3 AST2050 Application	6
Chapter 2: Board Installation	
2.1 Board Image	8
2.2 Block Diagram	9
2.3 Board Parts, Jumpers and Connectors	10
2.4 Installing the Processor and Heatsink	20
2.5 Thermal Interface Material	23
2.6 Finishing Installing the Heatsink	24
2.7 Tips on Installing Motherboard in Chassis	25
2.8 Installing the Memory	26
2.9 Attaching Drive Cables	29
2.10 Installing Add-in Cards	30
2.11 Installing I/O Shield	31
2.12 Connecting External Devices	32
2.13 Installing the Power Supply	33
2.14 Finishing up	33
Chapter 3: BIOS Setup	
3.1 BIOS Main Menu	37
3.2 Advanced Menu	38
3.3 PCI PnP Menu	63
3.4 Boot Menu	65
3.5 Security Menu	69
3.6 Chipset Menu	70
3.7 Exit Menu	75
Chapter 4: Diagnostics	
4.1 Beep Codes	77
4.2 Flash Utility	77
4.3 AMI BIOS Post Code	78
Glossary	81
Technical Support	87

Check the box contents!

	1x S7012 motherboard
	2 x mini SAS Cable (optional)
	6 x Serial ATA Cable
	1 x USB2.0 cable
	1 x S7012 User's Manual
	1 x S7012 Quick Reference Guide
	1 x I/O Shield Installation Guide
	1 x TYAN Installation CD
	1 x I/O shield

If any of these items are missing, please contact your vendor/dealer for replacement before continuing with the installation process.

NOTE

Chapter 1: Introduction

1.1 - Congratulations

You have purchased one of the most powerful server solutions. Based on Intel® 5520 and ICH10R chipsets, the S7012 is designed to support up to two Nehalem-EP Series processors and up to 144GB DDR3-800/1033/1066/1333 memory, providing a rich feature set and incredible performance. Leveraging advanced technology from Intel, the S7012 is capable of offering scalable 32 and 64-bit computing, high-bandwidth memory design, and lightning-fast PCI-E bus implementation.

The S7012 not only empowers your company in today's demanding IT environment but also offers a smooth path for future application usage. All of this provides the S7012 the power and flexibility to meet the needs of nearly any server application.

Remember to visit TYAN's Website at <http://www.tyan.com>. There you can find information on all of TYAN's products with FAQs, online manuals and BIOS upgrades.

1.2 - Hardware Specifications

Processor	Supported CPU Series	Intel Xeon Processor 5500 Series	
	Socket Type / Q'ty	LGA1366 / (2)	
	Thermal Design Power (TDP) wattage	Max up to 130W	
	System Bus	Up to 4.8/ 5.86/ 6.4GT/s with Intel QuickPath Interconnect (QPI) support	
Chipset	IOH / ICH	Intel 5520 / ICH10R	
	Super I/O	Winbond W83627DHG	
Memory	Supported DIMM Qty	(18) DIMM slots	
	DIMM Type / Speed	DDR3 800/1066/1333* RDIMM/UDIMM / * limit 1 per channel for 1333MHz speed	
	Capacity	Up to 144GB at launch w/ dual rank RDIMMs	
	Memory channel	3 Channels per CPU	
Expansion Slots	Memory voltage	1.5V	
	PCI-E	(1) PCI-E x8 slot (w/ x4 link) / (4) PCI-E Gen.2 x8 slots	
LAN	Port Q'ty	(4)	
	Controller	Intel 82574L / Intel 82576EB	
Storage	SAS (optional)	Connector (2) Mini-SAS connectors (totally support 8 ports) Controller LSI SAS1068E Speed 3.0 Gb/s RAID RAID 0/1/1E (LSI Integrated RAID)	
	SATA	Connector	(6) SATA
		Controller	ICH10R
		Speed	3.0 Gb/s
		RAID	RAID 0/1/10/5 (Intel Matrix RAID)
	Graphic	Connector type	D-Sub 15-pin

Input /Output	Resolution	1600x1200@60Hz
	Chipset	Aspeed AST2050
	USB	(7) USB2.0 ports (4 at rear, 2 via cable, 1 type A onboard)
	COM	(1) port (rear)
	SAS	(2) Mini-SAS (4-in-1) connectors
	VGA	(1) D-Sub 15-pin VGA port
	RJ-45	(4) GbE ports
	Power	SSI 24-pin + 8-pin + 8-pin power connectors / EPS12V
	Front Panel	(1) 2x12-pin SSI front panel header
	SATA	(6) SATA-II connectors
System Monitoring	Chipset	Winbond W83793G
	Voltage	Monitors voltage for CPU, memory, chipset & power supply
	Fan	Total (5) 4-pin headers / Total (5) 8-pin headers
	Temperature	Monitors temperature for CPU & system environment
	Others	Chassis intrusion detection / Watchdog timer support
Server Management	Onboard Chipset	Onboard Aspeed AST2050
	AST2050 IPMI Feature	IPMI 2.0 compliant baseboard management controller (BMC) / Supports storage over IP and remote platform-flash/ BIOS update / USB 2.0 virtual hub
	AST2050 iKVM Feature	24-bit high quality video compression / Dual 10/100 Mb/s MAC interfaces
BIOS	Brand / ROM size	AMI / 4MB
	Feature	Plug and Play (PnP) /PCI2.3 /WfM2.0 /SMBIOS2.3 /PXE boot / ACPI 2.0 power management /Power on mode after power recovery / User-configurable H/W monitoring / Auto-configurable of hard disk types / Multiple boot options
Form Factor	Form Factor	SSI EEB
	Board Dimension	12"x13" (305x330mm)
Operating System	OS supported list	Please refer to our OS supported list. http://www.tyan.com/tech/os_support1.aspx
Regulation	FCC (DoC)	Class B
	CE (DoC)	Yes
Operating Environment	Operating Temp.	10° C ~ 35° C (50° F ~ 95° F)
	Non-operating Temp.	- 40° C ~ 70° C (-40° F ~ 158° F)
	In/Non-operating Humidity	90%, non-condensing at 35° C
RoHS	RoHS 6/6 Compliant	Yes
Package Contains	Motherboard	(1) S7012 Motherboard
	Manual	(1) User's manual / (1) Quick Ref. Guide (1) IO Shield QR
	Installation CD	(1) TYAN installation CD
	I/O Shield	(1) I/O Shield
	SATA	(6) SATA signal cables
	Cable	(2) Mini-SAS (2x SFF-8470) cables (1) CCBL-035J, 2-port USB bracket cable
Optional accessories for future upgrade	Riser Card	M2091, PCI-E 1U riser card (left)
	Cable	(1) CCBL-0615, COM port bracket cable / (1) CCBL-0311, SATA 1-to-2 power cable / (1) CCBL-035J, 2-port USB bracket cable

1.3 - AST2050 Application

Please visit the TYAN Web Site at <http://www.tyan.com> to download the latest AST2050 User's Guide.

Chapter 2: Board Installation

You are now ready to install your motherboard. The mounting hole pattern of the S7012 matches the SSI EEB specification. Before continuing with installation, confirm that your chassis supports an SSI EEB motherboard.

How to install our products right... the first time


The first thing you should do is reading this user's manual. It contains important information that will make configuration and setup much easier. Here are some precautions you should take when installing your motherboard:

- (1) Ground yourself properly before removing your motherboard from the antistatic bag. Unplug the power from your computer power supply and then touch a safely grounded object to release static charge (i.e. power supply case). For the safest conditions, TYAN recommends wearing a static safety wrist strap.
- (2) Hold the motherboard by its edges and do not touch the bottom of the board, or flex the board in any way.
- (3) Avoid touching the motherboard components, IC chips, connectors, memory modules, and leads.
- (4) Place the motherboard on a grounded antistatic surface or on the antistatic bag that the board was shipped in.
- (5) Inspect the board for damage.

The following pages include details on how to install your motherboard into your chassis, as well as installing the processor, memory, disk drives and cables.

NOTE**DO NOT APPLY POWER TO THE BOARD IF IT HAS BEEN DAMAGED.**


2.1- Board Image



S7012


This picture is representative of the latest board revision available at the time of publishing. The board you receive may or may not look exactly like the above picture.

2.2 - Block Diagram



S7012

2.3 - Board Parts, Jumpers and Connectors




This diagram is representative of the latest board revision available at the time of publishing. The board you receive may not look exactly like the above diagram.

Jumper Legend

	OPEN - Jumper OFF, without jumper cover
	CLOSED – Jumper ON, with jumper cover

Jumper/Connector	Function
J9 (TYFP1)	Standard Front Panel Connector
J16	BMC I ² C Bus Header
J34	USB Front Panel Header (blue)
J18	COM2 Connector
J24	PSMI Connector
J6	Chassis Intrusion Header
J35	CPLD JTAG Header
USB3	Type-A USB Connector
J33	ICH SGPIO Header
J15	Port 80 Header
J41/J42/J43/J44/J45	8-pin 4056 Fan Connector (reserved for BB)
J2/J8/J36/J37/J38	4-pin Fan Connector
J39/J40	Reset Switch/Power Switch
J3	LSI 1068E Enable/Disable Jumper Pin 1-2 closed: Enable (Default) Pin 2-3 closed: Disable
J7	BMC Reset Jumper NC: Default Pin 1-2 closed: Disable BMC
JP3	Clear CMOS Jumper Pin 1-2 closed: Normal (Default) Pin 2-3 closed: Clear
JP1/JP2	COM2 Switch Jumper Pin 1-2 closed: SIO to COM2 (Default) Pin 2-3 closed: BMC UART2 to COM2
JP4	LSI 1068E Device ID Select Jumper Pin 1-2 closed: (Default) Pin 2-3 closed: Device ID bit [0]=0b1



J18: COM2 Connector

	<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>DCD</td> <td>2</td> <td>DSR</td> </tr> <tr> <td>3</td> <td>RXD</td> <td>4</td> <td>RTS</td> </tr> <tr> <td>5</td> <td>TXD</td> <td>6</td> <td>CTS</td> </tr> <tr> <td>7</td> <td>DTR</td> <td>8</td> <td>RI</td> </tr> <tr> <td>9</td> <td>GND</td> <td>10</td> <td>KEY</td> </tr> </tbody> </table>	Pin	Signal	Pin	Signal	1	DCD	2	DSR	3	RXD	4	RTS	5	TXD	6	CTS	7	DTR	8	RI	9	GND	10	KEY
Pin	Signal	Pin	Signal																						
1	DCD	2	DSR																						
3	RXD	4	RTS																						
5	TXD	6	CTS																						
7	DTR	8	RI																						
9	GND	10	KEY																						

J15: PORT 80 Header

	<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>NC</td> <td>2</td> <td>V3P3</td> </tr> <tr> <td>3</td> <td>NC</td> <td>4</td> <td>FRAME</td> </tr> <tr> <td>5</td> <td>CLK_33M</td> <td>6</td> <td>GND</td> </tr> <tr> <td>7</td> <td>GND</td> <td>8</td> <td>LAD3</td> </tr> <tr> <td>9</td> <td>PLTRST</td> <td>10</td> <td>LAD2</td> </tr> <tr> <td>11</td> <td>NC</td> <td>12</td> <td>LAD1</td> </tr> <tr> <td>13</td> <td>NC</td> <td>14</td> <td>LAD0</td> </tr> </tbody> </table>	Pin	Signal	Pin	Signal	1	NC	2	V3P3	3	NC	4	FRAME	5	CLK_33M	6	GND	7	GND	8	LAD3	9	PLTRST	10	LAD2	11	NC	12	LAD1	13	NC	14	LAD0
Pin	Signal	Pin	Signal																														
1	NC	2	V3P3																														
3	NC	4	FRAME																														
5	CLK_33M	6	GND																														
7	GND	8	LAD3																														
9	PLTRST	10	LAD2																														
11	NC	12	LAD1																														
13	NC	14	LAD0																														

J16: BMC I²C Header


	<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>IPMB_DAT</td> <td>2</td> <td>GND</td> </tr> <tr> <td>3</td> <td>IPMB_CLK</td> <td>4</td> <td>NC</td> </tr> </tbody> </table>	Pin	Signal	Pin	Signal	1	IPMB_DAT	2	GND	3	IPMB_CLK	4	NC
Pin	Signal	Pin	Signal										
1	IPMB_DAT	2	GND										
3	IPMB_CLK	4	NC										

J34: USB Front Panel Header (Blue)


	<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>+5V</td> <td>2</td> <td>+5V</td> </tr> <tr> <td>3</td> <td>USB D-</td> <td>4</td> <td>USB D-</td> </tr> <tr> <td>5</td> <td>USB D+</td> <td>6</td> <td>USB D+</td> </tr> <tr> <td>7</td> <td>GND</td> <td>8</td> <td>GND</td> </tr> <tr> <td>9</td> <td>KEY</td> <td>10</td> <td>GND</td> </tr> </tbody> </table>	Pin	Signal	Pin	Signal	1	+5V	2	+5V	3	USB D-	4	USB D-	5	USB D+	6	USB D+	7	GND	8	GND	9	KEY	10	GND
Pin	Signal	Pin	Signal																						
1	+5V	2	+5V																						
3	USB D-	4	USB D-																						
5	USB D+	6	USB D+																						
7	GND	8	GND																						
9	KEY	10	GND																						

SATA0/1/2/3/4/5: Serial ATA Connector

	<table border="1"> <tbody> <tr> <td>7</td> <td>GND</td> </tr> <tr> <td>6</td> <td>RXP</td> </tr> <tr> <td>5</td> <td>RXN</td> </tr> <tr> <td>4</td> <td>GND</td> </tr> <tr> <td>3</td> <td>TXN</td> </tr> <tr> <td>2</td> <td>TXP</td> </tr> <tr> <td>1</td> <td>GND</td> </tr> </tbody> </table>	7	GND	6	RXP	5	RXN	4	GND	3	TXN	2	TXP	1	GND	<p>Connects to the Serial ATA ready drives via the Serial ATA cable.</p> <table border="1"> <tbody> <tr> <td>SATA0: J30</td> <td>SATA1: J29</td> </tr> <tr> <td>SATA2: J26</td> <td>SATA3: J23</td> </tr> <tr> <td>SATA4: J22</td> <td>SATA5: J21</td> </tr> </tbody> </table>	SATA0: J30	SATA1: J29	SATA2: J26	SATA3: J23	SATA4: J22	SATA5: J21
7	GND																					
6	RXP																					
5	RXN																					
4	GND																					
3	TXN																					
2	TXP																					
1	GND																					
SATA0: J30	SATA1: J29																					
SATA2: J26	SATA3: J23																					
SATA4: J22	SATA5: J21																					



J6: Chassis Intrusion Header

	<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal</th> <th>Pin</th> <th>Signal</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>INTRUDER#</td> <td>2</td> <td>GND</td> </tr> </tbody> </table>	Pin	Signal	Pin	Signal	1	INTRUDER#	2	GND
Pin	Signal	Pin	Signal						
1	INTRUDER#	2	GND						

J9 (TYFP1): Standard Front Panel Connector




PIN1	PIN3	PIN5	PIN7
PWRLED+	KEY	PWRLED-	HDLED+
PIN2	PIN4	PIN6	PIN8
+5VSB	IDLED+	IDLED-	WLED-
PIN9	PIN11	PIN13	PIN15
HDLED-	PWRSW+	GND	RSTSW
PIN10	PIN12	PIN14	PIN16
PSI_BMC_R-	LAN1LED+	LAN1LED-	SMBDAT
PIN17	PIN19	PIN23	
GND	IDLED_SW	TEMP-SENSOR	NMI_SW-
PIN18	PIN20	PIN22	PIN24
SMBCLK	INTRD#	LAN2LED+	LAN2LED-

NOTE1: +3.3V power rail is IDLED, WLED (Warning LED), LANLED


NOTE2: +5V power rail is PWRLED, HDLED

J24: PSMI Connector



Pin	Signal	Pin	Signal
1	SMB_CLK	2	SMB_DAT
3	SMBALERT	4	GND
5	V3P3		


J2/J8/J36/J37/J38: 4-pin Fan Header



Use this header to connect the cooling fan to your motherboard to keep the system at optimum performance levels.

J2: Rear 1 FAN
 J8: CPU0FAN
 J36: Front 2 FAN
 J37: Front 1 FAN
 J38: CPU1FAN


J41/J42/J43/J44/J45: 8-pin 4056 Fan Header (reserved for barebone)




DUAL_FAN_8P

Pin	Signal	Pin	Signal
1	PWM1	2	+12V
3	TACH1	4	GND
5	GND	6	TACH2
7	+12V	8	PWM2


J41: Sys5 FAN & Sys10 FAN
 J42: Sys4 FAN & Sys9 FAN
 J43: Sys3 FAN & Sys8 FAN
 J44: Sys2 FAN & Sys7 FAN
 J45: Sys1 FAN & Sys6 FAN




USB3: Type-A USB Connector

	Pin	Signal	Pin	Signal
	1	+5V	2	USB D-
	3	USB D+	4	GND



J33: ICH SGPIO Header

	Pin	Signal	Pin	Signal
	1	SMBCLK	2	SDATAOUT0
	3	SMBDAT	4	SDATAOUT1
	5	GND	6	SLOAD
	7	KEY	8	SCLOCK
	9	NC	10	NC



J35: CPLD JTAG Header


	Pin	Signal	Pin	Signal
	1	JTAG_TCK	2	GND
	3	JTAG_TDO	4	+3.3V
	5	JTAG_TMS	6	NC
	7	NC	8	KEY
	9	JTAG_TDI	10	GND

JP3: Clear CMOS Jumper



 <p>Normal (Default)</p>	<p>Use this jumper when you forgot your system/setup password or need to clear system BIOS setting.</p> <p>How to clear the CMOS data</p> <ul style="list-style-type: none"> - Power off system and disconnect power supply from AC source - Use jumper cap to close Pin_2 and 3 for several seconds to Clear CMOS - Replace jumper cap to close Pin_1 and 2 <p>Reconnect power supply to AC source Power on system</p>
 <p>Clear</p>	

JP1/JP2: COM2 Switch Jumper



	Pin 1-2 Closed: SIO to COM2 (Default)
	Pin 2-3 Closed: BMC UART2 to COM2`





J7: BMC Reset Jumper

	Pin 1-2 Open: Enable BMC(Default)
	Pin 1-2 Closed: Disable BMC

J1: LSI 1068E Device ID Select Jumper

	Pin 1-2 Closed: LSI 1068E Device ID (Default)
	Pin 2-3 Closed: :LSI 1068E Device ID – Device ID bit [0] =0b1

J3: LSI 1068E Enable/Disable Jumper

	Pin 1-2 Closed: Enable LSI 1068E (Default)
	Pin 2-3 Closed: Disable LSI 1068E

2.4 - Installing the Processor and Heat Sink

Your S7012 supports the latest processor technologies from Intel®. Check the TYAN website for latest processor support:


<http://www.tyan.com>

Processor Installation (LGA1366 Socket)

The processor should be installed carefully. Make sure you are wearing an antistatic strap and handle the processor as little as possible. Please note that both processors of the **same type and frequency** are required for optimal system performance.

NOTE: TYAN is not liable for damage as a result of operating an unsupported configuration.

Follow these instructions to install your processor.



The diagram is provided as a visual guide to help you install the socket processor and may not be an exact representation of the processor you have.

Step 1: Take off the CPU protection cap.

Step 2: Pull the CPU lever up to unlock the CPU socket (A). Then open the socket in the direction as shown (B).

Step 3: Place the CPU on the CPU socket, ensuring that pin 1 is located in the right direction.

Step 4: Close the CPU socket cover (A) and press the CPU socket lever down to secure the CPU (B).



Take care when installing the processor as it has very fragile connector pins below the processor that can bend and break if inserted improperly.

Heat Sink Installation

After installing the processor, you should proceed to install the heat sink. The CPU heat sink will ensure that the processor do not overheat and continue to operate at maximum performance for as long as you own them. The overheated processor is dangerous to the motherboard.

For the safest method of installation and information on choosing the appropriate heat sink, using heat sinks validated by Intel®.


Please refer to Intel's website at www.intel.com

The following diagram illustrates how to install heat sink onto the CPU of S7012.




Place the heat sink on top of the CPU and secure it to the motherboard using four screws clockwise.

CPU VRD/IOH Heat Dispersion Notice




Install FAN INTO ChASSIS TO LET AIR FLOW IN!!!
- To ensure that the board runs efficiently and does not overheat, make sure there is air flow around the CPU VRD/IOH (as shown) to help disperse the heat generated around the area.

2.5 - Thermal Interface Material



There are two types of thermal interface materials designed for use with the processors.

The most common material comes as a small pad attached to the heat sink at the time of purchase. There should be a protective cover over the material. Take care not to touch this material. Simply remove the protective cover and place the heat sink on the processor.



The second type of interface material is usually packaged separately. It is commonly referred to as 'thermal compound'. Simply apply a thin layer on to the CPU lid (applying too much will actually reduce the cooling).




Note:

Always check with the manufacturer of the heat sink & processor to ensure the Thermal Interface material is compatible with the processor & meets the manufacturer's warranty requirements.

2.6 - Finishing Installing the Heat Sink

After you have finished installing the heat sink onto the processor and socket, attach the end wire of the fan (which should already be attached to the heat sink) to the motherboard. The following diagram illustrates how to connect fans onto the motherboard.



Once you have finished installing all the fans you can connect your drives (hard drives, CD-ROM drives, etc.) to your motherboard.


2.7 - Tips on Installing Motherboard in Chassis

Before installing your motherboard, make sure your chassis has the necessary motherboard support studs installed. These studs are usually metal and are gold in color. Usually, the chassis manufacturer will pre-install the support studs. If you are unsure of stud placement, simply lay the motherboard inside the chassis and align the screw holes of the motherboard to the studs inside the case. If there are any studs missing, you will know right away since the motherboard will not be able to be securely installed.

Some chassis' include plastic studs instead of metal. Although the plastic studs are usable, TYAN recommends using metal studs with screws that will fasten the motherboard more securely in place.

Below is a chart detailing what the most common motherboard studs look like and how they should be installed.


Mounting the Motherboard



2.8 - Installing the Memory

Before installing memory, ensure that the memory you have is compatible with the motherboard and processor. Check the TYAN Web site at: www.tyan.com for details of the type of memory recommended for your motherboard.

The following diagram shows common types of DDR3 memory modules.




Key points to note before installing memory:

- Automatic memory bus frequency setting based on memory configuration and memory SPD information (to be adjusted by BIOS)
- Supports un-buffered ECC/Non-ECC modules
- Supports ECC Registered DDR3-800/1066/1333 memory modules
- All memory must be of the **same type and density**

The following tables outline the suggested rules for populating memory.

For 3 slots per channel			
RDIMM	DIMM3	DIMM2	DIMM1
Single Rank			x
		x	x
	x	x	x
Dual Rank			x
		x	x
	x	x	x
Quad Rank			x
		x	x
UDIMM	DIMM3	DIMM2	DIMM1
Single Rank			x
		x	x
Dual Rank			x
		x	x


X: indicates a populated slot
NOTE: Please insert memory from DIMMC1 and DIMMF1 first, following the order of C1, B1, A1 (blue slots), and F1, E1, D1 (blue slots).




Memory Installation Procedure

Follow these instructions to install memory modules into the S7012.


1. Press the locking levers in the direction shown in the following illustration.



2. Align the memory module with the socket. The memory module is keyed to fit only one way in the socket.



3. Seat the module firmly into the socket by gently pressing down until it sits flush with the socket. The locking levers pop up into place.



2.9 - Attaching Drive Cables


Attaching Serial ATA Cables

The S7012 is also equipped with 6 Serial ATA (SATA) channels. Connections for these drives are also very simple.

There is no need to set Master/Slave jumpers on SATA drives.

TYAN has supplied six SATA cables. If you are in need of other cables or power adapters please contact your place of purchase.

The following pictures illustrate how to connect a SATA drive



2.10 - Installing Add-In Cards

Before installing add-in cards, it's helpful to know if they are fully compatible with your motherboard. For this reason, we've provided the diagrams below, showing the slots that appear on your motherboard.

4 PCI-E x8 slots with PCI-E x8 signal



1 PCI-E x8 slot with PCI-E x4 signal



Simply find the appropriate slot for your add-in card and insert the card firmly. Do not force any add-in cards into any slots if they do not seat in place. It is better to try another slot or return the faulty card rather than damaging both the motherboard and the add-in card.

NOTE

YOU MUST ALWAYS unplug the power connector from the motherboard before performing system hardware changes. Otherwise you may damage the board and/or expansion device.

2.11 – Installing I/O Shield

Before you connect external devices, look into your motherboard package and take out the I/O shield. Follow the following instructions to install the I/O shield to your rear panel.

1. Preparation

- ✓ flat-head screw driver x 1
- ✓ long nose pliers x 1
- ✓ protective gloves x 1
- ✓ I/O shield x 1




2. Caution



Warning: To reduce the risk of personal injury, always wear gloves when handling the I/O shield.

Note that each I/O port has its breaking point which may be not in the same direction. Use the pliers, not your fingers, to grasp and turn the cap towards the breaking point to twist it off the shield.



3. Installation

Step 1.


Use the screw driver to push open the I/O port cap.

Step 2.

Use the pliers to grasp and twist the I/O port cap off the shield.


Step 3.

Repeat *Step 1* & *2* to remove the I/O caps in accordance with your rear I/O configuration and then attach the I/O shield to the rear panel.



2.12 - Connecting External Devices


The following diagram will detail the rear port stack for this S7012 motherboard:



NOTE: Peripheral devices can be plugged straight into any of these ports but software may be required to complete the installation.

Onboard LAN LED Color Definition

The three onboard Ethernet ports have green and yellow LEDs to indicate LAN status. The chart below illustrates the different LED states.

10/100/1000 Mbps LAN Link/Activity LED Scheme			
<div style="display: flex; justify-content: space-around;"> LEFT RIGHT </div> 		Left LED	Right LED
10 Mbps	Link	Slow Blinking Green	Off
	Active	Blinking Green	Off
100 Mbps	Link	Green	Green
	Active	Blinking Green	Green
1000 Mbps	Link	Green	Orange
	Active	Blinking Green	Orange
No Link		Off	Off

2.13 - Installing the Power Supply

There are three power connectors on your S7012.

- 24-pin (PW3)
- 8-pin (PW1, PW4)

1 x 24-pin 12V Power Connector (PW2)



2 x 8-pin 12V Power Connector (PW1, PW3)



NOTE: Please be aware that ATX 2.x, ATX12V and ATXGES power supplies may **not** be compatible with the board and can damage the motherboard and/or CPU(s).

Applying power to the board:

1. Connect the 12V 8-pin power connectors.
2. Connect the EPS/12V 24-pin power connector.
3. Connect power cable to power supply and power outlet.

NOTE

YOU MUST unplug the power supply before plugging the power cables to motherboard connectors.

2.14 - Finishing up

Congratulations on making it this far! You're finished setting up the hardware aspect of your computer. Before closing up your chassis, make sure that all cables and wires are connected properly, especially IDE cables and most importantly, jumpers. You may have difficulty powering on your system if the motherboard jumpers are not set correctly.

In the rare circumstance that you have experienced difficulty, you can find help by asking your vendor for assistance. If they are not available for assistance, please find setup information and documentation online at our website or by **calling your vendor's support line.**

NOTE

Chapter 3: BIOS Setup

About the BIOS

The BIOS is the basic input/output system, the firmware on the motherboard that enables your hardware to interface with your software. The BIOS determines what a computer can do without accessing programs from a disk. The BIOS contains all the code required to control the keyboard, display screen, disk drives, serial communications, and a number of miscellaneous functions. This chapter describes the various BIOS settings that can be used to configure your system.

The BIOS section of this manual is subject to change without notice and is provided for reference purposes only. The settings and configurations of the BIOS are current at the time of print and are subject to change, and therefore may not match exactly what is displayed on screen.

This section describes the BIOS setup program. The setup program lets you modify basic configuration settings. The settings are then stored in a dedicated, battery-backed memory (called NVRAM) that retains the information even when the power is turned off.

To start the BIOS setup utility:

1. Turn on or reboot your system.
2. Press during POST (<Tab> on remote console) to start the BIOS setup utility.

BIOS Menu Bar

The menu bar at the top of the windows lists these selections:

Main	To configure basic system setups
Advanced	To configure the advanced chipset features
PCI/PnP	To configure legacy Plug & Play or PCI settings
Boot	To configure system boot order
Security	To configure user and supervisor passwords
Chipset	To configure chipset management features
Exit	To exit setup utility

Setup Basics

The table below shows how to navigate in the setup program using the keyboard.

Key	Function
<F1>	General help window
<ESC>	Exit current menu
← → arrow keys	Select a different menu
↑ or ↓ arrow keys	Move cursor up/down
<Tab> or <Shift-Tab>	Cycle cursor up/down
<Home> or <End>	Move cursor to top/bottom of the window
<PgUp> or <PgDn>	Move cursor to next/previous page
<->	Select the previous value/setting of the field
<+>	Select the next value/setting of the field
<F8>	Load Fail Safe default configuration values of the menu
<F9>	Load the Optimal default configuration values of the menu
<F10>	Save and exit
<Enter>	Execute command or select submenu

Getting Help

Press [F1] to display a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press [ESC].

In Case of Problems

If you have trouble booting your computer after making and saving the changes with the BIOS setup program, you can restart the computer by holding the power button down until the computer shuts off (usually within 4 seconds); resetting by pressing CTRL-ALT-DEL; or clearing the CMOS.

The best advice is to only alter settings that you thoroughly understand. In particular, do not change settings in the Chipset section unless you are absolutely sure of what you are doing. The Chipset defaults have been carefully chosen either by TYAN or your system manufacturer for best performance and reliability. Even a seemingly small change to the Chipset setup options may cause the system to become unstable or unusable.

NOTE: The following pages provide the details of BIOS menu. Please be noticed that the BIOS menu are continually changing due to the BIOS updating. The BIOS menu provided are the most updated when this manual is written. Please visit TYAN's website at <http://www.tyan.com> for the information of BIOS updating.

3.1 - BIOS Main Menu

The Main BIOS Menu is the first screen that you can navigate. The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. "Grayed-out" options cannot be configured, options in blue can be changed.

The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often, a text message will accompany it.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
System Overview	Use [ENTER], [TAB] or [SHIFT-TAB] to select a field
AMIBIOS Version : Vx.xx Build Date : DD/MM/YY ID : xxxx_xxx Processor Genuine Intel® CPU @ xxxx @ x.xxGHz Speed : xxxx MHz Count : x System Memory Size : xxxx MB System Time [HH:MM:SS] System Date [MM:DD:YYYY]	Use [+] or [-] to configure system time. ← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Main		
System Time	HH : MM : SS	Set the system time
System Date	MM : DD : YYYY	Set the system date

3.2 - Advanced Menu

You can select any of the items in the left frame of the screen, such as Super I/O Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown below. The sub menus are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Advanced Settings	Options for CPU
WARNING: Setting wrong values in below sections may cause system to malfunction. ▶ CPU Configuration ▶ IDE Configuration ▶ Super IO Configuration ▶ USB Configuration ▶ ACPI Configuration ▶ AHCI Configuration ▶ Hardware Health Configuration ▶ IPMI 2.0 Configuration ▶ Intel VT-d Configuration ▶ PCI Express Configuration ▶ Remote Access Configuration ▶ Trusted Computing ▶ Onboard Devices Configuration	← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Advanced Settings		
CPU Configuration	Menu Item	Options for CPU
IDE Configuration	Menu Item	Configure the IDE device(s)
Super IO Configuration	Menu Item	Configures Super IO Chipset Win627DHG
USB Configuration	Menu Item	Configure the USB support
ACPI Configuration	Menu Item	Section for Advanced ACPI Configuration
AHCI Configuration	Menu Item	Section for Advanced AHCI Configuration
Hardware Health Configuration	Menu Item	Configure/monitor the Hardware Health
IPMI 2.0 Configuration	Menu Item	IPMI configuration including server monitoring and event log

Feature	Option	Description
Advanced Settings		
Intel VT-d Configuration	Menu Item	Configure Intel® Virtualization Technology for Directed I/O (VT-d) support
PCI Express Configuration	Menu Item	Configure PCI Express Support
Remote Access Configuration	Menu Item	Configure Remote Access
Trusted Computing	Menu Item	Configure settings related to Trusted Computing Information
Onboard Devices Configuration	Menu Item	Onboard Devices and PCI Add-on cards Enable/Disable

3.2.1 CPU Configuration

You can use this screen to view CPU Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced
PCI/PnP Boot Security Chipset Exit	
Configure advanced CPU settings Module Version: xx.xx	
Manufacturer: Intel Intel® CPU: @ xxxx @ x.xxGHz Frequency: xxxGHz BCLK Speed: xxxxMHz Cache L1: xxKB Cache L2: xxxxKB Cache L3: xxxxKB Ratio Status: Unlocked (Min:12, Max:18) Ratio Actual Value: 18	This should be enabled in order to enable or disable the "Enhanced Halt State". ← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
C1E Support Hardware Prefetcher Adjacent Cache Line Prefetch Max CPUID Value Limit Intel® Virtualization Tech Execute-Disable Bit Capability Intel® HT Technology Active Processor Cores A20M Intel® SpeedStep™ Tech Intel® TurboMode Tech Intel® C-STATE Tech C3 State C6 State C State package limit setting C1 Auto Demotion C3 Auto Demotion	[Enabled] [Enabled] [Enabled] [Disabled] [Enabled] [Enabled] [Enabled] [All] [Disabled] [Disabled] [Disabled] [Disabled] [ACPI C3] [Enabled] [Auto] [Enabled] [Enabled]

Feature	Option	Description
CPU Configuration		
Manufacturer	Read only	Displays information about CPU
Intel® CPU		
Frequency		
BCLK Speed		
Cache L1/L2/L3		
Ratio Status		
Ratio Actual Value		

C1E Support	Enabled	This should be enabled in order to enable or disable the "Enhanced Halt State".
	Disabled	
Hardware Prefetcher	Enabled	For UP platforms, leave it enabled. For DP/MP servers, it may use to tune performance to the specific application.
	Disabled	
Adjacent Cache Line Prefetch	Enabled	For UP platforms, leave it enabled. For DP/MP servers, it may use to tune performance to the specific application.
	Disabled	
Max CPUID Value Limit	Enabled	Disabled for Windows XP
	Disabled	
Intel® Virtualization Tech	Enabled	When enabled, a VMM can utilize the additional HW caps. Provided by Intel® Virtualization Tech. Note: A full reset is required to change the setting.
	Disabled	
Execute-Disable Bit Capability	Enabled	When disabled, force the XD feature flag to always return 0.
	Disabled	
Intel® HT Technology	Enabled	When disabled, only one thread per enabled core is enabled.
	Disabled	
Active Processor Cores	All	Number of cores to enable in each processor package
A20M	Disabled	Legacy OSes and APs may need A20M enabled.
	Enabled	
Intel® SpeedStep™ Tech	Disabled	Enable (GV3) Disable (GV3)
	Enabled	
NOTE: <i>Intel® TurboMode Tech</i> will appear when <i>Intel® SpeedStep™ Tech</i> is set to [Enabled].		
Intel® TurboMode Tech	Disabled	Turbo mode allows processor cores to run faster than marked frequency in specific condition.
	Enabled	
Intel® C-STATE Tech	Disabled	C-State: CPU idle is set to C2/C3/C4
	Enabled	
NOTE: <i>C3 State and C6 State</i> will appear when <i>Intel® SpeedStep™ Tech</i> is set to [Disabled].		

C3 State	ACPI C2	Nehalem C State action select
	ACPI C3	
	Disabled	
C6 State	Enabled	Nehalem C State action select
	Disabled	
C State package limit setting	Auto	Selected option will program into C state package limit register.
	C1	
	C3	
	C6	
	C7	
C1 Auto Demotion	Enabled	When enabled, CPU will conditionally demote C3/C6/C7 requests to C1 based on uncore auto-demote information.
	Disabled	
C3 Auto Demotion	Enabled	When enabled, CPU will conditionally demote C6/C7 requests to C3 based on uncore auto-demote information.
	Disabled	

3.2.2 IDE Configuration Sub-Menu

You can use this screen to select options for the IDE Configuration Settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
IDE Configuration		Options
SATA Configuration Configure SATA as		Disabled Compatible Enhanced
▶ SATA0 (PM) ▶ SATA1 (SM) ▶ SATA2 (PS) ▶ SATA3 (SS) ▶ SATA4 (3M) ▶ SATA5 (4M)	[Enhanced] [IDE] [Not Detected] [Not Detected] [Not Detected] [Not Detected] [Not Detected] [Not Detected]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Hard Disk Write Protect	[Disabled]	
IDE Detect Time Out (Sec)	[35]	

Feature	Option	Description
IDE Configuration		
SATA Configuration	Enhanced	Configure SATA devices
	Disabled	
	Compatible	
Configure SATA as	IDE	Select legacy IDE, RAID or AHCI as the SATA interface.
	RAID	
	AHCI	
Hard Disk Write Protect	Disabled	Enable/Disable device write protection. This will be effective only if device is accessed through BIOS.
	Enabled	
IDE Detect Time Out (Sec)	0~35 (at 5 interval)	Select the time out value for detecting ATA/ATAPI device(s).

3.2.2.1 SATA0 Sub-Menu

BIOS Setup Utility			
Main	Advanced	PCI/PnP	Boot Security Chipset Exit
SATA0		Selects the type of device connected to the system.	
Device: Not Detected			
Type	[Auto]	← → Select Screen	
LBA /Large Mode	[Auto]	↑ ↓ Select Item	
Block (Multi-Sector Transfer)	[Auto]	+/- Change Option	
PIO Mode	[Auto]	Tab Select Field	
DMA Mode	[Auto]	F1 General Help	
S.M.A.R.T.	[Auto]	F10 Save and Exit	
32 Bit Data Transfer	[Enabled]	ESC Exit	

Feature	Option	Description
SATA0		
Type	Auto	Selects the type of device connected to the system.
	Not Installed	
	CD/DVD	
	ARMD	
LBA/Large Mode	Auto	Auto: Enabled LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled. Disabled: Disabled LBA Mode.
	Disabled	
Block (Multi-Sector Transfer)	Auto	Disabled: The Data transfer from and to the device occurs one sector at a time. Auto: The Data transfer from and to the device occurs multiple sectors at a time if the device supports it.
	Disabled	
PIO Mode	Auto	Selects the PIO Mode. Select Auto to enhance hard disk performance by optimizing the hard disk timing.
	0~4 (at 1 interval)	
DMA Mode	Auto	Selects DMA Mode. Auto: Auto detected.
S.M.A.R.T.	Auto	S.M.A.R.T (Self-Monitoring Analysis and Reporting Technology) is a utility that monitors your disk status to predict hard disk failure.
	Disabled	
	Enabled	
32Bit Data Transfer	Enabled	Enables 32-bit to maximize the IDE hard disk data transfer rate.
	Disabled	

3.2.3 Super IO Configuration Sub-Menu

You can use this screen to select options for the Super I/O settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Configure Win627DHG Super IO Chipset		Allows BIOS to select Serial Port1 Base Address.
Serial Port1 Address	[3F8/IRQ4]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Serial Port2 Address	[2F8/IRQ3]	
Watchdog Mode	[Disabled]	
Chassis Intrusion detection	[Disabled]	

Feature	Option	Description
Configure Win627DHG Super IO Chipset		
Serial Port1 Address	3F8 IRQ4	Allow BIOS to select Serial Port1 Base Addresses.
	3E8 IRQ4	
	2E8 IRQ3	
	2F8 IRQ3	
	Disabled	
Serial Port2 Address	3F8 IRQ4	Allow BIOS to select Serial Port2 Base Addresses.
	3E8 IRQ4	
	2E8 IRQ3	
	2F8 IRQ3	
	Disabled	
Watchdog Mode	Disabled	POST: Watchdog timer counting, start at Power on, stop at OS Boot OS: Start at OS Boot Power on: Start at power on
	POST	
	OS	
	Power ON	
Chassis Intrusion detection	Disabled	When a chassis open event is detected, the BIOS will record the event and issue a warning beep.
	Enabled	

3.2.4 USB Configuration Sub-Menu

You can use this screen to view the USB Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
USB Configuration	Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected.
Module Version – x.xx.x – xx.x	
USB Devices Enabled: None	
Legacy USB Support	[Enabled]
USB 2.0 Controller Mode	[Hi Speed]
BIOS EHCI Hand-Off	[Enabled]
Hotplug USB FDD Support	[Auto]
▶ USB Mass Storage Device Configuration	
	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
USB Configuration		
Legacy USB Support	Disabled	Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected.
	Auto	
	Enabled	
USB 2.0 Controller Mode	Hi Speed	Configure the USB 2.0 controller in Hi Speed (480 Mbps) or Full Speed (12Mbps).
	Full Speed	
BIOS EHCI Hand-Off	Enabled	This is a work around for OSES without EHCI hand-off support. The EHCI ownership change should claim by EHCI driver.
	Disabled	
Hotplug USB FDD Support	Enabled	Enable or disable hotplug USB floppy support. A dummy FDD device is created that will be associated with the hotplugged FDD later. AUTO option creates this dummy device only if there is no USB FDD present.
	Disabled	
	Auto	

3.2.4.1 – USB Mass Storage Device Configuration Sub-Menu

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
USB Mass Storage Device Configuration	
USB Mass Storage Reset Delay [20 Sec] Device #1 USB Flash Disk Emulation Type [Auto]	Number of seconds POST waits for the USB mass storage device after start unit command ← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
USB Mass Storage Device Configuration		
USB Mass Storage Reset Delay	10 Sec	Number of seconds POST waits for the USB mass storage device after the start unit command
	20 Sec	
	30 Sec	
	40 Sec	
Device #1	Read only	
Emulation Type	Auto	If Auto, USB devices less than 530 MB will be emulated as Floppy and remaining as hard drive. Forced FDD option can be used to force a HDD formatted drive to boot as FDD (Ex. ZIP drive).
	Floppy	
	Forced FDD	
	Hard Disk	
	CDROM	

3.2.5 ACPI Configuration Sub-Menu

Use this screen to select options for ACPI. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. A description of the selected item appears on the right side of the screen. The settings are described on this page. The screen is shown below.

BIOS Setup Utility	
Main	Advanced
<p>ACPI Settings</p> <ul style="list-style-type: none"> ▶ Advanced ACPI Configuration ▶ Chipset ACPI Configuration 	<p>Advanced ACPI Configuration settings</p> <p>Use this selection to configure additional ACPI options.</p> <p>← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit</p>

3.2.5.1 Advanced ACPI Configuration Sub-Menu

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Advanced ACPI Configuration		Enable RSDP pointers to 64-bit Fixed System Description Tables. Di ACPI version has some.
ACPI Version Features	[ACPI v3.0]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
ACPI APIC support	[Enabled]	
AMI OEMB table	[Enabled]	
Headless mode	[Disabled]	
ACPI SRAT Table	[Enabled]	

Feature	Option	Description
Advanced ACPI Configuration		
ACPI Version Features	ACPI v3.0	Enable RSDP pointers to 64-bit Fixed System Description Tables. Di ACPI version has some.
	ACPI v2.0	
	ACPI v1.0	
ACPI APIC Support	Enabled	Include ACPI APIC table pointer to RSDT pointer list.
	Disabled	
AMI OEMB table	Enabled	Include OEMB table pointer to R(X)SDT pointer lists.
	Disabled	
Headless mode	Enabled	Enable or disable Headless operation mode through ACPI.
	Disabled	
ACPI SRAT Table	Enabled	Enable or Disable the building of ACPI SRAT Table.
	NUMA for SLES 11	
	Disabled	

3.2.5.2 Chipset ACPI Configuration Sub-Menu

BIOS Setup Utility	
Main	Advanced
PCI/PnP	Boot
Security	Chipset
	Exit
South Bridge ACPI Configuration	
Options	
Enabled	
Disabled	
← → Select Screen	
↑ ↓ Select Item	
+/- Change Option	
F1 General Help	
F10 Save and Exit	
ESC Exit	
Energy Lake Feature	[Disabled]
ACPI APIC SCI IRQ	[Disabled]
High Performance Event Timer	[Enabled]
HPET Memory Address	[FED0000h]

Feature	Option	Description
Chipset ACPI Configuration		
Energy Lake Feature	Disabled	Allow you to configure Intel's Energy Lake power management technology. If you are running a Media Center you can install the Intel VIIV software to get the correct driver; otherwise disable the Energy Lake feature in BIOS (it relates purely to Intel's Quick Resume feature, which is generally useless).
	Enabled	
ACPI APIC SCI IRQ	Disabled	Enable / Disable ACPI APIC SCI IRQ
	Enabled	
High Performance Event Timer	Enabled	Enable/disable High Performance Event Timer.
	Disabled	
HPET Memory Address	FED0000h	Choose HPET Memory Address
	FED01000h	
	FED02000h	
	FED03000h	

3.2.6 AHCI Configuration Sub-Menu

You can use this screen to view the AHCI Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
AHCI Settings	Enable for Supporting
AHCI BIOS Support	[Enabled]
AHCI CD/DVD Boot Time out	[35]
<ul style="list-style-type: none"> ▶ AHCI Port0 [Not Detected] ▶ AHCI Port1 [Not Detected] ▶ AHCI Port2 [Not Detected] ▶ AHCI Port3 [Not Detected] ▶ AHCI Port4 [Not Detected] ▶ AHCI Port5 [Not Detected] 	← → Select Screen ↑ ↓ Select Item +/- Change Field F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
AHCI Configuration		
AHCI BIOS Support	Enabled	Enable for supporting AHCI.
	Disabled	
AHCI CD/DVD Boot Time Out	0	Some SATA CD/DVD in AHCI mode need to wait ready longer.
	5	
	10	
	15	
	20	
	25	
	30	
	35	

3.2.6.1 AHCI Port0/Port1/Port2/Port3/Port4/Port5 Sub-Menu

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
AHCI Port0		Select the type of device connected to the system.
Device: Not Detected		
SATA Port0	[Auto]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
S.M.A.R.T.	[Enabled]	

Feature	Option	Description
AHCI Port0 Configuration		
SATA Port0	Auto	Select the type of device connected to the system.
	Not Installed	
S.M.A.R.T.	Enabled	S.M.A.R.T (Self-Monitoring Analysis and Reporting Technology) is a utility that monitors your disk status to predict hard disk failure.
	Disabled	

3.2.7 Hardware Health Configuration Sub-Menu

You can use this screen to view the Hardware Health Configuration Settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Hardware Health Configuration		
Auto FAN Control	[Disabled]	FAN power duty cycle is auto dynamic programmed in selected temperature range. Disabled: Fan Power On. Enabled: Fan Power Duty Cycle=50%(32°C)-100%(0°C), see max (CPUs, SIO) temperature
PWM Minimal Duty Cycle	[50% Duty Cycle]	
Hardware Health Event Monitoring		
<ul style="list-style-type: none"> ▶ Sensor Data Register Monitoring ▶ Memory Temperature Sensor Monitoring 		
← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit		

Feature	Option	Description
Hardware Health Configuration		
Auto FAN Control	Disabled	FAN power duty cycle is auto dynamic programmed in selected temperature range. Disabled: Fan Power On.
	Enabled	Enabled: Fan Power Duty Cycle=50%(32°C)-100%(0°C), see max (CPUs, SIO) temperature
PWM Minimal Duty Cycle	50% Duty Cycle	Duty Cycle control range:
	40% Duty Cycle	50%-100%
	30% Duty Cycle	40%-100%
	0% Duty Cycle	30%-100%
		0%-100%

3.2.7.1 Sensor Data Register Monitoring Sub-Menu

Advanced			
ID#	NAME	READING	STATUS
01	CPU0 (PECI)	: xx°C	xx
02	CPU1 (PECI)	: xx°C	xx
03	DIMM0 Area (RT3)	: xx°C	xx
04	PCI Area (RT2)	: xx°C	xx
0B	CPU0 VCORE	: x.xxx V	xx
0C	CPU1 VCORE	: x.xxx V	xx
0D	3.3V	: x.xxx V	xx
0E	+12V	: x.xxx V	xx
0F	VBAT	: x.xxxV	xx
20	Sys. 1 (CPU0)	: xxxx RPM	xx
21	Sys. 2 (CPU1)	: xxxx RPM	xx
22	Sys. 3 (Front 1)	: xxxx RPM	xx
23	Sys. 4 (Front 2)	: xxxx RPM	xx
24	Sys. 5 (Rear 1)	: xxxx RPM	xx
25	Sys. 6	: xxxx RPM	xx
26	Sys. 7	: xxxx RPM	xx
27	Sys. 8	: xxxx RPM	xx
▶ SDR Monitoring Next Page			← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit

▶ SDR Monitoring Next Page

Advanced			
ID#	NAME	READING	STATUS
28	Sys. 9	: xxxx RPM	xx
29	Sys. 10	: xxxx RPM	xx

Read only. It can not be modified in user mode.

3.2.7.2 Memory Temperature Monitoring Sub-Menu

Advanced			
Channel A Temperature (CPU0)		N/A	
Channel B Temperature (CPU0)		N/A	
Channel C Temperature (CPU0)		N/A	
Channel A Temperature (CPU1)		N/A	
Channel A Temperature (CPU1)		N/A	
Channel A Temperature (CPU1)		40°C	
			← Select Screen ↑ ↓ Select Item Tab Select Field F1 General Help F10 Save and Exit ESC Exit

Read only. It can not be modified in user mode.

3.2.8 IPMI 2.0 Configuration Sub-Menu

You can use this screen to view the IPMI 2.0 Configuration Settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
IPMI 2.0 Configuration		
Status of BMC	Working	← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit
▶ View BMC System Event Log		
Clear BMC System Event Log		
▶ Set LAN Configuration		
▶ Set PEF Configuration		
BMC Watch Dog Timer Action	[Disabled]	
BMC Alert LED and Beep	[Off]	
FW Key	[xxxxxxx]	

Feature	Option	Description
IPMI 2.0 Configuration		
Status of BMC	Read only	Display BMC status
Clear BMC System Event Log	[Enter]	Clear all events in BMC System Event Log.
BMC Watch Dog Timer Action	Disabled	Allows the BMC to reset or power down the system if the operating system crashes or hangs.
	Reset System	
	Power Down	
	Power Cycle	
BMC Alert LED and Beep	Off	BMC Alert LED and Beep On/Off
	On	
FW Key	[xxxxxxx]	Enter IPMI FW key to upgrade IPMI or iKVM function

3.2.8.1 View BMC System Event Log Sub-Menu

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Total Number of Entries: 260		Use +/- to traverse the event log.
SEL Entry Number	[1]	
SEL Record ID	xxxx	← → Select Screen
SEL Record Type	xxxx (System Event)	↑ ↓ Select Item
Event Timestamp	MM DD, YYYY HH:MM:SS	+/- Change Option
Generator ID	xxxx	Tab Select Field
Event Message Format Ver	xx (IPMI Ver 2.0)	F1 General Help
Event Sensor Type	xx (Voltage)	F10 Save and Exit
Event Sensor Number	xx	ESC Exit
Event Dir Type	xx	
Event Data	xx xx xx	

Read only. It can not be modified in user mode.

3.2.8.2 Set PEF Configuration Sub-Menu

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Set PEF Configuration Parameters Command		Enable or Disable PEF Support
PEF Support	[Disabled]	← → Select Screen
		↑ ↓ Select Item
		+/- Change Option
		Tab Select Field
		F1 General Help
		F10 Save and Exit
		ESC Exit

Feature	Option	Description
Set PEF Configuration Parameters Command		
PEF Support	Disabled	Enable or Disable PEF Support
	Enabled	

3.2.8.3 LAN Configuration Sub-Menu

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
LAN Configuration		
Channel Number Status	Channel number is OK	← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit
IP Address Configuration	[DHCP]	
IPMI DHCP		
Current IP Address in BMC	xxx.xxx.xxx.xxx	
Current Subnet Mask in BMC	xxx.xxx.xxx.xxx	
Current MAC Address in BMC	xx.xx.xx.xx.xx.xx	

Feature	Option	Description
LAN Configuration		
Channel Number Status	Read only	
IPMI DHCP	DHCP	IPMI IP Source STATIC/DHCP (Read only)
	STATIC	
Current IP Address in BMC	Read only	
Current Subnet Address in BMC	Read only	
Current MAC Mask in BMC	Read only	

3.2.9 Intel VT-d Configuration Sub-Menu

You can use this screen to view the Intel VT-d Configuration Settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
Intel VT-d Configuration		Options
Intel VT-d	[Enabled]	Enabled Disabled ← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Intel VT-d Configuration		
Intel VT-d	Enabled	Enable or disable Intel® Virtualization Technology for Directed I/O (VT-d) support. VT-d support on Intel platforms provides the capability to ensure improved isolation of I/O resources for greater reliability, security, and availability.
	Disabled	

3.2.10 PCI Express Configuration Sub-Menu

You can use this screen to configure the PCI Express Support. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
PCI Express Configuration		Enable or disable PCI Express L0s and L1 link power status.
Active State Power-Management	[Disabled]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
PCI Express Configuration		
Active State Power-Management	Enabled	Enable/disable PCI Express L0s and L1 link power status.
	Disabled	

3.2.11 Remote Access Configuration Sub-Menu

You can use this screen to view the Remote Access Configuration Menu. This feature allows access to the Server remotely via serial port. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Configure Remote Access type and parameters	
Select remote access type.	
Remote Access	[Disabled]
Serial Port Number	[COM1]
Base Address, IRQ	[3F8h, 4]
Serial Port Mode	[38400 8, n, 1]
Flow Control	[None]
Redirection After BIOS POST	[Always]
Terminal Type	[ANSI]
VT-UTF8 Combo Key Support	[Enabled]
Sredir Memory Display Delay	[No Delay]
← → Select Screen ↑ ↓ Select Item + - Change Option F1 General Help F10 Save and Exit ESC Exit	

Feature	Option	Description
Configure Remote Access type and parameters		
Remote Access	Disabled	Enables remote access to system through serial port.
	Enabled	
NOTE: The items listed below will appear when Remote Access is set to [Enabled].		
Serial Port Number	COM1	Select Serial Port for console redirection. Make sure the selected port is enabled.
	COM2	
Base Address, IRQ	Read only	
Serial Port Mode	115200 8,n,1	Select Serial Port settings.
	57600 8,n,1	
	38400 8, n, 1	
	19200 8,n,1	
Flow Control	9600 8,n,1	Select Flow Control for console redirection.
	None	
	Hardware	
	Software	

Feature	Option	Description
Configure Remote Access type and parameters		
Redirection After BIOS POST	Disabled	Disable: Turns off the redirection after POST
	Boot Loader	Boot Loader: Redirection is active during POST and during Boot Loader.
	Always	Always: Redirection is always active. <Some OSs may not work if set to Always>
Terminal Type	ANSI	Select the target terminal type.
	VT100	
	VT-UTF8	
VT-UTF8 Combo Key Support	Enabled	Enable VT-UTF8 Combination key Support for ANSI/VT100 terminals.
	Disabled	
Sredir Memory Display Delay	No Delay	Gives the delay in seconds to display memory information
	Delay 1 Sec	
	Delay 2 Sec	
	Delay 4 Sec	

3.2.12 Onboard Devices Configuration Sub-Menu

You can use this screen to view the Onboard Devices Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Onboard Device and PCI Slots Configuration	Select which graphics controller to use as the primary boot device.
Boots Graphic Adapter Priority	[Auto]
Onboard VGA	[Enabled]
LSI 1068E Chip	[Enabled]
Lan (82575)	[Enabled]
Lan OP-ROM	[Disabled]
Lan (82574-1)	[Auto]
Lan OP-ROM	[Disabled]
Lan (82574-2)	[Auto]
Lan OP-ROM	[Disabled]
	← → Select Screen ↑ ↓ Select Item +/- Change Option Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Onboard Device and PCI Slots Configuration		
Boots Graphic Adapter Priority	Auto	Select which graphics controller to use as the primary boot device.
	Onboard VGA	
Onboard VGA	Enabled	Enable/disable onboard VGA controller
	Disabled	
LSI 1068E Chip	Enabled	Enable/disable onboard LSI 1068E SAS controller.
	Disabled	
Lan (82575)	Enabled	Enable/disable Lan controller.
	Disabled	
Lan (82574-1) Lan (82574-2)	Auto	Enable/disable Lan controller
	Enabled	
	Disabled	
Lan OP-ROM	Enabled	Executed Lan OP-ROM or not
	Disabled	

3.3 - PCI PnP Menu

You can use this screen to view PnP (Plug & Play) BIOS Configuration Menu. This menu allows the user to configure how the BIOS assigns resources & resolves conflicts. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Advanced PCI/PnP Settings			Clear NVRAM during System Boot.			
WARNING: Setting wrong values in below sections may cause system to malfunction.						
Clear NVRAM [No] Plug & Play O/S [No] PCI Latency Timer [64] Allocate IRQ to PCI VGA [Yes] Palette Snooping [Disabled] PCI IDE BusMaster [Enabled]			← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit			

Feature	Option	Description
Advanced PCI/PnP Settings		
Clear NVRAM	No	Clears NVRAM during system Boot.
	Yes	
Plug & Play OS	Yes	No: lets the BIOS configure all the devices in the system. Yes: lets the operating system configure Plug and Play (PnP) devices not required for boot if your system has a Plug and Play operating system.
	No	
PCI Latency Timer	32	This setting controls how many PCI clocks each PCI device can hold the bus before another PCI device takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth. Values in units of PCI clocks for PCI device latency timer register.
	64	
	96	
	128	
	160	
	192	
	224	
248		

Allocate IRQ to PCI VGA	Yes	Yes: assigns IRQ to PCI VGA card if card requests IRQ.
	No	
Palette Snooping	Disabled	This is the default setting and should not be changed unless the VGA card manufacturer requires Palette Snooping to be Enabled. Enabled: informs the PCI devices that an ISA graphics device is installed in the system so the card will function correctly.
	Enabled	
PCI IDE BusMaster	Disabled	Enabled: BIOS uses PCI bus mastering for reading / writing to IDE drives.
	Enabled	

3.4 - Boot Menu

You can display Boot Setup option by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Boot Settings	Configures settings during System Boot.
<ul style="list-style-type: none"> ▶ Boot Settings Configuration ▶ Boot Device Priority ▶ Hard Disk Drives 	<p>← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit</p>

3.4.1 Boot Settings Configuration Sub-Menu

Use this screen to select options for the Boot Settings Configuration. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Boot Settings Configuration	Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.
<ul style="list-style-type: none"> Quick Boot [Disabled] Quiet Boot [Disabled] AddOn ROM Display Mode [Force BIOS] Bootup Num-Lock [On] Wait for 'F1' if Error [Enabled] Hit 'DEL' Message Display [Enabled] Interrupt 19 Capture [Enabled] Endless Boot [Disabled] 	<p>← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit</p>

Feature	Option	Description
Boot Settings Configuration		
Quick Boot	Enabled	This option allows user bypass BIOS self test during POST.
	Disabled	
Quiet Boot	Disabled	Disabled: displays normal POST messages. Enabled: displays OEM log instead of POST messages.
	Enabled	
Add On ROM Display Mode	Force BIOS	Allows user to force BIOS/Option ROM of add-on cards to be displayed during quiet boot.
	Keep Current	
Bootup Num-Lock	On	Selects Power-on state for Numlock.
	Off	
Wait for 'F1' If Error	Enabled	Waits for F1 key to be present if error occurs.
	Disabled	
Hit 'DEL' Message Display	Enabled	Displays "Press DEL to run Setup" in POST.
	Disabled	
Interrupt 19 Capture	Disabled	Enabled: allows option ROMs to trap interrupt 19.
	Enabled	
Endless Boot	Disabled	Enable/Disable endless loop boot from BBS table.
	Enabled	

3.4.2 Boot Device Priority

Use this screen to select options for the Boot Device Priority. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Boot Device Priority	Specifies the boot sequence from the available devices.
1st Boot Device	[xx,xxx-xxxxx:xxx]
2nd Boot Device	[xx,xxx-xxxxx:xxx]
3rd Boot Device	[xx,xxx-xxxxx:xxx]
	A device enclosed in parenthesis has been disabled in the corresponding type menu.
	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Boot Device Priority		
1st Boot Device 2nd Boot Device 3rd Boot Device	xx,xxx-xxxxx:xxx	Settings for boot priority. These can be customized depending on your preference.
	xx,xxx-xxxxx:xxx	
	Disabled	

3.4.3 Hard Disk Drives

Use this screen to select options for the Hard Disk Drives. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
Hard Disk Drives	Specifies the boot sequence from the available devices.
1st Drive [xxxxxxx]	← → Select Screen ↑ ↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Hard Disk Drives		
1st Drive	xx,xxx-xxxxx:xxx	Specifies the boot sequence from the available devices.
	Disabled	

3.5 - Security Menu

The system can be configured so that all users must enter a password every time the system boots or when BIOS Setup is entered, using either the Supervisor password or User password. The Supervisor and User passwords activate two different levels of password security. If you select password support, you are prompted for a one to six character password. Type the password on the keyboard. The password does not appear on the screen when typed. Make sure you write it down. If you forget it, you must clear CMOS and reconfigure.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Security Settings				Install or change the password.		
Supervisor Password : Not Installed User Password : Not Installed				← → Select Screen ↑ ↓ Select Item		
Change Supervisor Password Change User Password				+/- Change Option F1 General Help F10 Save and Exit ESC Exit		
Boot Sector Virus Protection			[Disabled]			

Feature	Option	Description
Security Settings		
Supervisor Password:	Not Installed	If the password has been set, Installed displays. If no password is set, Not Installed displays.
	Installed	
User Password:	Not Installed	If the password has been set, Installed displays. If no password is set, Not Installed displays.
	Installed	
Change Supervisor Password	—	Selects this option to change or install Supervisor Password.
Change User Password	—	Selects this option to change or install User Password.
Boot Sector Virus Protection	Disabled	When it is set to [Enabled], BIOS will issue a virus warning message and beep if a write to the boot sector or the partition table of the HDD is attempted.
	Enabled	

3.6 - Chipset Menu

This menu allows the user to customize functions of the Intel Chipsets. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Advanced Chipset Settings					Configure CPU Bridge features.	
WARNING: Setting wrong values in below sections may cause system to malfunction. <ul style="list-style-type: none"> ▶ CPU Bridge Configuration ▶ North Bridge Configuration ▶ South Bridge Configuration ▶ ME Subsystem Configuration 					← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit	

3.6.1 CPU Bridge Configuration Sub-Menu

This menu gives options for customizing CPU Bridge Chipset settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
CPU Bridge Chipset Configuration				Transition the links to the specified speed when transitioning the links to full-speed. (if supported by all components)		
CPU Revision		xx				
Current QPI Frequency		x.xxx GT				
Current Memory Frequency		x.xxx GT				
QPI Frequency		[Auto]	← → Select Screen ↑ ↓ Select Item			
Memory Frequency		[Auto]	Enter Go to Sub Screen			
Memory Mode		[Independent]	F1 General Help			
Demand Scrubbing		[Disabled]	F10 Save and Exit			
Patrol Scrubbing		[Disabled]	ESC Exit			

Feature	Option	Description
North Bridge Chipset Configuration		
CPU Revision	Read only	
Current QPI Frequency		
Current Memory Frequency		
QPI Frequency	Auto	Transition the links to the specified speed when transitioning the links to full-speed. (if supported by all components)
	4.800 GT	
	5.866 GT	
	6.400 GT	
Memory Frequency	Auto	Force a DDR frequency slower than the command tCK detected via SPD
	Force DDR-800	
	Force DDR-1066	
	Force DDR-1333	
Memory Mode	Independent	Independent: independent channel
	Channel Mirroring	Mirroring: mirrors channel space between channels
	Lockstep	Lockstep: lockstep between channel 0 and 1
	Sparing	Spare: sparing mode
Demand Scrubbing	Disabled	ECC demand scrubbing enabled / disabled
	Enabled	
Patrol Scrubbing	Disabled	ECC patrol scrubbing enabled / disabled
	Enabled	

3.6.2 North Bridge Configuration Sub-Menu

This menu gives options for customizing North Bridge Chipset settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility		
Main	Advanced	PCI/PnP Boot Security Chipset Exit
North Bridge Chipset Configuration		Crystal Beach/DMA Configuration
NB Revision	xx	← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit
Current QPI Frequency	x.xxx GT	
Crystal Beach/DMA	[Enabled]	
Crystal Beach/DCA	[Disabled]	
Coarse-Grained Clock Gating	[Enabled]	

Feature	Option	Description
North Bridge Chipset Configuration		
NB Revision	Read only	
Current QPI Frequency		
Crystal Beach/DMA	Disabled	Crystal Beach/DMA Configuration
	Enabled	
NOTE: The item listed below will appear when Crystal Beach/DMA is set to [Enabled].		
Crystal Beach/DCA	Disabled	Crystal Beach/DCA Configuration
	Enabled	
Coarse-Grained Clock Gating	Enabled	Enable/disable Coarse-Grained Clock Gating
	Disabled	

3.6.3 South Bridge Configuration Sub-Menu

This menu gives options for customizing South Bridge Chipset settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
South Bridge Chipset Configuration	
SLP_S4# Min. Assertion Width [4~5 seconds] Restore on AC Power Loss [Power Off]	Options Enabled Disabled ← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
South Bridge Chipset Configuration		
SLP_S4# Min. Assertion Width	4~5 seconds	Select Timing for SLP_S4#
	3~4 seconds	
	2~3 seconds	
	1~2 seconds	
Restore on AC Power Loss	Power Off	Configure how the system board responds to a power failure.
	Power On	
	Last State	

3.6.4 ME Subsystem Configuration Sub-Menu

This menu provides selection for ME subsystem configuration. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility	
Main	Advanced PCI/PnP Boot Security Chipset Exit
ME Subsystem Configuration	
ME-HECI	[Enabled]
← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit	

Feature	Option	Description
South Bridge Chipset Configuration		
ME-HECI	Enabled	Enable or disable ME-HECI
	Disabled	

3.7 - Exit Menu

You can display an Exit BIOS Setup option by highlighting it Arrow (↑/↓) keys and pressing Enter.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Exit Options					Exit system setup after saving the changes.	
Save Changes and Exit Discard Changes and Exit Discard Charges Load Optimal Defaults Load Failsafe Defaults					F10 key can be used for this operation. ← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit	

Save Changes and Exit

Use this option to exit setup utility and re-boot.
 All new selections you have made are stored into CMOS.
 System will use the new settings to boot up.

Discard Changes and Exit

Use this option to exit setup utility and re-boot.
 All new selections you have made are not stored into CMOS.
 System will use the old settings to boot up.

Discard Changes

Use this option to restore all new setup values that you have made but not saved into CMOS.

Load Optimal Defaults

Use this option to load default performance setup values.
 Use this option when system CMOS values have been corrupted or modified incorrectly.

Load Failsafe Defaults

Use this option to load all default failsafe setup values.
 Use this option when troubleshooting.

NOTE

Chapter 4: Diagnostics

NOTE: if you experience problems with setting up your system, always check the following things in the following order:

Memory, Video, CPU

By checking these items, you will most likely find out what the problem might have been when setting up your system. For more information on troubleshooting, check the TYAN website at: <http://www.tyan.com>.

4.1 - Beep Codes

Fatal errors, which halt the boot process, are communicated through two kinds of audible beeps.

- Eight short beeps: It indicates that a video error has occurred.
 - A single long beep repeatedly: It indicates that a DRAM error has occurred.
- The most common type of error is a memory error.

Before contacting your vendor or TYAN Technical Support, be sure that you note as much as you can about the beep code length and order that you experience. Also, be ready with information regarding add-in cards, drives and O/S to speed the support process and come to a quicker solution.

4.2 - Flash Utility

Every BIOS file is unique for the motherboard it was designed for. For Flash Utilities, BIOS downloads, and information on how to properly use the Flash Utility with your motherboard, please check the TYAN web site: <http://www.tyan.com/>

NOTE: Please be aware that by flashing your BIOS, you agree that in the event of a BIOS flash failure, you must contact your dealer for a replacement BIOS. There are no exceptions. TYAN does not have a policy for replacing BIOS chips directly with end users. In no event will TYAN be held responsible for damages done by the end user.

4.3 - AMIBIOS Post Code

The POST code checkpoints are the largest set of checkpoints during the BIOS pre-boot process. The following table describes the type of checkpoints that may occur during the POST portion of the BIOS:

Checkpoint	Description
03	Disable NMI, Parity, video for EGA, and DMA controllers. Initialize BIOS, POST, Runtime data area. Also initialize BIOS modules on POST entry and GPNV area. Initialized CMOS as mentioned in the Kernel Variable "wCMOSFlags."
04	Check CMOS diagnostic byte to determine if battery power is OK and CMOS checksum is OK. Verify CMOS checksum manually by reading storage area. If the CMOS checksum is bad, update CMOS with power-on default values and clear passwords. Initialize status register A. Initializes data variables that are based on CMOS setup questions. Initializes both the 8259 compatible PICs in the system
05	Initializes the interrupt controlling hardware (generally PIC) and interrupt vector table.
06	Do R/W test to CH-2 count reg. Initialize CH-0 as system timer. Install the POSTINT1Ch handler. Enable IRQ-0 in PIC for system timer interrupt. Traps INT1Ch vector to "POSTINT1ChHandlerBlock."
08	Initializes the CPU. The BAT test is being done on KBC. Program the keyboard controller command byte is being done after Auto detection of KB/MS using AMI KB-5.
0A	Initializes the 8042 compatible Key Board Controller.
0B	Detects the presence of PS/2 mouse.
0C	Detects the presence of Keyboard in KBC port.
0E	Testing and initialization of different Input Devices. Also, update the Kernel Variables. Traps the INT09h vector, so that the POST INT09h handler gets control for IRQ1. Uncompress all available language, BIOS logo, and Silent logo modules.
13	Early POST initialization of chipset registers.
24	Uncompress and initialize any platform specific BIOS modules.
30	Initialize System Management Interrupt.
2A	Initializes different devices through DIM. See <i>DIM Code Checkpoints</i> section of document for more information.
2C	Initializes different devices. Detects and initializes the video adapter installed in the system that have optional ROMs.
2E	Initializes all the output devices.
31	Allocate memory for ADM module and uncompress it. Give control to ADM module for initialization. Initialize language and font modules for ADM. Activate ADM module.
33	Initializes the silent boot module. Set the window for displaying text information.
37	Displaying sign-on message, CPU information, setup key message, and any OEM specific information.

Checkpoint	Description
38	Initializes different devices through DIM. See <i>DIM Code Checkpoints</i> section of document for more information.
39	Initializes DMAC-1 & DMAC-2.
3A	Initialize RTC date/time.
3B	Test for total memory installed in the system. Also, Check for DEL or ESC keys to limit memory test. Display total memory in the system.
3C	Mid POST initialization of chipset registers.
40	Detect different devices (Parallel ports, serial ports, and coprocessor in CPU, ... etc.) successfully installed in the system and update the BDA, EBDA...etc.
50	Programming the memory hole or any kind of implementation that needs an adjustment in system RAM size if needed.
52	Updates CMOS memory size from memory found in memory test. Allocates memory for Extended BIOS Data Area from base memory.
60	Initializes NUM-LOCK status and programs the KBD typematic rate.
75	Initialize Int-13 and prepare for IPL detection.
78	Initializes IPL devices controlled by BIOS and option ROMs.
7A	Initializes remaining option ROMs.
7C	Generate and write contents of ESCD in NVRam.
84	Log errors encountered during POST.
85	Display errors to the user and gets the user response for error.
87	Execute BIOS setup if needed / requested.
8C	Late POST initialization of chipset registers.
8E	Program the peripheral parameters. Enable/Disable NMI as selected
90	Late POST initialization of system management interrupt.
A0	Check boot password if installed.
A1	Clean-up work needed before booting to OS.
A2	Takes care of runtime image preparation for different BIOS modules. Fill the free area in F000h segment with 0FFh. Initializes the Microsoft IRQ Routing Table. Prepares the runtime language module. Disables the system configuration display if needed.
A4	Initialize runtime language module.
A7	Displays the system configuration screen if enabled. Initialize the CPU's before boot, which includes the programming of the MTRR's.
A8	Prepare CPU for OS boot including final MTRR values.
A9	Wait for user input at config display if needed.
AA	Uninstall POST INT1Ch vector and INT09h vector. Deinitializes the ADM module.
AB	Prepare BBS for Int 19 boot.
AC	End of POST initialization of chipset registers.
B1	Save system context for ACPI.
00	Passes control to OS Loader (typically INT19h).

NOTE

Glossary

ACPI (Advanced Configuration and Power Interface): a power management specification that allows the operating system to control the amount of power distributed to the computer's devices. Devices not in use can be turned off, reducing unnecessary power expenditure.

AGP (Accelerated Graphics Port): a PCI-based interface which was designed specifically for demands of 3D graphics applications. The 32-bit AGP channel directly links the graphics controller to the main memory. While the channel runs at only 66 MHz, it supports data transmission during both the rising and falling ends of the clock cycle, yielding an effective speed of 133 MHz.

ATAPI (AT Attachment Packet Interface): also known as IDE or ATA; a drive implementation that includes the disk controller on the device itself. It allows CD-ROMs and tape drives to be configured as master or slave devices, just like HDDs.

ATX: the form factor designed to replace the AT form factor. It improves on the AT design by rotating the board 90 degrees, so that the IDE connectors are closer to the drive bays, and the CPU is closer to the power supply and cooling fan. The keyboard, mouse, USB, serial, and parallel ports are built-in.

Bandwidth: refers to carrying capacity. The greater the bandwidth, the more data the bus, phone line, or other electrical path, can carry. Greater bandwidth, then, also results in greater speed.

BBS (BIOS Boot Specification): is a feature within the BIOS that creates, prioritizes, and maintains a list of all Initial Program Load (IPL) devices, and then stores that list in NVRAM. IPL devices have the ability to load and execute an OS, as well as provide the ability to return to the BIOS if the OS load process fails for some reason. At that point, the next IPL device is called upon to attempt loading of the OS.

BIOS (Basic Input/Output System): the program that resides in the ROM chip, and provides the basic instructions for controlling your computer's hardware. Both the operating system and application software use BIOS routines to ensure compatibility.

Buffer: a portion of RAM which is used to temporarily store data, usually from an application, though it is also used when printing, and in most keyboard drivers. The CPU can manipulate data in a buffer before copying it, all at once, to a disk drive. While this improves system performance --- reading to or writing from a disk drive a single time is much faster than doing so repeatedly --- there is also the possibility of losing your data should the system crash. Information stored in a buffer is temporarily stored, not permanently saved.

Bus: a data pathway. The term is used especially to refer to the connection between the processor and system memory, and between the processor and PCI or ISA local buses.

Bus mastering: allows peripheral devices and IDEs to access the system memory without going through the CPU (similar to DMA channels).

Cache: a temporary storage area for data that will be needed often by an application. Using a cache lowers data access times, since the needed information is stored in the SRAM instead of in the slow DRAM. Note that the cache is also much smaller than your regular memory: a typical cache size is 512KB, while you may have as much as 4GB of regular memory.

Cache size: refers to the physical size of the cache onboard. This should not be confused with the cacheable area, which is the total amount of memory which can be scanned by the system in search of data to put into the cache. A typical setup would be a cache size of 512KB, and a cacheable area of 512MB. In this case, up to 512KB of the main memory onboard is capable of being cached. However, only 512KB of this memory will be in the cache at any given moment. Any main memory above 512MB could never be cached.

Closed and open jumpers: jumpers and jumper pins are active when they are “on” or “closed”, and inactive when they are “off” or “open”.

CMOS (Complementary Metal-Oxide Semiconductors): chips that hold the basic startup information for the BIOS.

COM port: another name for the serial port, which is called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another). Parallel ports transmit the bits of a byte on eight different wires at the same time (that is, in parallel form, eight bits at the same time).

DDR (Double Data Rate): is a technology designed to double the clock speed of the memory. It activates output on both the rising and falling edge of the system clock rather than on just the rising edge, potentially doubling output.

DIMM (Dual In-line Memory Module): faster and more capacious form of RAM than SIMMs, and do not need to be installed in pairs.

DIMM bank: sometimes called DIMM sockets, because the physical slot and the logical unit are the same. That is, one DIMM module fits into one DIMM socket, which is capable of acting as a memory bank.

DMA (Direct Memory Access): channels that are similar to IRQs. DMA channels allow hardware devices (like soundcards or keyboards) to access the main memory without involving the CPU. This frees up CPU resources for other tasks. As with

IRQs, it is vital that you do not double up devices on a single line. Plug-n-Play devices will take care of this for you.

Doze mode: in this mode, only the CPU's speed is slowed.

DRAM (Dynamic RAM): widely available, very affordable form of RAM which has the unfortunate tendency to lose data if it is not recharged regularly (every few milliseconds). This refresh requirement makes DRAM three to ten times slower than non-recharged RAM such as SRAM.

ECC (Error Correction Code or Error Checking and Correcting): allows data to be checked for errors during run-time. Errors can subsequently be corrected at the same time that they're found.

EEPROM (Electrically Erasable Programmable ROM): also called Flash BIOS, is a ROM chip which can, unlike normal ROM, be updated. This allows you to keep up with changes in the BIOS programs without having to buy a new chip. TYAN's BIOS updates can be found at <http://www.tyan.com>

ESCD (Extended System Configuration Data): a format for storing information about Plug-n-Play devices in the system BIOS. This information helps properly configure the system each time it boots.

Fault-tolerance: a term describing a system where one component can quickly be replaced without causing a loss of service, such as in a RAID system.

Firmware: low-level software that controls the system hardware.

Form factor: an industry term for the size, shape, power supply type, and external connector type of the Personal Computer Board (PCB) or motherboard. The standard form factors are the AT and ATX, although TYAN also makes some Baby-AT and ATX Footprint boards.

Global timer: onboard hardware timer, such as the Real-Time Clock (RTC).

Handshaking: a process where two devices initiate communications. One device, typically the server, sends a message to another device, typically a client, in order to request establishment of a communications channel. The two devices will then exchange messages back and forth in order to settle on a communications protocol.

HDD: stands for Hard Disk Drive, a type of fixed drive.

H-SYNC: controls the horizontal synchronization/properties of the monitor.

IC (Integrated Circuit): the formal name for the computer chip.

IDE (Integrated Device/Drive Electronics): a simple, self-contained HDD interface. It can handle drives up to 8.4 GB in size. Almost all IDEs sold now are in fact Enhanced IDEs (EIDEs), with maximum capacity determined by the hardware controller.

I/O (Input/Output): the connection between your computer and another piece of hardware (mouse, keyboard, etc.)

Initial Program Load (IPL): a feature built into BBS-compliant devices, describing those devices as capable of loading and executing an OS, as well as being able to provide control back to the BIOS if the loading attempt fails.

IPL: see Initial Program Load.

IRQ (Interrupt Request): an electronic request that runs from a hardware device to the CPU. The interrupt controller assigns priorities to incoming requests and delivers them to the CPU. It is important that there is only one device hooked up to each IRQ line; doubling up devices on IRQ lines can lock up your system. Plug-n-Play operating systems can take care of these details for you.

ISA (Industry Standard Architecture): a slower 8- or 16-bit bus (data pathway).

Latency: the amount of time that one part of a system spends waiting for another part to catch up. This is most common when the system sends data out to a peripheral device, and it waiting for the peripheral to send some data back (peripherals tend to be slower than onboard system components).

Mirroring: see RAID.

NVRAM: ROM and EEPROM are both examples of Non-Volatile RAM, memory that holds its data without power. DRAM, in contrast, is volatile.

OEMs (Original Equipment Manufacturers): Compaq or IBM package other companies' motherboards and hardware inside their case and sell them.

Parallel port: transmits the bits of a byte on eight different wires at the same time (that is, in parallel form, eight bits at the same time).

PCI (Peripheral Component Interconnect): a 32 or 64-bit local bus (data pathway) which is faster than the ISA bus. Local buses are those which operate within a single system (as opposed to a network bus, which connects multiple systems).

PCI PIO (PCI Programmable Input/Output) modes: the data transfer modes used by IDE drives. These modes use the CPU for data transfer (in contrast, DMA channels do not). PCI refers to the type of bus used by these modes to communicate with the CPU.

PCI-to-PCI bridge: allows you to connect multiple PCI devices onto one PCI slot.

Pipeline burst SRAM: a type of RAM that can maintain it's data as long as power is provided to the memory chips. In this configuration, SRAM requests are pipelined, which means that larger packets of data are sent to the memory at one time, and acted upon quickly. This type of SRAM operates at bus speeds higher than 66MHz.

PM timers (Power Management timers): software timers that count down the number of seconds or minutes until the system times out and enters sleep, suspend, or doze mode.

PnP (Plug-n-Play): a design standard that has become ascendant in the industry. Plug-n-Play devices require little set-up to use. Novice end users can simply plug them into a computer that is running on a Plug-n-Play aware operating system (such as Windows 98), and go to work. Devices and operating systems that are not Plug-n-Play require you to reconfigure your system each time you add or change any part of your hardware.

RAID (Redundant Array of Independent Disks): a way for the same data to be stored in different places on many hard drives. By using this method, the data is stored redundantly, also the multiple hard drives will appear as a single drive to the operating system. RAID level 0 is known as striping, where data is striped (or overlapped) across multiple hard drives, but offers no fault-tolerance. RAID level 1 is known as mirroring, which stores the data within at least two hard drives, but does not stripe. RAID level 1 also allows for faster access time and fault-tolerance, since either hard drive can be read at the same time. RAID level 0+1 is both striping and mirroring, providing fault-tolerance, striping, and faster access all at the same time.

RAIDIOS: stands for RAID I/O Steering, a type of RAID technology from Intel. RAIDIOS is a specification used to enable an embedded I/O controller, embedded on the motherboard, to be used as just an I/O controller or to be the I/O component of a hardware RAID subsystem. The RAIDIOS circuit allows an I/O Processor (either embedded on the motherboard or on an add-in card) to configure the I/O controller and service the I/O controller's interrupts. The I/O controller and the I/O Processor together are two of the primary components of a hardware RAID subsystem.

RAM (Random Access Memory): technically refers to a type of memory where any byte can be accessed without touching the adjacent data, is often used to refer to the system's main memory. This memory is available to any program running on the computer.

ROM (Read-Only Memory): a storage chip which contains the BIOS; the basic instructions required to boot the computer and start up the operating system.

SATA (Serial ATA): is an evolutionary replacement for the Parallel ATA physical storage interface. Serial ATA is a drop-in solution in that it is compatible with today's software and operating systems. It will provide for systems which are easier to design, with cables that are simpler to route and install, smaller cable connectors, and lower voltage requirements.

SDRAM (Synchronous Dynamic RAM): called as such because it can keep two sets of memory addresses open simultaneously. By transferring data alternately from one set of addresses and then the other, SDRAM cuts down on the delays

associated with non-synchronous RAM, which must close one address bank before opening the next.

Serial port: called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another).

SIMM (Single In-line Memory Module): formally the most common form of RAM for motherboards. They must be installed in pairs, and do not have the carrying capacity or the speed of DIMM modules.

Sleep/Suspend mode: in this mode, all devices except the CPU shut down.

SRAM (Static RAM): unlike DRAM, this type of RAM does not need to be refreshed in order to prevent data loss. Thus, it is faster and more expensive.

SSI (Server System Infrastructure): an industry initiative intended to provide ready-to-use design specifications for common server hardware elements (chassis, power supplies, and racks) to promote and support server industry growth.

Standby mode: in this mode, the video and hard drives shut down; all other devices continue to operate normally.

Striping: see RAID

UltraDMA-33/66/100: a fast version of the old DMA channel. UltraDMA is also called UltraATA. Without proper UltraDMA controller, your system cannot take advantage of higher data transfer rates of the new UltraDMA/UltraATA hard drives.

USB (Universal Serial Bus): a versatile port. This one port type can function as a serial, parallel, mouse, keyboard or joystick port. It is fast enough to support video transfer, and is capable of supporting up to 127 daisy-chained peripheral devices.

VGA (Video Graphics Array): the PC video display standard

V-SYNC: controls the vertical scanning properties of the monitor.

ZIF Socket (Zero Insertion Force socket): these sockets make it possible to insert CPUs without damaging the sensitive CPU pins. The CPU is lightly placed in an open ZIF socket, and a lever is pulled down. This shift the processor over and down, guiding into the board and locking it into place.

Technical Support

If a problem arises with your system, you should turn to your dealer for help first. Your system has most likely been configured by them, and they should have the best idea of what hardware and software your system contains. Furthermore, if you purchased your system from a dealer near you, you can bring your system to them to have it serviced instead of attempting to do so yourself (which can have expensive consequences).

Help Resources:

1. See the beep codes section of this manual.
2. See the TYAN website for FAQ's, bulletins, driver updates, and other information: <http://www.TYAN.com>
3. Contact your dealer for help BEFORE calling TYAN.
4. Check the TYAN user group:
alt.comp.periphs.mainboard.TYAN

Returning Merchandise for Service

During the warranty period, contact your distributor or system vendor FIRST for any product problems. This warranty only covers normal customer use and does not cover damages incurred during shipping or failure due to the alteration, misuse, abuse, or improper maintenance of products.

NOTE: A receipt or copy of your invoice marked with the date of purchase is required before any warranty service can be rendered. You may obtain service by calling the manufacturer for a Return Merchandise Authorization (RMA) number. The RMA number should be prominently displayed on the outside of the shipping carton and the package should be mailed prepaid. TYAN will pay to have the board shipped back to you.



Notice for the USA

Compliance Information Statement (Declaration of Conformity Procedure) DoC

FCC Part 15: This device complies with part 15 of the FCC Rules

Operation is subject to the following conditions:

This device may not cause harmful interference, and
This device must accept any interference received including interference that may cause undesired operation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Plug the equipment into an outlet on a circuit different from that of the receiver.

Consult the dealer on an experienced radio/television technician for help.

Notice for Canada

This apparatus complies with the Class B limits for radio interference as specified in the Canadian Department of Communications Radio Interference Regulations. (Cet appareil est conforme aux normes de Classe B d'interference radio tel que specifie par le Ministere Canadien des Communications dans les reglements d'ineteference radio.)



Notice for Europe (CE Mark)

This product is in conformity with the Council Directive 89/336/EEC, 92/31/EEC (EMC).

CAUTION: Lithium battery included with this board. Do not puncture, mutilate, or dispose of battery in fire. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by manufacturer. Dispose of used battery according to manufacturer instructions and in accordance with your local regulations.

Document #: D1994-110