



Quick Start Guide*

*See owner's manual for complete instructions and important safety information before using this product.

NEVER use the Copper Chef Microwave Grill with Grill Press Lid with a microwave oven that has a power rating exceeding 1350W.

Remove all metal racks or shelves from microwave interior before using the Copper Chef Microwave Grill with Grill Press Lid.



Step 1

Place ingredients in your Microwave Grill.

(Preheat your grill and grill press lid in the microwave if recipe calls for it.)



Step 2

Place lid onto your Microwave Grill.

(Always use the lid when using the Copper Chef Microwave Grill. Some recipes call for the use of the support ring.)



Step 3

Set microwave for proper cook time.



Step 4

Remove the Microwave Grill from microwave and serve.

CAUTION: Unit gets HOT while cooking. Be careful when removing from microwave and when handling. Always use dry pot holders.

Wash All Components Before First Use. Never submerge in water.

PARTS DIAGRAM

A. Grill Press Lid (GPL)

Contains microwave activated heat element.



A.

B. Support Ring

(Refer to the 'This Side Up' indicator on support ring) Not used when GPL is used to make contact with food.



B.

C. Silicone Baking/Muffin Insert

Only use Silicone Baking/Muffin Insert with Steam Tray.



C.

D. Steam Tray

Only use Silicone Baking/Muffin Insert with Steam Tray.



D.

E. Base Unit

Contains microwave activated heat element.



E.

Important Information About Using the Lid

When Preheating

- Place the lid flat in the base and preheat in the microwave for up to 3 minutes.

When Grilling

- Put the grill press lid directly onto the food, without the support ring.
- The lid must be inside the unit. Do not over fill the grill. Refer to the MAX/1.5 QT line in the base.

When Cooking

- Place the support ring directly on top of the base and then place the lid directly on top of the support ring so that it is secure. Refer to the 'This Side Up' indicator on the support ring.
- Do not allow the lid to sit loosely. Do not over fill the grill. Refer to the MAX/1.5 QT line in the base.

When Baking

- Place the steam tray into the base of the unit and then place the silicone baking/muffin insert on top of the tray.
- Place the support ring directly on top of the base and then place the lid directly on top of the support ring so that it is secure. Refer to the 'This Side Up' indicator on the support ring.
- Do not allow the lid to sit loosely. Do not overfill the grill. Refer to the Max/1.5 QT line in the base.