

Cuisinart®

INSTRUCTION AND
RECIPE BOOKLET



SmartPower Portable Compact Blending/Chopping System

CPB-300XA

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed, including the following:

1. **READ ALL INSTRUCTIONS BEFORE USING.**
2. To protect against the risk of electrical shock, do not put motor base of blender in water or other liquids.
3. This appliance should not be used by or near children or individuals with certain disabilities.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning or removing contents from blender jar or cup. **Never put hands into the blender jar or cups, or handle the blades with appliance plugged in.**
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to nearest Cuisinart® service facility for examination, repair, and/or mechanical or electrical adjustment.
7. The use of attachments, including canning or ordinary jars, not recommended or sold by Cuisinart® may cause fire, electric shock, or risk of injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of counter or table or touch hot surfaces.
10. **Keep hands and utensils out of jar while blending, to reduce the risk of severe injury to persons or damage to blender itself.** A rubber or plastic spatula may be used but must be used only when the blender is turned off.
11. When blender is in Standby mode, and the LED lights are flashing or glowing, do not touch cutting assembly, interfere with blade movement, or remove blender jar cover. Accidentally touching a speed button may activate the blender.
12. **BLADES ARE SHARP. HANDLE CAREFULLY.**
13. To reduce the risk of injury, never place cutting assembly on base unless the blender jar, chopper cup or travel cups are properly attached.
14. Always operate blender jar with the cover in place.
15. Never leave your blender unattended while running.
16. Twist on vessel firmly. Injury can result if moving blades accidentally become exposed.
17. Do not use an extension cord with this unit. Doing so may result in fire, electric shock, or personal injury.
18. Wash the blender jar, chopping cup, travel cups, cutting assemblies and lids/cover before first use.
19. Keep hands and utensils away from cutting blade while chopping food to reduce the risk of severe injury to persons or damage to the food chopper. A scraper may be used but only when the food chopper is not running.

20. Do not blend hot liquids in the travel cups or chopping cup.
21. Be certain cover is securely locked in place before operating appliance.
22. Do not attempt to bypass the interlock system that powers the unit on.
23. **WARNING: TO REDUCE THE RISK OF ELECTRICAL SHOCK OR FIRE, DO NOT REMOVE THE BASE PANEL. NO USER-SERVICEABLE PARTS ARE INSIDE. REPAIR SHOULD BE DONE ONLY BY AUTHORIZED PERSONNEL.**
24. **WARNING: FLASHING LIGHT INDICATES BLENDER IS READY TO OPERATE. DO NOT TOUCH BLADES.**
25. The jar chopping cup and travel mug are not recommended for microwave use.
26. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
27. Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

This appliance comes with a thermal resettable fuse feature to prevent damage to the motor in the case of extreme overload. Should the unit shut off unexpectedly, unplug it and let it cool for at least 15 minutes before continuing (see "Operating and Safety Tips," on page 5).

UNPACKING INSTRUCTIONS

1. Place the gift box containing your Cuisinart® SmartPower Portable Compact Blender on a flat, sturdy surface before unpacking.
2. Remove instruction booklet and other printed materials from top of packaging material. Next remove top pulp tray.
3. Carefully lift blender base from box and set aside.
4. Remove blender jar, chopping cup and travel cups and set aside.

Before using for the first time: Wash all parts according to the Cleaning and Maintenance section on page 6 of this booklet to remove any dust or residue.

To assemble the blender, follow the Assembly instructions on page 4 of this instruction booklet. Replace all packaging materials in the box and save the box for repackaging.

TABLE OF CONTENTS

Important Safeguards	2
Unpacking Instructions	3
Features and Benefits	3
Quick Reference Guide/Assembly	4
Blender Jar Operation	4
Travel Cup Operation	5
Chopping Cup Operation	5
Operating and Safety Tips	5
Cleaning and Maintenance	6
Troubleshooting	6
Warranty Information	7

FEATURES AND BENEFITS

1. **900ml BPA-free easy-grip blending jar**
with cover and pour lid has a unique, sturdy design for all your blending needs. Lid fits on top with a 30ml. measured pour lid.
2. **235ml BPA-free chopping cup** with lid handles a variety of food preparation tasks including chopping, grinding and whipping.
3. **Four 450ml BPA-free travel cups with 2 lid options**
allow you to blend for one. Make your favorite drinks: smoothies, protein, health and diet drinks and more!
4. **Two high-quality blade assemblies**
are strong enough for all blending, chopping and grinding tasks. They are self-aligning so that the cups easily fit on the base. Blade assemblies are interchangeable for desired tasks.
5. **Heavy-duty motor base with stainless steel accent**
is sturdy and stable, housing a compact 350-watt motor with a safety interlock feature.
6. **3-function touchpad control with LED indicator lights**
is easy to use, read and clean. The blue LED lights clearly indicate what speed you are using.
7. **Slip-proof feet (not shown)**
prevent movement during use and prevent damaging marks on countertops or tables.
8. **Cord storage (not shown)**
keeps countertops safe and neat by conveniently storing excess cord.
9. **Auto Stop Timer – (not shown)**
To prevent motor overheating, auto stop function would be started if product operates over 2 minutes continuously.



QUICK REFERENCE GUIDE

To activate blender	Place vessel fitted with blade assembly onto base
To begin blending	Press desired speed
To change speeds	Press desired speed
To pulse	In Standby mode press Pulse, then press and release desired speed button as needed.
To stop blending	Press activated speed

ASSEMBLY

After washing all parts, please see below for assembly. Place base on flat surface and plug in.

Blender Jar Assembly	Travel Cup Assembly	Chopping Cup Assembly
1. Turn blender jar upside down.	1. Place cup on flat surface.	1. Place cup on flat surface.
2. Place blade assembly (a) on the round opening of the jar and turn clockwise until tightened.	2. Attach blade assembly (a) on round opening of the cup and turn clockwise until tightened.	2. Attach blade assembly (b) on round opening of the cup and turn clockwise until tightened.
3. Stand jar upright, place cover with pour lid in place on blender jar.	3. Place on blender base.	3. Place on blender base.
4. Place on blender base.		

BLENDER JAR OPERATION

- With the base unit on the tabletop and unit plugged in, place the blender jar assembled with the blade assembly onto the base and secure into place. The unit automatically is activated and in Standby mode with the red POWER LED light illuminated and flashing.
Note: Blade assemblies are interchangeable based on recipes and desired end results.
- Add food ingredients. Replace the cover. You may add more ingredients by lifting the measured pour lid and dropping ingredients through the fill area. Replace the pour lid after adding ingredients.
Do not put hands into jar with blender in Standby mode.
Note: To remove blender jar cover, lift edge of cover upward. Do not use measured pour lid to remove cover.
- For continuous blending, press the desired speed. The blue LED light will illuminate, indicating that the blender is on and running. It is possible to switch between High and Low speeds by simply pushing the desired speed button.
- To pause the blending process, press the activated speed button.
The blending process will stop. The red Standby indicator light will continue to flash to let you know that the blender is still activated.
To reengage a function, choose the desired speed.
- To pulse, push the Pulse button. The blue Pulse indicator light will flash. Next, push and release the desired speed button. Repeat as needed. While pulsing, active indicator lights will be lit. The Pulse function can be used to break apart larger pieces of food. The Pulse function is also effective for starting the blending process when you do not want continuous power or processing items that do not require an extended amount of blending.
- When you have finished blending, press the activated speed to put unit in Standby mode. Then remove the blender jar from the base. Pour out ingredients. **NEVER TOUCH THE BLADE ITSELF.** Unplug the unit.
- Do not continue to operate the blender over 2 minutes.

TRAVEL CUP OPERATION

1. Put food ingredients into the travel cup, and then attach blade assembly.
Note: Blade assemblies are interchangeable based on recipes and desired end results.
2. With the base unit on the tabletop and the unit plugged in, place the assembled travel cup onto the base and secure into place. The unit automatically is activated and in Standby mode with the red POWER LED illuminated and flashing.
3. For continuous blending, press the desired speed. The blue LED light will illuminate, indicating that the blender is on and running. It is possible to switch between High and Low speeds by simply pushing the desired speed button.
4. To pause the blending process, press the activated speed button. The blending process will stop. The red Standby indicator light will continue to flash to let you know that the blender is still activated. To reengage the unit, choose the desired speed.
5. When you have finished blending, press activated speed to put in Standby mode. Remove the travel cup from the base. Unplug the unit.
6. Turn cup right side up, turn blade assembly counterclockwise to remove. Attach travel cup lid by twisting clockwise.
7. Do not continue to operate over 1 minute.

CHOPPING CUP OPERATION

1. Put food ingredients into chopper cup filling it to a maximum of one-quarter of its capacity, then attach blade assembly.
Note: Blade assemblies are interchangeable based on recipes and desired end results.
2. With the base unit on the tabletop and the unit plugged in, place the assembled chopper cup onto the base and secure into place. The unit automatically is activated and in Standby mode with the red POWER LED illuminated and flashing.
3. To continuously chop, press High or Low speed.
4. To pulse, press Pulse and then desired High or Low speed.
5. When you have finished chopping, press activated speed to put in Standby mode. Remove the chopping cup from the base. Carefully remove food with a spatula.
NEVER TOUCH THE BLADE ITSELF. Unplug the unit.
6. Do not continue to operate over 1 minute.

OPERATING AND SAFETY TIPS

- Make sure the electrical outlet is rated at the same voltage as that stated on the bottom of the blender motor base.
- Always use the blender on a clean, sturdy and dry surface.
- Always operate the blender jar with the cover on. Place cover on firmly. Keep the blender jar cover on the blender jar while blending.
- Don't put hands inside the blender jar when blender is plugged in.
- Don't remove blender jar or cups while unit is running.
- **Don't place blade assembly onto motor base without the jar or cup attached.**
- Make sure blade assembly is tightly attached to jar or cups.
- Always remove blade assembly before cleaning.
- **Don't twist blade assembly from blender jar or cups when removing from motor base. Simply lift jar or cups from motor base.**
- Use a rubber or plastic spatula as needed, only when the blender is turned off. Do not use any utensil inside the blender while motor is on.
- Never use metal utensils, as damage may occur to the jar, cup or cutting assembly.
- Don't store food or liquids in your blender jar.
- Don't overload blender jar or cups. If the motor stalls, turn the blender off immediately, unplug the unit and let it cool for at least 15 minutes. Then, remove a portion of the food and continue.
- Don't blend hot liquids or carbonated beverages in chopper and travel cups.
- Don't use any container or accessories not recommended by Cuisinart®. Doing so may result in injury.
- To remove jar or cup lift straight up. Do not twist to remove.
- The jar, chopping cup and travel cups are not recommended for microwave use.

CLEANING AND MAINTENANCE

Always unplug your Cuisinart® SmartPower Portable Compact Blender from the electrical outlet before cleaning. The base and parts are made of corrosion-resistant materials that are easy to clean. Before first use and after every use, clean each part thoroughly. Periodically check all parts before reassembly. **DO NOT USE** if any part is damaged, or if the jar or cups are chipped or cracked.

To remove blade assemblies, twist off by turning counterclockwise.

NEVER TOUCH THE BLADE ITSELF.

CAUTION: Handle the blade assemblies carefully. They are SHARP and may cause injury. DO NOT attempt to remove blades from cutting assembly.

Wash all parts in warm, soapy water; rinse and dry thoroughly. All parts are top rack dishwasher safe.

Tip: You may wish to clean your blending and chopper cutting assemblies as follows: squirt a small amount of dishwashing liquid into blender jar or cups and fill halfway with warm water. Attach blade assembly. Run on Low for 15 seconds. Repeat, using clean tap water. Carefully disassemble parts and empty blender jar or cups. Rinse and dry all parts thoroughly.

Finally, wipe the motor base clean with a damp cloth to remove any residue, and dry thoroughly. Never submerge the motor base in water or other liquids, or place in a dishwasher.

Any other servicing should be performed by an authorized service representative.

TROUBLESHOOTING

Problem:	Solution:
My blender is not turning on or going into Standby mode?	Be sure the blade assembly is on the jar or cup correctly. Be sure it is pushed all the way onto the base. A red light should come on and the unit should be in Standby mode. 1. Plug blender into an independent outlet. 2. Make sure blender is securely plugged in. as stated on page 5. 3. Check the outlet for power; try plugging into a different outlet. 4. Check your home's circuit breaker.
The blender stopped running.	1. To prevent overheating, auto stop function would be started if product operates over 2 minutes continuously. 2. The motor could have overheated. The resettable fuse, which protects the motor due to overloading, may have been tripped. When this happens, to reset the appliance unplug the unit and let it cool for a minimum of 15 minutes. Then, reduce the contents of the blender jar and/or clear any jams. Restart the unit as noted in the operating directions.
The rubber gasket won't come out from the blade assembly for cleaning.	Run under water and tap on the edge of sink upside down to loosen the gasket.
The blade assembly is hard to remove after blending.	The ingredients cause pressure, and with the air tight seal, pressure builds up creating a vacuum or a suction effect. This is normal.
Unit appears to be leaking	1. Check rubber gasket. Make sure it's flush with blender assembly. 2. Make sure rubber gasket is properly in place. 3. Make sure rubber gasket is not damaged.

WARRANTY

LIMITED THREE-YEAR WARRANTY

This warranty supersedes all previous warranties on Cuisinart® SmartPower Portable Compact Blender.

This warranty is available to consumers only. You are a consumer if you own a Cuisinart® SmartPower Portable Compact Blender that was purchased at retail for personal, family, or household use. Except as otherwise required under applicable state law, this warranty is not available to retailers or other commercial purchasers or owners.

We warrant that your Cuisinart® SmartPower Portable Compact Blender will be free of defects in material or workmanship under normal home use for three years from the date of original purchase.

Please visit our website, **www.cuisinart.com.au** for the fastest most efficient way to complete your product registration.

or

Call toll-free

1800 808 971 (AUST), 0800 435 000 (NZ),

or

Write to

Cuisinart® Australia

24 Salisbury Road

Asquith NSW 2077

or

Cuisinart® New Zealand

44 Apollo Drive Mairangi Bay

Auckland New Zealand

However, the above registration methods do not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture.

If your Cuisinart® SmartPower Portable Compact Blender should prove to be defective within the warranty period, we will repair it (or, if we think it necessary, replace it) without charge to you.

This warranty expressly excludes any defects or damages caused by accessories, replacement parts, or repair service other than those that have been authorized by Cuisinart®.

This warranty does not cover any damage caused by accident, misuse, shipment or other than ordinary household use.

NOTE: For added protection and secure handling of any Cuisinart® product that is being returned, we recommend you use a traceable, insured delivery service. Cuisinart® cannot be held responsible for in-transit damage or for packages that are not delivered to us. Lost and/or damaged products are not covered under warranty. Please be sure to include your return address, daytime phone number,

description of the product defect, product model number (located on bottom of product), original date of purchase, and any other information pertinent to the product's return.

Your Cuisinart® SmartPower Portable Compact Blender has been manufactured to the strictest specifications and has been designed for use with the authorized accessories and replacement parts.

BEFORE RETURNING YOUR CUISINART® PRODUCT

If you are experiencing problems with your Cuisinart® product, we suggest that you call our Cuisinart® Service Centre at 1800 808 971 (AUS) or 0800 435 000 (NZ) before returning the product serviced. If servicing is needed, a Representative can confirm whether the product is under warranty and direct you to the nearest service location.

Important: If the nonconforming product is to be serviced by someone other than Cuisinart®'s Authorized Service Centre, please remind the servicer to call our Consumer Service Centre at 1800 808 971 (AUS) or 0800 435 000 (NZ) to ensure that the problem is properly diagnosed, the product is serviced with the correct parts, and the product is still under warranty.

©2014 Cuisinart
Suite 101, 18 Rodborough Rd
Frenchs Forest NSW, 2086
Australia

Visit our Website:
www.cuisinart.com.au

Printed in China

IB-13/243B

Purée Carrots for Baby

Making baby food is so simple – isn't it comforting to know exactly what your little one is eating?

Makes about 2 cups purée

450g carrots, peeled and trimmed, cut into 1cm slices


1. Put sliced carrots into a steamer basket and place in a saucepan filled with at least 2cm of water. Place the pan with a tightfitting lid over high heat. Once the water comes to a boil, reduce the heat to medium. Steam carrots for at least 45 minutes, until they are completely soft.

2. Put steamed carrots with 1 cup of steaming liquid into the blender jar fitted with the blending blade. Pulse carrots on low 5 times and then run on low for about 45 seconds. Scrape jar down with a spatula and blend for an additional 20 seconds. If a smoother consistency is desired, pulse in 1 tablespoon of cooking liquid at a time to the purée.

3. Allow mixture to cool. Fill ice cube trays or other 30ml containers to freeze or serve immediately. Baby food should be consumed within 2 to 3 days if not freezing.

Nutritional information per serving (1-ounce):

Calories 16 (5% from fat) • carb. 4g • pro. 0g • fat 0g • sat. 0g • chol. 0mg • sod. 26mg • calc. 13mg • fibre 1g



Weights, Measures and Conversions

Metric cup & spoon sizes	
metric	cup
60ml	¼ cup
80ml	⅓ cup
125ml	½ cup
250ml	1 cup
spoon	
metric	½ teaspoon
1.25ml	½ teaspoon
2.5ml	1 teaspoon
5ml	2 teaspoon
10ml	2 teaspoon (equal to 4 teaspoons)
20ml	1 tablespoon

Liquids	
metric	cup
30 ml	1 fl oz
60 ml	½ cup
80 ml	3 ½ fl oz
100ml	⅓ cup
125ml	½ cup
150ml	¾ cup
180ml	¾ cup
200ml	7 fl oz
250ml	1 cup
310ml	1 ¼ cups
375ml	1 ½ cups
430ml	1 ¾ cups
475ml	2 cups
500ml	2 cups
625ml	2 ½ cups
750ml	3 cups
1L	4 cups
1.25L	5 cups
1.5L	6 cups
2L	8 cups
2.5L	10 cups
3L	12 cups
4L	16 cups
5L	20 cups
6L	24 cups
7L	28 cups
8L	32 cups
9L	36 cups
10L	40 cups
11L	44 cups
12L	48 cups
13L	52 cups
14L	56 cups
15L	60 cups
16L	64 cups
17L	68 cups
18L	72 cups
19L	76 cups
20L	80 cups
21L	84 cups
22L	88 cups
23L	92 cups
24L	96 cups
25L	100 cups
26L	104 cups
27L	108 cups
28L	112 cups
29L	116 cups
30L	120 cups
31L	124 cups
32L	128 cups
33L	132 cups
34L	136 cups
35L	140 cups
36L	144 cups
37L	148 cups
38L	152 cups
39L	156 cups
40L	160 cups
41L	164 cups
42L	168 cups
43L	172 cups
44L	176 cups
45L	180 cups
46L	184 cups
47L	188 cups
48L	192 cups
49L	196 cups
50L	200 cups
51L	204 cups
52L	208 cups
53L	212 cups
54L	216 cups
55L	220 cups
56L	224 cups
57L	228 cups
58L	232 cups
59L	236 cups
60L	240 cups
61L	244 cups
62L	248 cups
63L	252 cups
64L	256 cups
65L	260 cups
66L	264 cups
67L	268 cups
68L	272 cups
69L	276 cups
70L	280 cups
71L	284 cups
72L	288 cups
73L	292 cups
74L	296 cups
75L	300 cups
76L	304 cups
77L	308 cups
78L	312 cups
79L	316 cups
80L	320 cups
81L	324 cups
82L	328 cups
83L	332 cups
84L	336 cups
85L	340 cups
86L	344 cups
87L	348 cups
88L	352 cups
89L	356 cups
90L	360 cups
91L	364 cups
92L	368 cups
93L	372 cups
94L	376 cups
95L	380 cups
96L	384 cups
97L	388 cups
98L	392 cups
99L	396 cups
100L	400 cups
101L	404 cups
102L	408 cups
103L	412 cups
104L	416 cups
105L	420 cups
106L	424 cups
107L	428 cups
108L	432 cups
109L	436 cups
110L	440 cups
111L	444 cups
112L	448 cups
113L	452 cups
114L	456 cups
115L	460 cups
116L	464 cups
117L	468 cups
118L	472 cups
119L	476 cups
120L	480 cups
121L	484 cups
122L	488 cups
123L	492 cups
124L	496 cups
125L	500 cups
126L	504 cups
127L	508 cups
128L	512 cups
129L	516 cups
130L	520 cups
131L	524 cups
132L	528 cups
133L	532 cups
134L	536 cups
135L	540 cups
136L	544 cups
137L	548 cups
138L	552 cups
139L	556 cups
140L	560 cups
141L	564 cups
142L	568 cups
143L	572 cups
144L	576 cups
145L	580 cups
146L	584 cups
147L	588 cups
148L	592 cups
149L	596 cups
150L	600 cups
151L	604 cups
152L	608 cups
153L	612 cups
154L	616 cups
155L	620 cups
156L	624 cups
157L	628 cups
158L	632 cups
159L	636 cups
160L	640 cups
161L	644 cups
162L	648 cups
163L	652 cups
164L	656 cups
165L	660 cups
166L	664 cups
167L	668 cups
168L	672 cups
169L	676 cups
170L	680 cups
171L	684 cups
172L	688 cups
173L	692 cups
174L	696 cups
175L	700 cups
176L	704 cups
177L	708 cups
178L	712 cups
179L	716 cups
180L	720 cups
181L	724 cups
182L	728 cups
183L	732 cups
184L	736 cups
185L	740 cups
186L	744 cups
187L	748 cups
188L	752 cups
189L	756 cups
190L	760 cups
191L	764 cups
192L	768 cups
193L	772 cups
194L	776 cups
195L	780 cups
196L	784 cups
197L	788 cups
198L	792 cups
199L	796 cups
200L	800 cups
201L	804 cups
202L	808 cups
203L	812 cups
204L	816 cups
205L	820 cups
206L	824 cups
207L	828 cups
208L	832 cups
209L	836 cups
210L	840 cups
211L	844 cups
212L	848 cups
213L	852 cups
214L	856 cups
215L	860 cups
216L	864 cups
217L	868 cups
218L	872 cups
219L	876 cups
220L	880 cups
221L	884 cups
222L	888 cups
223L	892 cups
224L	896 cups
225L	900 cups
226L	904 cups
227L	908 cups
228L	912 cups
229L	916 cups
230L	920 cups
231L	924 cups
232L	928 cups
233L	932 cups
234L	936 cups
235L	940 cups
236L	944 cups
237L	948 cups
238L	952 cups
239L	956 cups
240L	960 cups
241L	964 cups
242L	968 cups
243L	972 cups
244L	976 cups
245L	980 cups
246L	984 cups
247L	988 cups
248L	992 cups
249L	996 cups
250L	1000 cups
251L	1004 cups
252L	1008 cups
253L	1012 cups
254L	1016 cups
255L	1020 cups
256L	1024 cups
257L	1028 cups
258L	1032 cups
259L	1036 cups
260L	1040 cups
261L	1044 cups
262L	1048 cups
263L	1052 cups
264L	1056 cups
265L	1060 cups
266L	1064 cups
267L	1068 cups
268L	1072 cups
269L	1076 cups
270L	1080 cups
271L	1084 cups
272L	1088 cups
273L	1092 cups
274L	1096 cups
275L	1100 cups
276L	1104 cups
277L	1108 cups
278L	1112 cups
279L	1116 cups
280L	1120 cups
281L	1124 cups
282L	1128 cups
283L	1132 cups
284L	1136 cups
285L	1140 cups
286L	1144 cups
287L	1148 cups
288L	1152 cups
289L	1156 cups
290L	1160 cups
291L	1164 cups
292L	1168 cups
293L	1172 cups
294L	1176 cups
295L	1180 cups
296L	1184 cups
297L	1188 cups
298L	1192 cups
299L	1196 cups
300L	1200 cups
301L	1204 cups
302L	1208 cups
303L	1212 cups
304L	1216 cups
305L	1220 cups
306L	1224 cups
307L	1228 cups
308L	1232 cups
309L	1236 cups
310L	1240 cups
311L	1244 cups
312L	1248 cups
313L	1252 cups
314L	1256 cups
315L	1260 cups
316L	1264 cups
317L	1268 cups
318L	1272 cups
319L	1276 cups
320L	1280 cups
321L	1284 cups
322L	1288 cups
323L	1292 cups
324L	1296 cups
325L	1300 cups
326L	1304 cups
327L	1308 cups
328L	1312 cups
329L	1316 cups
330L	1320 cups
331L	1324 cups
332L	1328 cups
333L	1332 cups
334L	1336 cups
335L	1340 cups
336L	1344 cups
337L	1348 cups
338L	1352 cups
339L	1356 cups
340L	1360 cups
341L	1364 cups
342L	1368 cups
343L	1372 cups
344L	1376 cups
345L	1380 cups
346L	1384 cups
347L	1388 cups
348L	1392 cups
349L	1396 cups
350L	1400 cups
351L	1404 cups
352L	1408 cups
353L	1412 cups
354L	1416 cups
355L	1420 cups
356L	1424 cups
357L	1428 cups
358L	1432 cups
359L	1436 cups
360L	1440 cups
361L	1444 cups
362L	1448 cups
363L	1452 cups
364L	1456 cups
365L	1460 cups
366L	1464 cups
367L	1468 cups
368L	1472 cups
369L	1476 cups
370L	1480 cups
371L	1484 cups
372L	1488 cups
373L	1492 cups
374L	1496 cups
375L	1500 cups
376L	1504 cups
377L	1508 cups
378L	1512 cups
379L	1516 cups
380L	1520 cups
381L	1524 cups
382L	1528 cups
383L	1532 cups
384L	1536 cups
385L	1540 cups
386L	1544 cups
387L	1548 cups
388L	1552 cups
389L	1556 cups
390L	1560 cups
391L	1564 cups
392L	1568 cups
393L	1572 cups
394L	1576 cups
395L	1580 cups
396L	1584 cups
397L	1588 cups
398L	1592 cups
399L	1596 cups
400L	1600 cups
401L	1604 cups
402L	1608 cups
403L	1612 cups
404L	1616 cups
405L	1620 cups
406L	1624 cups
407L	1628 cups
408L	1632 cups
409L	1636 cups
410L	1640 cups
411L	1644 cups
412L	1648 cups
413L	1652 cups
414L	1656 cups
415L	1660 cups
416L	1664 cups
417L	1668 cups
418L	1672 cups
419L	1676 cups
420L	1680 cups
421L	1684 cups
422L	1688 cups
423L	1692 cups
424L	1696 cups
425L	1700 cups
426L	1704 cups
427L	1708 cups
428L	1712 cups
429L	1716 cups
430L	1720 cups
431L	1724 cups
432L	1728 cups
433L	1732 cups
434L	1736 cups
435L	1740 cups
436L	1744 cups
437L	1748 cups
438L	1752 cups
439L	1756 cups
440L	1760 cups
441L	1764 cups
442L	1768 cups
443L	1772 cups
444L	1776 cups
445L	1780 cups
446L	1784 cups
447L	1788 cups
448L	1792 cups
449L	1796 cups
450L	1800 cups
451L	1804 cups
452L	1808 cups
453L	1812 cups
454L	1816 cups
455L	1820 cups
456L	1824 cups
457L	1828 cups
458L	1832 cups
459L	1836 cups
460L	1840 cups
461L	1844 cups
462L	1848 cups
463L	1852 cups
464L	1856 cups
465L	1860 cups
466L	1864 cups
467L	1868 cups
468L	1872 cups
469L	1876 cups
470L	1880 cups
471L	1884 cups
472L	1888 cups
473L	1892 cups
474L	1896 cups
475L	1900 cups
476L	1904 cups
477L	1908 cups
478L	1912 cups
479L	1916 cups
480L	1920 cups
481L	1924 cups
482L	1928 cups
483L	1932 cups
484L	1936 cups
485L	1940 cups
486L	1944 cups
487L	1948 cups

Garden Vegetable Sauce

This all-purpose pasta sauce is a great way to get your daily dose of vegetables.

Makes about 3 cups

1

tablespoon extra virgin olive oil
1
small onion, cut into 1cm pieces
1
carrot, cut into 1cm pieces
1
cup 1cm cubed eggplant (not peeled)
1/2
celery stalk, cut into 1cm pieces
1
garlic cloves, smashed
2
teaspoon sea or kosher salt, divided
1/2
teaspoon dried oregano
1/2
teaspoon dried basil
1
roasted red pepper, cut into 2cm pieces
1
cup dry white wine
1/4
tablespoon tomato paste
1
can (800g) diced tomatoes with their juices
1
pinch freshly ground black pepper
1
tablespoon granulated sugar

- Put the oil into a large saucepan set over medium heat. Once oil is hot, add the onion, carrot, eggplant, celery, garlic and 1/2 teaspoon salt. Sauté ingredients together so that they gently sauté and turn slightly golden.
- Add the oregano, basil, red pepper and wine. Cook until reduced by at least half. Add the tomato paste, tomatoes, pepper and sugar. Bring to a boil, then reduce heat and simmer for 35 to 40 minutes, loosely covered. Uncover and then simmer for an additional 15 to 20 minutes longer to thicken. Turn off heat and let sit 5 minutes.

- Strain the solids from the liquids and put 1/2 cup of the liquid into the blender jar fitted with the blending blade. Add 2 cups of the cooked vegetables. Pulse on High 4 times, and then run on High for 20 seconds. Add an additional 1/4 cup of liquid and the remaining vegetables. Pulse on High 3 more times, and then run for about 15 seconds, or until smooth. If you prefer a chunky sauce, do not process – rather, pulse until desired consistency.

Nutritional information per serving (1/4 cup):
Calories 41 (25% from fat) • carb. 7g • pro. 1g • fat 1g • sat. fat 0g
• chol. 0mg • sod. 245mg • calc. 18mg • fibre 2g

A vital ingredient to hummus, this sesame paste is very versatile and can be used as a base in salad dressings or sauces.

Tahini

Makes about 1/4 cup

1/2

cup sesame seeds, lightly toasted and cooled
2
tablespoons extra virgin olive oil
pinch sea salt

- Put the sesame seeds into the chopping cup fitted with the grinding blade. Pulse 8 to 10 times on High or until finely ground. Add the olive oil and salt and pulse 4 to 5 times on High, and then process for 20 to 30 seconds on Low, or until a paste forms.
- Store in an airtight container in the refrigerator for up to 3 months.

Nutritional information per serving (1/4 tablespoon):
Calories 91 (99% from fat) • carb. 0g • pro. 0g • fat 11g • sat. fat 2g
• chol. 0mg • sod. 76mg • calc. 3mg • fibre 0g

Tahini Vinaigrette

This simple dressing is very thick, but if you prefer it thinner just blend in some water until desired consistency is achieved.

3

garlic cloves
1
tablespoon balsamic vinegar
2
tablespoons tahini (see previous recipe)
1
tablespoon fresh lemon juice
1/4
teaspoon sea salt
3
tablespoons extra virgin olive oil

- Put all of the ingredients, except for the olive oil, into the blender jar fitted with the blending blade. Pulse 8 to 10 times on High to chop, and then process until smooth.
- With the blender running on Low, slowly add the olive oil through the pour lid and the process until fully emulsified, about 30 to 40 seconds.
- If thinning with water, wait until dressing is fully blended, and then add water, 1 tablespoon at a time.

Nutritional information per serving (1/4 tablespoon):
Calories 150 (60% from fat) • carb. 12g • pro. 4g • fat 10g • sat. fat 2g
• chol. 0mg • sod. 75mg • calc. 24mg • fibre 3g

Café au Lait “Shake”

Creamy Greens Soup

This earthy, nourishing soup is so delicious! Garnish with a dollop of crème fraîche and a sprig of parsley.

Makes about 4 cups

½	tablespoon extra virgin olive oil
1	tablespoon unsalted butter
2	small shallots (about 90g) finely chopped
3	garlic cloves, crushed
1	small leek (about 60g) white part only, sliced
300g	kale, hard stems discarded and roughly chopped
1	bunch Italian parsley, stems reserved for other use and roughly chopped
½	teaspoon kosher salt
¼	teaspoon freshly ground black pepper
3	cups vegetable broth
¼	cup thickened cream

1. Put the oil and butter in a large saucepan set over medium heat. Once butter is melted add the shallots, garlic and leek. Sweat ingredients together so that they gently sauté but do not pick up any colour.

2. Add the kale, parsley, salt and pepper and stir to coat. Add the vegetable broth and bring to a boil. Cover and reduce heat so that the soup is just simmering. Simmer for about 30 minutes. Add the cream and continue simmering uncovered for an additional 20 to 30 minutes.

3. Separate the solids from the liquids and put the liquids into the blender jar fitted with the blending blade, followed by half of the solids. Run on Low and blend for about 10 seconds. Add the remaining solids and increase to High to thoroughly blend, about 45 seconds. Taste and adjust seasoning accordingly.

Nutritional information per serving (1 cup):

Calories 180 (51% from fat) • carb. 17g • pro. 6g • fat 11g • sat. fat 6g • chol. 28mg • sod. 731mg • calc. 166mg • fibre 2g

- Makes about 480ml
1. Mix together the cream and ¾ cup of the coffee and pour into one standard (12 to 14 cube) ice cube tray. Freeze.
 2. Put 3” of the frozen cubes into the travel cup, with the sugar and the remaining coffee. Fit with the blending blade. Run on High until fully blended, about 20 seconds.
 3. Serve immediately. It may be easier to scoop than pour.
*Keep the remaining cream/coffee ice cubes in a resealable plastic bag in the freezer for the next time.

Nutritional information per serving (480ml):

Calories 162 (54% from fat) • carb. 16g • pro. 3g • fat 10g • sat. fat 6g • chol. 31mg • sod. 40mg • calc. 95mg • fibre 0g

Triple Chocolate Shake

The ultimate chocolate lover’s milkshake.

Makes about 480ml

- ½ cup reduced-fat chocolate regular milk (if you do not have chocolate milk on hand, you can substitute regular milk and then add an additional table-
spoon of chocolate syrup)
1½ cups premium chocolate ice cream
2 tablespoons chocolate syrup
1. Put all of the ingredients into the travel cup in the order listed. Fit with the blending blade.
 2. Run on High for about 30 to 45 seconds, or until homogeneous.
 3. Serve immediately.

Nutritional information per serving (8 ounces):

Calories 507 (50% from fat) • carb. 53g • pro. 10g • fat 28g • sat. fat 17g • chol. 178mg • sod. 145mg • calc. 296mg • fibre 2g

Summertime Cooler

Refreshing and light, a perfect summertime drink.

Makes about 360ml

2 tablespoons packed fresh mint leaves

1½ cups 2cm cubed honeydew and rockmelon (chilled)

¼ cup raspberries

1½ tablespoons fresh lime juice

60ml pineapple juice

1. Put all of the ingredients in the order listed into the travel cup. Fit with the blending blade.

2. Run on High until smooth, about 15 to 20 seconds.

3. Serve immediately. If not consuming out of the travel cup, pour over ice into individual cups.

Nutritional information per serving (160g):

*Calories 148 (3% from fat) • carb. 38g • pro. 2g • fat 1g • sat. fat 0g
• chol. 0mg • sod. 51mg • calc. 34mg • fibre 4g*

Super Veggie Juice

Get your veggies for the day to-go in this quick, fresh vegetable juice.

Makes about 480ml

4 to 5 ice cubes

¼ cup cherry tomatoes, halved

¼ red pepper, roughly chopped (about ½ cup)

½ celery stalk, cut into 1cm pieces

½ cup cucumber, peeled, seeded and roughly chopped

2 tablespoons fresh parsley

¾ cup vegetable juice, low-sodium

1½ teaspoons fresh lime juice (from about ½ lime)

1 to 2 dashes hot pepper sauce, or to taste

1. Put all of the ingredients, in the order listed, into the travel cup. Fit with the blending blade.

2. Run on High until smooth, about 25 to 30 seconds. If a thinner consistency is desired, add additional ice cubes, one at a time, through the removable pour lid.

3. Adjust seasonings to taste and serve immediately.

Nutritional information per serving (480ml):

*Calories 67 (5% from fat) • carb. 14g • pro. 3g • fat 0g • sat. fat 0g
• chol. 0mg • sod. 134mg • calc. 51mg • fibre 4g*

Chai Tea

The chopping cup grinds the spices perfectly for this traditional milky tea beverage. While it is delicious hot, use our recipe for a tasty iced version.

Makes about 480ml

½ teaspoon whole black peppercorns

¼ teaspoon whole cloves

1 whole cinnamon stick

1 star anise pod

2½ cups half-and-half (for a non-dairy version, use soy milk)

¾ cup water

½ teaspoon pure vanilla extract

1 1 x 1cm piece of fresh ginger, peeled

¼ teaspoon orange zest

6 black tea bags (Darjeeling or Ceylon is recommended)

2 tablespoons honey

1. Put the peppercorns, cloves, cinnamon stick and star anise into the chopping cup fitted with the grinding blade. Pulse 2 to 3 times to chop on High, and then process on High until finely ground, about 45 seconds. Reserve.

2. In a small saucepan set over medium-low heat, bring the half-and-half, water, vanilla and ground spices to a boil. Once mixture comes to a boil, stir in the ginger and orange zest.

Let mixture simmer 10 to 15 minutes. Add the tea and let simmer 5 to 6 minutes. Strain the mixture, squeezing all of the liquid out of the tea bags, and then stir the honey into the strained liquid. If serving as a hot tea, serve immediately.

3. If serving the chai as an iced beverage, first bring the tea to room temperature. Stir to combine and then fill one standard (12 to 14 cube) ice cube tray with the chai. Reserve the remaining chai (about ¾ cup) in the refrigerator until chai ice cubes are frozen (at least four hours, or overnight).

4. Once chai ice cubes are frozen, put half* of them into the travel cup and then add the reserved chai. Fit with the blending blade. Run on High for about 25 to 30 seconds, or until homogenous. Serve immediately.

*Keep the remaining chai ice cubes in a resealable plastic bag in the freezer for the next time.

Nutritional information per serving (480ml):

*Calories 471 (65% from fat) • carb. 33g • pro. 9g • fat 35g • sat. fat 22g
• chol. 112mg • sod. 128mg • calc. 355mg • fibre 2g*

Immune Support Smoothie

When you're feeling run-down, this smoothie is a great pick-me-up!

Makes about 480ml

- 1/4 cup frozen strawberries
- 1/4 cup frozen blackberries
- 1/4 cup mango, cut into 2cm pieces
- 1/4 cup seedless grapes (red or green)
- 1 cup papaya (cut into 1cm pieces)
- 1 kiwi, cut into 4 pieces
- 1/2 tablespoon wheat germ
- 1/2 tablespoon flax seed oil
- 1/2 cup pomegranate juice

1. Put ingredients into the travel cup in order listed. Fit with the blending blade.

2. Run on High until smooth, about 20 seconds.

3. Serve immediately.

Nutritional information per serving (480ml):

Calories 314 (21% from fat) • carb. 63g • pro. 3g • fat 8g • sat. fat 1g • chol. 0mg • sod. 14mg • calc. 71mg • fibre 8g

Tropical Vitamin C Smoothie

A delicious way to get your daily vitamin C.

Makes about 480ml

- 1/2 cup frozen strawberries
- 1/2 cup frozen mango
- 1/2 cup 2cm cubed papaya (about 1/4 large papaya)
- 1/2 cup fresh strawberries, hulled and halved
- 1/2 cup orange juice

1. Put ingredients into the travel cup in order listed. Fit with the blending blade.

2. Run on High until smooth, about 30 seconds.

3. Serve immediately.

Nutritional information per serving (480ml):

Calories 188 (2% from fat) • carb. 47g • pro. 2g • fat 1g • sat. fat 0g • chol. 0mg • sod. 10mg • calc. 57mg • fibre 6g

Power Blast Protein Smoothie

Nuts give your smoothie added protein.

Makes about 480ml

- 2 tablespoons raw nuts
- 1/4 cup frozen peaches
- 1/4 cup frozen blueberries
- 1 banana, quartered
- 2 tablespoons protein powder
- 2 tablespoons honey (optional)
- 3/4 cup soy, almond or hemp milk (cow's milk may also be used)
- 1/2 cup plain or vanilla yoghurt

1. Put nuts into the chopping cup fitted with the grinding blade. Run on High for 15 seconds to finely grind. Reserve.

2. Put remaining ingredients into the travel cup and top with the ground nuts.

Fit with the blending blade.

3. Run on High until smooth, about 25 to 30 seconds.

4. Serve immediately.

Nutritional information per serving (480ml):

Calories 512 (11% from fat) • carb. 92g • pro. 29g • fat 7g • sat. fat 3g • chol. 15mg • sod. 344mg • calc. 269mg • fibre 5g

Super Antioxidant Smoothie

Berries are the ultimate antioxidant ingredients!

Makes about 480ml

- 1 tablespoon flax seed
- 1 1/2 cups mixed frozen berries
- 1/2 banana, cut into 2cm pieces
- 1 cup pomegranate juice

1. Put flax seeds into the chopping cup fitted with the grinding blade.

Run on High for 15 to 20 seconds to finely grind. Reserve.

2. Put remaining ingredients, in the order listed, into the travel cup, and then add the ground flax seeds. Fit with the blending blade.

3. Run on High until smooth, about 30 seconds.

4. Serve immediately.

Nutritional information per serving (1 cup):

Calories 72 (14% from fat) • carb. 13g • pro. 4g • fat 1g • sat. fat 0g • chol. 2mg • sod. 46mg • calc. 37mg • fibre 1g

ALL THE FOLLOWING DRINK RECIPES CAN EASILY BE DOUBLED AND PREPARED IN THE BLENDER JAR.

Breakfast Shake for the Road

Nutriton in a cup! Make this smoothie in the morning for breakfast on the road.

Makes about 480ml

- 1 tablespoon flax seeds
- 3 frozen strawberries
- 1/2 banana, broken into 3 pieces
- 1/2 cup blueberries
- 3/4 cup lowfat vanilla yoghurt
- 1/2 cup orange peach mango juice

- 1. Put flax seeds into the chopping cup fitted with the grinding blade. Run on High for 15 to 20 seconds to finely grind. Reserve.
- 2. Put remaining ingredients, in order listed, into the travel cup and top with the ground flax seeds. Fit with the blending blade.
- 3. Run on High until smooth, about 20 to 25 seconds.
- 4. Serve immediately.

Nutritional information per serving (480ml):

Calories 349 (12% from fat) • carb. 68g • pro. 11g • fat 5g • sat. fat 1g • chol. 11mg • sod. 121mg • calc. 304mg • fibre 6g

Berry Cherry Smoothie

This kid-friendly smoothie is a vitamin-packed way to start the day.

Makes about 420g

- 1 cup frozen cherries
- 1 banana, quartered
- 1/2 cup fresh strawberries, hulled and halved
- 1/2 cup orange juice
- 1/4 cup plain yoghurt
- 1 tablespoon honey (optional)

- 1. Put ingredients into the travel cup in order listed. Fit with the blending blade.
- 2. Run on High until smooth, about 25 seconds.
- 3. Serve immediately.

Nutritional information per serving (14 ounces):
Calories 274 (9% from fat) • carb. 62g • pro. 6g • fat 3g • sat. fat 1g • chol. 8mg • sod. 39mg • calc. 141mg • fibre 6g

- To make baby food, process 1 cup of very soft steamed vegetables with 1 to 3 tablespoons of the steaming liquid.
- The amount of liquid depends on the type of vegetable that you are processing. For example, denser vegetable like a carrot requires about 3 tablespoons, while a softer vegetable like broccoli requires only 1 tablespoon. Always run on Low. Always allow baby food to cool.
- To process soft fruits for baby food, again use 1 cup at a time. No water is needed with most fruits, but if you are having
- trouble processing, add a teaspoon of water at a time.
- The chopping cup with the grinding blade provides you with the perfect tool for grinding nuts and seeds for many different applications. Grind flax seeds or almonds and put them into the travel cup with your smoothie ingredients for added protein.
- See our recipes for some guidelines.
- After chopping/blending, flip the chopping cup over so that the blade assembly is on the top. Gently tap the cup on the counter a few times to prevent any spillage. Either use the food right away or cover with the provided storage lid to use at another time.

BLENDER JAR – TIPS AND HINTS

- Add liquid ingredients first, then follow with solid ingredients. This will provide more consistent blending and prevent unnecessary stress on the motor.
 - It is recommended that most foods be cut into 1-2cm pieces to achieve the most uniform result.
 - For best results in the fastest time, pulse a few times before running continuously. Pulses should be short bursts with about 1 second in between each one to allow the blade to stop rotating between pulses.
 - If you want to add ingredients during the blending process, remove the pour lid and drop or pour ingredients through the opening at the top.
 - To crush ice, put no more than 1 tray of standard ice cubes (12 to 14 cubes) into the blender jar at one time. Pulse on High until uniformly crushed.
 - When making hot soups, add a small amount of the hot liquid to the blender jar first, and then follow with some of the solids. Pulse ingredients and then run on Low. You can always thin it out more by carefully adding liquid through the opening at the top of the cover.
 - If food sticks to the sides of the jar when blending, stop the blender, carefully scrape down the food, replace cover and pulse in short bursts to combine.
 - When blending thicker mixtures, lightly hold down top of blender jar to prevent jumping.
 - Do not attempt to mash white potatoes or knead bread dough in the blender.
- ## TRAVEL CUPS – TIPS AND HINTS
- When using the travel cup, ingredients are put in the reverse order of the blender jar. Always put the hardest ingredients into the travel cup first (ice cubes, frozen fruit) and finish with the softer ingredients and liquids.
 - It is recommended that most foods be cut into 1-2cm pieces to achieve the most uniform result.
 - For best results in the fastest time, pulse a few times before running continuously. Pulses should be short bursts with about 1 second in between each one to allow the blade to stop rotating between pulses.
 - Results are usually achieved in seconds rather than minutes, so keep a close eye on the foods to prevent over-processing.
 - When grinding nuts, use quick pulses on High. Pulse to achieve chopped nuts.
 - To make nut butters, we recommend using no more than ½ cup of nuts. Always pulse on High first, remove cup from base and lightly tap to knock the food down from the side walls of the cup. Return to base and process on Low, scraping down as necessary if the nuts are not being brought into the blade.
 - It should take no more than 1½ minutes to achieve a butter. This method works for all nuts from almonds to pecans to peanuts.

CHOPPING CUP – TIPS AND HINTS

- 1 second in between each one to allow the blade to stop rotating between pulses.
- To crush ice, put as many as 6 ice cubes into the travel cup at one time. Pulse on High until uniformly crushed.
- If food sticks to the sides of the cup when blending, stop the blender, carefully scrape down the food, replace cover and pulse in short bursts to combine.
- When blending thicker mixtures, lightly hold down top of travel cup to prevent jumping.
- After blending, flip the travel cup over so that the blade assembly is on the top. Gently tap the cup on the counter a few times to prevent any spillage. Remove the blade assembly and replace with one of the provided lids.
- All beverage recipes in the booklet are portioned for the travel cup. If you wish to make more servings, simply double the recipe and prepare in the blender jar. Be sure to reverse the order of ingredients when doing so.

QUICK REFERENCE GUIDES

You'll find many easy ways to prepare savory, healthful drinks, sauces and more with your Cuisinart® SmartPower Compact Portable Blending/Chopping System. The simple recipes that follow include some old Cuisinart® favourites as well as some creative combinations that are sure to please your friends and family.

QUICK REFERENCE GUIDE – FOOD AND DRINK CHART

Food	Blade	Vessel	Instruction
Baby Food (cooked vegetables)	Blending	Chopping Cup, Travel Cup or Blender Jar	Using VERY soft, cooled steamed vegetables and 1 to 3 tablespoons of steaming liquid; run on Low until smooth.
Baby Food (raw fruits)	Blending	Chopping Cup, Travel Cup or Blender Jar	Pulse on High and then run on Low until smooth.
Bread Crumbs	Blending	Chopping Cup or Blender Jar	Pulse and then run on High. One slice for chopping cup; two slices for travel cup; three slices for blender jar.
Chopping Citrus	Blending	Chopping Cup	Run on High with a small amount (1 to 2 pinches) of sugar. Maximum three 2cm pieces of citrus peel.
Cookie Crumbs	Blending	Blender Jar	Pulse on High. Use ¾ cup of 2cm cookie pieces (60g) maximum.
Frozen Cocktails	Blending	Blender Jar	Run on High.
Garlic	Blending	Chopping Cup	Run on High.
Graham Cracker Crumbs	Blending	Chopping Cup, Travel Cup or Blender Jar	Pulse on High. Two full sheets for chopping or travel cup; four full sheets for blender jar.
Hard Cheeses	Grinding	Chopping Cup	Pulse 3 to 4 times to desired end result. Maximum 60g (1cm cubes).
Ice	Blending	Travel Cup or Blender Jar	Pulse on High.
Nuts (butters)	Grinding	Chopping Cup	3 to 6 quick pulses on High to break up, then run on Low until desired consistency, scraping down cup as needed. ½ cup maximum.
Nuts (chopped)	Grinding	Chopping Cup	Quick pulse on High until desired consistency. No more than ⅓ cup maximum.
Salad Dressings	Blending	Travel Cup or Blender Jar	Run on Low.
Seeds	Grinding	Chopping Cup	Pulse on High.
Smoothies/Shakes/Health Drinks	Blending	Travel Cup or Blender Jar	Run on High.
Soups	Blending	Blender Jar	Run on Low.
Spices	Grinding	Chopping Cup	Quick pulses on High to break up, then run on High.
Whipped Cream	Blending	Travel Cup or Blender Jar	Run on Low, 15 to 30 seconds. Half cup maximum.

Cuisinart®

Recipe Booklet

Instruction Booklet on reverse side



SmartPower Portable Blending/Chopping System

Version no : CPB300XA IB-13/243B

Fold Size: 210MM(W)X148MM(H) 16pp

Material (Cover): 105gsm Both side Artpaper for Whole Book
(Inside): 105gsm Both side Artpaper for Whole Book

Coating: Gloss Varnishing in cover

Color (Cover): 4C(CMYK)+1C(K)

(Inside): 1C(K)+1C(K)

Date: June-17-2014 Co-ordinator: Astor You/Andy WS Chan

BOND FUND Descriptio

PDF version : CPB300XA IB-13/243B (0,0)

BOND FUND Code : _____ Operator : hua

Color Series: Non

Remark: Gloss Varnishing in cove

