

User guide

gizmowatch

verizon^v



About This Guide

Thank you for choosing this ZTE mobile device. In order to keep your device in its best condition, please read this manual and keep it for future reference.

Copyright

Copyright © 2019 ZTE CORPORATION

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

Notice

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice. This manual has been designed with the utmost care to ensure the accuracy of its content. However, all statements, information, and recommendations contained therein do not constitute a warranty of any kind, either expressed or implied. We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.zteusa.com) for more information on product support. Information on the website takes precedence.

Disclaimer

ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Images and screenshots used in this manual may differ from the actual product. Content in this manual may differ from the actual product or software.

Trademarks

ZTE and the ZTE logos are trademarks of ZTE Corporation.

Other trademarks and trade names are those of their respective owners.

Version No.: R1.0

Edition Time: November 18, 2019

Contents

Getting Started.....	6
Getting to Know Your Watch.....	6
Charging Your Watch	8
Turning Your Watch On and Off	9
Setting Up the GizmoHub App.....	10
Getting the GizmoHub App	10
Creating a GizmoHub Account.....	10
Pairing Your Watch to Your Phone.....	12
Managing Contacts	14
Using the GizmoHub App	17
The Control Panel.....	17
Adding Another Child	22
Calling Your Child's Watch	24
Messaging.....	24
Locating Your Child's Watch	25
Viewing Notifications.....	30
Using the Step Counter.....	31
Managing Your Child's To-Dos	33
Managing Watch Settings.....	34
Ringing the Watch Alarm.....	35
Resetting Your Watch	36

Protecting Your Privacy With a PIN.....	36
Getting More App Support.....	37

Using Your Watch.....38

Navigating the Watch	38
Making a Call	39
Receiving a Call	40
Sending a Message.....	41
Receiving a Message.....	42
Changing a Contact's Picture.....	43
Sending Your Location	43
Fun and Gadgets	44
Configuring the Watch Settings.....	50

For Your Safety.....54

FCC RF Exposure Information (SAR).....	55
FCC Regulations.....	56
CTIA Requirements.....	57
Distraction While Walking	59
Product Handling.....	59
Electrical Safety.....	66
Radio Frequency Interference	66
Explosive Environments.....	68

Getting Started

Getting to Know Your Watch

Front



Back




NOTE:

Devices, software and apps are constantly evolving. The images, icons and features mentioned in this document are for reference only.

Charging Your Watch

Before turning on your watch, charge it fully.

1. Align the gold pins on the charging dock with the gold charging contacts on the back of the watch. The watch and the charging dock are magnetized and should connect easily.



2. Plug the other end of the cord into the charging adapter and plug the adapter into an electrical outlet.

WARNING!

Only use approved chargers with your device. Use of incompatible chargers or tampering with the charging contacts could damage your device and void the warranty.


Turning Your Watch On and Off


To turn your watch on:

Press and hold the **Power** button until the screen lights up.



To turn your watch off:

Press and hold the **Power** button until you see "Do you want to turn off?" on the screen. Then touch .



Setting Up the GizmoHub App

You need the GizmoHub app to connect and manage paired watches.

Getting the GizmoHub App

The GizmoHub app is available on the Google Play Store and the Apple App Store. Download and install it on your Android smartphone (with Android OS 5.0 or later) or Apple devices (with iOS 9.0 or later.)

NOTE:

Data usage may apply for download and use of the app.

Creating a GizmoHub Account

Follow the instructions in the app to register as Guardian 1 and add your child's profile.

Guardians are contacts who have the maximum control of the watch and Guardian 1 will complete the registration, pairing, and initial setup.

- Register as Guardian 1

Let's Get Started!

By continuing, you agree to the [Terms](#) and [Privacy Policy](#)

Create an Account

Sign In

- Add your child's profile

Success!


Your Gizmo Account has been created.
Now you can set up your GizmoHub.


Get Started:

Add Your Child's Info

Pairing Your Watch to Your Phone


Before you begin, choose a place with strong network signals.


1. The first time you turn on the watch, it should start activating automatically.
2. Choose the person whom you want to be Guardian 1.
3. When the watch is successfully activated, follow its instruction to download and install the GizmoHub app to Guardian 1's smartphone from the Google Play Store (Android OS 5.0 or later) or the Apple App Store (iOS 9.0 or later.)
4. After downloading the app, touch  on the watch screen.



5. Follow the instructions in the GizmoHub app to create an account and pair your watch by scanning the QR code or entering the mobile number, which are displayed on the watch screen.



6. When the app start to pair with the watch, touch on the watch screen. 



Managing Contacts

Know Your Contact Types and Permissions

Guardians can use the GizmoHub app to add up to 9 additional contacts to one GizmoWatch. The types of contacts and their permissions to interact with the watch are as shown below.


Contact Types	Guardians	Caregivers	Gizmo Buddies	Buddies
Call & get calls from Gizmo	√	√	√	√
Text with Gizmo	√	√	√	
Locate Gizmo	√	√		
Get Time, Location & other alerts	√	√		
Turn Gizmo off & change settings	√			
Add & manage contacts	√			


To view the contacts paired to a watch, open the GizmoHub app and touch **Kids**. Then scroll down to **Contacts**.


To view the contacts on the watch, swipe left from the watch face screen.

Add Contacts

Guardians can use the GizmoHub app on their phone to add new contacts.

1. From your GizmoHub app, touch **Contacts**.
2. Touch  at the top right of the screen or **Add Contact** at the bottom of the contacts list.





3. Touch  to add a contact from your phone or enter the contact information in each field. Then touch **Next**.
4. Touch the Select permission box to choose the permission level for the contact.
5. Touch **Save**.


NOTE:

The new contact will also appear in the GizmoWatch's contact list.

Delete Contacts

1. From the GizmoHub app of a Guardian's phone, touch **Contacts**.
2. Touch  at the top right.
3. Touch the delete icon next to the contact you want to remove.
4. Touch **Delete Contact**.
5. Touch  at the top right again.

NOTES:

- Deleting Guardian 1 will reset the GizmoWatch and delete all contacts.
- If you just want to delete a contact from one GizmoWatch and keep the contact on another, just touch the contact, touch  next to **Assigned Devices**, uncheck the watch you want to delete the contact from, and touch **Save**.

Using the GizmoHub App

Guardians and Caregivers can use the GizmoHub app on their phone to locate and communicate with the watch they are paired with. Guardians can also use the app to manage the child's contacts, profile settings, exercise targets, to-do list, and watch settings.

The Control Panel

With the Control Panel at the bottom of the GizmoHub app, you can navigate to different parts of the app's features.


Dashboard

From the Dashboard, you can call & chat with your kid, check the watch's location & battery status, view notifications for you, call log between you and the watch, and the kid's step count and To-Do list. If you have more than one kid, swipe left or right to see their Dashboard.




Kids

Check your child's full profile. If you have added more than one child, swipe left or right to see their profiles. You can edit each child's profile, manage their saved locations, location alerts, contacts and more.



Contacts


Add, edit and delete contacts, manage their permission level for each child you've added, and control which watch they can contact.



More


Get more options including:

- Managing your Gizmo devices
- Managing your account profile and security PIN
- Adding more children to your account
- Getting user support and sending feedback
- Reading the Terms & Privacy info, software versions, or just signing out



Adding Another Child

The GizmoHub app allows you to manage multiple devices. To add a new Gizmo for another child, start by adding the child.

1. From a Guardian's GizmoHub app, touch **More > Add a child**.
2. Touch  to change the profile image. Then enter the child's information, including name, gender, birth month, birth year, and your relationship.
3. Touch **Add Child**.
4. Make sure the Gizmo you want to add to this child's profile is fully charged and activated. When you're ready, touch **Add Gizmo > Get Started**.




NOTE:


You can add a child without adding a Gizmo to the child's profile. To add the Gizmo later, touch **More** on the Control Panel and touch **Manage Devices > Add Gizmo**, or swipe to the kid's profile and touch **Add Gizmo**.

5. Choose how to pair the GizmoWatch with the GizmoHub app. You can scan the QR code on the watch screen, or touch **Don't have a QR Code** to manually enter the watch's mobile number.


 **NOTE:**

The QR code and mobile number will appear on the watch after activation. To find the mobile number, see [View Watch Information](#).


6. Once the watch is successfully paired with the app, touch  on the watch screen.



 **NOTE:**

To edit the existing profile of a child, touch **Kids** on the Control Panel, swipe to the child's profile, and touch  . If you are Guardian 1 of the child, you can swipe to the bottom and touch **Remove Child Profile** (iOS devices) or **Delete Gizmo** (Android devices) to delete it and reset the child's watch.

Calling Your Child's Watch

From the GizmoHub Dashboard, swipe left or right to find the child you want to call and touch  to call the GizmoWatch.

NOTE:



The GizmoWatch supports auto-answer (the setting can be controlled with the GizmoHub app), which automatically answers the call in 10 seconds and ends it after one minute.

Messaging



Kids can use the GizmoWatch to exchange text and voice messages with Guardians and Caregivers (using GizmoHub) as well as Gizmo Buddies (using their Gizmo devices.)

From the GizmoHub Dashboard, swipe left or right to find the child and touch  to check your message exchange with the child.

To send a message to the child:

Type your message and touch . You can enter up to 120 characters per message. Touch  to enter emoji.

To edit pre-written messages on the child's watch:


1. Touch  > **Edit Child's Messages**.
2. Touch a message to edit it.
3. Touch  to save the change.

To clear past messages with the child:






Touch  > **Delete All Messages** > **OK**.

Locating Your Child's Watch

Check the Current Location

1. Touch **Dashboard** on the Control Panel and swipe to select the child you want to locate.
2. Touch  to locate the watch.


In the map area, you can also do the following:

- Touch  to turn on Real-time Tracking.
- Touch  to turn on or off the satellite view.
- Touch  and touch a date to check location history.
- Touch the current location to show its address. You can then touch  to add this place as a saved location, or touch  to find the direction to the watch with your phone's maps application.


Name Places

Name the places your child visits often (such as “school”, “grandma’s house”, or “home”) so you can identify them by names instead of GPS addresses.


1. On the Control Panel, touch **Kids > Add Location**.
2. Enter the address and touch **Next**.



3. Enter a name for the location and touch **Save**.

The named locations are displayed in the **Saved Locations** card in the child’s profile. You can touch them to edit or touch  to delete.

NOTE:

You can also name places from the Dashboard. Touch the location on the map and touch , and then enter the place name and touch **Save**.

Set Location Alerts

Guardians and Caregivers can use the GizmoHub app to set alerts to keep track of your GizmoWatch.

Choosing the alert type

You can choose between two kinds of alerts.

- **Location-based alert:** Get notifications when your child's watch moves into or out of a specific area. For example, set a library-based alert and you will get alerts when your child arrives and leaves the library.
- **Time-based alert:** Get notifications on the location of the watch at a specific time or during a specific time range.

NOTE:

You can set up to 5 location-based alerts and 20 time-based alerts.

Adding a location-based alert

1. Touch **Kids** on the Control Panel.
2. If necessary, swipe left or right to the profile of the kid you want to add an alert for.
3. Touch **Add a Location Alert > Location-based**.
4. Enter the location or touch a named location below **Known Places** or drag the map to a desired spot.

5. Drag the circle around the location pin to a desired size. You will receive alerts when the watch crosses the circle.
6. Touch **Next** and enter a name for this place (for example, Grandma's house).
7. Touch **Next** and set when you want to be notified. You can set the time range and the day for notification. The maximum time range is 8 hours.
8. Touch **Save**.

Adding a time-based alert

1. Touch **Kids** on the Control Panel.
2. If necessary, swipe left or right to the profile of the kid you want to add an alert for.
3. Touch **Add a Location Alert > Time-based**.
4. Select when you want to be notified. You can specify the exact time or time range and set alert days.
 - ▶ Touch **Specific Time** to set the time and day(s) you want to receive alerts. Then touch **Save**.
 - ▶ Touch **Time Range** to set a start time and end time for getting alerts. Then select the day(s) and touch **Next**. Drag the **Frequency Setting** slider to set how often you want to be alerted.

 **NOTE:**


More frequent alerts will drain the watch's battery faster.


Notice on Location Accuracy

The location of the watch is usually shown as a place name, an address, or GPS coordinates. While the location is determined by a variety of methods, it may not be always be accurate or available.

- When the mobile network, GPS or Wi-Fi is not available where the watch is, or when the watch is turned off, the GizmoHub app won't be able to show location information.
- Depending on the surrounding of the watch (for example, if the watch is indoors), the location information may be inaccurate, unavailable or incomplete.
- Depending on the network condition, it may take a few minutes to get the location information.

Viewing Notifications

To view notifications about one watch, touch **Dashboard** or **Kids** on the Control Panel, swipe to select a child, and touch .



Using the Step Counter

The GizmoWatch supports the pedometer function. You can set or delete a step goal for your child and check step records.

Set a Step Goal

1. From the Dashboard, swipe to select a child and touch **Set Goal** on the **Steps** card.
2. Enter the number of steps per day in the **Step Goal** field.
3. Swipe on the time area to set the time when you want to receive daily notification. You can also turn off the notification.
4. If necessary, add a reward for reaching the goal.
5. Touch **Add Step Goal**.

The daily step goal and step count will appear on the Dashboard, in your child's profile in **Kids**, and on your child's watch (see [Count Your Steps](#)).

Edit or Delete the Step Goal

After setting a step goal, you can edit it or turn the step counter off to disable the function.

1. Touch **Kids** on the Control Panel and swipe to a child's profile.
2. Touch the **Steps** card.
3. Edit the step goal, notification, and reward. If you want to delete the goal, touch the **Active** switch at the top.



4. Touch **Update Step Goal**.

Check Step Records

You can check your child's step count records up to the last 12 months.

Touch the **Steps** card on the Dashboard to view the history in a graph and spreadsheet. Touch **7 Days**, **30 Days**, **3 Months**, or **12 Months** to switch time range.

Managing Your Child's To-Dos


You can create a to-do list to remind your child of important tasks.

Add a To-Do

1. From your child's Dashboard, touch **Set To-Do** on the **To-Do List** card.
2. Touch **Add To-Do**.
3. Enter the task name, set the duration and how often you want the child to do it (Recurrence).
4. Enter an optional reward message, which your child can see when the task is completed.
5. Touch the switch next to **Play alarm on Gizmo until dismissed** to turn on or off alert to remind your child of the task.
6. Touch **Save**.

The task will appear on the kid's watch (see [Finish To-Do Tasks](#)) and the **To-Do List** card of the child's profile in the GizmoHub app.

Delete a To-Do

1. Touch **Kids** on the Control Panel and swipe to the child's **To-Do List** card.
2. Touch  and then the delete icon.

Edit a To-Do

1. Touch **Kids** on the Control Panel and swipe to the child's **To-Do List** card.
2. Touch the task.
3. Edit the task name, duration, recurrence, reward, and alarm. You can also touch the **Active** switch at the top to turn off the task.
4. Touch **Save**.

Managing Watch Settings

You can manage some settings for your GizmoWatch from the GizmoHub app.

From the Control Panel, touch **More > Manage Devices** and touch the watch you need. You can control settings for:

- Quiet Mode
- Quiet Time
- Auto-answer Calls
- Ringtone
- Touch Sound
- Volume
- Theme

You can also:

- Check the battery life
- Check the GizmoWatch user
- Check the software version, model number, and mobile number of the watch
- Check for software updates for the watch
- Turn off the watch

Ringling the Watch Alarm

When you cannot find the watch or the child, you can use the GizmoHub app to make the watch ring.

From the child's profile, swipe to the bottom and touch **Find Gizmo**. The app will ring your child's watch. Press the **Back** or **Power** button on the watch to stop the alarm.

Resetting Your Watch

1. From the Control Panel, touch **More > Manage Devices** and touch the watch you want to reset.
2. Swipe to the bottom and touch **Delete Gizmo > Continue to Delete** to reset the watch to its factory status.

NOTE:

You can also reset the watch by connecting it to the charging dock and then pressing the **Back** button 4 times.

Protecting Your Privacy With a PIN

You can set up a PIN for the GizmoHub app so that others cannot open the app.


1. On the Control Panel, touch **More > Manage Security PIN > Set security PIN**.
2. Enter a 4-digit PIN.
3. Reenter the 4-digit PIN and touch **Save**.

NOTE:

After the PIN is set, you can turn the PIN protection off, change the PIN, or set the time-out. Whenever you enter your PIN incorrectly 5 times, the app will be reset and you have to log back into your account.

Getting More App Support

From the Control Panel, touch **More** and select a help option to get information about using the app.



- **Chat:** Find answers to the most frequently asked questions from the Gizmo AI Support Agent.
- **Share Feedback:** Email Gizmo support team directly from your smartphone.
- **Turn On/Off Guide:** Show or hide tips about the app interface on the app screen.

Using Your Watch

Navigating the Watch

Your GizmoWatch is equipped with a touch screen. Swipe left or right to switch pages: the watch face, Contacts, Fun Activities, Gadgets, and Settings. You can also press the **Back** button to return to the previous screen, or press the **Power** button to return to the watch face.


You can also swipe down from the top of the screen to access the quick settings menu where you can adjust the volume, change the ringtone, change the watch face, or send your location.




NOTE:

Your watch's screen turns off automatically after some time when you do not touch it. You can wake it up by touching the screen or raise your wrist. See [Set Screen Timeout](#) and [Set Raise-to-Wake](#).

Making a Call

1. From the watch face, swipe left to the Contacts list. Then touch the contact you want to call.
2. Touch  to make a call.





To end the call, touch .

NOTE:


Your watch can only make and receive calls from phone numbers on the Contacts list. You can manage the contacts in the GizmoHub app on your phone with a Guardian account.

Receiving a Call

When someone calls the watch, it will ring and the caller name will be shown on the screen.

- Touch  to answer the call.
- Touch  to reject or end the call.




- To adjust the volume during the call, touch .





NOTE:


Making and receiving calls and messages require a network connection.

Sending a Message



1. From the watch face, swipe left to the Contacts list. Then touch the contact you want to message.




2. Touch  to create a new message. Then:
 - ▶ To send a text message, touch  to choose from a list of pre-written messages and touch the one you need.
 - ▶ To send an emoji, touch .
 - ▶ To send a voice message, touch .



Receiving a Message

When the watch receives a new message, it will appear on the screen. Touch  to reply or  to close the message.




NOTE:

The watch can only exchange messages with contacts whose permission is Guardian, Caregiver, or Gizmo Buddy. You can manage contact permissions with the GizmoHub app.

Changing a Contact's Picture


Contacts are displayed on the watch with pictures in front of their names and relations. If the picture is not set from the GizmoHub app, you can change the picture from the watch.

1. From the watch face, swipe left to the Contacts list.
2. Touch and hold on the contact whose picture you want to change, or touch the contact and touch .



3. Swipe up and down and touch the picture you like.



Sending Your Location


In addition to check your child's location from the GizmoHub app, your child can send their current location to the GizmoHub by swiping down from the top of the watch screen and touching .

Guardians and Caregivers will receive an alert displaying the watch's location from their GizmoHub app.



Fun and Gadgets

Play Jumping Games

Swipe left from the watch face to **Fun Activities** and touch  >  to start the jumping game. Children can finish the targeted number of jumps to play the next level.




Play Fun Sounds

Swipe left from the watch face to **Fun Activities** and touch  to play fun sounds. Swipe left or right to choose a desired category and touch one of the  icons at the bottom to play the sound.




Change Your Voice

You can play the voice changer game and send a voice message.

1. Swipe left from the watch face to **Fun Activities** and touch .


 **NOTE:**



You can also use the voice changer when sending a voice message. See [Sending a Message](#).

2. Touch  to start recording your message.




 **NOTE:**

You can also touch  to use the message you recorded last time.


3. Touch  to stop the recording or wait for it to stop automatically when you reach the maximum 20 seconds.
4. Swipe left or right to play your recording as different characters.
5. Touch  to send your recording as a voice message.

Count Your Steps





Swipe left from the watch face to **Fun Activities** and touch  to check your daily step goal and your current number of steps.



Use the Timer


1. Swipe left from the watch face to **Gadgets** and touch  to go to the **Timer** screen.
2. Set a time by swiping on the hours, minutes, or seconds column.






3. Touch  to start the timer. When the timer is running, you can touch  /  to pause or resume the timer, or touch  to reset it.



When the timer ends, the watch will play an alert sound.

Finish To-Do Tasks

Swipe left from the watch face to **Gadgets** and touch  to check your future tasks. Swipe left or right to view all tasks.






When it is the time for your next task, a reminder will pop up on the watch. You can touch  to begin the task or  to snooze for 10 minutes. If the task has a duration, a timer will start counting when you begin the task.




NOTE:

Depending on the setting for the task on the GizmoHub app, you may need to start or snooze the task, or press the **Power** button to stop the reminder alarm.



Using the Alarm

1. Swipe left from the watch face to **Gadgets** and touch  to go to the **Alarms** screen.
2. Touch  to add a new alarm.
3. Swipe up or down to set the alarm time and touch .









4. Touch **Repeat** or **Ringtone** to set the days you need the alarm or select an alarm sound.
5. Touch  to save the alarm.

NOTE:

You can edit or delete existing alarms. Touch it on the **Alarms** screen to turn it on or off, change the time, repeat, and ringtone, or touch  >  to delete the alarm.


Use the Stopwatch

1. Swipe left from the watch face to **Gadgets** and touch  to go to the **Stopwatch** screen.
2. Touch  to start timing. When the stopwatch is running, you can touch  /  to pause or resume it, or touch  to reset it.





Configuring the Watch Settings


Adjust the Volume


1. Swipe right from the watch face to **Settings** and touch .

 **NOTE:**


You can also swipe down from the top of the screen and touch .

2. Drag the  icon to adjust the volume.




You can also touch  to turn off the sound or turn it back on.


Turn on/off Vibration

1. Swipe right from the watch face to **Settings** and touch .
2. Touch the screen to turn the function on or off, as displayed at the bottom of the screen.


Change the Watch Face

1. Swipe right from the watch face to **Settings** and touch .

 **NOTE:**


You can also touch and hold on the watch face or swipe down from the top of the screen and touch .

2. Swipe left and right to find the watch face you like.





3. Touch .

Change the Ringtone



1. Swipe right from the watch face to **Settings** and touch .

 **NOTE:**

You can also swipe down from the top of the screen and touch .

2. Swipe up and down to view available ringtones. Touch one to play it.
3. Select the ringtone you like and touch .


Adjust the Screen Brightness

1. Swipe right from the watch face to **Settings**.
2. Swipe up and touch .
3. Drag  to adjust the brightness.




Set Raise-to-Wake



You can set the watch to wake the display when you raise your watch wrist.

1. Swipe right from the watch face to **Settings**.
2. Swipe up and touch .
3. Touch the screen to turn the function on or off, as displayed at the bottom of the screen.








View Watch Information






1. Swipe right from the watch face to **Settings**.
2. Swipe up and touch .
3. Swipe up and down to check the watch's model number, mobile number, IMEI, ICCID, software version, hardware version, and total lifetime calls.

Set Screen Timeout

1. Swipe right from the watch face to **Settings**.
2. Swipe up and touch .
3. Select the length of time you want the screen to display before it times out.
4. Touch .

For Your Safety

	Don't use while walking or running. Pay attention to the traffic.
	Don't use at gas stations.
	Your device may produce a bright or flashing light.
	Don't dispose of your device in fire.
	Your device can produce a loud sound.
	To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding the device near your ear.
	Avoid contact with anything magnetic.
	Avoid extreme temperatures.
	Keep away from pacemakers and other electronic medical devices.
	Avoid contact with liquids. Keep your device dry.

	Turn off when asked to in hospitals and medical facilities.
	Don't take your device apart.
	Turn off when told to in aircraft and airports.
	Only use approved accessories.
	Turn off when near explosive materials or liquids.

FCC RF Exposure Information (SAR)

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg for 1g SAR and 4.0W/kg for 10g SAR.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC

and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching for

FCC ID: SRQ-ZW20.

For this device, the highest reported mouth SAR value is 0.44 W/kg and the highest wrist-worn SAR value is 0.90 W/kg.

This device has been tested and meets RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device a minimum of 0.0 cm from the extremity.


FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

 **CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CTIA Requirements

- Do not disassemble or crush, bend or deform, puncture or shred the battery.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose

to water or other liquids, expose to fire, explosion or other hazards.

- Only use the battery for the device for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazards.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazards. Only authorized service providers shall replace the battery (if the battery is not user-replaceable.)
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center

for inspection.

- Improper battery use may result in a fire, explosion or other hazards.
- The device shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

Distraction While Walking

Full attention must be given to traffic at all times when walking or running in order to reduce the risk of an accident. Please observe relevant provisions on prohibitions or restrictions on the use of mobile phones.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your device and any consequences of its use.

- Always treat your device and its accessories with care and keep them in a clean place.
- Keep the screen clean. An unclean screen may slow down the device's reaction to your operations.
- Clean the device and its accessories with a soft

material such as a microfiber cleaning cloth. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.

- Do not expose your device or its accessories to open flames or lit tobacco products.
- Do not expose your device or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your device or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your device or its accessories.
- Do not attempt to disassemble your device or its accessories. Only authorized personnel can do so.
- Do not place your device inside or near heating equipment or high-pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your device may be damaged.
- Please check local regulations for disposal of electronic products.
- Do not wrap your device, charging cable or adapter in quilts or other packages during use or charging. Poor ventilation may cause heat build-up and damage internal components or cause fire.

- Do not wear or play with the device while it is being charged.
- Do not use conductive foreign objects (such as metal plates, pencils, etc.) to contact with the charging port or connectors.
- Do not expose or use your device or its accessories in an environment with or that can reach extreme temperatures.

Battery Safety

- Using ZTE-unapproved or incompatible battery, charger or power adapter may damage your device, shorten its lifespan or cause a fire, explosion or other hazards.
- The recommended operating temperatures are 0 °C to 35 °C and the storage temperatures are -20 °C to +45 °C. Extreme temperatures can damage the device and reduce the charging capacity and lifespan of your device and battery.
- The battery is not removable. Removal may cause fire or explosion.
- Do not change or replace the built-in rechargeable battery in your device by yourself. The battery can only be changed or replaced by ZTE or ZTE authorized service provider.

- Do not place the device or the battery in or near heating equipment, such as microwave ovens, stoves or radiators. Keep the device and the battery away from excessive heat and direct sunlight. If not, the device or the battery may overheat and cause explosion or fire.
- Do not disassemble, squeeze or puncture the device, as this can cause explosion or fire.
- Do not throw the device into a fire to avoid explosion.
- Please disconnect the charger when the battery is fully charged. Overcharging may shorten the battery life.
- When not using the device for a long period, please charge the battery about half and then store the device in a cool dry place.
- If the battery damages or shows signs of swelling or leakage, please stop use immediately and contact ZTE or ZTE authorized service provider for replacement.

Small Children

Do not leave your device and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could

accidentally damage the device.

Your device contains small parts that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your device for a long time.

Seizures/Blackouts

Your device can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician. To reduce the risk of blackouts or seizures, use your device in a well-lit room and take frequent breaks.

Emergency Calls

This device operates using radio signals, which cannot guarantee connection in all conditions.

Loud Noise

This device is capable of producing loud noises, which may damage your hearing. Turn down the volume if

necessary.

Users who have heart disease should pay attention to the vibration and volume settings.

Sensitive Skin

Some people may have allergic reaction when their skin is exposed to wearable items for a long time. This may be due to allergies, environmental factors, exposure to irritants (such as soap or sweat) or other factors. If you have allergies, you may feel uncomfortable when using a wearable device. If you do have skin allergy, please pay special attention.

Do not wear the device too tight. Let the skin breathe by removing the device regularly. Keep the device clean and dry will reduce the likelihood of skin discomfort. If the skin shows redness, swelling, itching or other allergic symptoms around the area where you wear the device, please remove the device and consult a physician.

Even when the symptoms alleviate, they may be induced again if you continue to wear the device.

Device Cleaning

Keep your watch clean and dry. After exercising or sweating, clean and dry the watch, the bands and your skin. If exposed to water, dry the device thoroughly.

Clean the watch when following situations appear:

contact with dirt or other damaging substances (such as dust or sand, cosmetics, ink, soap, cleaning agent, acid or acid food), contact with non-water liquid and liquid that may cause skin allergy (such as sweat, brine, soap water, perfume, pesticide spray, lotion, sunscreen, oil, hair dye, or solvent).

Watch and bands color may vary, or fade over time. Clean the watch with a soft non-fleece cloth. If necessary, moisten the cloth with clean water.

Device Heating

Your device may become warm during charging and during normal use.

During use in high temperature environments, such as inside a car or under direct sunshine for a long time, the watch may start to control its temperature to prevent users from being burned. You may encounter the following situations: charging slows down or stops, the screen turns dark, temperature warning appears on the screen, data transmission is suspended or delayed, or the watch may be turned off. If your arm feels uncomfortable, please take off the watch temporarily.

The watch may become warm during FOTA upgrade. Please took off the watch during the upgrade.

The surface temperature of the watch complies with standards and limits on temperature rise. However, even within these limits, prolonged contact with a warm

surface may cause discomfort or injury. If the temperature of the watch makes you uncomfortable, take it off.

Electrical Safety

Accessories

Use only approved accessories. Do not connect with incompatible products or accessories.

Never puncture the surface of the device with sharp objects.

Faulty and Damaged Products

Do not attempt to disassemble the device or its accessories. Only qualified personnel can service or repair the device or its accessories.

If your device (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Radio Frequency Interference

General Statement on Interference

Care must be taken when using the device in close

proximity to personal medical devices, such as pacemakers and hearing aids.

Please consult your doctor and the device manufacturers to determine if the operation of your watch may interfere with the operation of your medical devices.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the device on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source. Increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Equipment

Turn off your wireless device when you are requested to do so in hospitals, clinics or health care facilities. These

requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Turn off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices onboard the aircraft. If your device offers a 'airplane mode', this must be enabled prior to boarding an aircraft.

Interference in Vehicles

Please note that because of possible interference with electronic equipment, some vehicle manufacturers forbid the use of mobile devices in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Gas Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your watch or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air

contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile device when in a blasting area or in areas where signs are posted to power off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.