



RICOH

RICOH IM C6500/C8000

Common Criteria Guide

Version 0.5

December 2020

Document prepared by



www.lightshipsec.com

Table of Contents

1	About this Guide	3
1.1	Overview	3
1.2	Audience	3
1.3	About the Common Criteria Evaluation	3
1.4	Conventions	7
1.5	Related Documents	8
2	Secure Acceptance and Update	9
2.1	Obtaining the TOE	9
2.2	Verifying the TOE	9
2.3	Power-on Self-Tests	9
2.4	Updating the TOE	9
3	Configuration Guidance	11
3.1	Installation	11
3.2	Administration Interfaces	11
3.3	Initial Configuration	11
3.4	Services	40
3.5	Administration	41
3.6	Management of Security Functions	42
3.7	U_NORMAL User Access	49
4	Clearing the machine for redeployment or at end-of-life	49

List of Tables

Table 1: TOE Models	3
Table 2: Machine Firmware and Hardware	4
Table 3: Drivers	6
Table 4: Evaluation Assumptions	7
Table 5: Related Documents	8
Table 6: System Settings	13
Table 7: Basic Authentication	22
Table 8: LDAP Authentication	23
Table 9: Printer Settings	24
Table 10: Scanner Settings	24
Table 11: Fax Settings	25
Table 12: Device Settings	27
Table 13: Excluded Printer Features	28
Table 14: Excluded Fax Features	29
Table 15: Network Settings	29
Table 16: Security Settings	31
Table 17: WIM Auto Logout Settings	38
Table 18: System Settings 2	38
Table 19: Fax Settings	39
Table 20: Management Functions	41
Table 21: Changing System Settings	42
Table 22: SMTP Settings	45
Table 23: Changing Security Settings	46
Table 24: WIM Auto Logout Settings	48
Table 25: Audit Events	50

1 About this Guide

1.1 Overview

- 1 This guide provides supplemental instructions to achieve the Common Criteria evaluated configuration of the RICOH IM C6500/C8000 and related information.

1.2 Audience

- 2 This guide is intended for system administrators and the various stakeholders involved in the Common Criteria evaluation. It is assumed that readers will use this guide in conjunction with the related documents listed in Table 5.

1.3 About the Common Criteria Evaluation

- 3 The Common Criteria for Information Technology Security Evaluation (ISO/IEC 15408) is an international standard for security certification of IT products and systems. More information is available at <https://www.commoncriteriaportal.org/>

1.3.1 Protection Profile Conformance

- 4 The Common Criteria evaluation was performed against the requirements of the Protection Profile for Hardcopy Devices (HCD PP) v1.0 and Protection Profile for Hardcopy Devices, v1.0, Errata #1, June 2017 available at <https://www.niap-ccevs.org/Profile/PP.cfm>

1.3.2 Evaluated Software and Hardware

- 5 The TOE includes the RICOH MFP models: IM C6500 and IM C8000 labeled and marketed under different RICOH Family Group brand names as noted in Table 1.
- 6 The TSF is executed by the main controller and the operation unit respectively. For all TOE models, the main controller has an Intel® Atom Processor Apollo Lake (E3940 or E3930) and runs LPUX 6.0 OS, a customized OS based on NetBSD; the operation unit has an ARM Cortex-A9 Quad Core processor and runs a customized Linux 3.18 OS.
- 7 The first two numeric digits in the TOE model number correspond to copy speed, e.g. 6500 performs 65 prints per minute, 8000 performs 80 prints per minute, the alphabetic suffix corresponds to regional fonts and printer languages.
- 8 Differences between models with different printing speeds are limited to print engine components; differences between branding variants are limited to labels, displays, packaging materials, and documentation. The differences are not security relevant. The TOE version JE-1.00-H includes the TOE models listed in Table 1, the firmware and hardware listed in Table 2 as well as the printer driver PCL6 Driver 1.0.0.0 and the Lan-Fax Driver 9.4.0.0.

Table 1: TOE Models

Branding	Model
RICOH	IM C6500
	IM C8000

Branding	Model
SAVIN	IM C6500
	IM C8000
LANIER	IM C6500
	IM C8000
nashuatec	IM C6500
	IM C8000
Rex Rotary	IM C6500
	IM C8000
Gestetner	IM C6500
	IM C8000

Table 2: Machine Firmware and Hardware

Primary Classification	Secondary Classification	Version
Firmware	System/Copy	1.02
	Network Support	19.21
	Web Support	1.02
	OSS Info	1.00
	Fax	01.00.00
	Scanner	01.01
	Web Uapl	1.00
	NetworkDocBox	1.01.1
	animation	1.00

Primary Classification	Secondary Classification	Version
	Printer	1.01
	RPCS	3.24.6
	FontEXP	1.00
	PCL	1.00
	IRIPS PS3	1.00
	IRIPS PDF	1.02
	IRIPS Font	1.20
	GraphicData	1.01
	HelpData	0.03
	MovieData	1.00
	MovieData2	1.00
	MovieData3	1.00
	Data Erase Onb	1.05
	GWFCU3.8-25(WW)	01.00.00
	PowerSaving Sys	F.L3.25
	RICOHACT	1.10
	Engine	1.01
	CheetahSystem	1.02

Primary Classification	Secondary Classification	Version
	OpePanel	ADF01.040:02D3HA5260C TDCU0.07.1:05D0CN5530
Hardware	Ic Ctlr	03
	Ic Key	01024704

Table 3: Drivers

Drivers	Model
Printer Driver	PCL6 Driver 1.0.0.0
	RPCS Driver 1.0.0.0
LAN-Fax Driver	LAN-Fax Driver 9.5.0.0
	PCFAX Driver 9.3.0.0

1.3.3 Evaluated Functions

9

The following functions have been evaluated under Common Criteria:

- a) **Security Audit.** The TOE generates audit records of user and administrator actions. It stores audit records both locally and on a remote syslog server.
- b) **Cryptographic Support.** The TOE includes a cryptographic module for the cryptographic operations that it performs. The relevant CAVP certificate numbers are noted in the Security Target.
- c) **Access Control.** The TOE enforces access control policy to restrict access to user data. The TOE ensures that documents, document processing job information, and security-relevant data are accessible only to authenticated users who have the appropriate access permissions.
- d) **Storage Data Encryption.** The TOE encrypts data on the HDD and in NVRAM to protect documents and confidential system information if those devices are removed from the TOE.
- e) **Identification and Authentication.** Except for a defined minimal set of actions that can be performed by an unauthenticated user, the TOE ensures that all users must be authenticated before accessing its functions and data. Users login to the TOE by entering their credentials on the local operation panel, through WIM login, through print or fax drivers, or using network authentication services.
- f) **Administrative Roles.** The TOE provides the capability for managing its functions and data. Role-based access controls ensure that the ability to

configure the security settings of the TOE is available only to the authorized administrators. Authenticated users can perform copy, printer, scanner, document server and fax operations based on the user role and the assigned permissions.

- g) **Trusted Operations.** The TOE performs power-on self-tests to ensure the integrity of the TSF components. It provides a mechanism for performing trusted update that verifies the integrity and authenticity of the upgrade software before applying the updates. It uses an NTP server for accurate time.
- h) **TOE Access.** Interactive user sessions at the local and remote user interfaces are automatically terminated by the TOE after a configured period of inactivity.
- i) **Trusted Communications.** The TOE protects communications from its remote users using TLS/HTTPS, and communications with the LDAP, FTP, NTP, syslog, and SMTP servers using IPsec.
- j) **PSTN Fax-Network Separation.** The TOE restricts information received from or transmitted to the telephone network to only fax data and fax protocols. It ensures that the fax modem cannot be used to bridge the LAN.
- k) **Image Overwrite.** the TOE actively overwrites residual image data stored on the HDD after a document processing job has been completed or cancelled.

10 **NOTE:** No claims are made regarding any other security functionality.

1.3.4 Evaluation Assumptions

11 The following assumptions were made in performing the Common Criteria evaluation. The guidance shown in the table below should be followed to uphold these assumptions in the operational environment.

Table 4: Evaluation Assumptions

Assumption	Guidance
A.PHYSICAL — Physical security, commensurate with the value of the TOE and the data it stores or processes, is assumed to be provided by the environment.	Ensure that the device is hosted in a physically secure environment and that adequate security measures are in place to protect access.
A.NETWORK — The Operational Environment is assumed to protect the TOE from direct, public access to its LAN interface.	Ensure that the device is hosted on a protected network environment.
A.TRUSTED_ADMIN — TOE Administrators are trusted to administer the TOE according to site security policies	Ensure that administrators are trustworthy – e.g. implement background checks or similar controls.
A.TRAINED_USERS — Authorized Users are trained to use the TOE according to site security policies	Ensure that authorized users receive adequate training.

1.4 Conventions

12 The following conventions are used in this guide:

- a) CLI Command `<replaceable>` - This style indicates to you that you can type the word or phrase on the command line and press [Enter] to invoke a command. Text within `<>` is replaceable. For example:
Use the `cat <filename>` command to view the contents of a file
- b) [key] or [key-combo] – key or key combination on the keyboard is shown in this style. For example:
The [Ctrl]-[Alt]-[Backspace] key combination exits your graphical session and returns you to the graphical login screen or the console.
- c) **GUI => Reference** – denotes a sequence of GUI screen interactions. For example:
Select **File => Save** to save the file.
- d) [REFERENCE] *Section* – denotes a document and section reference from Table 5. For example:
Follow [ADMIN] *Configuring Users* to add a new user.

1.5 Related Documents

- 13 This guide supplements the below documents which are available on the [RICOH Support site](#) help pages.

Table 5: Related Documents

Reference	
[ADMIN]	RICOH IM C6500/C8000 Series User Guide User Guide
[SECURITY]	RICOH IM C6500/C8000 Series User Guide User Guide Security Reference

- 14 **NOTE:** The information in this guide supersedes related information in other documentation.

2 Secure Acceptance and Update

2.1 Obtaining the TOE

15 The TOE is delivered via commercial carrier.

2.2 Verifying the TOE

16 To verify the TOE Model, check that the machine's model number on the label to the rear of the machine ends with -17, -27, -29 or -00 which correspond to the branding variants of RICOH IM C6500/C8000 included in the evaluated configuration.

17 To verify the TOE firmware, the authorized administrator login and use the following steps:

18 On the Operation Panel:

- a) -Press [Home]
- b) -Press the [Settings] icon
- c) -Press [System Settings]
- d) -Press [Machine/Control Panel Information]
- e) -Press [Firmware version]

The firmware list is displayed.

On the WIM:

- a) -Device Management -> Configuration->Firmware Update

This lists all the firmware except for the TPM device driver which is only shown in the Ops panel firmware listing.

2.3 Power-on Self-Tests

19 At system start-up, the TOE performs a firmware validity test to determine if the firmware is valid. If an error occurs and the test fails, a verification error is displayed on the control panel. The firmware validity test error will also display on the Web Image Monitor after the machine starts.

20 The TOE also performs software integrity test at TOE start-up by verifying the digital signature on the TOE software. Any errors are displayed on the Control Panel or on the WIM interface.

2.4 Updating the TOE

21 TOE updates are hand delivered by RICOH service personnel. The update packages are digitally signed and uploaded to the TOE using WIM.

22 For MFP Control or FCU Software, the TOE performs the following verifications installing the package:

- a) Identifies the type of software (e.g., MFP Control, Operation Panel, FCU)
- b) Verifies that the software model name matches the TOE

- c) Verifies the digital signature on the update package.
- 1 For Operation Panel software, the TOE performs the following verifications before the installing the package:
- a) Identifies the type of software (e.g., MFP Control, Operation Panel, FCU)
 - b) Verifies that the software model name matches the TOE
 - c) Verifies the digital signature

3 Configuration Guidance

3.1 Installation

23 The TOE is delivered pre-installed with initial settings for CC-mode configuration performed by a RICOH Authorized Service representative.

3.1.1 Printer and Fax Driver

24 The printer and LAN-Fax driver are downloaded from the RICOH support site. To install the printer driver, enter the machine's IP address or host name in the [URL] box as follows:

`https://(machine's IP address or host name)/printer`

25 To install the LAN-Fax driver, enter the following URL in the [Printer URL] box as follow:

`https://(machine's IP address or host name)/printer`

26 Install the LAN-Fax driver (INF file) in the following location:

27 32-bit driver

28 X86\DRIVERS\LAN-FAX\X86\DISK1

29 64-bit driver

30 X64\DRIVERS\LAN-FAX\X64\DISK1

3.2 Administration Interfaces

31 The TOE provides the following administrator interfaces:


- a) **Operation Panel of the MFP** is an LCD touch screen interface that provides a local user interface where users can perform copy, fax print, network transmission of documents operations. The administrator user can configure the MFP via this local interface.
- b) **Web Image Monitor (WIM)** this is the remote user interface accessible via TLS/HTTPS where users can perform print, copy, fax, storage operations on documents. This interface provides various settings for administrators to perform limited configuration of the MFP. For additional details on how to launch the WIM interface see '[Using Web Image Monitor](#)' in the Introduction and Basic Operations section of the User Guide.

3.3 Initial Configuration

32 Both the Operation Panel and the WIM are used to setup initial configuration of the MFP TOE. Administrator must be registered during the initial setup by entering a username/password combination. Procedures 1 through 3 describe the sequential steps for initial configuration of the TOE.

33 The following warnings are noted:

- a) Before using the MFP, the encryption key to encrypt the data in the machine must be provided by the service representative or be newly created.
- b) Back up the encryption key only when the machine is not operating.

- c) For faxing, use the public switched telephone network. IP-Fax and Internet Fax are not CC conformant.
- d) For print jobs and fax transmissions from the client computer, use IPP-SSL authentication.
- e) If the message "SD Card authentication has failed" is displayed, contact RICOH Service Representative.
- f) In the event of a hard disk error, the machine will display options to initialize the disk or not. User authentication might fail after a hard disk initialization, if this happens, contact the service representative.
- g) To send files by e-mail using the scanner or fax function, install the user certificate when registering a user in the address book and set the encryption setting to [Encrypt All]. When you display addresses to send an e-mail, a  icon will appear next to destinations for which [Encrypt All] has been set.
- h) When using Scan to Folder make sure IPsec is enabled and complete the following steps:
 - 1. The Scan to Folder destination (FTP or SMB server) must be registered in the address book by the administrator.
 - 2. When you register the Scan to Folder destination in the address book, go to "Protection -> Protect Destination -> Access Privileges" Click [Change] and then and then select [Read- onl y] for users who are allowed to access the Scan to Folder destination.
 - 3. Configure IPsec for the server selected as the Scan to Folder destination
- i) Before receiving faxes, specify "Stored Reception File User Setting" in the Fax setting.
- j) When you configure "Program Special Sender" in the fax mode, do not specify "Forwarding per Sender" or "Memory Lock RX per Sender" before registering or changing special senders.
- k) The file creator (owner) has the authority to grant [Full Control] privileges to other users for stored documents in the Document Server. However, administrators should tell users that [Full Control] privileges are meant only for the file creator (owner).
- l) When using Web Image Monitor, users should not access other Web sites. Users should logout of WIM when it is not being used.
- m) Obtain log files by downloading them via Web Image Monitor or by automatic log collection.
- n) To prevent incorrect timestamps from being recorded in the audit log, ensure that the Audit Server that connects to the MFP is synchronized with the MFP.
- o) If the power plug is pulled out before the main power is turned off so that the machine is shut down abnormally, the date and time when the main power is turned off (the value for "Main Power Off", which is an attribute of the eco log) is not registered correctly to the "eco" log.
- p) When you specify "HDD Erase Method" in "Erase All Memory", do not select "Format".
- q) Do not assign "Reception File Settings" to a Quick Operation key in Fax mode.

- r) When you delete all logs, make sure that the following functions are not being used:
- i) Scan file transmission
 - ii) When switching from [On] to [Off] in [Document Server Function] in [Settings for Administrator] in [System Settings], delete all the received fax documents and specify the following settings again:
 1. System Settings
 2. Settings for Administrator -> File Management -> Document Server Function -> Select [On]
 3. Fax Settings
 4. Reception Settings -> Reception File Settings -> Store [On]
 5. Reception Settings -> Reception File Settings -> Print [Off]
- s) If [SHA1] in [DIGEST] in [TCP/IP] in [Network Security] in [Security] in [Configuration] in [Device Management] has been switched from [Active] to [Inactive] on Web Image Monitor, [SSL3.0] is automatically set to [Active]. In such a case set [SHA1] to [Inactive], and then, in [Configuration] in [Device Management] on Web Image Monitor, specify the following setting:
- i) Security -> Network Security -> SSL/TLS Version
 - ii) Set "TLS1.2" to [Active] and all others to [Inactive]

3.3.1 Procedure 1 – Settings Specified using the Operation Panel

- 34 Follow the instructions in "[Registering Administrators Before Using the Machine](#)" to activate the administrator account that would configure the machine. Enter passwords for administrator and supervisor, these are the authorized administrators roles that comprise U.ADMIN and the only roles with permissions to configure the TOE and the TSF.
- 35 Login to the operation panel as the administrator to configure the settings below.
- 36 Select "English" from "Change Language". Delete all the icons on the Home screen except for "Copy", "Scanner", "Fax", "Settings", "Quick Print Release", "Printer", "Document Server", "Address Book", "Substitute RX File". Do not re-register the deleted icons.

3.3.1.1 System Settings













- 37 The administrator must specify the settings in [System Settings] within the ranges shown in **Error! Reference source not found..**
















Table 6: System Settings

Tab	Item	Settings
Date/Time/Timer	Date/Time Time Zone	Set the appropriate time zone. The specified setting is applied after the machine reboots.

Tab	Item	Settings
Date/Time/Timer	Date/Time Daylight Saving Time	Set the appropriate daylight-saving time. The specified setting is applied after the machine reboots. Reboot the machine after configuring this setting.
Date/Time/Timer	Date/Time Set Date	Set the appropriate date.
Date/Time/Timer	Date/Time Set Time	Set the appropriate time.
Date/Time/Timer	Date/Time Auto Logout Timer	Select [On], and then set the range for the timer between 10-999 seconds.
Network/Interface	IP Address (IPv4) IPv4 Address Configuration	Specifying a static IPv4 address Enter the IPv4 address and subnet mask. Obtaining the DHCP server address automatically Select [Auto-Obtain (DHCP)].
Network/Interface	IP Address (IPv4) IPv4 Gateway Address	Enter the IPv4 gateway address.
Network/Interface	DNS Configuration	Specify this only if you are using a static DNS server. Specifying a static DNS server Enter the IPv4 address in "DNS Server 1", "DNS Server 2", and "DNS Server 3". (Specify DNS Server 2 and 3 if required.) Obtaining the DHCP server address automatically Select [Auto-Obtain (DHCP)].

Tab	Item	Settings
Network/Interface	Effective Protocol ▶IPv4	[Active]
Network/Interface	Effective Protocol ▶IPv6	[Inactive]
Network/Interface	SMB ▶SMB Client Advanced Settings ▶SMBv2/SMBv3	[Active]
Network/Interface	IEEE 802.1X Authentication for Ethernet	[Inactive]
Network/Interface	MLP Network Interface settings	[Wi-Fi Connection]
Network/Interface	Control Panel : Wireless LAN ▶Wi-Fi	[Off]
Network/Interface	Control Panel : Wireless LAN ▶Wireless Direct	[Off]
Network/Interface	Control Panel : Proxy Settings ▶Use Proxy	[Disable]
Network/Interface	Bluetooth ▶Bluetooth	[Off]
Network/Interface	External Interface Software Settings ▶Select IC Card Reader	[Do not Use]
Network/Interface	USB Port ▶USB Port	[Inactive]

Tab	Item	Settings
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Administrator Authentication Management  User Management	Set [Administrator Authentication] to [On], and then select [Administrator Tools] in [Available Settings].
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Administrator Authentication Management  Machine Management	Set [Admin. Authentication] to [On], and then select [General Features], [Tray Paper Settings], [Timer Settings], [Interface Settings], [File Transfer], and [Administrator Tools] in [Available Settings].
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Administrator Authentication Management  Network Management	Set [Admin. Authentication] to [On], and then select [Interface Settings], [File Transfer], and [Administrator Tools] in [Available Settings].
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Administrator Authentication Management  File Management	Set [Admin. Authentication] to [On], and then select [Administrator Tools] in [Available Settings].

Tab	Item	Settings
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Login User Name/Login Password  Administrator 1-4	Specify settings for one or more administrators. Specify the administrator's "Login User Name" and "Login Password".
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Privileges	Assign all administrator roles (user administrator, machine administrator, network administrator, and file administrator) to a single administrator.
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Login User Name/Login Password  Supervisor	Change the supervisor's "Login User Name" and "Login Password".
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Setting for Entering Authentication Password	[Only 1 Byte Characters]
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Application Authentication Management	Set [Copier Function], [Printer Function], [Document Server Function], [Fax Function] and [Scanner Function] to [On].

Tab	Item	Settings
Settings for Administrator	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ User's Own Customization	[Prohibit]
Settings for Administrator	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ LDAP Search	[Off]
Settings for Administrator	Security ▶ Extended Security Settings ▶ Restrict Display of User Information	[On]
Settings for Administrator	Security ▶ Extended Security Settings ▶ Restrict Adding of User Destinations (Fax)	[On]
Settings for Administrator	Security ▶ Extended Security Settings ▶ Restrict Adding of User Destinations (Scanner)	[On]
Settings for Administrator	Security ▶ Extended Security Settings ▶ Restrict Use of Destinations (Fax)	[On]
Settings for Administrator	Security ▶ Extended Security Settings ▶ Restrict Use of Destinations (Scanner)	[On]

Tab	Item	Settings
Settings for Administrator	Security ▶Extended Security Settings ▶Transfer to Fax Receiver	[Prohibit]
Settings for Administrator	Security ▶Extended Security Settings ▶Authenticate Current Job	[Access Privilege]
Settings for Administrator	Security ▶Extended Security Settings ▶Update Firmware	[Prohibit]
Settings for Administrator	Security ▶Extended Security Settings ▶Change Firmware Structure	[Prohibit] Click [OK]
Settings for Administrator	Security ▶Extended Security Settings ▶Password Policy	Set "Complexity Setting" to [Level 1] or [Level 2], press [Change] on the right of "Minimum Character No.", and then set the number of characters to 15 or more. (Note — The TOE requires minimum password length of 15 characters).
Settings for Administrator	Security ▶Extended Security Settings ▶Security Setting for Access Violation	[Off]
Settings for Administrator	Security ▶Service Mode Lock	[On]
Settings for Administrator	Security ▶Server Settings ▶Server Function	[Inactive]

Tab	Item	Settings
Settings for Administrator	Data Management ▶ Auto Erase Memory Setting	Select [On], and then select [NSA], [DoD], or [Random Numbers]. If you set this to [Random Numbers], set [Number of Erase] to three or more.
Settings for Administrator	Data Management ▶ Transfer Log Setting	[Forward to the System Log Server]
Settings for Administrator	File Management ▶ Machine Data Encryption Settings	Ensure that the current data has been encrypted. If the data has been encrypted, the following message will appear: "The current data in the machine has been encrypted."
Settings for Administrator	File Management ▶ Auto Delete File in Document Server	Select [Specify Days], [Specify Hours] or [Off]
Settings for Administrator	File Management ▶ Document Server Function	Select [On]
Settings for Administrator	Function Restriction ▶ Menu Protect ▶ Copier	[Level 2]
Settings for Administrator	Function Restriction ▶ Menu Protect ▶ Printer	[Level 2]
Settings for Administrator	Function Restriction ▶ Menu Protect ▶ Scanner	[Level 2]
Settings for Administrator	Function Restriction ▶ Menu Protect ▶ Fax	[Level 2]

Tab	Item	Settings
Display/Input	Key/Keyboard/Input Assistance ▶ Keyboard & Input Methods ▶ Switchable Keyboard Settings ▶ iWnn IME	[Active]
Machine	Power/Energy Saving ▶ Shift to Main Power-Off When Network Disconnected (mainly Europe and Asia)	[Off]
Machine	Power/Energy Saving ▶ Main Power On By Remote Operation	[Inactive]
Machine	External Device ▶ Control Panel SD Card Slot	[Inactive]
Machine	External Device ▶ Control Panel USB Memory Slot	[Inactive]
Machine	External Device ▶ Allow Media Slots Use ▶ Store to Memory Storage Device	[Prohibit]
Machine	External Device ▶ Allow Media Slots Use ▶ Print from Memory Storage Device	[Prohibit]
Machine	Others ▶ Central Management	[Do not Manage Centrally]

3.3.1.2 User Authentication Settings

38

The TOE is configured to do either local authentication labeled [Basic Authentication] or external authentication labeled [LDAP Authentication], using an LDAP Server in its operational environment. The TOE supports both methods of user authentication but both cannot be enforced on the same running instance of the TOE. The administrator configures User Authentication in [System Settings] -> [Administrator Tools (System Settings)] with the following settings:

3.3.1.2.1 Basic Authentication Settings

Table 7: Basic Authentication

Tab	Item	Settings
Administrator Tools	Authentication/Charge Administrator Authentication/User Authentication/App Auth. User Authentication Management	[Basic Authentication]
Administrator Tools	Authentication/Charge Administrator Authentication/User Authentication/App Auth. User Authentication Management Basic Authentication Available Functions	Specify this in accordance with your operating environment and set the browser to [unavailable]
Administrator Tools	Authentication/Charge Administrator Authentication/User Authentication/App Auth. User Authentication Management Basic Authentication Printer Job Authentication	[Entire]

3.3.1.2.2 LDAP Authentication Settings

39

Prior to configuring the LDAP Authentication settings, an LDAP server must be configured and available for used by the TOE. For details on preparing the LDAP Server in the operational environment, see the Security Guide Section '[Preparing the Server to Use for User Authentication](#)'.

Table 8: LDAP Authentication

Tab	Item	Settings
Administrator Tools	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ User Authentication Management	[LDAP Authentication]
Administrator Tools	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ User Authentication Management ▶ LDAP Authentication ▶ LDAP Servers	Select the LDAP server to authenticate.
Administrator Tools	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ User Authentication Management ▶ LDAP Authentication ▶ Available Functions	Specify this in accordance with your operating environment and set the browser to [unavailable].
Administrator Tools	Authentication/Charge ▶ Administrator Authentication/User Authentication/App Auth. ▶ User Authentication Management ▶ LDAP Authentication ▶ Printer Job Authentication	[Entire]

3.3.1.3 Printer Settings

40

The administrator must configure the printer settings within the range specified in Table 9.

Table 9: Printer Settings

Tab	Item	Settings
Data Management/Maintenance	Print Jobs Auto Delete Temporary Print Jobs	Select [On] or [Off].
Data Management/Maintenance	Print Jobs Auto Delete Stored Print Jobs	Select [On] or [Off].
Data Management/Maintenance	Print Jobs Jobs Not Printed as Machine Was Off	[Do not Print]
Data Management/Maintenance	Print Jobs Restrict Direct Print Jobs	[Automatically Store Jobs]
Data Management/Maintenance	Print Jobs Auto Store Jobs Without User Authentication Information	Select [Off]
Data Management/Maintenance	Administrator Tools Prohibit List/Test Print	[On]

3.3.1.4 Scanner Settings

41 The administrator must configure the scanner settings as specified in Table 10.

Table 10: Scanner Settings

Tab	Item	Settings
Sending Settings	Email (URL Link) Download File Directly From URL Link	[Off]
Others	History Settings Print & Delete Scanner Records	[Do not Print: Disable Send]

3.3.1.5 Fax Settings

42

The administrator must configure the fax settings as specified in Table 11.

Table 11: Fax Settings

Tab	Item	Settings
Send Settings	Backup File Transmission Setting	[Off]
Reception Settings	Reception File Settings ▶ Action on Receiving File ▶ Store	[On]
Reception Settings	Reception File Settings ▶ Action on Receiving File ▶ Forwarding	[Off]
Reception Settings	Reception File Settings ▶ Action on Receiving File ▶ Print	[Off]
Reception Settings	Reception File Settings ▶ Action on Receiving File ▶ Memory Lock Reception	[Off]
Reception Settings	Reception File Settings ▶ Reception File Storing Error Setting	[Do not Receive]
Reception Settings	Reception File Settings ▶ Reception File Storage Location	[Fax Memory]
Reception Settings	Box Setting ▶ Register/Change/Delete Box	Leave the default values – do not specify (register) the items in this setting.

Tab	Item	Settings
Detailed Initial Settings	Parameter Setting ▶Parameter Setting ▶switch 40, bit 0	[1] If the memory for stored received faxes becomes full, the MFP stops receiving new faxes and keeps the stored ones without printing or deleting them.
Detailed Initial Settings	Parameter Setting ▶Parameter Setting ▶switch 10, bit 0	[1] Only authorized users can see the stored received faxes from the control panel.
Detailed Initial Settings	Parameter Setting ▶Parameter Setting ▶switch 04, bit 7	[0] If this is enabled, previews will not be included in the reports.
Detailed Initial Settings	Internet Fax/Email/Folder ▶Internet Fax Setting	[Off]
Detailed Initial Settings	Internet Fax/Email/Folder ▶Email Setting	[Off]
Detailed Initial Settings	Internet Fax/Email/Folder ▶Folder Setting	[Off]
Detailed Initial Settings	IP-Fax Settings ▶IP-Fax Use Settings	Set [Enable H.323] and [Enable SIP] to [Off].
Detailed Initial Settings	Fax Email Account	[Do not Receive]

3.3.2 Procedure 2 – Setting Specified using WIM

43 The administrator login to the WIM interface using a web browser from a client computer to configure values for various MFP settings including Device, Printer, Fax, Network, Security and Webpage. For details on launching the WIM interface see the [Using Web Image Monitor](#) page in the User Guide.

3.3.2.1 Device Settings

44 The administrator sets the values in [Device Settings] as specified in Table 12.

Table 12: Device Settings

Category	Item	Settings
Device Settings	System ▶ Prohibit printing stored files from Web Image Monitor	[Prohibit]
Device Settings	Logs ▶ Collect Job Logs	[Active]
Device Settings	Logs ▶ Job Log Collect Level	[Level 1]
Device Settings	Logs ▶ Collect Access Logs	[Active]
Device Settings	Logs ▶ Access Log Collect Level	[Level 2]
Device Settings	Logs ▶ Collect Eco-friendly Logs	[Active]
Device Settings	Logs ▶ Eco-friendly Log Collect Level	[Level 2]
Device Settings	Logs ▶ Common Settings for All Logs ▶ Transfer Logs	[Inactive]
Device Settings	SYSLOG Transfer ▶ Transfer SYSLOG Server	[Active]

Category	Item	Settings
Device Settings	Email ▶ Administrator Email Address	Enter the administrator's email address.
Device Settings	Email ▶ SMTP Server Name	Enter the SMTP server name or IP address.

3.3.2.2 Excluded Printer Features

45 On the WIM interface, the administrator configures the settings for [printer] with the values specified in Table 13.

Table 13: Excluded Printer Features

Category	Item	Settings
Printer	Basic Settings ▶ Virtual Printer	[Inactive]
Printer	Permissions for Printer Language to Operate File System ▶ PDF, PostScript	[Do not Permit]
Printer	Google Cloud Print Settings ▶ Google Cloud Print	Select [Off], and then press [Start registration].

3.3.2.3 Excluded Fax Features

46 On the WIM interface, the administrator configures the settings for [Fax] with the values specified in Table 14Table 13.

Table 14: Excluded Fax Features

Category	Item	Settings
Fax	Initial Settings ▶ Cloud Fax Settings ▶ Enable/Disable Cloud Fax	[Disable]
Fax	IP-Fax Settings ▶ Enable H.323	[Off]
Fax	IP-Fax Settings ▶ Enable SIP	[Off]
Fax	Parameter Settings ▶ LAN-Fax Result Report	[Off]

3.3.2.4 Network Settings

47 The administrator login to the WIM to configures the network settings listed in Table 15.

Table 15: Network Settings

Category	Item	Settings
Network	IPv4 ▶ LLMNR	[Inactive]

3.3.2.5 Security Settings

48 The TOE includes FIPS validated cryptographic module which it uses to provide its cryptographic services. The TOE uses IPsec for communication with LDAP, FTP, Syslog, SMTP and NTP servers. The TOE uses TLSv1.2 for remote administration via WIM and for communication with remote non-administrative users.

49 If the TLS channel for remote administration is broken unintentionally, the TOE will attempt to re-establish the connection automatically or by prompting the user to retry manually.

50 If the IPsec trusted channel with a remote server is unintentionally disrupted, the TOE will automatically attempt to re-establish the connection and a message will be displayed on the operation panel.

- 51 While the trusted channel to a remote syslog server is disrupted, the TOE will store audit records locally on the MFP up to the document storage limits. Once the disruption has been corrected the TOE will automatically resume transmission. All LDAP user authentication attempts will be denied while the trusted channel to an LDAP server is disrupted.
- 52 All pre-shared keys, symmetric keys, and private keys are encrypted and are not accessible through normal interfaces during operation. Instructions for clearing the machine before disposal are provided in the [Security Guide](#).
- 53 The TOE stores keys and certificates in encrypted form in NVRAM and Flash memory. Destruction of old keys is performed directly without delay in NVRAM; in Flash, it is performed by an internal microcontroller in concert with wear-leveling, bad block management, and garbage collection processes. There are no situations where key destruction may be delayed at the physical layer.

3.3.2.5.1 IPSEC

- 54 The TOE supports only IKEv1 Main Mode. IKEv1 Aggressive mode must be disabled by using telnet to login to the MFP. In the evaluated configuration, Telnet is disabled by default, enable it using the WIM and go to Security->Network Security and select 'Enable telnet for IPv4. Use the following steps to disable aggressive mode; disable telnet again once the steps are completed.
- 55 -Telnet to the MFP using the admin account for login.
- a) -At the the "msh>" command prompt, enter the command:"ipsec aggressive_mode off" and
-Exit the system by entering the command "logout"
 - b) -At the "Do you save configuration data? (yes/no/return)" prompt enter
-"yes".
- 56 Launch the WIM to configure the following settings.

3.3.2.5.2 Installing a certificate on an IPsec Server

- 57 The authorized administrator must generate a certificate from the TOE device, export it and install it on the server. Use the following steps to export and install the certificate:
- 58 -Log in to the WIM as the administrator
- 59 -On the home screen click on Device Management ->Configuration -> Device Certificate -> Export
- 60 -Select "Base 64 encoded X.509" and "Export"
- 61 -Place the exported certificate into a location where your IPsec endpoint can make use of it.
- 62 -In the "Encryption Key Auto Exchange Settings" in "IPsec" in "Security" setting screen, you can select tabs. The tab has "Settings 1" to "Settings 4" and "Default Settings". "Settings 1" to "Settings 4" are applied in order when connecting to IPsec, and if any connection cannot be established, the settings of "Default Settings" are applied.
- 63 For additional details see the Security Guide section on "[Encrypting Network Communication](#)"

3.3.2.5.3 Cryptographic Settings –

64

The authorized administrator must configure the following cryptographic parameters using the WIM.







Table 16: Security Settings











Category	Item	Settings
Security	Device Certificate ▶Certificate 1 ▶Create	Configure this to create and install the device certificate (self-signed certificate) Set "Algorithm Signature" to one of the following: sha512WithRSA-2048 sha256WithRSA-2048 See the Security Guide for the other necessary settings.
Security	Device Certificate ▶Certificate 1 ▶Request	Configure this to create a certificate request for the device certificate. Set "Algorithm Signature" to one of the following: sha512WithRSA-2048 sha256WithRSA-2048 Submit the certificate request according to the methods required by the certificate authority. Install the issued certificate using the WIM.
Security	Device Certificate ▶Install	Use this setting to install the device certificate and any intermediate certificate. See the Security Guide for additional instructions on this setting.
Security	Device Certificate ▶Install Intermediate Certificate	When using an intermediate certificate, configure this setting to install the certificate.
Security	Device Certificate ▶Certification ▶S/MIME	Select the installed device certificate.











Category	Item	Settings
Security	Device Certificate ▶ Certification ▶ IPsec	Select the installed device certificate.
Security	Network Security ▶ Security Level	[FIPS 140] After setting this to [FIPS 140], be sure to click [OK].
Security	Network Security ▶ TCP/IP ▶ IPv6	[Inactive]
Security	Network Security ▶ HTTP - Port 80 ▶ IPv4	[Close] Doing this will also set "IPv4" to [Close] in "Port 80" in "IPP".
Security	Network Security ▶ SSL/TLS Version	Set "TLS1.2" to [Active], and "TLS1.1", "TLS1.0", and "SSL3.0" to [Inactive].
Security	Network Security ▶ Encryption Strength Setting	Check "AES", and uncheck "RC4" and "3DES".
Security	Network Security ▶ TCP/IP ▶ KEY EXCHANGE ▶ RSA	[Inactive]
Security	Network Security ▶ TCP/IP ▶ DIGEST ▶ SHA1	[Inactive]

Category	Item	Settings
Security	Network Security ▶FTP ▶IPv4	[Inactive]
Security	Network Security ▶WSD (Device) ▶IPv4	[Inactive]
Security	Network Security ▶WSD (Printer)	[Inactive]
Security	Network Security ▶WSD (Scanner)	[Inactive]
Security	Network Security ▶SNMP	[Inactive]
Security	S/MIME ▶Encryption Algorithm	Select [AES-256 bit], or [AES-128 bit]. When using S/MIME, it is necessary to register the user certificate.
Security	S/MIME ▶Digest Algorithm	Select [SHA-512 bit], [SHA-384 bit], or [SHA-256 bit].
Security	S/MIME ▶When Sending Email by Scanner	[Use Signatures]
Security	S/MIME ▶When Transferring by Fax	[Use Signatures]
Security	S/MIME ▶When Sending Email by Fax	[Use Signatures]

Category	Item	Settings
Security	S/MIME ▶When Emailing TX Results by Fax	[Use Signatures]
Security	S/MIME ▶When Transferring Files Stored in Document Server (Utility)	[Use Signatures]
Security	IPsec ▶IPsec	Select [Active]
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Encapsulation Mode	[Transport Mode]
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Address Type	[IPv4]
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Local Address	The machine's IP address

Category	Item	Settings
Security	IPsec  Encryption Key Auto Exchange Settings  Remote Address	Connected server's IP address Set the following server IP addresses. FTP server NTP server LDAP server SMTP server Syslog server (Note: the evaluated configuration uses IPsec for trusted channel communication with these listed servers required in the TOE operational environment. However, for SMTP and Syslog servers, the TOE can optionally be configured to use either TLS or IPsec to protect communication.)
Security	IPsec  Encryption Key Auto Exchange Settings  Security Level	[Authentication and High-Level Encryption] For Default Settings set to [PROTECT] Settings 1 through Settings 4, set values [PROTECT] [BYPASS] [DISCARD]
Security	IPsec  Encryption Key Auto Exchange Settings  Security Policy	[Apply]


Category	Item	Settings
Security	IPsec  Encryption Key Auto Exchange Settings  Authentication Method	<p>[Certificate] or [PSK].</p> <p>If you select PSK, press the “Change” button for “PSK Text” to set PSK.</p> <p>“PSK Text” is limited (truncated) to 32 characters; is composed of any combination of upper and lower-case characters, numbers and special characters that include and (that include: “!”, “@”, “#”, “\$”, “%”, “^”, “&”, “*”, “(”, and “”).</p> <p>Note: It is recommended that long “PSK Text” composed of all permitted characters should be chosen as this is considered more secure.</p>
Security	IPsec  Encryption Key Auto Exchange Settings  Hash Algorithm	Select [SHA256], [SHA384], or [SHA512].
Security	IPsec  Encryption Key Auto Exchange Settings  Encryption Algorithm	Select [AES-128-CBC] or [AES-256-CBC].
Security	IPsec  Encryption Key Auto Exchange Settings  Diffie-Hellman Group	[14]
Security	IPsec  Encryption Key Auto Exchange Settings  Validity Period	<p>Enter “86,400” for Phase 1</p> <p>Enter “28, 800” for Phase 2</p> <p>The default is 300 seconds for both Phase 1 and phase 2.</p>

Category	Item	Settings
Security	IPsec  Encryption Key Auto Exchange Settings  Authentication Algorithm	Check [HMAC-SHA256-128], [HMAC-SHA384-192] and [HMAC-SHA512-256], and uncheck [HMAC-SHA1-96] and [HMAC-MD5-96].
Security	IPsec  Encryption Key Auto Exchange Settings  Encryption Algorithm Permissions	Check [AES-128] and [AES-256], and uncheck [Cleartext], [DES] and [3DES].
Security	IPsec  Encryption Key Auto Exchange Settings  PFS	[14]
Security	User Lockout Policy  Lockout	[Active]
Security	User Lockout Policy  Number of Attempts before Lockout	1-5
Security	User Lockout Policy  Lockout Release Timer	[Active]
Security	User Lockout Policy  Lock Out User for	1-9999

3.3.2.6 WIM Auto Logout Settings

65 The administrator must configure the values for [Webpage] settings as specified in Table 17.

Table 17: WIM Auto Logout Settings

Category	Item	Settings
Webpage	Webpage  Web Image Monitor Auto Logout Settings	3 - 60 Note that the default setting is 60 seconds.






3.3.3 Procedure 3 – Additional Settings Using the Operation Panel

66 After completing the configurations in Procedure 2 using the WIM interface, the administrator must go back to the Operation Panel and login to configure the following additional system and fax settings.

3.3.3.1 System Settings

67 The administrator must configure the values for [System] settings specified in Table 18.

Table 18: System Settings 2

Tab	Item	Settings
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Application Authentication Management	Select [Auth. Not Required] for all applications.
Network/Interface	Effective Protocol  Firmware Update (IPv4)	[Inactive]
Network/Interface	Effective Protocol  Firmware Update (IPv6)	[Inactive]
Network/Interface	Effective Protocol  @Remote Service	[Inactive]

3.3.3.2 Fax Settings

- 68 The administrator must configure in the address book the users and groups who are authorized to receive faxes stored by the MFP. See the User Guide Section on [‘Registering Fax Numbers in the Address Book’](#). After users are entered in the address book, the administrator can configure the Fax settings in Table 19.

Table 19: Fax Settings

Tab	Item	Settings
Reception Settings	Stored Reception File User Setting	[On] After setting this to [On], specify the users or groups that can access stored reception files.

3.3.4 Verifying the MFP Settings

- 69 After completing procedure 1 through procedure 3, check the log data and ROM version with the following steps:
- a) Check that the machine is OFF
 - b) Turn the machine ON.
 - c) Check the details of the Log files that were stored in the machine. Check that the details for "Log Type", "Result", and "Module Name" in the recorded access log are as follows:
 - i) Log Type: Firmware: Structure
 - ii) Result: Succeeded
 - iii) Module Name: G3
 - iv) For additional details about logs, see “Collecting Logs”, “Managing Devices”, settings.
 - d) Login as admin to the Operation Panel and check the fax parameter settings with the following steps:
 - i) Press [Settings]
 - ii) Press [Fax Settings]
 - iii) Press [Detailed Initial Settings]
 - iv) Press [Parameter Settings: Print List]
 - v) Check that the following ROM version matches the one shown in the printed list: [ROM Version]
G3: 01.00.00 (Validation Data: 2BA7)
 - e) Log off

3.4 Services

3.4.1 Firewall

70 See System Settings

3.4.2 Syslog Server

71 Configure the SYSLOG server use the WIM interface settings from [Configuration] of [Device Management]. Set

72 -Device Settings -> SYSLOG Transfer -> Transfer to SYSLOG Server and select "Active".

73 -Enter the Syslog Destination <IP address> and <port number>

74 -Select 'Inactive' for Verification of Syslog Server Certificate

75 For additional information see "[Collecting Logs](#)" in the User Guide.

3.4.3 LDAP Server

76 [Registering the LDAP Server](#) in the Settings page of the online User Guide provides instructions for configuring the LDAP server that the TOE will use for user authentication. Server information to be configured includes:

- a registration name for the LDAP sever

- host name or IPv4 address of the LDAP server

- a root folder to store email addresses

- port number used for communication with the LDAP server (636)

- Use Secure Connection (SSL) is set to [ON]

- Digest Authentication

77 Additional settings for the LDAP server are described in Table 8: LDAP Authentication.

3.4.4 NTP Server

78 See System Settings

3.4.5 FTP Server

79 See System Settings

3.4.6 SMTP Server

80 See System Settings

3.4.7 CAC/PIV Authentication Solutions

81 For CAC/PIV authentication, follow the installation and configuration guidance in CAC/PIV/SIPR v4.1 Installation & Configuration Guide and CAC PIV SIPR ELPNX SOP Option v2.3 Installation Guide for v4.x.

3.5 Administration

3.5.1 Administration Interfaces

82 See Administration Interfaces above.

83 Table 20 below shows the management functions available at the different administration interfaces.

Table 20: Management Functions

Management Functions	Enable	Interface(s)
Manage user accounts (users, roles, privileges and available functions list)	Create, modify, delete	Operation Panel, WIM
Manage the document user list for stored documents	Create, modify	Operation Panel, WIM
Configure audit transfer settings	Modify	WIM
Manage audit logs	Download, Delete, export	Operation Panel, WIM
Manage Audit Functions	Enable, Disable	Operation Panel, WIM
Manage time and date settings	Modify	Operation Panel, WIM
Configure minimum password length	Modify	Operation Panel, WIM
Configure Password complexity settings	Modify	Operation Panel, WIM
Configure Operation Panel Auto Logout Time	Modify	Operation Panel, WIM
Configure WIM Auto Logout Time	Modify	WIM
Configure number of authentication failure before account lockout	Modify	WIM
Configure account release timer settings	Modify	WIM
Configure PSTN Fax-Line Separation Stored Reception File User	Modify	Operation Panel, WIM
Configure image overwrite	Modify	Operation Panel
Configure network settings for trusted communications (specify IP addresses and port to connect to the TOE)	Modify	Operation Panel, WIM

Management Functions	Enable	Interface(s)
Manage HDD Cryptographic key	Create Delete	Operation Panel, WIM
Manage Device Certificates	Create, query, modify, delete, upload, download	Operation Panel, WIM
Manage TOE Trusted Update	Query, Modify	WIM
Configure FTP	Modify	WIM
Configure IPsec	Modify	WIM
Configure SMTP over IPsec	Modify	WIM
Configure NTP	Modify	Operation Panel, WIM

3.6 Management of Security Functions

84 After initial configuration the TOE security functions can be modified and managed via the WIM or the Operation Panel.












3.6.1 Functions Managed via the Operation Panel




85 The following settings on the Operation Panel are used to manage the TOE time services, network services, administrators, the password policy and the auto erase memory function.

Table 21: Changing System Settings

Tab	Item	Settings
Date/Time/Timer	Date/Time Time Zone	Set the appropriate time zone. The specified setting is applied after the machine reboots.
Date/Time/Timer	Date/Time Daylight Saving Time	Set the appropriate daylight-saving time. Reboot the machine after configuring this setting.
Date/Time/Timer	Date/Time Set Date	Set the appropriate date.

Tab	Item	Settings
Date/Time/Timer	Date/Time ▶Set Time	Set the appropriate time.
Date/Time/Timer	Timer ▶Auto Logout Timer	Select [On], and then set the range for the timer between 10-999 seconds.
Network/Interface	IP Address (IPv4) ▶IPv4 Address Configuration	Specifying a static IPv4 address Enter the IPv4 address and subnet mask. Obtaining the DHCP server address automatically Select [Auto-Obtain (DHCP)].
Network/Interface	IP Address (IPv4) ▶IPv4 Gateway Address	Enter the IPv4 gateway address.
Network/Interface	DNS Configuration	Specify this only if you are using a static DNS server. Specifying a static DNS server Enter the IPv4 address in "DNS Server 1", "DNS Server 2", and "DNS Server 3". (Specify DNS Server 2 and 3 if required.) Obtaining the DHCP server address automatically Select [Auto-Obtain (DHCP)].

Tab	Item	Settings
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Login User Name/Login Password  Administrator 1-4	Specify settings for one or more administrators. Specify the administrator's "Login User Name" and "Login Password".
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Privileges	Assign all administrator roles (user administrator, machine administrator, network administrator, and file administrator) to a single administrator.
Settings for Administrator	Authentication/Charge  Administrator Authentication/User Authentication/App Auth.  Register/Change Administrator  Set Administrator Login User Name/Login Password  Supervisor	Change the supervisor's "Login User Name" and "Login Password". Note: You must be login as the Supervisor admin to change the login information for the supervisor admin.

Tab	Item	Settings
Settings for Administrator	Security  Specifying the Extended Security Functions  Password Policy	<p>Set "Complexity Setting" to [Level 1] or [Level 2], press [Change] on the right of "Minimum Character No.", and then set the number of characters to 15 or more.</p> <p>For example, to set the number of characters to 15, press the number key "1", "5", and then "#".</p> <p>Changes to the password policy apply to passwords that are specified or changed after the policy has been updated.</p>
Settings for Administrator	Data Management  Auto Erase Memory Setting	<p>Select [On], and then select [NSA], [DoD], or [Random Numbers].</p> <p>If you set this to [Random Numbers], set [Number of Erase] to three or more.</p>



3.6.2 Functions Managed via the WIM

86 The following settings are used to manage TOE functions via the WIM interface.

3.6.2.1 SMTP Settings

87 The TOE provides secure communication with an SMTP server. Use the following settings on WIM to manage the SMTP server.

Table 22: SMTP Settings

Category	Item	Settings
Device Settings	Email  Administrator Email Address	Enter the administrator's email address.
Device Settings	Email  SMTP Server Name	Enter the SMTP server name or IP address.

3.6.2.2 Security Settings

88 The following settings on WIM are used to manage the TOE cryptographic and trusted channel functions as well as the user lockout policy.

Table 23: Changing Security Settings

Category	Item	Settings
Security	Device Certificate ▶Certificate 1 ▶Create	Create and install a self-signed device certificate. Set "Algorithm Signature" to one of the following: sha512WithRSA-2048 sha256WithRSA-2048
Security	Device Certificate ▶Certificate 1 ▶Request	Create a certificate request Set "Algorithm Signature" to one of the following: sha512WithRSA-2048 sha256WithRSA-2048 Submit the request Install the issued certificate
Security	Device Certificate ▶Install	Install a certificate issued by the certificate authority and any intermediate certificate.
Security	Device Certificate ▶Install Intermediate Certificate	When using an intermediate certificate, configure this setting to install the certificate.
Security	Device Certificate ▶Certification ▶S/MIME	Select the installed device certificate.
Security	Device Certificate ▶Certification ▶IPsec	Select the installed device certificate.

Category	Item	Settings
Security	S/MIME ▶Encryption Algorithm	Select [AES-256 bit] or [AES-128 bit]. When using S/MIME, it is necessary to register the user certificate.
Security	S/MIME ▶Digest Algorithm	Select [SHA-512 bit], [SHA-384 bit], or [SHA-256 bit].
Security	IPsec ▶IPsec	Select [Active].
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Local Address	The machine's IP address
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Remote Address	Connected server's IP address (the TOE uses IPsec for communication with the LDAP, Syslog, NTP, SMTP and FTP servers)
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Authentication Method	[Certificate] or [PSK]. If you select PSK, press the "Change" button for "PSK Text" to set PSK. "PSK Text" is limited (truncated) to 32 characters.
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Hash Algorithm	Select [SHA256], [SHA384], or [SHA512].

Category	Item	Settings
Security	IPsec ▶Encryption Key Auto Exchange Settings ▶Encryption Algorithm	Select [AES-128-CBC] or [AES-256-CBC].
Security	User Lockout Policy ▶Number of Attempts before Lockout	1-5
Security	User Lockout Policy ▶Lock Out User for	1-9999

3.6.2.3 Auto Logout Settings

89 The TSF initiated termination function can be managed via the WIM with by configuring the value for the following setting.

Table 24: WIM Auto Logout Settings

Category	Item	Settings
Webpage	Webpage ▶Web Image Monitor Auto Logout Settings	3 - 60 The default setting is 60 seconds.

3.6.3 User Management

90 Users accessing the TOE functions are identified and authenticated and allowed to access only the functions that they have permissions to access. The TOE includes an address book of registered users accounts that stores individual user attributes including username, user role, available function lists. The instructions for managing users are provided in “User Authentication” in the [“Introduction and Basic Operations”](#) pages of the User Guide.

91 It should be noted that changes to user security attributes are effective immediately with the press of the “OK” button.

3.6.4 Administrator Roles

92 The System Settings in Procedure 1 above identifies the settings for managing the administrator roles in the TOE.

3.6.5 Default Passwords

93 The administrator and supervisor passwords are blank by default, they must be set as part of the initial configuration.

3.6.6 Password Management

94 The System Settings in Procedure 1 above identify the settings for configuring the TOE password policy.

3.6.7 Setting Time

95 See "Table 6: System Settings " for the settings to configure Time and for the Time settings and "Table 16: Security Settings " for settings to configure access to an NTP server for time synchronization.

3.6.8 Audit Logging

96 The TOE collects audit data in 3 types of logs:

- a) Job log – which logs user actions such as printing, copying, storing documents or faxing documents.
- b) Access Log - which logs identification and authentication events, system events and security operations events. This log includes records of the use of the management functions, login and logout events.
- c) Eco -Friendly Log — Which logs power on and power off events.

97 Only the authorized administrator can access, configure and manage the audit settings. Only the authorized administrator can review and manage the audit logs

98 The TOE limits the number of audit records that it stores in the 3 logs: 4000 job logs, 12,000 access logs and 4,000 eco-friendly logs before the oldest audit record are overwritten. Using the WIM, the authorized administrator can download the audit logs and delete them.

99 Additional instructions for managing the audit logs are available in the [Collecting Logs](#) RICOH Help pages,

3.7 U_NORMAL User Access

100 The U_Normal user does not have administrator access to the TOE. They can access TOE protected user data and functions based on the available functions list configured for their user account. The user guide describes the job and operations accessible to the U_Normal user.

4 Clearing the machine for redeployment or at end-of-life

101 All pre-shared keys, symmetric keys, and private keys are encrypted and are not accessible through normal interfaces during operation.

102 To clear the machine of all customer-supplied information, perform the following steps:

- a) Replace the data encryption key
- b) Replace the device certificate

- c) Perform the Erase All Memory function .

103 This deletion function is outside the scope of the evaluation. See the [Security Guide](#) for additional information.

5 Annex A: Log Reference

5.1 Format

104 The TOE generates audit records for all required auditable events. Each audit record includes time and date, type of events, user identify, outcome of events.

5.2 Events

105 The TOE generates the following log events.

Table 25: Audit Events

[illegible]

Requirement	Auditable Events	Example Event
		<p> Print: "2020-09-03T09:24:06.0", "2020-09-03T09:24:54.0", "Fax: Sending", "Failed", "Control Panel", "Failed", "Cancelled by User", "0x00000003", "u1", "0x00000000000000001b364" </p> <p> Fax: "2020-09-03T09:24:06.0", "2020-09-03T09:24:54.0", "Fax: Sending", "Failed", "Control Panel", "Failed", "Cancelled by User", "0x00000003", "u1", "0x00000000000000001b364" </p> <p> Scan: "2020-09-03T09:24:06.0", "2020-09-03T09:24:54.0", "u1d", "1234", "" </p>

Requirement	Auditable Events	Example Event
		"Succeeded", "Completed" "0x000000000001bee9" "Scan File", "2020-09- 09T16:52:36.0", "2020-09- 09T16:52:40.0" "Succeeded", "Completed" "0x000000000001bee9" "Send" "2020- 09-09T16:52:40.0", "2020-09- 09T16:52:47.0", "u1d", "10.20.5.7: /u1" Document Server: "2020-09-03T09:13:24.0", "2020- 09-03T09:13:28.0", "Document Server: Storing", "Succeeded", "C ontrol Panel", "Completed", "0x0 0000003", "u1", "0x00000000000 1b349" "Succeeded", "Completed" "0x000000000001b349" "Scan File", "2020-09- 03T09:13:24.0", "2020-09- 03T09:13:28.0" "Store" "2020- 09-03T09:13:24.0", "2020-09- 03T09:13:28.0", " ", "903", "COP Y0012", "0", " COPY: "2020-09-01T12:41:09.0", "2020- 09- 01T12:41:19.0", "Copier: Copyin g", "Succeeded", "Control Panel", "Completed", "0x00000003". "u1"

Requirement	Auditable Events	Example Event
		<pre> "0x0000000000001adf4" "" "" "" "Successful" "Completed" "" "0x0000000000001adf4" "" "" "Scan File", "2020-09- 01T12:41:09.0", "2020-09- 01T12:41:19.0" "Successful" "Completed" "" "0x0000000000001adf4" "" "" "Print", "2020-09- 01T12:41:09.0", "2020-09- 01T12:41:19.0" "1" "LT", "normal" </pre>
FIA_UAU.1/ FIA_UID.1	Unsuccessful identification Unsuccessful authentication	<p>Operation Panel</p> <pre> "2020-09-03T09:13:00.0", "2020-09- 03T09:13:00.0", "Login", "Failed", , "Password Mismatch", "0x00000000", "u1", " 0x0000000000001b347", "", "Auth entication", "", "Control Panel" "Completed" </pre> <p>WIM</p> <pre> "2020-09-09T16:35:58.0", "2020-09- 09T16:35:58.0", "Login", "Failed", , "Password Mismatch", "0x00000000", "admi n", "0x0000000000001bea1", "ip:1 72.16.200.10", "Authentication", " "via Network" </pre>

[illegible]

[illegible]

[illegible]

Requirement	Auditable Events	Example Event
		<pre> Encryption Communication", "500", "UDP", "i p:10.20.5.3", "500", "", "IPsec", "IP sec", "Communication Start Request Sender (Out)" "" "Start" "" "" "" "" "" "" "" "" "" "" "Failed" "" </pre>
		<p>TLS:</p> <pre> {"parentLogId":"00000000000018 f5f", "subLogId":"0008000000000 0650000000000018f5f", "subJob Type":"destination.network", "des NetSubState":"ended- incomplete", "desNetStartTime":" 2020-08- 25T20:29:51Z", "desNetStartVali dTimeFlag":"on", "desNetEndTim e":"2020-08- 25T20:30:01Z", "desNetEndValid TimeFlag":"on", "desNetAddress Name":"u1d", "desNetAddress":" u1@example.com", "desNetSen dKind":"mail", "desNetSendOwn er":"u1d", "desNetSendMode":"d ocument", "desNetSendPages":" ", "desNetFileNo":"", "desNetError Info":"", "desNetSubStatusDetail" :"dest-connect- fail", "logPart":"1 of 1"} </pre>