



User Manual



Facial
Recognition



Works During
Internet and
Power Outages



7 Days of
Free Storage

Contents

3 Welcome to Ooma Butterfleye!

- What Ooma Butterfleye Can Do for You
- How Ooma Butterfleye Works
- Getting Help

4 Setting up Ooma Butterfleye

- Getting Started
- Adding Ooma Butterfleye to an Existing Account
- Ooma Butterfleye LED Blink Codes
- Firmware Updates
- App Updates
- Finding the Best Location for Your Ooma Butterfleye
- Using Your Ooma Butterfleye Unplugged and Offline

6 Faces (Facial Recognition)

- Understanding Faces
- How Faces Works
- Using Faces

8 Viewing Events

- Viewing the Camera's Page
- Viewing the Camera's Livestream
- Panning and Zooming Video
- Instant Video Capture
- Livestream Recording
- Two-Way Talk
- Timeline: Viewing Recordings
- Sharing, Managing, and Downloading Recordings

11 Features, Rules, and Smart Alerts

- Power and Internet Outages
- Privacy Mode
- Auto Privacy Mode (Geofencing)
- Managing Notifications
- Timeline Filtering
- Local Network Streaming

15 Settings

- Wi-Fi Preferences
- Notifications
- Enabling/Disabling Audio
- Changing the Camera's Name
- Camera Status
- Battery Remaining
- Firmware Version
- MAC Address

16 Personalizing Your Ooma Butterfleye

- Profile Settings
- Sharing Login Credentials

17 Managing Your Ooma Butterfleye Account

- Upgrading to a Membership Plan
- Cancelling a Paid Plan

19 FAQs and Troubleshooting

20 Specifications

Welcome to Ooma Butterfleye!

What Ooma Butterfleye Can Do for You

Ooma Butterfleye is a smart video security camera with facial recognition and the ability to record during internet and power outages. The Ooma Butterfleye camera can be plugged in or used with a backup battery. The camera connects to your Wi-Fi network and does not require a base station, so it can be used in any household configuration. The Faces feature provides facial recognition, making your alerts more accurate and resulting in fewer false alarms.

Advanced features of the Ooma Butterfleye include:

- **Facial recognition** – Artificial intelligence built into the Ooma Butterfleye and its cloud storage service allows users to train the camera to recognize faces. This can significantly reduce false positives, common in other home security cameras, where friends or family members trigger unnecessary alerts.
- **Backup battery and onboard storage** – The Ooma Butterfleye contains an internal battery that will keep the camera running for two to four weeks under typical usage conditions, along with 16 gigabytes of onboard storage (32 gigabytes for the black camera). When reconnected to Wi-Fi, the camera automatically uploads all recorded clips, so users can see what happened even during a power outage or when the camera is used in locations where power and internet aren't available.
- **Instant video capture** – The Ooma Butterfleye records a constantly refreshed five-second video buffer when connected to AC power. Whenever an event is triggered – such as motion or a loud noise – the camera adds the buffer to the uploaded video clip. In effect, this creates a mini time machine where the clip shows what happened in the five seconds before the triggering event.
- **Auto privacy mode** – The camera can be set for geofencing, where it is automatically turned off when a user returns home, based on the location of the user's mobile phone, and automatically turned on when the user departs.
- **Two-way audio** – The Ooma Butterfleye contains both a microphone and a speaker. While livestreaming, users can talk to people in range of the camera through the Ooma Butterfleye app on their phones.

How Ooma Butterfleye Works

When your Ooma Butterfleye detects motion, sound, or that the camera has been moved, it communicates via your Wi-Fi to stream video to your Ooma Butterfleye cloud account. Your iOS or Android device will alert you when a new video clip is uploaded through the Butterfleye app.

Getting Help

Ooma Butterfleye customer support is available by phone at **877-629-0562** or by email to butterfleye.support@ooma.com.

Setting up Ooma Butterfleye

Getting Started

Ooma Butterfleye is shipped with a permanently-installed battery. When you unbox the device, your first step should be to use the included AC adapter and Micro-USB cable to plug your Ooma Butterfleye in. Allow the camera to charge until it is at 100% battery capacity. If the battery is fully drained, charging the camera takes about four to six hours.










Once the camera is fully charged, follow these steps to complete your setup:

- 1 Download the Butterfleye Security Camera app from the App Store (iOS) or from Google Play (Android) and install it on your mobile device.
- 2 Open the app and either create an Ooma Butterfleye account or sign into an existing account. Make sure your phone's Wi-Fi and Bluetooth capabilities are turned on.
- 3 Hold down the power button on top of the camera to turn the Ooma Butterfleye on. The button will blink green three times and then turn solid blue. The application will automatically detect your camera.
- 4 In the Ooma Butterfleye app, go to "Add a Camera" and follow the on-screen prompts to pair your camera and connect it to the internet.

Adding Ooma Butterfleye to an Existing Account

You can add up to six Ooma Butterfleye cameras to your Butterfleye account. Simply navigate to the "Add a Camera" page inside the Ooma Butterfleye app and follow steps 3 and 4 above to add additional cameras.

Ooma Butterfleye LED Blink Codes

	Blue blink - Video is recording
	Blue solid - Find & Identify button is being pressed in the app, or the camera is unpaired
	Green 3x blink - Camera is turning on
	Red 3x blink - Camera is turning off
	Red continuous blink - Battery is at or below 20%
	Red solid - There is an error
	Amber continuous blink - Internet is unavailable
	Amber 3x blink (when camera is on) - Camera is plugged into the charger
	Purple continuous blink - Camera upgrade in progress

Setting up Ooma Butterfleye

Firmware Updates

Ooma is continuously working to enhance the Ooma Butterfleye with new software features and more efficient operation. When an update becomes available, a circle with a 1 inside will appear on the gear icon in the Ooma Butterfleye app. Tap the gear icon and scroll to the bottom of the camera details page. Tap “Update Camera Software” to begin the firmware update.

App Updates

The Butterfleye Security Camera app will update automatically whenever a new version is released provided that your phone is configured to accept automatic updates.

Finding the Best Location for Your Ooma Butterfleye

You should set up your Ooma Butterfleye camera in an indoor location with a clear, unobstructed field of view for the area you want to monitor. The camera should be within range of your Wi-Fi network.

The field of view is the area in which the camera can detect motion. Your Ooma Butterfleye camera has a 120-degree viewing angle.

Do not block the camera’s field of view. Make sure that no walls, tables, or objects are too close to the camera. If an object is within 2.5 inches of the sides or front of your camera, it can reflect light back into the camera lens and cause glare or hazy video.

For optimal facial recognition results, place the camera at eye level.

Using Your Ooma Butterfleye Unplugged and Offline

Ooma Butterfleye has a built-in battery and onboard storage that allows the camera to record even when it is disconnected from AC power and Wi-Fi.

The camera is designed to be usable in locations without electrical outlets. Under typical circumstances, a fully-charged camera will operate for two to four weeks when it is unplugged. The camera only needs to be plugged in for about four to six hours to fully recharge. While the camera is unplugged, the Instant Video Capture feature does not function and video clips are limited to 10 seconds in length instead of 20 seconds.

Ooma Butterfleye can also operate without a Wi-Fi connection. Video clips are stored in the camera’s onboard memory and are uploaded to the user’s account when the camera is reconnected to Wi-Fi. The power button will blink amber when the camera is operating without a Wi-Fi connection. This is normal.

Faces (Facial Recognition)

Understanding Faces

The Faces feature allows Ooma Butterfleye users to identify the person appearing on camera, making the notifications you receive accurate and detailed.

Ooma Butterfleye leverages proprietary facial recognition that uses machine learning and artificial intelligence to learn to recognize individual faces. Once a face has been recognized it can be named, or tagged, inside the Ooma Butterfleye app. The recognition of faces increases as you train the camera over the course of a few weeks.


For best results, the Ooma Butterfleye camera should be placed at eye level in a location where it will see faces from the front rather than from the side.

How Faces Works

You can train the Ooma Butterfleye camera to recognize new faces, add images to existing faces for better recognition, or delete faces you do not wish the camera to remember.



THE FACES PAGE




THE COMBINE OPTION

- 1 Navigate to the Feeds & Events page in the app. Tap the Menu icon in the upper left and select **Faces**.
- 2 Tap any of the faces in the Unfamiliar Faces section to identify them. You have three options:
 - A If this is the first time you are identifying the person, enter their name in the pop-up window.
 - B If this is a person you have previously identified, select an existing face from the list in the pop-up window and then tap “Combine.” This will help improve the recognition accuracy when the person is next seen by the camera.
 - C If this is a person you don’t want to have identified in future, click the trash icon in the upper right corner of the pop-up window.

Faces (Using Faces)

The camera may occasionally incorrectly associate an image of an unknown person to a known face. To correct this, tap on the known face on the Faces page. In the pop-up window, tap the picture of the face in the center circle. This will open a gallery of all recent images associated with that face.



THE GALLERY PAGE

Scroll through the gallery and use the trash icon at the bottom of the screen to delete any incorrect images.

Using Faces


You can choose to receive notifications only when the camera sees unknown faces, when it sees only known faces, or for all faces.

Navigate to the Feeds & Events page in the app. Tap the gear icon in the upper right corner of the screen, then tap the Notifications line. You can toggle the “Known Person was detected” and the “Unknown Person was detected” switches on or off.

Viewing Events

Viewing the Camera's Page

Videos that are recorded by your Ooma Butterfleye, which are also known as events, are stored in the event timeline. You can swipe right or left to view all the cameras connected to your account. This page allows you to view your recordings as well as download, share, and delete events.



THE FEEDS & EVENTS PAGE

Viewing the Camera's Livestream

You can view a livestream of the camera's video feed at any time.

- 1 Open the Ooma Butterfleye app on your mobile device.
- 2 Navigate to the Feeds & Events page.
- 3 Click the play button on the top video player.
- 4 Swipe left or right to end the livestream.

Panning and Zooming Video

You can pan and zoom to see the details of any live or recorded video. Just pinch and drag on the desired location.

- 5 Open the Ooma Butterfleye app on your mobile device.
- 6 Start the livestream or select an event from your timeline, and:
 - A To zoom in and out of the video, pinch the screen.
 - B To move around in the player, touch and drag to the desired location without removing your fingers after pinching the screen.

Viewing Events

Instant Video Capture

When Ooma Butterfleye is plugged in and synced with an Ooma Butterfleye account, your camera uses a prebuffer to store the previous five seconds of recordings. This allows the camera to include the five seconds before an event in every saved recording. Your video recordings begin before the event is detected, ensuring you do not miss anything.


Livestream Recording

Whenever livestream viewing is initiated, the video is recorded and uploaded to the cloud as an event. This enables real-time viewing along with later playback from the timeline.

Two-Way Talk

Two-Way Talk enables you to communicate remotely with people who appear on your Ooma Butterfleye camera's feed.

- 1 Start the livestream to display the camera's video feed and play audio (if enabled). Be sure that the mobile device is in landscape mode.



LIVESTREAM IN LANDSCAPE MODE

- 2 Tap the microphone icon in the upper left corner and wait for it to turn red, indicating that two-way audio is enabled.
- 3 Press and hold the microphone icon to speak. You will not hear audio while the microphone button is pressed. Expect a delay of several seconds between the time you speak and when your voice comes out of the speaker on the camera.

Viewing Events

Timeline: Viewing Recordings


All recordings are posted on the Ooma Butterfleye's timeline. The timeline can be used to manage events: re-watching events, downloading events as MP4 files, sharing events, and deleting events.

If you receive a notification of a new event but do not see that event on your timeline, please close and reopen the Ooma Butterfleye app.


Sharing, Managing, and Downloading Recordings

You can share, download, and manage recordings from the Ooma Butterfleye camera's timeline.

- 1 Open the Ooma Butterfleye app on your mobile device.



THREE GRAY DOTS



SHARE OR SAVE FULL EVENT

- 2 Navigate to the events timeline, then select the event you wish to manage by tapping the three gray dots on the right side of the event.
- 3 Tap on Delete This Event to delete the event, or on Share or Save Full Event to download the event to your mobile device as a video.
- 4 If you have chosen to download the video, a notification will appear when the download is complete so you can save the event on your mobile device or share it.

Features, Rules, and Smart Alerts

Power and Internet Outages

Ooma Butterfleye has battery backup that can last for two to four weeks. It also has internal storage that can hold the data from several weeks of recordings, depending on usage patterns. When the Internet or power goes out, Ooma Butterfleye operates normally. Once the Wi-Fi connection is re-established, all data is uploaded to the cloud.

Privacy Mode

The **Privacy Mode** feature allows you to put the camera to sleep when you want to stop recording or when you don't want to be disturbed by notifications.


Auto Privacy Mode (Geofencing)

Ooma Butterfleye supports geofencing to automatically arm and disarm cameras based on the location of the user's mobile device. If you travel 50 meters (about 165 feet) away from your camera while carrying your mobile device, **Privacy Mode** will turn off so that your camera will capture anything that happens while you are away. When you return to the camera's home zone, Privacy Mode will be reenabled.


Features, Rules, and Smart Alerts

To set up Auto Privacy Mode:

- 1 Open the Ooma Butterfleye mobile app, navigate to the **Feeds & Events** page, and click the gear icon in the upper-right.



DETAILS PAGE



AUTO PRIVACY MODE PAGE

- 2 Toggle the Auto Privacy Mode switch to the on position.
- 3 Follow the instructions to either enter the street address for the camera's location or to accept the GPS location shown on your mobile device and then accept the address shown in the pop-up window.


If you have multiple Ooma Butterfleye cameras on your account, you must enable **Auto Privacy Mode** for each one.

Features, Rules, and Smart Alerts


Managing Notifications

Ooma Butterfleye allows users to determine which notifications they wish to receive and which they would prefer to mute. Notification options can be automatically changed depending on the time of day.

- 1 Open the Ooma Butterfleye mobile app, navigate to the Feeds & Events page, and click the gear icon in the upper-right.



DETAILS PAGE



NOTIFICATIONS PAGE

- 2 On the Details page, tap the word “Custom” on the Notifications line.
- 3 Use the toggle switches to select the notifications you wish to receive.
- 4 Toggle the switch at the bottom of the page to create a Notification Schedule, which will turn off notifications at set times of day such as when you’re home at night.


Features, Rules, and Smart Alerts

Timeline Filtering


Timeline filtering allows users to quickly sort through all timeline events to find specific recordings.

To filter your timeline:

- 1 Open the Ooma Butterfleye mobile app and navigate to the **Feeds & Events** page.



FEEDS & EVENTS PAGE



FILTER TIMELINE EVENTS PAGE

- 2 Tap the filter icons on the “Filter by:” line.
- 3 On the **Filter Timeline Events** page, de-select the items of your choice to create a filter. You can filter your results to a specific date range by using the “Show Videos On:” filter at the bottom of the page.

Local Network Streaming

Local Network Streaming allows users to bypass an external internet connection to create instant livestreams if their mobile device is connected to the same Wi-Fi router as the Ooma Butterfleye.

To turn on Local Network Streaming:

- 1 Ensure that the Ooma Butterfleye and the mobile device are connected to same Wi-Fi router
- 2 Open the Ooma Butterfleye app, navigate to the Feeds & Events page, and click on the gear icon in the upper right
- 3 Turn on Local Network Streaming

Settings

Wi-Fi Preferences

Your mobile device must be within Bluetooth range of the Ooma Butterfleye camera to change the Wi-Fi network. To switch your Wi-Fi settings, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose Wi-Fi connection you wish to update. From the Details page, select “Change Settings” and then select the new network you wish to connect to. You may need to enter the network’s credentials.

Notifications

To switch your notification settings, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose notifications you wish to update. From this page, you can customize the notifications you wish to receive. You can also schedule times when you would prefer not to receive notifications.

Enabling/Disabling Audio

To change audio settings, launch the Ooma Butterfleye app and tap the gear icon of the camera whose settings you wish to update. Toggle the “Audio Enabled” switch on or off.

Changing the Camera’s Name

To change your camera’s name, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose name you wish to change. Tap on the camera’s current name on the “Camera Name” line. A popup window will ask for the camera’s new name.

Camera Status

To view your camera’s status, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose status you wish to see. The status will either be “Connected to cloud” or “Offline.”

Battery Remaining

To view the remaining battery charge, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose details you wish to see. The remaining battery capacity is listed on the camera’s Details page.

Firmware Version

To view the camera’s firmware version, launch the Ooma Butterfleye app on your mobile device and tap the gear icon of the camera whose firmware you wish to check. The firmware version is listed on the camera’s Details page.

MAC Address

To view your camera’s MAC address, launch the Ooma Butterfleye app and tap the gear icon of the camera whose MAC address you wish to view. The MAC address can be found at the bottom of the camera’s Details page

Personalizing Your Ooma Butterfleye

Profile Settings

To customize your profile settings, launch the Ooma Butterfleye app on your mobile device. Tap the **Menu icon** in the upper left and select **Profile**. You can use this page to:

- Change your username
- Update the email address of your Ooma Butterfleye account
- Update your password
- See what version of the app you are using
- See which Membership plan you have subscribed to
- Sign out of your account

Sharing Login Credentials

For privacy purposes, we do not encourage sharing your account's login credentials. We recommend that only one mobile device is used to log into an account.

Only one user can be logged into an account at a time. If a second user logs in, the first user is automatically logged out of the account.

Managing Your Ooma Butterfleye Account

Upgrading to a Membership Plan

Ooma Butterfleye can be used without a monthly subscription plan, although Ooma offers two membership plans that unlock powerful features and increase the duration of cloud storage. All plans allow users to connect up to six cameras to a single account at no additional cost.

Details of current Ooma Butterfleye plans are:

	Monitor	Home Secure	Business Secure
Price per customer	Free	\$9.99/mo \$99.99/yr	\$29.99/mo \$299.99/yr
Cloud storage	7 Days	30 days	90 Days
Instant video capture	●	●	●
Livestreaming	●	●	●
Video history	●	●	●
Works during power and internet outages	●	●	●
Instant alerts (motion, sound, anti-tamper)	●	●	●
Onboard storage	●	●	●
Instant streaming	●	●	●
Privacy arm/disarm	●	●	●
Unlimited video download & share	●	●	●
Audio enabled/disabled	●	●	●
Ability to save multiple Wi-Fi credentials	●	●	●
Camera software upgrade over the air	●	●	●
Programmable notifications	●	●	●
Filter and sort timeline events	●	●	●
Bank-level AES-256 encryption	●	●	●
Facial recognition		●	●
Remote 911 (coming soon, Telo customers only)		●	●
Automatic arm/disarm		●	●
Two-way audio		●	●
Scheduled notifications		●	●
Fixed fee up to six cameras		●	●
Multi-site automatic arm/disarm (coming soon)			●
Business analytics (coming soon)			●

Managing Your Ooma Butterfleye Account

Cancelling a Paid Plan

You can use the Ooma Butterfleye mobile app to manage payment methods and cancellations.

For iPhone:

- 1 Open your device's **Settings app**.
- 2 Scroll down and tap **iTunes Store & App Store**.
- 3 Tap your **email address** and **Apple ID**.
- 4 Tap **View Apple ID** and enter your password.
- 5 Tap **Subscriptions**, then select **Ooma Butterfleye**.

For Android:

- 1 Launch the **Google Play Store app**
- 2 Tap **Menu**, then **My Apps**, then **Subscriptions**, then tap on the Ooma Butterfleye app.
- 3 Tap **"Cancel"** and then **"Yes"** to confirm the cancellation
- 4 The status of the subscription should change from **Subscribed** to **Canceled**.

FAQs and Troubleshooting

1 What is the minimum internet speed required for Ooma Butterfleye cameras?

Ooma Butterfleye cameras require a minimum upload speed of 1Mbps per camera. For example, you will need a minimum of 3Mbps of upload speed on your wireless network to support three cameras in your home.

2 Does Ooma Butterfleye work with both the 2.4GHz and the 5GHz frequency bands on Wi-Fi routers?

Ooma Butterfleye only works with the 2.4GHz frequency band.

3 Does Ooma Butterfleye work outdoors?

The Ooma Butterfleye is not weatherproof, but it can work outside if it is sheltered from rain, snow, and other forms of moisture.

4 Does the Ooma Butterfleye camera work without an internet connection?

Yes. Ooma Butterfleye needs a Wi-Fi connection for live view and video uploads. When the internet connection is interrupted, Ooma Butterfleye can use its built-in storage to record events that will be uploaded when a connection becomes available. Ooma Butterfleye can also connect directly to a mobile device through a local Wi-Fi network without needing an internet connection.

5 Does the Ooma Butterfleye record audio?

Yes. You can also use the Ooma Butterfleye app to talk to people who are near your camera.

6 How do I access my videos?

Ooma Butterfleye automatically uploads videos to the cloud and can be accessed through the Ooma Butterfleye app.

7 How can I update my camera?

The Ooma engineering team frequently releases free software updates for the Ooma Butterfleye. These updates will be available through your app under the Details tab. If the camera software update button is greyed out, then you are running the latest version of the software. If you have notifications enabled, you'll also receive a notification through the app when new software is released.

Specifications

Camera

- 1/3" 3.5 megapixel full color CMOS sensor
- 120-degree field of view
- 1080p full HD video with 8x digital zoom
- H.264 encoding
- Auto-adaptive white and black balance + exposure
- Noise reduction – low-light high sensitivity
- Focus range – fixed focus (2 feet to infinity)

Wireless & Audio

- 802.11 b/g/n 2.4 Ghz
- WEP, WPA, and WPA2 support
- Half duplex two-way audio with speaker and microphone

Power & Capacity

- USB: Input – Micro USB 5V DC, 2A
- AC Adaptor: Input – 110-240VAC, 50-60Hz
- AC Adaptor: Output – 5V DC, 2A
- 10,400mAh built-in rechargeable battery
- Battery level indicator
- 16GB built-in storage (white Ooma Butterfleye)
- 32GB built-in storage (black Ooma Butterfleye)

Sensors & Detection

- Passive infrared detector
- Ambient light detector
- Accelerometer
- Sound sensor
- Instant push notifications
- Five-second preview (instant video capture)
- Adjustable sound detection

Dimensions & Certifications

- Weight: 12.5oz (355g)
- Height: 3.3" (83mm)
- Width: 3.8" (97mm)
- Depth: 1.6" (41mm)
- UL, FCC, and IC certified

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.