

COMMUNICATION

Address _____ City _____ State _____ Zip _____

Transmission Delay _ _ (0, 15 to 45 seconds, default = 30)

Account Number _ _ _ _ (1 to 65535, default = 12345)

The Communication charts below contain all available options for communication programming. Refer to the Available With column to determine which option is available for the communication type being programming.

[illegible]

ADVANCED COMMUNICATION

[illegible]

DEVICE SETUP

	NO	YES
DHCP		
Local IP Address	— — — . — — — . — — — . — — —	
Gateway Address	— — — . — — — . — — — . — — —	
Subnet Mask	— — — . — — — . — — — . — — —	
DNS Server	— — — . — — — . — — — . — — —	
734N Listen Port	— — — —	(Default = 2002)
734N Passphrase	— — — — — — — — — — — — — — — —	

#	Device		Device Name	Wireless?	Serial Number	Supervision Time (0, 60, 240)	Access Areas (1-8)	Egress Areas (1-8)	Display Areas (1-8)	Strike Time (0-250 sec)	Strike Delay (0-9 min)	Fire Exit	Output Group	Over-ride	Auto Force Arm	Door Real Time	Door Force Msg
	Type	Comm Type															
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y

DEVICE SETUP (continued)

[illegible]

MESSAGING SETUP

Enable Messaging	NO	YES
System Name		
Destination 1		
Destination 1 User Number	_ _ _ _ _	
Destination 2		
Destination 2 User Number	_ _ _ _ _	
Destination 3		
Destination 3 User Number	_ _ _ _ _	
Email Comm Type	NET	CELL
O/C Email	NO	YES
O/C SMS	NO	YES
Monthly Limit	_ _ _ _ (0-999, Default = 0)	
SMTP Server		
SMTP Port	_ _ _ _ _	
SMTP Username		
SMTP Password		
From Email		

REMOTE OPTIONS

Remote Key	_ _ _ _ _		
Remote Disarm	NO	YES	
Armed Answer Rings	_ _	(0 to 15, default = 8)	
Disarmed Answer Rings	_ _	(0 to 15, default = 8)	
PC Modem	NO	YES	
Alarm Receiver Auth	NO	YES	
Service Receiver Auth	NO	YES	
Manufacturer Auth	NO	YES	
Allow Network Remote	NO	YES	
Network Programming Port	_ _ _ _	(Default = 2001)	
Encrypt Network Remote	NO	YES	
Allow Cellular Remote	NO	YES	
First GPRS APN	_ _ _ _ _		
	(Default = SECURECOM400)		
Second GPRS APN	_ _ _ _ _		
	(Default = SECURECOM400)		
Encrypt Cellular Remote	NO	YES	
Entre Connection	NONE	NET	
Entre Incoming TCP Port	_ _ _ _	(Default = 2011)	
Entre IP Address	_ _ _ . _ _ . _ _ . _ _		
Entre Outbound TCP Port	_ _ _ _	(Default = 2001)	
Entre Backup IP Address	_ _ _ . _ _ . _ _ . _ _		
Entre Backup TCP Port	_ _ _ _	(Default = 2001)	
Entre Checkin Minutes	_ _ _	(0, 3-240 minutes, default = 0)	
Entre Passphrase	_ _ _ _ _		
Send Local Changes	NO	NET	DD
Remote Change IP	_ _ _ . _ _ . _ _ . _ _		
Remote Change Port	_ _ _ _	(Default = 2002)	
Remote Phone No	_ _ _ _ _		

SYSTEM REPORTS

Abort Reports	NO	YES	
Restoral Reports	NO	YES	DISARM
Bypass Reports	NO	YES	
Schedule Change Rpts	NO	YES	
Code Change Reports	NO	YES	
Access Keypads	1 2 3 4 5 6 7 8		
Ambush	NO	YES	

SYSTEM OPTIONS

System	AREA	A/P	H/A	GST
Instant Arming	NO	YES		
Closing Wait	NO	YES		
Entry Delay 1	_ _ _	(30 to 250 sec, default = 30)		
Entry Delay 2	_ _ _	(30 to 250 sec, default = 60)		
Entry Delay 3	_ _ _	(30 to 250 sec, default = 90)		
Entry Delay 4	_ _ _	(30 to 250 sec, default = 120)		
Cross Zone Time	_ _ _	(4 to 250 sec, default = 4)		
Zone Retard Delay	_ _ _	(0 to 250 sec, default = 10)		
Power Fail Delay Hrs	_ _	(0 to 15 hours, default = 1)		
Swinger Bypass Trips	_	(0 to 6, default = 2)		
Reset SwngR Bypass	NO	YES		
Time Change	NO	YES		
Hours from GMT	_ _	(0 to 23, default = 6)		
Latch Supervisory	NO	YES		
Programming Language				
Primary Language	ENGLISH	SPANISH	FRENCH	
Secondary Language	NONE	ENG	SPN	FRN
User Language				
Primary Language	ENGLISH	SPANISH	FRENCH	
Secondary Language	NONE	ENG	SPN	FRN
Bypass Limit	_	(0 to 8, default = 0)		
Wireless House Code	_ _	(0, 1 to 50, 99, default = 0)		
Detect Wireless Jamming	NO	YES		
Wireless Audibles	ANY	DAY	MIN	
Enable Keypad Panic Keys	NO	YES		
Occupied Premise	NO	YES		
Enhanced Zone Test	NO	YES		
Send 16 Character Names	NO	YES		
Keypad Armed LED	ALL	ANY		
Use False Alarm Question	NO	YES		
Change Own User Code	NO	YES		
Panic Supervision	NO	YES		

BELL OPTIONS

Bell Cutoff Time	_ _	(0 to 99 minutes, default = 15)		
Automatic Bell Test	NO	YES		
Bell Output	_ _ _			
Bell Action . . .				
Fire Zones	Steady	Pulse	Temporal	None
Burglary Zones	Steady	Pulse	Temporal	None
Supervisory Zones	Steady	Pulse	Temporal	None
Panic Zones	Steady	Pulse	Temporal	None
Emergency Zones	Steady	Pulse	Temporal	None
Auxiliary 1 Zones	Steady	Pulse	Temporal	None
Auxiliary 2 Zones	Steady	Pulse	Temporal	None

OUTPUT OPTIONS

Cutoff Output	1 2 3 4 5 6			
Cutoff Time	_ _ _	(0 to 99 minutes, default = 0)		
Comm Fail Output	_ _ _			
Fire Alarm Output	_ _ _	Phone Trouble Output	_ _ _	
Fire Trouble Output	_ _ _	Late to Close Output	_ _ _	
Panic Alarm Output	_ _ _	Device Fail Output	_ _ _	
Ambush Output	_ _ _	Sensor Reset Output	_ _ _	
Entry Output	_ _ _	Closing Wait Output	_ _ _	
Exit Output	_ _ _	Arm-Alarm Output	_ _ _	
Ready Output	_ _ _	Supv Alarm Output	_ _ _	

OUTPUT INFORMATION

Output No. *	Output Name	Real-Time Status Reports N or Y	Serial Number	Superv. Time (0, 3, 15, 60 min.)	Trip with Panel Bell (YES or NO)

* Output Numbers = 0 to 6, 450 to 474 (slow wireless output response), 480 to 499 (fast wireless output response), 500 to 599, D1 to D8, G1 to 20

OUTPUT GROUPS

#	Name	Output Number

MENU DISPLAY

Armed Status	1	2	3	4	5	6	7	8
Time Display	1	2	3	4	5	6	7	8
Arm/Disarm	1	2	3	4	5	6	7	8

STATUS LIST

Display Keypads:								
System Monitor Trbl	1	2	3	4	5	6	7	8
Fire Zones	1	2	3	4	5	6	7	8
Burglary Zones	1	2	3	4	5	6	7	8
Supervisory Zones	1	2	3	4	5	6	7	8
Panic Zones	1	2	3	4	5	6	7	8
Emergency Zones	1	2	3	4	5	6	7	8
Auxiliary 1 Zones	1	2	3	4	5	6	7	8
Auxiliary 2 Zones	1	2	3	4	5	6	7	8
Communication Path Trouble	NO			YES			ALL	

PC LOG REPORTS

Net IP Address:									
Net IP Port:									
Arm/Disarm Reports	NO						YES		
Zone Reports	NO						YES		
User Command Rpts	NO						YES		
Door Access Reports	NO						YES		
Supervisory Reports	NO						YES		
Real-Time Status Rpts	NO						YES		

AREA INFORMATION

Exit Delay	— — —	(30 to 250 seconds, default = 60)	Closing Code	NO	YES
Burglary Bell Output	— — —	(0-6, 500-599, D1-D8, G1-20)	Any Bypass	NO	YES
Open/Close Reports	NO	YES	Area Schedules	NO	YES
Closing Check	NO	YES			

[illegible]

Type	Area	Fire Bell	LX-Bus Zone Numbers Only										Disarmed Open	Disarmed Short	Armed Open	Armed Short	Entry Delay	Retard Delay	Presignal	Fast Response	Cross Zone	Priority	Fire Panel Slave	Follow Area	Real-Time Reports	Zone Audit Days	Report w/ Acct #	TGL		
			Wireless	DMP Wireless					FA Series Wireless																					
				Contact	EXT Contact	1114 Contact	Supervision Time	LED Operation	Disarm Disable	Pulse Count	Sensitivity	Check-in Time																	INT Contact	End-of-line
Keypad/LX-Bus Zones	--	NT	INT	Output *	N	INT	1	0	N	2	Low	None	N	N	N	N	N	N	N	N	N	N	N	N	0	0	ARM	TGL		
Zone Type Defaults	AR	FV	A2	1	or	Y	EXT	4	240	Y	4	High	60	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	8	365	to	DIS	STEP	
NIGHT	NT					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0			MNT	
DAY	DY					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
EXIT	EX					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
FIRE	FI			0		N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
PANIC	PN					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
EMERGENCY	EM					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
SUPERVISORY	SV			0		N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
AUXILIARY 1	A1					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
AUXILIARY 2	A2					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
FIRE VERIFY	FV			0		N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				
ARMING	AR					N	INT	N	1	240	Y	4	Low	60	N	N	N	N	N	N	N	N	N	N	0	0				TGL

[illegible]