

BEFORE USING YOUR HEADSET FOR THE FIRST TIME

- Pair the headset with a mobile phone. Please refer to the "Pairing the BLUETREK® M2" section of this manual.

Introduction

The BLUETREK® M2 headset is a wireless headset based on the Bluetooth® technology. It complies with Bluetooth® 1.2 protocol, supporting Headset and Hands-free profile.

The BLUETREK® M2 headset has 3 buttons:

- "TALK "button (main button),
- 1 "VOL+ "button,
- 1 "VOL- "button.

Charging the BLUETREK® M2

For your convenience, your headset may be delivered fully charged.

Please connect the charger to the headset and to the main. During the charge, the indicator light is red, the indicator light will turn off when the charge is complete. During subsequent charges, the charging should take approximately 2 hour 40 minutes.

When you hear a light beep in your headset at regular intervals, and the indicator light flashes in red, your headset needs to be recharged.

Important:

- If your headset is fully charged, the red indicator light will not turn on when plugging into the charger.
(To check if your headset is fully charged, press the talk button for approx. 2 seconds and the red indicator light will turn on for approx. 3 seconds.)
- To maximize battery lifetime, it is recommended to recharge your headset to full capacity only when the battery is low, since a battery has a lifetime of about 500 charging cycles.
- If you leave your headset battery empty for an extended period of time, it could excessively discharge the battery. In this case, charge your headset for 10 hours or more until the battery recovers and recharges completely. When you first charge the headset after prolonged storage, it may take about 1 minute for the red indicator light to turn on.
- Do not let the battery charger remain plugged in the headset for more than 24h.
- The use of any other charger will automatically suspend the warranty.

Pairing the BLUETREK® M2

Before using the BLUETREK® M2 headset, you must pair it with your Bluetooth® mobile phone. Pairing is the process of linking 2 Bluetooth® devices, so that they can communicate.

To initiate pairing:

1. Place the BLUETREK® M2 and your mobile phone within 0.3 meter (1 foot) from each other.
2. Switch on your phone and select its Bluetooth® discover mode (refer to the Bluetooth® mobile phone user manual).
3. When the BLUETREK® M2 is switched off, press and hold the TALK button for about 7 seconds until the indicator light flashes red and blue alternately. And a sound can be heard in the speaker.
4. Once the mobile phone detects the headset, a “BLUETREK M2” message will be displayed. Follow the phone instructions to accept the pairing. The PIN code (or passkey) is 0000, then press “yes” or “ok”.

If pairing success, the indicator light will switch to blue and flashes slowly.

If you haven't started the discovery mode within 5 minutes, the headset will switch off. You must then switch on your headset and start the pairing again.

Wearing the BLUETREK® M2

For your convenience, the ear hook of BLUETREK® M2 are designed to be removable and adjustable which allows the headset to be worn on either ear. BLUETREK®M2, as packaged, is ready to be worn on your right ear.

For left ear, simply unsnap the ear clamp from the headset by pulling gently at the case of the ear clamp ring.

Flip the ear clamp over, and snap it back onto the headset by applying gentle pressure on the case of the ear clamp ring.

The ear hook is made of a soft material which can be shaped to fit your ear. Please refer to the above diagram of how it can be adjusted.

Switching the BLUETREK® M2 ON and OFF

Switching BLUETREK® M2 ON

When your headset is off, press and hold the TALK button for about 2 seconds until the blue indicator light is on. A beep (2 tones) can be heard in the speaker. Release the TALK Button.

To check if your headset is ON, press once on the TALK button. If the indicator light flashes blue, it means your headset is ON.

Switching BLUETREK® M2 OFF

When your headset is on, press and hold the TALK button for about 5 seconds until the red indicator light is on after the quick blue flashes. A beep (2 tones) can be heard in the speaker then release the TALK button.

Making a call

****Mobile phone with voice recognition***

- . Make sure the voice recognition function on your mobile is activated and your voice tags have been recorded with the phone. To enter these, please refer to your phone's manual
- . When there is no incoming or active call, press once on the TALK button
- . Wait for the audio signal sent by the mobile phone (generally a short tone).
- . Speak the name of person you wish to call.

Mobile without voice recognition

- . Make sure both the headset and the mobile phone are ON and in stand-by mode.
- . Dial the number on the phone keypad, after approximately 2 seconds the audio connection will be established.

*This function may not be available on some phones, please refer to the trouble shooting frequent asked questions in our website: www.bluetrek.com. to find out more.

Answering a call

When the headset rings, press once on the TALK button to take the call.

Ending a call

Press once on the TALK button to end an active call.

Adjusting the volume

To increase the volume during an active call, press the "VOL+" button on the headset.

To decrease the volume during an active call, press the "VOL-" button on the headset.

Muting the microphone

To mute the microphone during an active call

During an active call, press and hold the VOL+ button for approximately 2 seconds. A periodic tone can be heard in the speaker when the microphone is muted.

To end the mute function

When the microphone is muted quickly press the VOL+ button on the BLUETREK® M2. The periodic tone will end.

Transferring a call from BLUETREK® M2 to the mobile phone

During an active call, press the TALK button for about 2 seconds.
(This function only works in the Hands-Free Profile.)

In the Headset profile, you can simply turn off your headset.

Transferring a call from the mobile phone to the BLUETREK® M2

To transfer the call back to the headset, use the menu option on your phone.

This function may not be available, depending on your phone's functionality.

Call waiting

When you hear a call waiting alert while you are on a call, a long press on the TALK button to accept the second call and place the current call on hold.

To switch between an active call and a hold call, a long press on the TALK button.

To end the active call and take the hold call, press once on the TALK button.

Additional features with some phones

Rejecting a call

When the headset rings, press the TALK button for about 2 seconds.

Redial the last number

When there is no incoming or active call, press the TALK button for about 2 seconds until you hear a beep.

Troubleshooting guide

The first thing you should do when encountering a problem that you cannot solve with this manual, is to switch off your headset and your mobile phone, and switch them on again.

To find out more, please refer to the trouble shooting frequent asked questions in our website: www.bluetrek.com.

Guidelines for safe use

Read those guidelines before using your headset.

- Do not drop or try to alter the shape of your headset.
- Do not expose your headset to liquid or moisture.
- Do not expose your headset to extreme temperatures. Temperature range: 0-40C.
- Do not expose your headset to fire or open flames.
- Do not try to disassemble your headset. Service and Maintenance can only be performed by authorized BLUETREK® dealers.
- Keep your headset away from dust and dirt.
- Do not let children play with your headset, since it contains small parts that could become detached and create a choking hazard.
- Check the regulation in your area if you plan to use your headset while driving.
- Turn off your headset before boarding an airplane.

CAUTION : Danger of explosion if battery is incorrectly replaced. Dispose of batteries according to local regulations. Do not dispose as household waste.