

GAI-TRONICS® CORPORATION A HUBBELL COMPANY

Model 711-102 and 7115-102 Desk-Edge Subsets

Confidentiality Notice

This manual is provided solely as an operational, installation, and maintenance guide and contains sensitive business and technical information that is confidential and proprietary to GAI-Tronics. GAI-Tronics retains all intellectual property and other rights in or to the information contained herein, and such information may only be used in connection with the operation of your GAI-Tronics product or system. This manual may not be disclosed in any form, in whole or in part, directly or indirectly, to any third party.

General Information

Product Overview

The Model 711-102 Single Party and 7115-102 Multi-party Desk-Edge Subsets are intended for use in GAI-Tronics Page/Party[®] and SmartSeries[®] systems.

The subset enables you to perform page and party line communication when installed with a remote amplifier and enclosure. The rugged remote subsets include a pressbar handset, a handset cradle, and a five-party rotary selector switch (Model 7115-102 Subset only).

The subset's compact design allows it to be mounted where space is limited. The compact size is made possible by housing most of the support electronics in a separate remote amplifier.

The angle bracket, supplied with the subset, supports a wide variety of mounting options. The integral connectorized cable permits mounting up to eight feet from the amplifier.




Figure 1. Multi-party Outline Diagram

WARNING Explosion hazard - substitution of components may impair suitability for Class 1, Div. 2 usage.

System Requirements and Limitations

The Model 711-102 Single Party and Model 7115-102 Multi-Party Desk-Edge Subsets must be installed with a certified remote subset amplifier and a certified Model 7245 Enclosure for proper operation. Mount the subset in an indoor location within eight feet of the enclosure. It is not designed for outdoor use.

Features and Functions

The subsets provide the following features/functions, when installed with a certified Model 723 Series Remote Subset Amplifier and Model 7245 Remote Amplifier Enclosure, in a Page/Party[®] system:

- Paging
- Party line communication over one party line (Model 711-102 only)
- Selective party line communication over one of up to five party lines (Model 7115-102 only)
- Magnetic hookswitch

The subsets provide the following features/functions, when installed with a certified Model 723 SmartSeries Remote Subset Amplifier and Model 7245 Remote Amplifier Enclosure, in a SmartSeries ADVANCE system:

- Paging
- Party line communication over one party line
- Selective party line communication over one of up to five party lines (Model 7115-102 only)
- Magnetic hookswitch
- Page duration limit
- Off-hook duration limit
- Normal and alarm mode page destinations
- Normal and alarm mode page priorities
- Normal and alarm mode pre-announcement tones

Description of Major Components

External Components

The Model 711-102 and 7115-102 Subsets contain the following subassemblies:

- **Pressbar handset** is used to perform full-duplex party line communication. Also, one-way paging is enabled by depressing the handset pressbar.
- Party line selector switch (Model 7115-102 Subset only) is used to select the desired party line.
- Magnetic hookswitch/cradle assembly provides the subset with on/off-hook control.
- Mounting angle allows the subset to mounted on the left or right side of a desk.
- **Subset cable** is an 8-foot connectorized cable that enables connection of the subset to the Model 7245 Amplifier Enclosure.




Figure 2. Top View (without handset and mounting bracket)

Internal Components

The Model 711-102 and 7115-102 Subsets contain one internal component, the Subset Termination PCBA. This assembly routes the signals of the handset, party-line selector switch, and hookswitch to the subset cable.

Block Diagram

As shown in Figure 3, the handset, hookswitch, party line switch (Model 7115-102 only), and auxiliary input (optional) signals connect to the Subset Termination PCBA. The Subset Termination PCBA then connects these signals to the appropriate terminals of the subset cable for connection to the amplifier/amplifier enclosure.




Figure 3. Block Diagram

Installation

Do not install this equipment in hazardous areas. Such installations may cause a safety hazard and consequent injury or property damage.

- 1. Refer to Figure 4 for a typical desk-edge installation example.
- 2. Remove the mounting angle from the subset.
- 3. Secure the mounting angle on the mounting surface using the two screws and the 0.203 inch (5.16 mm) mounting holes.
- 4. Re-connect the subset to the mounting angle with the screws provided.
- 5. Plug the subset cable into the amplifier enclosure and secure the connector with the connector guard (located on the amplifier enclosure).




Figure 4. Typical desk-edge installation

Operation

GAI-Tronics offers two types of Page/Party[®] systems: Single party with one page line and one party line, and multi-party with one page line and five party lines allowing up to five simultaneous two-way conversations.

For *single party* systems, complete the following steps to make a page announcement:

- 1. Lift the handset from the cradle.
- 2. Depress and hold the handset pressbar.
- 3. Speak directly into the microphone to broadcast your announcement over the loudspeakers.
- 4. Release the handset pressbar, and if requested, wait for a response.

The paged individual(s) responds by picking up a station handset.

For *multi-party* systems, *c*omplete the following steps to make a page announcement:

- 1. Lift the handset from the cradle.
- 2. If party line conversation is desired, rotate the selector switch to an unoccupied party line.
- 3. Depress and hold the handset pressbar.
- 4. Speak directly into the microphone to broadcast your announcement over the loudspeakers.
- 5. Release the handset pressbar, and if requested, wait for a response.

The paged individual(s) responds by picking up a station handset and turning the selector switch to the requested party line.

With either type of system, the full duplex party line communication is not broadcast over the system speakers. Other individuals can also pick up and join the conversation at any time. Always return the handset to the cradle following a page or a party line conversation.

Maintenance

Adjustments

The following adjustments affecting the subsets can be made on the remote amplifier. Refer to the applicable remote subset amplifier manual for the adjustment details.

Audio Transmit Level

The audio transmit level controls the microphone gain.

Handset Receiver Volume

The handset receiver volume controls the receiver volume level.

Other Controls

The following additional controls affect system performance; therefore, only qualified GAI-Tronics personnel with the appropriate test equipment should make adjustments. Tampering with these controls may void your warranty.

AGC Threshold (on SmartSeries remote amplifier only)

The control labeled AGC THRESH (on the Handset/FSK/µP PCBA) sets the level at which Automatic Gain Control (AGC) circuit begins to limit the handset microphone signals.

Sidetone Volume

The sidetone volume controls the handset sidetone (portion of the microphone audio that is fed to the handset receiver).

Troubleshooting

Problem	Possible Solution	
Outgoing conversation level requires adjustment.	 Adjust the microphone gain at the remote amplifier. Replace handset microphone. 	
Incoming conversation level requires adjustment.	 Adjust the receiver volume control at the remote amplifier. Replace the receiver element in the handset. 	
Sidetone (how the operator hears himself) requires adjustment.	 Adjust the receiver sidetone at the remote amplifier. Check the wire terminations for proper connections in the line balance assembly. 	
Feedback/distortion (a hum or buzz on the line) occurs during all Page/Party [®] station operation.	 Adjust the receiver sidetone at the remote amplifier. The line may be improperly terminated. Inspect the system cable for loose connections, shorts, and grounds. Line balance assembly connections are critical. 	
Feedback occurs during paging.	Use the muting feature in the amplifier enclosure at the terminal blocks as detailed in the enclosure manual.	
Crosstalk occurs.	One or more system cable pairs may be improperly terminated. Visually inspect the system cable connections for accidental crossing of the cable pairs or grounds.	
Miscellaneous	A defective handset/speaker amplifier printed circuit board assembly (PCBA) can cause numerous problems. If the station is not functioning properly, it may be necessary to replace the handset/speaker amplifier PCBA.	

The following table lists some hints to aid technicians in troubleshooting.

Specifications

Construction/finish	16-gauge cold-rolled steel/gray polyurethane enamel	
Receiver Cable	Dynamic, noise-canceling, 10 ohms Dynamic, 150 ohms, hearing aid compatible PVC retractile, 6-foot extended Gray ABS	
External controls	Handset pressbar for paging rotary selector switch (Model 7115-102 only)	
Mounting	Desk-edge or similar location; Two 13/64-inch mounting holes (in bracket)	
Temperature range	-22° F to 158° F (-30° C to +70° C)	
Connections	8-foot cable with connector, hard-wired to subset	
Dimensions		
Shipping weight		
Approvals		

NRTL certified for use in US and Canada forClass 1, Div. 2, Groups A, B, C, D when connected to a certified Model 7245 Enclosure using a certified Model 723 Amplifier

CE mark:Complies with Low Voltage Directive 73/23/EEC, and the EMC Directive 89/336/EEC amended by the Directive 93/68/EEC

Replacement Parts

Model No.	Description
10112-101	Handset Assembly with PVC Cord, 6 foot
12502-101	Replacement Receiver
13204-002	Receiver Cap
12511-001	Transmitter Dynamic Microphone & Cap
12512-011	Hookswitch Assembly Replacement Kit
12607-002	Party Line Selector Switch Kit
69200-101	Subset Termination PCBA

Warranty

Equipment. GAI-Tronics warrants for a period of one (1) year from the date of shipment, that any GAI-Tronics equipment supplied hereunder shall be free of defects in material and workmanship, shall comply with the then-current product specifications and product literature, and if applicable, shall be fit for the purpose specified in the agreed upon quotation or proposal document. If (a) Seller's goods prove to be defective in workmanship and/or material under normal and proper usage, or unfit for the purpose specified and agreed upon, and (b) Buyer's claim is made within the warranty period set forth above, Buyer may return such goods to GAI-Tronics nearest depot repair facility, freight prepaid, at which time they will be repaired or replaced, at Seller's option, without charge to Buyer. Repair or replacement shall be Buyer's sole and exclusive remedy, and the warranty period on any repaired or replacement equipment shall be one (1) year from the date the original equipment was shipped. In no event shall GAI-Tronics warranty obligations with respect to equipment exceed 100% of the total cost of the equipment supplied hereunder. Buyer may also be entitled to the manufacturer's warranty on any third-party goods supplied by GAI-Tronics.

<u>Services</u>. Any services GAI-Tronics provides hereunder, whether directly or through subcontractors, shall be performed in accordance with the standard of care with which such services are normally provided in the industry. If the services fail to meet the applicable industry standard, GAI-Tronics will, for a period of one (1) year from the date of completion, re-perform such services at no cost to Buyer. Reperformance of services shall be Buyer's sole and exclusive remedy, and in no event shall GAI-Tronics warranty obligations with respect to services exceed 100% of the total cost of services provided hereunder.

<u>Warranty Periods</u>. Every claim by Buyer alleging a defect in the goods and/or services provided hereunder shall be deemed waived unless such claim is made in writing within the applicable warranty periods as set forth above. Provided, however, that if the defect complained of is latent and not discoverable within the above warranty periods, every claim arising on account of such latent defect shall be deemed waived unless it is made in writing within a reasonable time after such latent defect is or should have been discovered by Buyer.

Limitations / Exclusions. The warranties herein shall not apply to, and GAI-Tronics shall not be responsible for, any damage to the goods or failure of the services supplied hereunder, to the extent caused by Buyer's neglect, failure to follow operational and maintenance procedures provided with the equipment, or the use of technicians not specifically authorized by GAI-Tronics to maintain or service the equipment. THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE IN LIEU OF AND EXCLUDE ALL OTHER WARRANTIES AND REMEDIES, WHETHER EXPRESS OR IMPLIED BY OPERATION OF LAW OR OTHERWISE, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Return Policy

If the equipment requires service, contact your Regional Service Center for a return authorization number (RA#). Equipment should be shipped prepaid to GAI-Tronics with a return authorization number and a purchase order number. If the equipment is under warranty, repairs or a replacement will be made in accordance with the warranty policy set forth above. Please include a written explanation of all defects to assist our technicians in their troubleshooting efforts.

Call 800-492-1212 (inside the USA) or 610-777-1374 (outside the USA) for help identifying the Regional Service Center closest to you.