


Production change notice : (Combination of fan and filter-net has changed.)				
	Combination before change.		Combination after change.	
■ Attachment direction of fan(FN902). (Page 11, 17 and 62.)	Direction of inhalation of air.		Direction of exhaust.	
	Part No.	Description	Part No.	Description
■ Filter-net-B (Page-63 NO. 19)	610 292 3179	Filter-net-B	Delete.	
■ Owner's manual for PLC-XF30 only. (009MY6A).	610 297 5383	O/M-MY6A-A	610 299 6487	O/M-MY6A-B
	610 293 5073	O/M-MY6A-D	610 299 6494	O/M-MY6A-D-A
	610 293 5080	O/M-MY6A-F	610 299 6500	O/M-MY6A-F-A
	610 293 5097	O/M-MY6A-I	610 299 6517	O/M-MY6A-I-A
	610 293 5103	O/M-MY6A-E	610 299 6524	O/M-MY6A-E-A
Owner's manual for PLC-XF30N only. (009MY6AA).	610 297 8032	O/M-MY6AA-A	610 299 6692	O/M-MY6AA-A
	610 297 8049	O/M-MY6AA-D	610 299 6708	O/M-MY6AA-D-A
	610 297 8056	O/M-MY6AA-F	610 299 6715	O/M-MY6AA-F-A
	610 297 8063	O/M-MY6AA-I	610 299 6722	O/M-MY6AA-I-A
	610 297 8070	O/M-MY6AA-E	610 299 6739	O/M-MY6AA-E-A
Owner's manual for PLC-XF30NL only. (009MY6AL).	610 297 5383	O/M-MY6A-A	610 299 6487	O/M-MY6A-B
■ Serial No.				
PLC-XF30 .	G1601001-G2101420		After left lots.	
PLC-XF30N .	G1X01001-G1Z01130		After left lots.	
PLC-XF30N L .	G1X01061-G1Y01120		After left lots.	
Note : About the model before change. Surely change the attachment direction of fan(FN902) to direction of exhaust, when the filter-net-B deletes.				



CONTENTS ;

Specifications	2
Safety Instructions	3
Protections	4
Ass'y lamp replacement	6
Mechanical disassemblies	9
Optical unit disassemblies	13
Troubleshooting	18
Waveforms	33
Electrical adjustments	35
Optical adjustments	43
CPU input/output port functions	49
The cautions in schematic diagrams	53
Unit PFC, Unit lamp ballast and IC block diagrams	55
Parts list	60
Cabinet, Chassis and Optical parts list	63
Electrical parts list	66
Schematic diagrams	S1~S10
Block diagrams	B1~B2
PWB parts location diagrams	P1~P5

PRODUCT CODE :

PLC-XF30	MY6A	1 122 105 00	U.S.A. , Canada
PLC-XF30	PY6A	1 122 106 00	Continental Europe, Asia, Africa, M.E.
PLC-XF30	PY6C	1 122 106 02	U.K.
PLC-XF30N	MY6AA	1 122 105 20	U.S.A. , Canada
PLC-XF30NL	MY6AL	1 122 105 30	U.S.A. , Canada

FILE NO.

MODEL NO.

PLC-XF30 (Projection lens is optional.)

Canada, Europe, Asia, Africa, M.E., U.K.

PLC-XF30N

U.S.A., Canada

PLC-XF30L (Projection lens is optional.)

U.S.A.

Chassis No. MY6-XF3000
 MY6-XF30N00
 MY6-XF30NL00

NOTE: Match the Chassis No. on the rating sheet on the cabinet with the Chassis No. in the Service Manual.

If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.

Give complete "CHASSIS NO." for parts order or servicing, it is shown on the rating sheet on the cabinet of the Projector.


Service Instructions & Parts List

Schematic Diagrams

Printed Wiring Board Diagrams

This Service Manual is provided with the above sections. Click the sections you wish.

Production change notice : (Combination of fan and filter-net has changed.)				
	Combination before change.		Combination after change.	
■ Attachment direction of fan(FN902). (Page 11, 17 and 62.)	Direction of inhalation of air.		Direction of exhaust.	
	Part No.	Description	Part No.	Description
■ Filter-net-B (Page-63 NO. 19)	610 292 3179	Filter-net-B	Delete.	
■ Owner's manual for PLC-XF30 only. (009MY6A).	610 297 5383	O/M-MY6A-A	610 299 6487	O/M-MY6A-B
	610 293 5073	O/M-MY6A-D	610 299 6494	O/M-MY6A-D-A
	610 293 5080	O/M-MY6A-F	610 299 6500	O/M-MY6A-F-A
	610 293 5097	O/M-MY6A-I	610 299 6517	O/M-MY6A-I-A
	610 293 5103	O/M-MY6A-E	610 299 6524	O/M-MY6A-E-A
Owner's manual for PLC-XF30N only. (009MY6AA).	610 297 8032	O/M-MY6AA	610 299 6692	O/M-MY6AA-A
	610 297 8049	O/M-MY6AA-D	610 299 6708	O/M-MY6AA-D-A
	610 297 8056	O/M-MY6AA-F	610 299 6715	O/M-MY6AA-F-A
	610 297 8063	O/M-MY6AA-I	610 299 6722	O/M-MY6AA-I-A
	610 297 8070	O/M-MY6AA-E	610 299 6739	O/M-MY6AA-E-A
Owner's manual for PLC-XF30NL only. (009MY6AL).	610 297 5383	O/M-MY6A-A	610 299 6487	O/M-MY6A-B
■ Serial No.				
PLC-XF30 .	G1601001-G2101420		After left lots.	
PLC-XF30N .	G1X01001-G1201130		After left lots.	
PLC-XF30N L .	G1X01061-G1Y01120		After left lots.	
Note : About the model before change. Surely change the attachment direction of fan(FN902) to direction of exhaust, when the filter-net-B deletes.				



CONTENTS ;

Specifications	2
Safety Instructions	3
Protections	4
Ass'y lamp replacement	6
Mechanical disassemblies	9
Optical unit disassemblies	13
Troubleshooting	18
Waveforms	33
Electrical adjustments	35
Optical adjustments	43
CPU input/output port functions	49
The cautions in schematic diagrams	53
Unit PFC, Unit lamp ballast and IC block diagrams	55
Parts list	60
Cabinet, Chassis and Optical parts list	63
Electrical parts list	66
Schematic diagrams	S1~S10
Block diagrams	B1~B2
PWB parts location diagrams	P1~P5

FILE NO.

MODEL NO.

PLC-XF30 (Projection lens is optional.)

Canada, Europe, Asia, Africa, M.E., U.K.

PLC-XF30N

U.S.A., Canada

PLC-XF30L (Projection lens is optional.)

U.S.A.

Chassis No. **MY6-XF3000**
MY6-XF30N00
MY6-XF30NL00

NOTE: Match the Chassis No. on the rating sheet on the cabinet with the Chassis No. in the Service Manual.

If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.

Give complete "CHASSIS NO." for parts order or servicing, it is shown on the rating sheet on the cabinet of the Projector.

PRODUCT CODE :

PLC-XF30	MY6A	1 122 105 00	U.S.A. , Canada
PLC-XF30	PY6A	1 122 106 00	Continental Europe, Asia, Africa, M.E.
PLC-XF30	PY6C	1 122 106 02	U.K.
PLC-XF30N	MY6AA	1 122 105 20	U.S.A. , Canada
PLC-XF30NL	MY6AL	1 122 105 30	U.S.A. , Canada

TECHNICAL SPECIFICATIONS

Projector Type	Multi-media Projector
Dimensions (W x H x D)	17.3" x 9.1" x 23.8" (439 mm x 230 mm x 605.6 mm)
LCD Panel System	1.8" TFT Active Matrix type, 3 panels
Panel Resolution	1024 x 768 dots
Number of Pixels	2,359,296 (1024 x 768 x 3 panels)
Color System	PAL, SECAM, NTSC, NTSC4.43, PAL-M and PAL-N
High Definition TV Signal	480i, 480p, 575i, 575p, 720p, 1035i, 1080i-50 and 1080i-60
Motorized Lens Shift	Up and Down
Scanning Frequency	H-sync. 15 ~ 120 KHz, V-sync. 50 ~ 120 Hz
Horizontal Resolution	800 TV lines
Projection Lamp	200 watt type x 2
Input 1 Jacks	DVI-I Terminal (Digital/Analog), RCA Type (Audio R and L) and DIN 8-pin (Control port)
Input 2 Jacks	BNC Type x 5 (R/Pr, G/Y, B/Pb, H/HV and V), RCA Type (Audio R and L) and DIN 8-pin (Control port)
Input 3 Jacks	BNC Type x 2 (VIDEO/Y, C), RCA Type (Audio R and L) and DIN 4-pin (S-Video)
Other Jacks	Serial port in (DB 9), Serial port out (DB 9), USB port, Audio Monitor out (RCA Type R and L) and Wired Remote Jack
Built-in Speakers	INT. SP. Stereo (R and L), 3 watt RMS (T.H.D. 10%)
Feet Adjustment	0° to 6.9°
Voltage and Power Consumption	AC 100 ~ 120 V (7.8 A Max. Ampere), 50 / 60 Hz AC 200 ~ 240 V (3.3 A Max. Ampere), 50 / 60 Hz
Operating Temperature	41 °F ~ 95 °F (5 °C ~ 35 °C)
Storage Temperature	14 °F ~ 140 °F (-10 °C ~ 60 °C)
Remote Control Transmitter	Power Source : AA, UM3 or R06 Type x 2 Operating Range : 16.4' (5m) / ±30° Dimensions : 2.2" x 1.3" x 7.6" (55mm x 34mm x 192mm) Net Weight : 0.36 lbs (165 g) (including batteries) Laser Pointer : Class II Laser (Max. Output : 1mW / Wave length : 650±20nm)
Accessories	Owner's Manual AC Power Cord Wireless/Wired Remote Control Transmitter and Batteries Remote Control Cable VGA Cable and DVI Cable MAC/VGA Adapter and DVI/VGA Adapter 3 Types Control Cable (For PS/2, Serial and ADB port) 3 Types Light-Block Sheet (For option lens) Lens Mounting Adapter Protective Dust Cover

● Specifications are subject to change without notice.

Safety Instructions



SAFETY PRECAUTIONS

WARNING:

The chassis of this projector is isolated (COLD) from AC line by using the converter transformer. Primary side of the converter and lamp power supply unit circuit is connected to the AC line and it is hot, which hot circuit is identified with the line () in the schematic diagram. For continued product safety and protection of personnel injury, servicing should be made with qualified personnel.

The following precautions must be observed.

- 1: An isolation transformer should be connected in the power line between the projector and the AC line before any service is performed on the projector.
- 2: Comply with all caution and safety-related notes provided on the cabinet back, cabinet bottom, inside the cabinet or on the chassis.
- 3: When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as, control knobs, adjustment covers or shields, barriers, etc.

DO NOT OPERATE THIS PROJECTOR WITHOUT THE PROTECTIVE SHIELD IN POSITION AND PROPERLY SECURED.

- 4: Before replacing the cabinet cover, thoroughly inspect the inside of the cabinet to see that no stray parts or tools have been left inside.

Before returning any projector to the customer, the service personnel must be sure it is completely safe to operate without danger of electric shock.

PRODUCT SAFETY NOTICE

Product safety should be considered when a component replacement is made in any area of the projector. Components indicated by mark  in the parts list and the schematic diagram designate components in which safety can be of special significance. It is, therefore, particularly recommended that the replacement of the parts must be made by exactly the same parts.

SERVICE PERSONNEL WARNING

Eye damage may result from directly viewing the light produced by the Lamp used in this equipment. Always turn off Lamp before opening cover. The Ultraviolet radiation eye protection is required during this servicing.

Never turn the power on without the lamp to avoid electric-shock or damage of the devices since the stabilizer generates high voltages (20~25kV) at its starts.

Since the lamp is very high temperature during units operation. Replacement of the lamp should be done at least 45 minutes after the power has been turned off, to allow the lamp cool-off.

DO NOT ATTEMPT TO SERVICING THE REMOTE CONTROL UNIT.

Laser Beam may be leaked out when in disassemble the Unit. As the Laser Beam used in this Remote control unit is harmful to the eyes.

CAUTION



LASER RADIATION
DO NOT STARE INTO BEAM
MAX. OUTPUT: 1mW
WAVE LENGTH: 650±20nm
CLASS II LASER PRODUCT

This product is complied with 21 CFR
part 1040.10

LASER RADIATION
DO NOT STARE INTO BEAM
CLASS 2 LASER PRODUCT
LASER-STRAHLUNG
NICHT IN DEN STRAHL BLICKEN
LASER-KLASSE 2
レーザー放射クラス2レーザー製品
ビームをのぞき込まないこと
IEC60825-1, Am. 1 1997
MAX OUTPUT (最大出力) : 1 mW
WAVE LENGTH (波長) : 650±20nm

Protections

This projector is equipped with the following protections to operate in safety.


Fuse for circuit protection

The fuse is located in the rear inside a projector. (Refer to figure.) When either the LAMP indicator or the READY indicator is not illuminated, fuse may be opened. Check the fuse as following steps.

1. Remove the Cabinet-top following to "Mechanical Disassemblies".
 2. Remove the fuse from fuse holder.
 3. Check the resistance of fuse using a tester.
- To install the fuse, take reversed step in the above.

It should be used the specified fuse as follows;

Fuse Part No.: 423 027 2602
TYPE T10AH250V FUSE
LITTLEFUSE INC. TYPE 215010



MY6A

ATTENTION: POUR MAINTENIR LA PROTECTION CONTRE LES RISQUES D'INCENDIE. N'UTILISER QUE DES FUSIBLES DE RECHANGE CALIBRES A T10AH250V. (LITTLEFUSE INC TYPE 215010)




MY6A

Protection equipment for users

Electric shock protection. (Interlock switch)

■ The Lamp circuit (the lamp and the electrode of the lamp socket) of this projector is **not insulated** from AC line, and it is "**HOT.**" Therefore, when replacing lamp assembly, an electric shock may be received. However, the interlock switch (SW902) is designed so that it may protect from the accident.

■ This switch(SW902) insulates a lamp circuit from AC line, when a lamp cover is removed. (The lamp circuit changes to "**COLD.**")



*The temperature monitor system is provided to prevent damage of optical components (the LCD panel and polarization film etc.) inside a projector from overheat. Two protection systems are provided.
Each system operation as follows ;*

----- The temperature monitor -1: -----

■ To control the driving power of the cooling fans.

The CPU checks the temperature and atmospheric pressure inside a projector. It checks a temperature using temperature sensor-IC5801 and it checks an atmospheric pressure using pressure sensor-IC886.

The CPU controls the driving power of the cooling fans so the temperature inside the projector is maintained to normal temperature.

■ To shut down the projector.

The CPU checks temperature of Red-LCD panel periphery (IC2541) and inhalation air (IC5801). If each part temperature reaches to abnormal temperature (IC2541 ; 47degrees / IC5801 ; 42degrees), the CPU will turn off a projector, and will blink TEMPERATURE WARNING indicator at intervals of 0.6 seconds. Cooling fans operate until temperature returns to normal. Indicator will stop blink, if temperature returns to normal.

Y/V

--- The temperature monitor -2 : ---

(Temperature check of lamps.)

Temperature switches (SW 903~904) are arranged near the two lamps. Temperature switches will operate, if temperature reaches 90~100 degrees.

SW904 (Lamp-1)----- It operates at 90 degrees.


SW903 (Lamp-2)----- It operates at 100 degrees.

When temperature switches have operated, lamp ballast units will be shut down, then a projector will be turned off.

Note.

CPU does not check operation of temperature switches. Therefore, when temperature switches have operated and a projector has shut down, TEMPERATURE-WARNING indicator does not blink.


Y/V




LAMP REPLACEMENT

Before Replacement

This Projector is equipped with 2 Projection Lamps to ensure brighter image and those lamps are controlled by Lamp Management Function. Lamp Management Function detects status of two lamps and shows status on screen or on LAMP REPLACE indicator. This function also automatically controls Lamp Mode when any of lamps is out for end of life or malfunctions.



LAMP STATUS




Lamp Replace Indicator

This LAMP REPLACE indicator lights yellow when any of Projection Lamps is nearing its end, and flashes when any of them becomes out. Check number of lamp on Lamp Status Display and replace lamp.

Lamp Status Display

Lamp Status Display appears on screen when power switch is on or changed input position (input 1, input 2 or input 3). This shows status of each lamp as; ON, OFF, NEAR END, or OUT. Refer to following for each status.



LAMP STATUS
DISPLAY

Yellow Lamp ----- Projection Lamp lights normally.


Dim Lamp ----- Projection Lamp is turned off.

Red Lamp ----- Projection Lamp is nearing its end. When image becomes darker or color becomes unnatural, replace lamp.
(LAMP REPLACE indicator lights yellow.)


X Mark on Lamp ----- (LAMP REPLACE indicator flashes yellow.)
Projection lamp is defective or fails to be turned on. Restart a projector on, and make sure lamp is on. If this mark still appears, replace lamp corresponding with number marked X.

Lamp Mode Changeover


Lamp Management Function automatically changes combination of lighting lamp (Lamp Mode) by detecting status of lamp. When any of 2 lamps becomes out, Lamp Mode is changed over from 2 lamps to 1 lamp. Lamp Mode can be switched to 2 lamps or 1 lamp manually. Refer to SETTING section on page 39, 40 of Owner's manual.



2 LAMP MODE



1 LAMP MODE
(Example)



Lamp Replacement



CAUTION

For continued safety, replace with a lamp assembly of same type. Allow a projector to cool for at least 45 minutes before you open Lamp Cover. Inside of a projector can become very hot.





CAUTION

Do not drop a lamp assembly or touch a glass bulb! Glass can shatter and may cause injury.

Follow these steps to replace lamp assembly.

- 1** Check number of lamp to be replaced on Lamp Status Display.
- 2** Turn off a projector and disconnect AC Power Cord. Allow a projector to cool for at least 45 minutes.
- 3** Loosen 3 screws on Lamp Cover and remove Lamp Cover. (See right figure.)
- 4** Loosen 2 screws and pull out Lamp Assembly to be replaced by grasping handle.
- 5** Replace Lamp Assembly with a new one and tighten 2 screws. Make sure that Lamp Assembly is set properly
- 6** Replace Lamp Cover and tighten 3 screws.
- 7** Connect AC Power Cord to a projector and turn projector on.
- 8** Reset Lamp Replacement Counter. (Refer to section "Lamp Counter Reset".)

NOTE : Do not reset LAMP REPLACEMENT COUNTER when lamp is not replaced.



Make sure which number of lamp needs to be replaced on Lamp Status Display. Figure shows case of replacing LAMP 2.

CAUTION : DO NOT OPERATE A PROJECTOR WHILE ANY OF LAMPS IS REMOVED. IT MAY RESULT IN MALFUNCTIONS, FIRE HAZARD, OR OTHER ACCIDENTS.

NOTES ON LAMP REPLACEMENT

To maintain quality of picture (better balance of color and brightness in entire screen), we recommend replacing all 2 lamps at a time.

ORDER REPLACEMENT LAMP

● Replacement *Lamp Type No.* : **POA-LMP39**

Lamp Service Parts No. : **610 292 4848**





Lamp counter reset


Be sure to reset Lamp Counter when Lamp Assembly is replaced. When Lamp Replace Counter is reset, LAMP REPLACE indicator stops lighting.

- 1 Turn projector on, press MENU button and ON-SCREEN MENU will appear. Press POINT LEFT/RIGHT button(s) to move a red frame pointer to SETTING Menu icon.
- 2 Press POINT DOWN button to move a red frame pointer to "Lamp counter reset" and then press SELECT button.
- 3 Move arrow to replaced lamp number (Lamp 1 or Lamp 2) and then press SELECT button. Message "Lamp replace counter Reset?" is displayed. Move pointer to [Yes] and then press SELECT button.
- 4 Another confirmation dialog box appears and select [Yes] to reset Lamp Replace Counter.

Do not reset Lamp Replace Counter except after Projection lamp is replaced.



Mechanical disassemblies




1. Panel ballast and Lamp ballast Assemblies removal.

1. Remove 5 screws A and remove the Panel ballast.
2. Remove the connectors. Remove 8 screws B and remove the 2 Lamp ballast assemblies.

Note : To connect the connector.

Be careful to connecting the connectors of the Lamp ballast assemblies. Refer to the figure-(a).




2. Cabinet front bottom, Cabinet front top and Cabinet front removal.

Note :


Be careful not to damage Hook. The cabinet-front-bottom is being fixed with cabinet-front-top by hook.

1. Remove 2 screws-A. Push part(a) and pull the Cabinet-front-bottom down.
2. Remove 4 screws B and remove the Cabinet front top.
3. Remove 7 screws C and remove the Cabinet front.



3. Lamp cover and cabinet top removal.

1. Remove 3 screws A and remove the Lamp cover.
2. Remove 8 screws B and remove the Cabinet top.




4. Assembly main and Terminal slots unit removal.

1. Remove the connectors and the flexible cables of the LCD panels from the assembly Main. (*Never touch the electrode of flexible cables.*) Remove 6 screws A and remove the Assembly main.
2. Remove 2 screws B and pull the Terminal slots unit upward and remove.

Note :

Two screws B are not used in some particular models.

5. Assembly Motor & audio, assembly Power, assembly PFC, assembly Sub power and Fan(FN902) Removal.




NOTE :

Be careful of the attachment direction of Fan.
FN902 is Fan for an exhaust. *

FN902 :
See the Production change
notice of the cover. (Page-1)


1. Remove 3 screws A and remove the assembly motor & audio
2. Remove 4 screws B and remove the power holder.
3. Remove 4 screws C and remove the power holder top.
4. Remove 6 screws D and remove the assembly sub power.
5. Remove 4 screws E and remove the Fan (FN902).
6. Pull the assembly power upward and remove.
7. Pull the assembly PFC upward and remove.

6. Optical unit removal.



Remove 12 screws and then pull the optical unit upward and remove.


7. Fans(FN906, FN909 and FN910) removal.



NOTE :
Be careful of the attachment direction of Fan.
FN906 is Fan for an exhaust.

1. Remove 4 screws A and remove the fan FN909 and remove the fan FN910.
2. Remove 4 screws B and remove the assembly fan.
3. Remove 4 screws C and remove the fan FN906.

8. Fans(FN903, FN904, FN905, FN907 and FN908), AC SW unit, Handle and Adjustable feet removal.




NOTE :
Be careful of the attachment direction of Fan.
FN908 is Fan for an exhaust.

Mark the Fans as they are removed from the cabinet bottom so that they may be reassembled in the same location from which they were removed.


1. Remove 5 screws A and remove the duct for FN907 and remove the Fan (FN907).
2. Remove 9 screws B and remove the Fans (FN903 and FN904) and remove the duct for FN903/4.
3. Remove 8 screws C and remove the holder for FN908 and remove the Fan (FN908).
4. Remove 8 screws D and remove the holder for FN905 and remove the Fan (FN905) and remove the duct for FN905.
5. Remove 8 screws E and remove the AC switch unit.
6. Remove 4 screws F and remove 2 pins F and remove the handle.
7. Remove 8 screws G and remove the adjustable feet.

Optical unit disassemblies



1. Projection lens and Holder lens unit removal.

1. Remove 4 screws A and remove the Projection lens.
2. Remove 4 screws B and remove the Holder lens unit.



2. Integrator lens in unit, Integrator lens out & PBS unit, Condenser lens unit, Relay lens unit and Polarizer units removal.

Note :

Each polarizer unit uses different characteristic polarization glasses. Mark the Polarizer units as they are removed from the optical unit so that they may be reassembled in the same location from which they were removed.


1. Remove 2 screws A and remove the Integrator lens in unit.
2. Remove 3 screws B and remove the Integrator lens out & PBS unit.
3. Remove 2 screws C and remove the Condenser lens unit.
4. Remove 2 screws D and remove the Relay lens unit.
5. Remove 6 screws E and remove the 3 Polarizer units.

3. Lamp assemblies and Assembly mirror removal.

Note :

The characteristics and ages of lamps are managed by CPU. Mark the lamp assemblies as they are removed from the optical unit so that they may be reassembled in the same location from which they were removed.

1. Remove 4 screws A and remove the 2 Lamp assemblies.
2. Remove 4 screws B and remove the assembly mirror.



4. Prism / LCD panel assembly removal.

Note :

Prism / LCD panel assembly is a precision part. be sure to handle this part with special attention. Do not drop it or give it excessive force. It may damage the parts and alignment.


Remove 4 screws and remove the prism / LCD panel assembly.

At the time, be careful not to damage the prism / LCD panel assembly with the driver.





Caution :

- (1). Never touch the LCD panel and prism part directly with hand. Otherwise the optical parts may get dirty.
- (2). Since the LCD panel is equipped with CMOS-LSI, pay attention to static electricity.
And never touch the electrode of flexible cables.
- (3). Don't disassemble prism / LCD panel assembly, otherwise it can be damaged.




Optical parts location --- The optical parts name(description) can see it on parts list(page65).






**PWB ASSEMBLIES
LOCATION**




**MOTOR FANS
LOCATION**

FN902 :
See the Production change
notice of the cover. (Page-1)


TERMINAL BOARD DVI




TERMINAL BOARD-COMPONENT




TERMINAL BOARD AV



TERMINAL BOARD-D-SUB15




The Terminal board D-SUB15 does not exist in some particular models.



The input-4 does not exist in some particular models.

CHECK RGB SIGNAL




NO PICTURE -2

Troubleshooting


Check the terminal board-DVI.

Check the Vcc voltages.
S9V / -5V / S6V (Always)
9V / 5VB (Switched)
Check the test points.




Check the terminal board-COMPONENT.

Check the Vcc voltages.
S9V / -5V / S6V (Always)
9V / 5VB (Switched)
Check the test points.




Check the terminal board-AV.

Check the Vcc voltages.
 S9V / -5V / S6V (Always)
 9V / 5VB (Switched)
 Check the test points.




Check the terminal board-DSUB15.

Check the Vcc voltages.
 S9V / -5V / S6V (Always)
 9V / 5VB (Switched)
 Terminal board DSUB15 does not exist in some particular models.



Timing Chart





Is fuse (F901) blown?
Fuse may be opened when either the LAMP indicator or the READY indicator isn't illuminated. Check the fuse. For continued safety, replace it with a new fuse of the same type

Isn't the lamp cover of a projector removed?
When it is removed, the projector cannot be turned on.

Is the lamp cover attached correctly? And has not the boss (inner side of the lamp cover) broken?
Check the boss and the Interlock switch (SW902). SW902--open: Abnormality

Refer to next page but one

Hot circuit



* NO POWER-2

Troubleshooting

Check the switching regulator.


STR-Z2156
Switching regulator

Caution : "HOT" Circuit !

If a temperature of this frame reaches to 150°C, the IC632 will be shut down.

If this Vcc voltage reaches to abnormal voltage (exceeds 22V), the IC632 will be shut down.

Check the signal at pin 5 of T621. (Switching power IC output signal.)



Timing chart

Pin 4


OSC OUT

Pin 2

Pin 10

No sound

Troubleshooting



Terminal board DVI, Component, AV and D-SUB15.

1. Check that the R and L signals are correct.
Pins 122(R) and 33(L).
K80H, K10H, K3101 and K71H.
- Terminal board DSUB15 does not exist in some particular models.

assembly CG-Mother


1. Check that the R and L signals are correct.
Pins 3(R) and 13(L) of IC9002.

Assembly Main

1. Check that the Vcc-voltages are correct.
2. Check that the R and L input signals are correct.
Pins 2 and 19 of IC1851
3. Check that the IC1851 output signals are correct.
Pins 7(L) and 14(R).
4. Check that the audio output signals are correct.
Pins 7(L) and 1(R) of IC1871.
5. Check that the AUDIO MUTE signal is correct.
6. Check that the SP-OFF signal is correct.
7. Check that the SDA-signal is correct. Pin 9 of IC1851.
8. Check that the SCL-signal is correct. Pin 10 of IC1851.

Assembly Motor audio

1. Check that the Vcc-voltages are correct.
2. Check that the R and L input signals are correct.
Pins 2(R) and 5(L) of IC001
3. Check that the AUDIO MUTE signal is correct.
4. Check that the SP-OFF signal is correct.
5. Check that the IC001 output signals are correct.
Pins 10(L) and 7(R).



LAMP ABNORMALITY -2

Troubleshooting

Check the unit P.F.C..


Caution : "HOT" Circuit !

Has not the temperature switch operated?

If the temperature around FET reaches 85 degrees, the PFC circuit will be shut down.

Check!

OUTPUT
DC 380V~400V




Check the unit lamp Ballast.


Caution : "HOT" Circuit !

When the temperature around a lamp driver reaches 85 degrees, unit lamp ballast will be shut down and a lamp monitor signal changes to H from L.

Check!



Motor-driven lens system. (Zoom, Focus and lens shift.)



Assembly Main


- Check that the Vcc-voltages are correct.
- Check that the POWER FAIL signal is correct.
Pin125 of IC801 H: Normal
- Check that the LENS SHIFT up and down signals are correct.
Pins 6 and 7 of K8E
- Check that the LENS SHIFT left and right signals are correct.
Pins 8 and 9 of K8E
- Check that the FOCUS up and down signals are correct.
Pins 10 and 11 of K8E
- Check that the ZOOM up and down signals are correct.
Pins 12 and 13 of K8E
- Check that the TOP DET. signal is correct.
Pin 2 of K8E L: TOP
- Check that the BOTTOM DET. signal is correct.
Pin 1 of K8E L: BOTTOM
- Check that the CENTER DET. signal is correct.
Pin 17 of K8E Center position=The edge of "H to L" or "L to H."
- Check that the LEFT DET. signal is correct.
Pin 9 of K8N L: LEFT
- Check that the RIGHT DET. signal is correct.
Pin 10 of K8N L: RIGHT
- Check that the CENTER DET. signal is correct.
Pin 11 of K8N Center position=The edge of "H to L" or "L to H."

Assembly Motor audio

- Check that the Vcc-voltages are correct.
- Check that the POWER FAIL signal is correct.
Pin14 of K16A. H: Normal
- Check that the LENS SHIFT up and down signals are correct.
Pins 5 and 6 of IC1631.
- Check that the LENS SHIFT left and right signals are correct.
Pins 5 and 6 of IC1621.
- Check that the FOCUS up and down signals are correct.
Pins 5 and 6 of IC1611.
- Check that the ZOOM up and down signals are correct.
Pins 5 and 6 of IC1601.
- Check that the LENS SHIFT motor drive signals are correct.
Pins 10 and 2 of IC1631 and IC1621.
- Check that the FOCUS motor drive signals are correct.
Pins 10 and 2 of IC1611.
- Check that the ZOOM motor drive signals are correct.
Pins 10 and 2 of IC1601.

---- Horizontal shift function does not exist in some particular models. ----

Motor drive IC block diagram



Truth table IC1601/IC1611/IC1621/IC1631

Input		Output		Operation
5	6	2	10	
H	L	H	L	Forward(reverse) drive
L	H	L	H	Reverse(forward) drive
L	L	L	L	Braking

NOTE : Temperature monitor operation.

■ The temperature monitor system is provided to prevent damage of optical components (the LCD panel and polarization film etc.) inside a projector from overheating. Two protection systems are provided. Each system operation as follows ;

■ **Temperature monitor -1.**

--- To control the driving power of the cooling fans. ---

CPU checks the temperature and atmospheric pressure inside a projector. And CPU controls the drive power of the cooling fans so the temperature inside the projector is maintained at normal temperature.

--- To shut down the projector. ---

CPU checks temperature of LCD panel periphery and inhalation air(IC5801). If each part temperature reaches an abnormal temperature, CPU will turn off a projector, and will blink TEMPERA-


TURE WARNING indicator at intervals of 0.6 seconds. Cooling fans operate until temperature returns to normal. Indicator will stop blink, if temperature returns to normal.

■ **Temperature monitor -2.** --- (Temperature check of lamps) . ---

Temperature switches are arranged near each lamp. Temperature switches will operate, if temperature reaches 90 - 100 degrees. When temperature switches have operated, lamp ballast units will be shut down, then a projector will be turned off.

Note. CPU does not check operation of temperature switches. Therefore, when temperature switches have operated and a projector has shut down, TEMPERATURE-WARNING indicator does not blink.

Hot circuit



CHECK Fan

POWER-FAIL

CHECK !

CHECK !

***NOTE : TEMP. MONITOR LED OPERATION**

■ The red LED indicates temperature monitor operation as follows:

LED off: Normal temperature.
LED flashes in 0.6 second interval: Abnormality temperature.

Doesn't the temperature warning indicator (red) blink?


The projector is turned off when the temperature around the LCD panel reaches 46 - 48 degrees. And a temperature warning indicator blinks.



NOTE : CPU OPERATION

■ CPU (IC801) performs an input check by the IIC-SDA signal pin.


■ When it has detected an abnormal condition, CPU turns off the projector compulsorily. Cooling fans operate until temperature returns to normal. Moreover, a projector cannot be turned on during this period.



TEMPERATURE ABNORMALITY -2

Troubleshooting


Check the fan control circuit



Waveforms

Timing chart


10us/Div



Timing chart


5us/Div

TP_2561
TP_2571
PSIG



Red LCD panel drive signal


5V/Div



Green LCD panel drive signal


TP_2527
G 5V/Div

TP_2526
G 5V/Div




Blue LCD panel drive signal

5V/Div




2ms/Div

Input signal
NTSC 0.5V/Div



TP_32V1
V_sync 5V/Div



Alignment procedures

Service adjustment menu operation

■ To enter the "service mode."

To enter the service mode, press the "MENU" and "IMAGE" buttons on the projector simultaneously and hold for 2 seconds. As shown in a figure, a service mode display appears on a screen.


■ Adjustment.

Adjust service data using the following control buttons.

1. "POINT RIGHT" -- A group number increases.
2. "POINT LEFT" ---- A group number decreases.
3. "POINT UP" ----- An item number increases.
4. "POINT DOWN" -- An item number decreases.
5. "VOLUME+" ----- An adjustment value increases.
6. "VOLUME - " ----- An adjustment value decreases.

■ To exit the "service mode."

Press the "POWER on/off" button only once on the projector or remote control unit to quit the service mode.



■ Readjustments after Parts Replacement

After replacing electric parts and optical parts, electric readjustment and optical readjustment are required. Refer to the section of "parts list" for the required readjustment items after parts replacement.

(Refer to page 60.)

■ Service mode adjustment Menu

Group-no.	Adjustment Item	Adjustment Mode			
		Not designated	PC	AV	Component
140-0	Fans-A driving voltage adjustment	●			
140-1	Fans-A driving voltage adjustment	●			
140-2	Fans-C driving voltage adjustment	●			
140-3	Fans-C driving voltage adjustment	●			
140-4	Fans-B driving voltage adjustment	●			
140-5	Fans-B driving voltage adjustment	●			
200-0	G-Video center DC adjustment		●		
200-1	R-Video center DC adjustment		●		
200-2	B-Video center DC adjustment		●		
200-3	PSIG signal adjustment		●		
200-4	PSIG signal adjustment		●		
200-5	Green pedestal level adjustment -PC		●		
200-6	Red pedestal level adjustment -PC		●		
200-7	Blue pedestal level adjustment -PC		●		
200-8	Green Contrast adjustment-PC		●		
200-9	Red Contrast adjustment-PC		●		
200-10	Blue Contrast adjustment-PC		●		
200-11	Green panel driving signal adjustment -PC		●		
200-12	Green panel driving signal adjustment -PC		●		
200-13	Red panel driving signal adjustment -PC		●		
200-14	Red panel driving signal adjustment -PC		●		
200-15	Blue panel driving signal adjustment -PC		●		
200-16	Blue panel driving signal adjustment -PC		●		
200-17	Flicker reduction--Green		●		
200-18	Flicker reduction--Red		●		
200-19	Flicker reduction--Blue		●		
210-5	Green pedestal level adjustment -AV			●	
210-6	Red pedestal level adjustment -AV			●	
210-7	Blue pedestal level adjustment -AV			●	
210-8	Green Contrast adjustment-AV			●	
210-9	Red Contrast adjustment-AV			●	
210-10	Blue Contrast adjustment-AV			●	
210-11	Green panel driving signal adjustment -AV			●	
210-12	Green panel driving signal adjustment -AV			●	
210-13	Red panel driving signal adjustment -AV			●	
210-14	Red panel driving signal adjustment -AV			●	
210-15	Blue panel driving signal adjustment -AV			●	
210-16	Blue panel driving signal adjustment -AV			●	

Group-no.	Adjustment Item	Adjustment Mode			
		Not designated	PC	AV	Component
210-14 & 16	AV White balance adjustment. 2 lamp mode			●	
200-14 & 16	PC White balance adjustment. 2 lamp mode		●		
211-14 & 16	AV White balance adjustment. Lamp-1 of 1 lamp mode			●	
212-14 & 16	AV White balance adjustment. Lamp-2 of 1 lamp mode			●	
1000-25	AV Color and Tint adjustment			●	
1000-24	AV Color and Tint adjustment			●	
1010-0	AV Green Video signal adjustment			●	
1010-1	AV Green Video signal adjustment			●	
1010-2	AV Red Video signal adjustment			●	
1010-3	AV Red Video signal adjustment			●	
1010-4	AV Blue Video signal adjustment			●	
1010-5	AV Blue Video signal adjustment			●	
5010-0	Component G Video signal adjustment				●
5010-1	Component G Video signal adjustment				●
5010-2	Component R Video signal adjustment				●
5010-3	Component R Video signal adjustment				●
5010-4	Component B Video signal adjustment				●
5010-5	Component B Video signal adjustment				●
0-0	Temperature monitor IC5801 Read only	●			
0-1	Temperature monitor IC2541 Read only	●			
1-0	Atmospheric Pressure monitor IC886 Read only	●			
10-0	RS232C Baud rate (0:9600 / 1:19200)	●			
10-0	RS232C RTS/CTS Flow Control (0:Disable / 1:Enable)	●			
111-0	Lamp-1 Lamp illumination time Read only	●			
111-1	Lamp-2 Lamp illumination time Read only	●			
930-0	Lamp mode 2 Lamp Mode (See Note.)	●			
930-1	Lamp mode Lamp-1 of 1 Lamp Mode (See Note.)	●			
930-2	Lamp mode Lamp-2 of 1 Lamp Mode (See Note.)	●			
998-0	Grid Test Pattern Display	●			

Note : Group-no. 930

- If the data value appears "11" on the screen, the lamp mode is selected.
- If the data value appears "0" on the screen, the lamp mode is not selected. Set the data value to "10."
- If the data value appears "99" on the screen, it is period for cooling of the lamp. Wait until it is changed to "0." Then set the data value to "10."

Caution :

Other adjustment items are not related to service and a maintenance. Don't change the data values of those adjustment items. Otherwise it may cause loss of product safety.

■ Electrical adjustments

Note :

■ The following adjustment is the adjustment item for Assembly power. The test point exists on **the Assembly power**.

1. Voltage adjustment.

■ The following adjustments are the adjustment item for Terminal board-AV. The adjustment data is stored to Terminal board-AV (IC2143). The test points exist on **the Terminal board-AV and the Assembly main**.

2. AV Video signal adjustments.
3. 3DNR-PLL Lock check.
4. AV Color and Tint adjustments.

■ The following adjustment is the adjustment item for Terminal board component. The adjustment data is stored to Terminal board-component (IC2082). The test points exist on **the Terminal board component and the Assembly main**.

5. Component Video signal adjustments.

■ The following adjustment is the adjustment item for Assembly sub power. But the adjustment data is stored to Assembly main (IC1811 and IC871). The test points exist on **the Assembly optical fan-net and the Assembly sub-power**.

6. Fans driving voltage adjustments.

■ The following adjustments are the adjustment item for Assembly main. The adjustment data is stored to Assembly main (IC1811 and IC871). The test points exist on **the Assembly main**.

7. Video center DC adjustments.
8. PSIG signal adjustments.
9. PC pedestal level adjustments.
10. PC contrast adjustments.
11. AV pedestal level adjustment.
12. AV contrast adjustments.
13. Panel driving signal adjustments -AV.
14. Panel driving signal adjustments -PC.
15. Flicker reduction.
16. White balance adjustments.

Location of test points can see it on "PWB location diagrams."

1. Voltage adjustment

Equipment
Connections

Digital voltmeter
+ K6D(2)
- chassis ground

Adjustment:

Adjust the voltage of K6D to **6.35± 0.05V DC** with the VR652.

2. AV Video signal adjustments

Equipment
Input mode
Input signal
Picture condition

Oscilloscope
AV
16 step gray scale signal
Normal

Set the image to "Service mode."

2-1. AV Green Video adjustment

Connections : + TP211 or TP5182 / - chassis ground.
Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
1010-	0	Amplitude-A in a figure.	0.7± 0.05Vp-p
1010-	1	Pedestal level and black level.	Make it the same level.

2-2. AV Red Video adjustment


Connections : + TP201 or TP5181 / - chassis ground.
Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
1010-	2	Amplitude-A in a figure.	0.7± 0.05Vp-p
1010-	3	Pedestal level and black level.	Make it the same level.

2-3. AV Blue Video adjustment

Connections : + TP221 or TP5183 / - chassis ground.
Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
1010-	4	Amplitude-A in a figure.	0.7± 0.05Vp-p
1010-	5	Pedestal level and black level.	Make it the same level.



3. The voltage check of the 3D-Noise-reduction-PLL circuit.

Equipment	Digital voltmeter
Connections :	+ TP5103/ - chassis ground.
Input mode	AV
Input signal	Color bar signal(PAL)
Picture condition	Normal

Check that the voltage of TP5103 is **2.9± 0.5VDC**.

If it is not 2.9± 0.5VDC, check the periphery of the 3D-Noise-reduction-PLL circuit and repair it.


4. AV Color and Tint adjustments

Equipment	Oscilloscope.
Input mode	AV.
Input signal	Color bar signal(NTSC)
Picture condition	Normal.
Connections	+ TP221 or TP5183 - chassis ground.

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
1000-	25	Amplitude-A in a figure.	0.45± 0.02Vp-p
1000-	24	Part-B, C and D in a figure.	Make those the same width.



5. Component Video signal adjustments

Equipment	Oscilloscope.
Input mode	Y, Cb, Cr.
Input signal	16 step gray scale signal
Picture condition	Normal.

Set the image to "Service mode."

3-1. Component G Video adjustment

Connections + TP211 or TP2072 / - chassis ground.

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
5010-	0	Amplitude-A in a figure.	0.66± 0.05Vp-p
5010-	1	Pedestal level and black level.	Make it the same level.

3-2. Component R Video adjustment

Connections + TP201 or TP2071 / - chassis ground.

Adjust each item for below values with the Volume + and - buttons.


Group	No.	Adjustment part.	Adjustment or adjustment value.
5010-	2	Amplitude-A in a figure.	0.66± 0.05Vp-p
5010-	3	Pedestal level and black level.	Make it the same level.

3-3. Component B Video adjustment

Connections + TP221 or TP2073 / - chassis ground.

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Adjustment part.	Adjustment or adjustment value.
5010-	4	Amplitude-A in a figure.	0.66± 0.05Vp-p
5010-	5	Pedestal level and black level.	Make it the same level.



6. Fan driving voltage adjustments

Equipment Digital voltmeter.

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Connection	Adjustment or adjustment value.
140-	0	TP7611 (Fan-A)	$9.0 \pm 0.1\text{VDC}$
140-	1	TP7611 (Fan-A)	$13.5 \pm 0.1\text{VDC}$
140-	2	TP2641 (Fan-C)	$9.0 \pm 0.1\text{VDC}$
140-	3	TP2641 (Fan-C)	$13.5 \pm 0.1\text{VDC}$
140-	4	TP7613 (Fan-B)	$9.0 \pm 0.1\text{VDC}$
140-	5	TP7613 (Fan-B)	$13.5 \pm 0.1\text{VDC}$

7. Video center DC adjustments

Equipment Digital voltmeter.
Input mode Computer.
Input signal 16 step gray scale signal.

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Connection	Adjustment or adjustment value.
200-	0	TP2526 (G-DC)	$7.4 \pm 0.1\text{VDC}$
200-	1	TP2536 (R-DC)	$7.4 \pm 0.1\text{VDC}$
200-	2	TP2516 (B-DC)	$7.4 \pm 0.1\text{VDC}$


8. PSIG signal adjustments

Equipment Oscilloscope.
Input mode Computer.
Input signal 16 step gray scale signal.

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Connection	Adjustment part.	Adjustment or adjustment value.
200-	3	TP2561	Amplitude-A in a figure.	$10.0 \pm 0.1\text{Vp-p}$
200-	4	TP2571	Amplitude-A in a figure	$3.8 \pm 0.1\text{Vp-p}$




9. Pedestal level adjustments -PC

Equipment Oscilloscope.
Input mode Computer.
Input signal 16 step gray scale signal
Set the image to "Service mode."

Adjust the pedestal level and black level in same level with the Volume + and - buttons.

However, the amplitude-A in a figure must not shrink.

Group	No.	Connection
200-	5	TP2526 (Green pedestal level adjustment)
200-	6	TP2536 (Red pedestal level adjustment)
200-	7	TP2516 (Blue pedestal level adjustment)




10. Contrast adjustments-PC

Equipment Oscilloscope.
Input mode Computer.
Input signal 16 step gray scale signal
Set the image to "Service mode."

Adjust each test point value part-A in a figure minimum amplitude with the Volume + and - buttons.

Group	No.	Connection
200-	8	TP2526 (Green contrast adjustment)
200-	9	TP2536 (Red contrast adjustment)
200-	10	TP2516 (Blue contrast adjustment)




11. Pedestal level adjustments AV

Equipment Oscilloscope.
Input mode AV
Input signal 16 step gray scale signal
Set the image to "Service mode."

Adjust the pedestal level and black level in same level with the Volume + and - buttons.

However, the amplitude-A in a figure must not shrink.

Group	No.	Connection
210-	5	TP2526 (Green pedestal level adjustment)
210-	6	TP2536 (Red pedestal level adjustment)
210-	7	TP2516 (Blue pedestal level adjustment)




12. Contrast adjustments-AV

Equipment Oscilloscope.
Input mode AV.
Input signal 16 step gray scale signal
Set the image to "Service mode."

Adjust each test point value part-A in a figure minimum amplitude with the Volume + and - buttons.

Group	No.	Connection
210-	8	TP2526 (Green contrast adjustment)
210-	9	TP2536 (Red contrast adjustment)
210-	10	TP2516 (Blue contrast adjustment)




13. Panel driving signal adjustments -AV

Equipment Oscilloscope.
Input mode AV.
Input signal 16 step gray scale signal
Picture condition Normal.

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Connection	Adjustment part.	Adjustment or adjustment value.
210-	11	TP2526(Green)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
210-	12	TP2526(Green)	Amplitude-B in a figure.	$1.6 \pm 0.05V_{p-p}$
210-	13	TP2536(Red)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
210-	14	TP2536(Red)	Amplitude-B in a figure.	$1.6 \pm 0.05V_{p-p}$
210-	15	TP2516(Blue)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
210-	16	TP2516(Blue)	Amplitude-B in a figure.	$1.6 \pm 0.05V_{p-p}$




14. Panel driving signal adjustments -PC

Equipment Oscilloscope.
Input mode Computer
Input signal 16 step gray scale signal

Set the image to "Service mode."

Adjust each item for below values with the Volume + and - buttons.

Group	No.	Connection	Adjustment part.	Adjustment or adjustment value.
200-	11	TP2526(Green)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
200-	12	TP2526(Green)	Amplitude-B in a figure.	$1.5 \pm 0.05V_{p-p}$
200-	13	TP2536(Red)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
200-	14	TP2536(Red)	Amplitude-B in a figure.	$1.5 \pm 0.05V_{p-p}$
200-	15	TP2516(Blue)	Amplitude-A in a figure.	$4.1 \pm 0.05V_{p-p}$
200-	16	TP2516(Blue)	Amplitude-B in a figure.	$1.5 \pm 0.05V_{p-p}$



15. *Flicker reduction*

Input mode Computer.
Input signal 1 dot line computer signal

Set the image to "Service mode."

Adjust each color for minimum flickers with the Volume + - buttons.

Group	No.	Screen
200-	17	Display only green light.
200-	18	Display only red light.
200-	19	Display only blue light.

16. *White balance adjustments*

Input signal 16 step gray scale signal

Set the image to "Service mode."


Adjust each item value with the Volume + and - buttons and to obtain better white balance.

Group	No.	Lamp mode	Input mode	Adjustment value.
930-	0			See note.
210-	14 and 16	2 lamp mode	AV	Better white balance.
200-	14 and 16	2 lamp mode	Computer	Better white balance.
930-	1			See note.
211-	14 and 16	Lamp-1 of 1 lamp mode	AV	Better white balance.
930-	2			See note.
212-	14 and 16	Lamp-2 of 1 lamp mode	AV	Better white balance.

Note :

- . If the data value appears "11" on the screen, go to next item.
- . If the data value appears "0" on the screen, set the data value to "10" and go to next item.
- . If the data value appears "99" on the screen, wait until it is changed to "0". Then set the data value to "10" and go to next item.


Optical components adjustments




■ Before Adjustment

- Each adjustment requires ball allen wrenches set and slot screwdrivers set.
- Set the position of motorized lens shift to the center position.
(The position where an arrow becomes red on a screen is a center position.)
- The test pattern display exists in service mode. Use it at the time of Panel's Focus adjustment.
 - Set the image to "service mode."
 - Select Group no. 998-0.
 - Press the Volume+ - buttons, and each color grid pattern is displayed.
 - Press menu button to quit the service mode.
- When adjusting lenses of the Relay and Condenser, follow the following procedure.
 - Remove the connector K8E, connector K8V and the flexible cables of the LCD panels from the assembly Main. (Never touch the electrode of flexible cables.)
 - As shown in a figure, Set the assembly-Main to the upright position.
 - At this time, the assembly main must not short-circuit with the chassis. Protect assembly-Main using an insulator.

Y/V



■ Focus of LCD Panel Adjustment




Before Adjustment :

1. Turn on a projector.
2. Set the image to "service mode" and project a green grid pattern on a screen. And adjust green grid pattern to sharp focus, pressing Focus(▲)(▼) buttons on the projector or remote control unit.
3. Press Zoom(▲)(▼) buttons on the projector or remote control unit. And if the focus shifts by the ZOOM position moves between TELE and WIDE, adjust in the following procedure.

Adjustment :

1. Loosen four screws-A using ball allen wrench.
2. Set image size to the maximum, pressing Zoom(▲) button on the projector or remote control unit.
3. Adjust center part of green grid pattern to sharp focus, pressing Focus(▲)(▼) buttons on the projector or remote control unit.
4. Set image size to the minimum, pressing Zoom(▼) button on the projector or remote control unit.
5. Insert a slot screwdriver into slot-B, turn it and adjust center part and four corners on the green grid pattern to sharp focus.
6. Repeat steps 2 to 5. If the focus does not shift by the ZOOM position moves between TELE and WIDE, it will be the completion of adjustment.
7. Tighten four screws-A to fix the assembly LCD panel / prism using ball allen wrench.

■ Integrator-lens-in adjustment-1




Before Adjustment :

- * Remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
- * Shift the adjustment position of Integrator-lens-out temporarily until shade appears the right or the left on the screen. After the Integrator-lens-in-1 adjustment, readjust the Integrator-lens-out.
- * Refer to "Integrator-lens-out adjustment" of next step for the adjustment method.

Adjustment :

1. Insert light block sheets in front of the Red and Blue panels to block the red and blue lights so that green light is projected.
2. loosen 2 screws A.
3. Insert slot screwdriver into slot B, turn it until the shade edge is sharp focus.
4. Tighten the 2 screws A to fix the integrator-lens-in unit.

■ Integrator-lens-out adjustment




Before Adjustment :



1. Remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
2. Insert light block sheets in front of the Red and Blue panels to block the red and blue lights so that green light is projected.
3. If the shade appears on the left or right of the screen, adjust in the following procedure.

Adjustment :

1. Loosen three screws-B.
2. Insert a slot screwdriver into slot-A, turn it and erase shade.
3. Tighten the three screws B to fix the integrator lens-out unit.



■ Integrator-lens-in adjustment-2




Before Adjustment :

1. Remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
2. Insert light block sheets in front of the Red and Blue panels to block the red and blue lights so that green light is projected.
3. If the shade appears on the top or bottom of the screen, adjust in the following procedure.

Adjustment :

1. Loosen two screws-A.
2. Insert a ball allen wrench into screw-B, turn it and erase shade.
3. Tighten the two screws A to fix the integrator lens-in unit.

■ Condenser-lens adjustment





Before Adjustment :


1. Remove the connector K8E and connector K8V, and remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
2. Insert light block sheet in front of the blue panel to block the blue light so that yellow(Green and Red lights) light is projected.
3. If the shade appears on the screen, adjust in the following procedure.

Adjustment :

1. Set the assembly-Main to the upright position.
2. Loosen four screws-A.
3. If it appears on the top or bottom.----> Use two slots-B.
If it appears on the left or right. -----> Use slot-C.
-- Insert slot screwdriver into each slot, turn it and erase shade. --
4. Tighten the four screws-A to fix the condenser-lens unit.



■ Relay-lens adjustment





Before Adjustment :


1. Remove the connector K8E and connector K8V, and remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
2. Insert light block sheet in front of the red panel to block the red light so that cyan(Green and Blue lights) light is projected.
3. If the shade appears on the screen, adjust in the following procedure.

Adjustment :

1. Set the assembly-Main to the upright position.
2. Loosen four screws-A.
3. If it appears on the top or bottom.----> Use slot-B.
If it appears on the left or right. -----> Use slot-C.
-- Insert slot screwdriver into each slot, turn it and erase shade. --
4. Tighten the four screws-A to fix the Relay-lens unit.




■ Prism P.B.S. adjustment



Adjustment :

1. Remove the flexible cables of LCD panels from the assembly Main. And turn on the projector.
2. Loosen two screws-B.
3. Insert a slot screwdriver into slot-A, turn it and adjust the center position of screen to maximum brightness.
4. Tighten the two screws-B to fix the prism PBS unit.

■ Polarizer adjustment



R, G and B polarizer adjustment :

1. Turn on a projector. And input the black raster signal(0% of white raster signal.)
2. Loosen two screws-A on the polarizer unit which you intend to adjust using ball allen wrench.
3. Block the lights of the color which do not adjust using light block sheets.
4. Move the lever-B in the direction of an arrow and adjust the brightness on the screen to the lowest level of black.
5. Tighten the two screws-A to fix the polarizer unit.
6. Adjust the polarizer of other colors.

Y/V

CPU and I/O-Expander Control port functions

CPU (IC801 144 pin) Control port functions

Pin No.	Name	Function Name	Function	Polarity	I/O
1	PA23/WRHH	USB RESET	USB Reset signal	Active L	O
2	PE14/TIOC4C/DACK0/AH				O
3	PA22/WRHL	RS232C_SW	RS232C Output select signal		O
4	PA21/CASHH				O
5	PE15/TIOC4D/DACK1/IRQOUT	POWER SW	"L":Power OFF "H":Power ON		O
6	VSS	GND			
7	PC0/A0	ADDRESS0	Address Bus 0		O
8	PC1/A1	ADDRESS1	Address Bus 1		O
9	PC2/A2	ADDRESS2	Address Bus 2		O
10	PC3/A3	ADDRESS3	Address Bus 3		O
11	PC4/A4	ADDRESS4	Address Bus 4		O
12	VCC	5V			
13	PC5/A5	ADDRESS5	Address Bus 5		O
14	VSS	GND			
15	PC6/A6	ADDRESS6	Address Bus 6		O
16	PC7/A7	ADDRESS7	Address Bus 7		O
17	PC8/A8	ADDRESS8	Address Bus 8		O
18	PC9/A9	ADDRESS9	Address Bus 9		O
19	PC10/A10	ADDRESS10	Address Bus 10		O
20	PC11/A11	ADDRESS11	Address Bus 11		O
21	PC12/A12	ADDRESS12	Address Bus 12		O
22	PC13/A13	ADDRESS13	Address Bus 13		O
23	PC14/A14	ADDRESS14	Address Bus 14		O
24	PC15/A15	ADDRESS15	Address Bus 15		O
25	PB0/A16	ADDRESS16	Address Bus 16		O
26	VCC	5V			
27	PB1/A17	ADDRESS17	Address Bus 17		O
28	VSS	GND			
29	PA20/CASHL	SCL 1	IIC Bus 1 Clock		I/O
30	PA19/BACK/DRAK1	SDA 1	IIC Bus 1 Data		I/O
31	PB2/IRQ0/POE0/RAS				
32	PB3/IRQ1/POE1/CASL				
33	PA18/BREQ/DRAK0	SYS SW	IC on/off Switch (ON="L", OFF="H")		O
34	PB4/IRQ2/POE2/CASH	AFT-V	V SYNC Input (LCD Panel Drive)	Active L	I
35	VSS	GND			
36	PB5/IRQ3/POE3/RDWR				I
37	PB6/IRQ4/A18/BACK	ADDRESS18	Address Bus 18		O
38	PB7/IRQ5/A19/BREQ	ADDRESS19	Address Bus 19		O
39	PB8/IRQ6/A20/WAIT	ADDRESS20	Address Bus 20		O
40	VCC	5V			
41	PB9/IRQ7/A21/ADTRG	ADDRESS21	Address Bus 21		O
42	VSS	GND			
43	PA14/RD	READ	Read Signal	Active L	O
44	WDTOVF				
45	PD31/D31/ADTRG	RTS	RS232C RTS (Request To Send)		O
46	PD30/D30/IRQOUT	CTS	RS232C CTS (Clear To Send)		I
47	PA13/WRH				
48	PA12/WRL	WRL	Write Signal (L-8Bit)	Active L	O
49	PA11/CS1				
50	PA10/CS0	CS0	Flash Memory Chip Select	Active L	O
51	PA9/TCLKD/IRQ3	SCL 2	IIC Bus 2 Clock		I/O
52	PA8/TCLKC/IRQ2	SDA 2	IIC Bus 2 Data		I/O
53	PA7/TCLKB/CS3	CS3	USB/IP/IO EXP/SRAM/FIFO Chip Select	Active L	O
54	PA6/TCLKA/CS2	CS2	CXD3511Q Chip Select	Active L	O
55	VSS	GND			
56	PD29/D29/CS3				
57	PD28/D28/CS2	PW_SEL	PW365 232C Select(SH="H",PIXEL="L")		O
58	PD27/D27/DACK1	PW_INTR	PW365 Interrupt Signal		O
59	PD26/D26/DACK0	PW_OUT1	PW365 Data Outout		O
60	PD25/D25/DREQ1	PW_OUT0	PW365 Data Output		O
61	VSS	GND			
62	PD24/D24/DREQ0				
63	VCC	5V			
64	PD23/D23/IRQ7				
65	PD22/D22/IRQ6				
66	PD21/D21/IRQ5				
67	PD20/D20/IRQ4	SCONF_DONE	Single to Dual converter Enhancer Done Signal		I/O
68	PD19/D19/IRQ3	SSTATUSq	Single to Dual converter Enhancer Status Signal		I/O
69	PD18/D18/IRQ2	PW_IN1	PW365 Data Input		I
70	PD17/D17/IRQ1	PW_IN0	PW365 Data Input		I
71	VSS	GND			

CPU and I/O-Expander Control port functions

Pin No.	Name	Function Name	Function	Polarity	I/O
72	PD16/D16/IRQ0	PW_PG_SEL	PW365 232C Write SW(SH="H",PIXEL="L")		I
73	PD15/D15	DATA15	Data Bus 15		I/O
74	PD14/D14	DATA14	Data Bus 14		I/O
75	PD13/D13	DATA13	Data Bus 13		I/O
76	PD12/D12	DATA12	Data Bus 12		I/O
77	VCC	5V			
78	PD11/D11	DATA11	Data Bus 11		I/O
79	VSS	GND			
80	PD10/D10	DATA10	Data Bus 10		I/O
81	PD9/D9	DATA9	Data Bus 9		I/O
82	PD8/D8	DATA8	Data Bus 8		I/O
83	PD7/D7	DATA7	Data Bus 7		I/O
84	PD6/D6	DATA6	Data Bus 6		I/O
85	VCC	5V			
86	PD5/D5	DATA5	Data Bus 5		I/O
87	VSS	GND			
88	PD4/D4	DATA4	Data Bus 4		I/O
89	PD3/D3	DATA3	Data Bus 3		I/O
90	PD2/D2	DATA2	Data Bus 2		I/O
91	PD1/D1	DATA1	Data Bus 1		I/O
92	PD0/D0	DATA0	Data Bus 0		I/O
93	VSS	GND			
94	XTAL	XTAL	OSC Signal Input		I
95	MD3	Mode-3	Mode-3		I
96	EXTAL	EXTAL	OSC Signal Output		O
97	MD2	Mode-2	Mode-2		I
98	NMI	NONMASK	NONMASK		I
99	VCC (FWP)	FWP	Flash Memory Write Mode		I
100	PA16/AH	FLASH MODE	FWP Control		O
101	PA17/WAIT				O
102	MD1	Mode-1	Mode-1		I
103	MD0	Mode-0	Mode-0		I
104	PLL VCC	PLL VCC	PLL Vcc		
105	PLL CAP	PLL CAP	PLL Filter		
106	PLL VSS	PLL GND	PLL Gnd		
107	PA15/CK	M-CLK	CPU Clock Output (Auto Image FPGA)		O
108	RES	Reset	Reset	Active L	I
109	PE0/TIOC0A/DREQ0	PCTL	CXD3511Q		O
110	PE1/TIOC0B/DRAK0	SCL 6	IIC Bus 6 Clock		I/O
111	PE2/TIOC0C/DREQ1	SDA 6	IIC Bus 6 Data		I/O
112	VCC	5V			
113	PE3/TIOC0D/DRAK1	SDA 3	IIC Bus 3 Data		I/O
114	PE4/TIOC1A	SCL 3	IIC Bus 3 Clock		I/O
115	PE5/TIOC1B	SDA 4	IIC Bus 4 Data		I/O
116	PE6/TIOC2A	SCL 4	IIC Bus 4 Clock		I/O
117	VSS	GND			
118	PF0/AN0	KEY1	Top Control Keys-1 (A/D Input)		I
119	PF1/AN1	KEY2	Top Control Keys-2 (A/D Input)		I
120	PF2/AN2	KEY3	Top Control Keys-3 (A/D Input)		I
121	PF3/AN3	OPT1	Logo Mark		I
122	PF4/AN4	Press Sensor	Atmospheric Pressure Sensor		I
123	PF5/AN5	Temp Sensor	Thermistor		I
124	AVSS	GND	A / D Gnd		
125	PF6/AN6	POWER FAIL	Power Fail (L : Abnormality)		I
126	PF7/AN7	SDATA IN	SDATA IN		I
127	AVREF	5V	5V A / D REF.		
128	AVCC	5V	5V A / D Vcc		
129	VSS	Gnd			
130	PA0/RXD0	SH_RX	PW365 Rx		I
131	PA1/TXD0	SH_TX	PW365 Tx		O
132	PA2/SCK0/DREQ0/IRQ0				
133	PA3/RXD1	Rx	RS232C Rx		I
134	PA4/TXD1	Tx	RS232C Tx		O
135	VCC	5V			
136	PA5/SCK1/DREQ1/IRQ1	USB INTR	USB Interrupt Signal Input	Active L	I
137	PE7/TIOC2B	SDA 5	IIC Bus 5 Data		I/O
138	PE8/TIOC3A	SCL 5	IIC Bus 5 Clock		I/O
139	PE9/TIOC3B	SDATA OUT	Single to Dual converter Enhancer Data Output Signal		O
140	PE10/TIOC3C	SCLK	Single to Dual converter Enhancer Clock Output Signal		O
141	VSS	Gnd			
142	PE11/TIOC3D	EXP RESET	I / O Expander	Active H	O
143	PE12/TIOC4A	R/C	R / C Input	Active L	I
144	PE13/TIOC4B/MRES	PW RESET	PW365 Reset Signal	Active L	O

CPU and I/O-Expander Control port functions

I/O Expander Control port functions (IC1801 64 pin)					Y / V
Pin No.	Name	Function Name	Function	Polarity	I/O
1	PF6	BLAST_SW3	Lamp Ballast 1 On/Off SW *	ON = H	O
2	PF7	BLAST_SW4	Lamp Ballast 2 On/Off SW *	ON = H	O
3	Vcc	Vcc	5V ±10%		-
4	PE0	LENS_UP	Lens Up		O
5	PE1	LENS_DOWN	Lens Down		O
6	PE2	LENS_RIGHT	Not used Lens Right *		O
7	PE3	LENS_LEFT	Not used Lens Left *		O
8	PE4	FOCUS+	Focus +		O
9	PE5	FOCUS-	Focus -		O
10	PE6	ZOOM+	Zoom +		O
11	PE7	ZOOM-	Zoom -		O
12	GND3	GND			-
13	PB0	LENS_TOP	Lens Top Detection	Top= " L "	I
14	PB1	LENS_VC	Lens U/D Center Detection	Center= Edge	I
15	PB2	LENS_BOT	Lens Bottom Detection	Bottom= "L"	I
16	PB3	LENS_RE	Not used Lens Right Detection *	Right= "L"	I
17	PB4	LENS_HC	Not used Lens R/L Detection *	Center= Edge	I
18	PB5	LENS_LE	Not used Lens Left Detection *	Left= "L"	I
19	PB6	SEL_CTIN1	SEL_CTIN1	INIT	I
20	PB7	SEL_CTIN2	SEL_CTIN2	DONE_SEL	I
21	PA7				O
22	PA6				O
23	PA5				O
24	PA4	RESET	FPGA Reset	Low->High Reset	O
25	PA3				O
26	PA2	50_60_SW	50/60Hz Select SW	50Hz= "L"	O
27	PA1	CG_SW	CG Select SW	CG= "H"	O
28	PA0	COMP_SW	COMPONENT Select SW	COMPO= "L"	O
29	Vcc	Vcc	5V ±10%		-
30	RD	READ_CPU	Read Select	Active "L"	I
31	WR	WRITE_CPU	Write Select	Active "L"	I
32	CS	CS_EXP	Chip Select	Active "L"	I
33	RESET	EXP_RST	Reset	Active "H"	I
34	GND1	GND			-
35	A2	A2CPU	Port Select 2		I
36	A1	A1CPU	Port Select 1		I
37	A0	A0CPU	Port Select 0		I
38	D0	D0CPU	Data Bus 0		I/O
39	D1	D1CPU	Data Bus 1		I/O
40	D2	D2CPU	Data Bus 2		I/O
41	D3	D3CPU	Data Bus 3		I/O
42	D4	D4CPU	Data Bus 4		I/O
43	D5	D5CPU	Data Bus 5		I/O
44	D6	D6CPU	Data Bus 6		I/O
45	D7	D7CPU	Data Bus 7		I/O
46	PC7	SLOT_SEL1	Slot select 1		O
47	PC6	SLOT_SEL2	Slot select 2		O
48	PC5				O
49	PC4	AUDIO_MUTE	Mute Output		O
50	PC0	LAMP1	Not used PFC On/Off SW *	ON = H	O
51	PC1	LAMP2	Not used PFC On/Off SW *	ON = H	O
52	PC2	LAMP3	PFC 1 On/Off SW *	ON = H	O
53	PC3	LAMP4	PFC 2 On/Off SW *	ON = H	O
54	PG0	LAMP1_ERR	Not used Lamp monitor *	Abnormality "H"	I
55	PG1	LAMP_ERR	Not used Lamp monitor *	Abnormality "H"	I
56	PG2	LAMP3_ERR	Lamp monitor 1 *	Abnormality "H"	I
57	PG3	LAMP4_ERR	Lamp monitor 2 *	Abnormality "H"	I
58	GND2	GND			-
59	PF0	TEMP_LED	Temp Warning LED Drive	LED ON = "L"	O
60	PF1	LAMP_LED	Lamp Replacement LED Drive	LED ON = "L"	O
61	PF2	READY_LED	Ready LED Drive	LED ON = "L"	O
62	PF3	SP_SW	Speaker on/off Switch	"L":ON "H":OFF	O
63	PF4	BLAST_SW1	Not used Lamp Ballast On/Off SW *	ON = H	O
64	PF5	BLAST_SW2	Not used Lamp Ballast On/Off SW *	ON = H	O

CPU and I/O-Expander Control port functions

Output Expander Control port functions (IC1822 20 pin)

Pin No.	Name	Function Name	Function	Polarity	I/O
1	OE	EXP_RST			
2	O0	SCONFIG	Single to Dual converter Enhancer CONFIG Signal		O
3	D0		Data Bus 0		
4	D1		Data Bus 1		
5	O1	IP_RESET	IP_RESET		O
6	O2	PROGRAM	PROGRAM		O
7	D2		Data Bus 2		
8	D3		Data Bus 3		
9	O3	USB_BRST	USB on-off		O
10	GND		GND		
11	CP				
12	O4	BUS_SW1	BUS Select SW1		O
13	D4		Data Bus 4		
14	D5		Data Bus 5		
15	O5	BUS_SW2	BUS Select SW2		O
16	O6	BUS_SW3	BUS Select SW3		O
17	D6		Data Bus 6		
18	Çc7		Data Bus 7		
19	O7	SSTB	Single to Dual converter Enhancer STB Signal		O
20	Vcc		+5V		

I/O Expander Control port functions (IC9021 16 pin)

Pin No.	Name	Function Name	Function	Polarity	I/O
1	SO	S0	Serial Data Output		O
2	SCL	IIC BUS SCL			I
3	SDA	IIC BUS SDA			I/O
4	D0	M-IDA1	Slot 1 Type Detection 1		I
5	D1	M-IDA2	Slot 2 Type Detection 1		I
6	D2	M-IDA3	Slot 3 Type Detection 1		I
7	D3	M-IDA4	Slot 4 Type Detection 1		I
8	Vss	GND			-
9	D4	M-IDB1	Slot 1 Type Detection 2		I
10	D5	M-IDB2	Slot 2 Type Detection 2		I
11	D6	M-IDB3	Slot 3 Type Detection 2		I
12	D7	M-IDB4	Slot 4 Type Detection 2		I
13	Vdd		5V ±10%		-
14	CS2	CS2			I
15	CS1	CS1			I
16	CS0	CS0			I

I/O Expander Control port functions (IC9022 16 pin)

Pin No.	Name	Function Name	Function	Polarity	I/O
1	SO	S0	Serial Data Output		O
2	SCL	IIC BUS SCL			I
3	SDA	IIC BUS SDA			I/O
4	D0	M-IDC1	Slot 1 Type Detection 3		I
5	D1	M-IDC2	Slot 2 Type Detection 3		I
6	D2	M-IDC3	Slot 3 Type Detection 3		I
7	D3	M-IDC4	Slot 4 Type Detection 3		I
8	Vss	GNDÄ			-
9	D4	SLOT1 ID	SLOT1 ID		I
10	D5	SLOT2 ID	SLOT2 ID		I
11	D6	SLOT3 ID	SLOT3 ID		I
12	D7	SLOT4 ID	SLOT4 ID		I
13	VDD		5V ±10%		-
14	CS2	CS2			I
15	CS1	CS1			I
16	CS0	CS0			I

The cautions in schematic diagrams

■ 1. PRODUCT SAFETY NOTICE

THE COMPONENTS DESIGNATED BY A MARK ($\triangle$) IN THIS SCHEMATIC DIAGRAM DESIGNATE COMPONENTS WHOSE VALUES ARE OF SPECIAL SIGNIFICANCE TO PRODUCT SAFETY. SHOULD ANY COMPONENT DESIGNATED BY A MARK NEED TO BE REPLACED, USE ONLY THE PART DESIGNATED IN THE PARTS LIST. DO NOT DEVIATE FROM THE RESISTANCE, WATTAGE AND VOLTAGE RATINGS SHOWN.



■ 2. The cautions in collation of parts.

Specification of capacitor and resistors will be shown with coded symbols, reading code symbols following the chart and notes. Some capacitor and resistors will be shown directly with values and no other information. Detailed information on each capacitor and resistor will be shown in the list.

NOTE; DO NOT REPLACE OR ORDER RESISTOR AND CAPACITOR PARTS FOLLOWING THE SPECIFICATIONS SHOWN IN THE SCHEMATIC DIAGRAMS. ALWAYS CHECK FOR THE CORRECT SPECIFICATIONS IN THE PARTS LIST. ESPECIALLY FOR CRITICAL COMPONENT MARKED $\triangle$. SPECIAL ATTENTION MUST BE GIVEN TO CRITICAL COMPONENTS.

■ 3. Reading of parts.

Read resistor codes as follows:

1. All resistance values are indicated in ohms: K=1,000. M=1,000,000.
2. Resistor which is indicated with resistance value only are 1/6W carbon resistor. Resistor which is indicated with material tolerance and value are 1/4W rated wattage.

Read capacitor codes as follows:

1. For capacitors identified with $\pm$, values less than 1 are expressed in uF, values more than 1 are in pF.
2. For capacitors (electrolytic) identified with $\mp$, values are expressed in uF.

Voltage and waveforms were taken using a video color bar signal (1V p-p at 75 ohms terminated) and controls to normal.

Voltages were taken with a high-impedance voltmeter.

The cautions in schematic diagrams

Read description in the Capacitor and Resister as follows:

CAPACITOR

16 K K 0.47 BA

Characteristic

Rated value

Material :

C	CERAMIC	Temperature compensating ceramic
K	CERAMIC	High dielectric rate ceramic
B	CERAMIC	Semiconductor ceramic
Z	MT-PAPER	Metallized paper
F	POLYESTER	Polyester
G	MT-POLYEST	Metallized polyester
N	POLYPRO	Polypropylene
M	MT-POLYPRO	Metallized polypropylene
Y	COMPO FILM	Composite film
H	MT-COMPO	Metallized composite film
S	STYRENE	Styrol
T	TA-SOLID	Tantalum oxide solid electrolytic
A	AL-SOLID	Aluminum solid electrolytic
E	ELECT	Aluminum foil electrolytic
P	NP-ELECT	Non-polarized electrolytic
U	OS-SOLID	Aluminum solid capacitors with organic semiconductive electrolyte
V	POS-SOLID	Polymerized organic semiconductor
D	DL-ELECT	Electric double layer electrolytic
J	AL-SOLID	Aluminum manganese wind solid
L	PPS-FILM	Polyphenylene sulfide film
Q	MT-PPS-FILM	Metallized Polyphenylene sulfide film
R	MT-PEN-FILM	Metallized polyethylenenaphthalate film
W	EP-ELECT	Electric Conductor Polymerized Aluminum foil electrolytic
X	CAPACITOR	Other

Rated Voltage

Tolerance Symbols

Static capacitance of 10PF or less

A:	Nondesignated
B:	±0.1PF
C:	±0.25PF
D:	±0.5PF
F:	±1PF
G:	±2PF
H:	+0.1 ~ -0PF
L:	+0 ~ -0.1PF
R:	+0.25 ~ -0PF
S:	+0 ~ -0.25PF
E:	+0 ~ -1PF
J:	±5%
K:	±10%
M:	±20%

Note: J, K, and M are used only for tubular Ceramic Capacitors

Static capacitance of more than 10PF

A:	Nondesignated
B:	±0.1%
C:	±0.25%
D:	±0.5%
F:	±1%
G:	±2%
E:	±2.5%
H:	±3%
J:	±5%
K:	±10%
L:	±15%
M:	±20%
N:	±30%
P:	+100 ~ -0%
Q:	+30 ~ -10%
R:	+20 ~ -0%
T:	+50 ~ -10%
U:	+75 ~ -10%
V:	+20 ~ -10%
W:	+100 ~ -10%
X:	+40 ~ -20%
Y:	+150 ~ -10%
Z:	+80 ~ -20%

FIXED RESISTER

1/10 G J 100K

Rated value, ohms : K: x1,000 ohms.
M: x1,000,000 ohms

Material :

D	CARBON	Carbon film fixed
N	MT-FILM	Metal film fixed
S	OXIDE-MT	Metal oxide film fixed
C	SOLID	Solid
G	MT-GLAZE	Metal glaze type fixed
W	WIRE WOUND	Power type covered wiring fixed
H	CERAMIC RES	Ceramic fixed
F	FUSIBLE RES	Fusible
X	RESISTER	Used for "others"

Rated Wattage

Tolerance Symbols:

A:	±0.05%
B:	±0.1%
C:	±0.25%
D:	±0.5%
F:	±1%
G:	±2%
J:	±5%
K:	±10%
M:	±20%
P:	+5 ~ -15%
Z:	Use when 0 ohm


Chip transistor (list of replaceable)

Mark	AJ
	2SA1179-M6
	2SA1179-M7
	2SA1037K-R
	2SA1037K-S
	2SA1037AK-R
	2SA1037AK-S


Mark	AH
	2SC2812-L6
	2SC2812-L7
	2SC2412K-R
	2SC2412K-S

UNIT P.F.C., UNIT LAMP BALLAST and IC BLOCK DIAGRAMS

UNIT P.F.C.



UNIT LAMP BALLAST





Switching regulator



FA7612CN PWM POWER CONTROL




LB1641/1645N MOTOR DRIVER





MPXA4115A Pressure sensor for altimeter

SMALL OUTLINE
PACKAGE






PPXA4115A
CASE 482-01

<FF>




CXD3511Q **DIGITAL SIGNAL** **DRIVER**

240 pin QFP (Plastic)



CXA3562R **LCD DRIVER**

100 pin LQFP (Plastic)



Parts list

■ PRODUCT SAFETY NOTICE

Product safety should be considered when a component replacement is made in any area of a Projector. Components indicated by a ⚠ mark in this parts list and the schematic diagram show components whose value have special significance to product safety. It is particularly recommended that only parts specified on the following parts list be used for components replacement pointed out by the mark.

Note:

Part order must contain Chassis No., Part No., and descriptions.

■ Readjustments after parts replacement.

Y/V

-- Assembly Power --

- When it is replaced to the new assembly power.
- * Factory adjustment of the new assembly power has completed. Readjustment is unnecessary.
- When the component parts of assembly-power are replaced.
- * Readjust the following adjustment item.
- 1. DC voltage adjustment.

-- Terminal board AV --

- When it is replaced to the new terminal-board-AV.
- * Factory adjustments of the new terminal-board-AV have completed. Readjustments are unnecessary.
- When the component parts of terminal-board-AV are replaced.
- * Readjust the following adjustment items.
- 2. AV Video signal adjustments
- 3. 3DNR-PLL Lock check
- 4. AV Color and Tint adjustments

-- Terminal board component --

- When it is replaced to the new terminal-board-component.
- * Factory adjustment of the new terminal-board-component has completed. Readjustment is unnecessary.
- When the component parts of terminal-board-component are replaced.
- * Readjust the following adjustment item.

5. Component Video signal adjustments

-- Unit-lamp-ballast --

- In case this unit is fault, replace the unit completely, do not replace the individual component. Readjustment is unnecessary.

-- Unit-PFC. --

- In case this unit is fault, replace the unit completely, do not replace the individual component. Readjustment is unnecessary.

-- Assembly Sub power --

- When it is replaced to the new assembly-sub-power or when component parts are replaced. * Readjust the following adjustment item.

6. Fans driving voltage adjustments

Assembly-main.

■ Replace memory ICs in the following procedure.

1. Remove IC871 and IC1811 from an old (damaged) assembly-main.
2. Attach IC removed to new assembly-main. The data recorded is all taken over to a new assembly-main, readjustment is unnecessary.

■ When ICs are not replaced.

- (1). The life data of a lamp starts from an initial value compulsorily. Manually, this life data cannot be set up.
- (2). Readjust the following adjustment items.
6. Fans driving voltage adjustments
7. Video center DC adjustments
8. PSIG signal adjustments
9. PC pedestal level adjustments
10. PC contrast adjustments-1
11. AV pedestal level adjustment
12. AV contrast adjustments-2
13. Panel driving signal adjustments -AV
14. Panel driving signal adjustments -PC
15. Flicker reduction.
16. White balance adjustments

-- The component parts inside the optical unit -- (Part no. 102, 106-111, 114, and 123-124.)

- When the optical component parts inside the optical unit are replaced.
- * Check the following adjustment items.

Integrator-lens-in adjustment-1
Integrator-lens-out adjustment
Integrator-lens-in adjustment-2
Condenser-lens adjustment
Relay-lens adjustment
Prism-P.B.S. adjustment
Polarizer. adjustment

Y/V

-- Relay-lens --

- When the relay-lens is replaced.
- * Readjust the following adjustment item.
- Relay-lens adjustment

-- Condenser-lens --

- When the Condenser-lens is replaced.
- * Readjust the following adjustment item.
- Condenser-lens adjustment

-- Integrator-lens-in --

- When the integrator-lens-in is replaced.
- * Readjust the following adjustment items.

Integrator-lens-in adjustment-1
Integrator-lens-in adjustment-2

-- Prism / LCD panel Assembly --

- When the Assembly LCD-panel/prism is replaced.
- * Readjust the following adjustment items.

Focus of LCD Panel adjustment
15. Flicker reduction
16. White balance adjustments

-- Integrator-lens-out and prism-PBS --

- When the integrator-lens-out and prism-PBS are replaced.
- * Readjust the following adjustment item.
- Integrator-lens-out adjustment
Prism-P.B.S. adjustment

-- Polarization-glasses--

- When the Polarization-glasses are replaced.
- * Readjust the following adjustment item.
- Polarizer adjustment

Read description in the Capacitor and Resister as follows:

**CAPACITOR
CERAMIC 100P K 50V**

Rated Voltage

Rated value: P=Pico farad, U=Micro farad

Material :	
CERAMIC	Temperature compensating ceramic High dielectric rate ceramic Semiconductor ceramic
MT-PAPER	Metallized paper
POLYESTER	Polyester
MT-POLYEST	Metallized polyester
POLYPRO	Polypropylene
MT-POLYPRO	Metallized polypropylene
COMPO FILM	Composite film
MT-COMPO	Metallized composite film
STYRENE	Styrol
TA-SOLID	Tantalum oxide solid electrolytic
AL-SOLID	Aluminum solid electrolytic
ELECT	Aluminum foil electrolytic
NP-ELECT	Non-polarized electrolytic
OS-SOLID	Aluminum solid capacitors with organic semiconductive electrolyte
POS-SOLID	Polymerized organic semiconductor
DL-ELECT	Electric double layer electrolytic
AL-SOLID	Aluminum manganese wind solid
PPS-FILM	Polyphenylene sulfide film
MT-PPS-FILM	Metallized Polyphenylene sulfide film
MT-PEN-FILM	Metallized polyethylenenaphthalate film
EP-ELECT	Electric Conductor Polymerized Aluminum foil electrolytic
CAPACITOR	Other

Tolerance Symbols

Static capacitance of 10PF or less

A:	Nondesigned
B:	±0.1PF
C:	±0.25PF
D:	±0.5PF
F:	±1PF
G:	±2PF
H:	+0.1 ~ -0PF
L:	+0 ~ -0.1PF
R:	+0.25 ~ -0PF
S:	+0 ~ -0.25PF
E:	+0 ~ -1PF
J:	±5%
K:	±10%
M:	±20%

Note: J, K, and M are used only for tubular Ceramic Capacitors

Static capacitance of more than 10PF

A:	Nondesigned
B:	±0.1%
C:	±0.25%
D:	±0.5%
F:	±1%
G:	±2%
E:	±2.5%
H:	±3%
J:	±5%
K:	±10%
L:	±15%
M:	±20%
N:	±30%
P:	+100 ~ -0%
Q:	+30 ~ -10%
R:	+20 ~ -0%
T:	+50 ~ -10%
U:	+75 ~ -10%
V:	+20 ~ -10%
W:	+100 ~ -10%
X:	+40 ~ -20%
Y:	+150 ~ -10%
Z:	+80 ~ -20%

**FIXED RESISTER
CARBON 4.7K J A 1/4W**

Rated Wattage

Rated value, ohms : K: X1,000 ohms. M: X1,000,000 ohms

Material :	
CARBON	Carbon film fixed
MT-FILM	Metal film fixed
OXIDE-MT	Metal oxide film fixed
SOLID	Solid
MT-GLAZE	Metal glaze type fixed
WIRE WOUND	power type covered wiring fixed
CERAMIC RES	Ceramic fixed
FUSIBLE RES	Fusible
RESISTER	Used for "others"

Tolerance Symbols:

A:	±0.05%
B:	±0.1%
C:	±0.25%
D:	±0.5%
F:	±1%
G:	±2%
J:	±5%
K:	±10%
M:	±20%
P:	+5 ~ -15%
Z:	Use when 0 ohm

Performance Symbols:


A:	General
B:	Flame retardance (including noncombustible)
Z:	Low noise (Less than 100Kohms : 0.3uV/V, 100Kohms to 1Mohm : 0.5uV/V, More than 1Mohm : 1.0uV/V)

C-Y : Temperature characteristics


T:	±10ppm/°C
U:	±25ppm/°C
C:	±50ppm/°C
D:	±100ppm/°C
E:	±200ppm/°C
F:	±250ppm/°C
G:	±350ppm/°C
H:	±1000ppm/°C±10%
W:	±1200ppm/°C±10%
Y:	±1400ppm/°C±10%
J:	±2000ppm/°C±10%
K:	±2400ppm/°C±10%
L:	±2700ppm/°C±10%
M:	±3000ppm/°C±10%
N:	±3300ppm/°C±10%
P:	±3600ppm/°C±10%
Q:	±3900ppm/°C±10%
R:	±4200ppm/°C±10%
S:	±4300ppm/°C±10%
V:	±4500ppm/°C±10%
X:	±800ppm/°C±150ppm/°C
O:	+500ppm/°C ~ -250ppm/°C

Note :

1. "General" (symbol A) means properties for which there are some differences among manufacturers but which can be used when within the range given in the catalogs.
2. Parts for which temperature characteristics are especially designated (required) due to design are indicated by "temperature characteristic classifications" (symbol C to Y). Others are indicated by "General" (symbol A).
3. What are called "cement resistors" are noncombustible, so are indicated as "General"(symbol A), not "Flame retardant (including noncombustible)"(symbol B)




**PWB ASSEMBLIES
LOCATION**




← :Direction of a wind.

**MOTOR FANS
LOCATION**

FN902 :
See the Production change
notice of the cover. (Page-1)



Cabinet Chassis



Cabinet and Optical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description

CABINET PARTS 005MY6A			OPTICAL PARTS 014MY6A		
1.	610 290 9180	ASSY, BUTTON-MV6A	101.	645 046 1323	ASSY, PRISM(PBS)
2.	610 290 5366	ASSY, STAND LEG A-MV6A	or	645 046 1330	ASSY, PRISM(PBS)
3.	610 291 9431	ASSY, STAND LEG B-MV6A	102.	645 046 9459	LENS, RELAY(IN)
4.	610 289 1829	BADGE V MARK L-ML6A	103.	645 046 9466	LENS, RELAY(OUT)
6.	610 290 4062	CABINET FRONT-MV6A	104.	645 046 9411	LENS, INTEGRATOR
7.	610 292 9379	CABINET TOP-MY6A	106.	645 047 9731	LENS, CONDENSER 1
8.	610 290 4086	CABINET BOTTOM-MV6A	107.	645 047 9748	LENS, CONDENSER 2
9.	610 290 4093	COVER, LMP-MV6A	108.	645 051 1431	LENS, CONDENSER
11.	610 290 9241	COVER LNS A-MV6A	109.	645 046 1361	MIRROR(RH)
12.	610 290 9265	DEC INLAY R/C-MV6A	111.	645 046 1378	MIRROR(B-COLD)
13.	610 290 9272	DEC INLAY A-MV6A	112.	645 046 9428	MIRROR(COLD)
14.	610 293 2409	DEC INLAY REAR-MV6A	113.	645 046 1392	OPTICAL FILTER(UV/IR)
16.	610 290 9296	DEC COMP SHEET A-MV6A	114.	645 046 1408	OPTICAL FILTER(UV CUT)
17.	610 290 9302	DEC COMP SHEET B-MV6A	116.	645 041 2837	POLARIZATION GLASS(HIN/R)
18.	610 292 3162	FILTER NET A-MV6A	117.	645 041 2882	POLARIZATION GLASS(HIN/G)
19.	See the Production change notice of the cover. (Page-1)		118.	645 041 2899	POLARIZATION GLASS(HIN/B)
21.	610 292 3186	FILTER NET C-MV6A	119.	645 041 2905	POLARIZATION GLASS(IN/R)
22.	610 290 9326	HANDLE-MV6A	121.	645 041 2912	POLARIZATION GLASS(IN/G)
23.	610 290 9364	MOUNTING COVER LNS A-MV6A	122.	645 041 2929	POLARIZATION GLASS(IN/B)
24.	610 290 9371	MOUNTING COVER LNS B-MV6A	123.	645 046 1446	DICHROIC MIRROR (C)
26.	610 290 4116	PANEL FRONT BTM-MV6A	124.	645 046 1453	DICHROIC MIRROR (Y)
27.	610 290 4123	PANEL FRONT TOP-MV6A	128.	610 296 8224	ASSY, LCD PNL/PRISM-MY6A
28.	610 290 4130	PANEL FRONT MID-MV6A	*****		
29.	610 290 4147	PANEL COMP A-MV6A	For model PLC-XF30N Only		
31.	610 290 9388	PANEL FILTER A-MV6A	126.	645 044 0977	ASSY, LENS, PROJECTION
32.	610 290 9395	PANEL FILTER B-MV6A	126-A	645 034 8327	MOTOR, LENS(Z, F) DC 0.3W
33.	610 290 9401	PANEL FILTER C-MV6A	127.	610 277 8755	CAP LENS A-M6VA
34.	610 291 8762	PANEL BLST A-MV6A	*****		
36.	610 290 9456	SPACER CT-MV6A	SANYO--		
37.	610 289 1263	STAND LEG CT-MJ6A			
38.	610 272 9238	SPRING COIL-M6MA			
39.	645 032 6400	BADGE, SANYO*43.5X10L43.5			

CHASSIS PARTS 006MY6A					
51.	610 290 1887	COMPL, HOLDER LNS-MV6A			
51-A	645 048 3929	MOTOR, SHIFT LNS			
51-B	645 012 2422	SWITCH, LEVER			
53.	610 290 5328	COMPL, HOLDER REL A-MV6A			
54.	610 297 4430	COMPL, HOLDER COND C-MY6A			
56.	610 293 8111	COMPL, HOLDER INT A-MY6A			
57.	610 293 8135	COMPL, HOLDER PBS A-MY6A			
58.	610 292 4350	COVER DUCT TOP A-MV6A			
59.	610 292 4367	COVER DUCT BTM A-MV6A			
61.	610 292 4374	COVER DUCT TOP B-MV6A			
62.	610 292 4381	COVER DUCT BTM B-MV6A			
63.	610 292 4398	COVER DUCT TOP C-MV6A			
64.	610 292 4404	COVER DUCT BTM C-MV6A			
66.	610 292 4411	COVER DUCT TOP D-MV6A			
67.	610 292 4428	COVER DUCT BTM D-MV6A			
68.	610 292 4435	COVER DUCT TOP E-MV6A			
69.	610 292 4442	COVER DUCT BTM E-MV6A			
71.	610 290 9098	HOLDER, PRM BTM-MV6A			
72.	610 290 9104	HOLDER, PRM TOP-MV6A			
73.	610 292 4459	HOLDER POWER PWB BTM-MV6A			
74.	610 292 4466	HOLDER POWER PWB TOP-MV6A			
76.	610 293 4335	HOLDER FN C-MV6A			
77.	610 282 7996	MOUNTING PLT A-MJ6A			
78.	610 290 5526	MOUNTING POL IN A MV6A			
79.	610 290 5533	MOUNTING POL IN B MV6A			
81.	610 290 5540	MOUNTING POL IN C MV6A			
82.	610 294 2255	OPTICAL BASE TOP-MY6A			
83.	610 290 2235	OPTICAL BASE BTM A-MV6A			
84.	610 290 2242	OPTICAL BASE BTM B-MV6A			
86.	610 290 5373	HOLDER REL D-MV6A			
87.	610 290 5380	HOLDER INT D-MV6A			
88.	610 290 5397	HOLDER PBS D-MV6A			
89.	610 293 9088	HOLDER COND D-MY6A			

SCREWS					
96.	411 102 2203	SCR BIN 4X8			
97.	411 182 6207	PIN PARALLEL 5X35			
98.	412 063 3209	SPECIAL SCREW			
99.	411 109 2107	WASHER Y 3.6X6X0.5			

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description

Out of PWB Assembly					
COIL					
▲ LF901	645 040 7628	UNIT, NOISE FILTER			
L901	645 050 8417	CORE, CLAMP			
	645 044 3817	CORE, CLAMP			
L902	645 050 8417	CORE, CLAMP			
	645 044 3817	CORE, CLAMP			
L903	645 050 8417	CORE, CLAMP			
	645 044 3817	CORE, CLAMP			
L904	645 050 8417	CORE, CLAMP			
	645 044 3817	CORE, CLAMP			
L905	645 050 8417	CORE, CLAMP			
	645 044 3817	CORE, CLAMP			
MISCELLANEOUS					
▲ FN901	645 047 9120	MOTOR, FAN DC 1.68W			
▲ FN902	645 041 7542	MOTOR, FAN DC 1.68W			
▲ FN903	645 047 9700	MOTOR, FAN DC 11W			
▲ FN904	645 047 9700	MOTOR, FAN DC 11W			
▲ FN905	645 047 3333	MOTOR, FAN DC 11W			
▲ FN906	645 049 5274	MOTOR, FAN DC 1.68W			
▲ FN907	645 043 3115	MOTOR, FAN DC 5.3W			
▲ FN908	645 042 7787	MOTOR, FAN DC 1.68W			
▲ FN909	645 047 7416	MOTOR, FAN DC 3.8W			
▲ FN910	645 047 7416	MOTOR, FAN DC 3.8W			
▲ F901	423 027 2602	FUSE 250V 10A			
▲ F901A	645 023 3777	HOLDER, FUSE			
▲ K901	645 040 7598	SOCKET, INLET AC 3P			
▲ LP901	610 292 4848	COMPL OPTICAL LAMP-MY6A			
▲ LP902	610 292 4848	COMPL OPTICAL LAMP-MY6A			
SP901	610 055 5471	SPEAKER			
SP902	610 055 5471	SPEAKER			
▲ SW901	645 047 0400	SWITCH, POWER 2P-2TX2			
▲ SW902	645 031 7743	SWITCH, PUSH 2P-2TX2			
SW903	645 043 5966	SWITCH, REED			
SW904	645 043 7335	SWITCH, REED			
WK2B-K90	610 287 1005	CORD, SHIELD 1P			
WK2G-K90	610 287 0992	CORD, SHIELD 1P			
WK2R-K90	610 287 0985	CORD, SHIELD 1P			
W901	610 293 0719	CORD, 32P			
W902	610 295 2810	CORD, SHIELD 40P(BLACK)			
W903	610 295 2827	CORD, SHIELD 40P(GRAY)			
W904	610 294 5072	CABLE, LAMP			
W905	610 294 5072	CABLE, LAMP			

▲ BALAST1	645 047 1346	UNIT, BALLAST LAMP			
▲ BALAST2	645 047 1346	UNIT, BALLAST LAMP			

▲ PFC1	645 042 2928	UNIT, PFC			

610 286 8791 ASSY PWB AV ML6A					
TRANSISTOR					
Q101	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q102	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q1101	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q1151	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
Q1152	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q1153	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
	405 134 5905	TR 2SA1037AK-T146-R			
	405 147 2205	TR 2SA1037AK-S-T146			
	405 002 0308	TR 2SA1037K T146 R			
	405 002 0407	TR 2SA1037K T146 S			
	405 002 6706	TR 2SA1179-M6-TB			
	405 002 6904	TR 2SA1179-M7-TB			
	405 163 1503	TR 2SA1179N-M6-TB			
	405 163 2708	TR 2SA1179N-M7-TB			
	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405				

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	
Q2151	405 002 0308	TR 2SA1037K T146 R	Q4182	405 163 1701	TR 2SC2812N-L7-TB0	
	405 002 0407	TR 2SA1037K T146 S		405 014 4509	TR 2SC2412K T146 R	
	405 002 6706	TR 2SA1179-M6-TB		405 014 4608	TR 2SC2412K T146 S	
	405 002 6904	TR 2SA1179-M7-TB		405 015 8704	TR 2SC2812-L6-TB	
	405 163 1503	TR 2SA1179N-M6-TB		405 015 8902	TR 2SC2812-L7-TB	
	405 163 2708	TR 2SA1179N-M7-TB		405 163 1602	TR 2SC2812N-L6-TB0	
	405 014 4509	TR 2SC2412K T146 R		405 163 1701	TR 2SC2812N-L7-TB0	
	405 014 4608	TR 2SC2412K T146 S		Q4185	405 134 5905	TR 2SA1037AK-T146-R
	405 015 8704	TR 2SC2812-L6-TB			405 147 2205	TR 2SA1037AK-S-T146
	405 015 8902	TR 2SC2812-L7-TB			405 002 0308	TR 2SA1037K T146 R
405 163 1602	TR 2SC2812N-L6-TB0	405 002 0407	TR 2SA1037K T146 S			
405 163 1701	TR 2SC2812N-L7-TB0	405 002 6706	TR 2SA1179-M6-TB			
Q2191	405 134 5905	TR 2SA1037AK-T146-R	405 002 6904		TR 2SA1179-M7-TB	
	405 147 2205	TR 2SA1037AK-S-T146	405 163 1503		TR 2SA1179N-M6-TB	
	405 002 0308	TR 2SA1037K T146 R	405 163 2708		TR 2SA1179N-M7-TB	
	405 002 0407	TR 2SA1037K T146 S	Q5101		405 014 4509	TR 2SC2412K T146 R
	405 002 6706	TR 2SA1179-M6-TB			405 014 4608	TR 2SC2412K T146 S
	405 002 6904	TR 2SA1179-M7-TB		405 015 8704	TR 2SC2812-L6-TB	
	405 163 1503	TR 2SA1179N-M6-TB		405 015 8902	TR 2SC2812-L7-TB	
	405 163 2708	TR 2SA1179N-M7-TB		405 163 1602	TR 2SC2812N-L6-TB0	
	405 014 4509	TR 2SC2412K T146 R		405 163 1701	TR 2SC2812N-L7-TB0	
	405 014 4608	TR 2SC2412K T146 S		Q5103	405 134 5905	TR 2SA1037AK-T146-R
405 015 8704	TR 2SC2812-L6-TB	405 147 2205			TR 2SA1037AK-S-T146	
405 015 8902	TR 2SC2812-L7-TB	405 002 0308			TR 2SA1037K T146 R	
405 163 1602	TR 2SC2812N-L6-TB0	405 002 0407			TR 2SA1037K T146 S	
405 163 1701	TR 2SC2812N-L7-TB0	405 002 6706	TR 2SA1179-M6-TB			
Q3100	405 014 4509	TR 2SC2412K T146 R	405 002 6904		TR 2SA1179-M7-TB	
	405 014 4608	TR 2SC2412K T146 S	405 163 1503		TR 2SA1179N-M6-TB	
	405 015 8704	TR 2SC2812-L6-TB	405 163 2708		TR 2SA1179N-M7-TB	
	405 015 8902	TR 2SC2812-L7-TB	Q5104		405 014 4509	TR 2SC2412K T146 R
	405 163 1602	TR 2SC2812N-L6-TB0			405 014 4608	TR 2SC2412K T146 S
	405 163 1701	TR 2SC2812N-L7-TB0		405 015 8704	TR 2SC2812-L6-TB	
	405 014 4509	TR 2SC2412K T146 R		405 015 8902	TR 2SC2812-L7-TB	
	405 014 4608	TR 2SC2412K T146 S		405 163 1602	TR 2SC2812N-L6-TB0	
	405 015 8704	TR 2SC2812-L6-TB		405 163 1701	TR 2SC2812N-L7-TB0	
	405 015 8902	TR 2SC2812-L7-TB		Q5105	405 134 5905	TR 2SA1037AK-T146-R
405 163 1602	TR 2SC2812N-L6-TB0	405 147 2205			TR 2SA1037AK-S-T146	
405 163 1701	TR 2SC2812N-L7-TB0	405 002 0308			TR 2SA1037K T146 R	
405 134 5905	TR 2SA1037AK-T146-R	405 002 0407			TR 2SA1037K T146 S	
405 147 2205	TR 2SA1037AK-S-T146	405 002 6706	TR 2SA1179-M6-TB			
405 002 0308	TR 2SA1037K T146 R	405 002 6904	TR 2SA1179-M7-TB			
405 002 0407	TR 2SA1037K T146 S	405 163 1503	TR 2SA1179N-M6-TB			
405 002 6706	TR 2SA1179-M6-TB	405 163 2708	TR 2SA1179N-M7-TB			
405 002 6904	TR 2SA1179-M7-TB	Q3143	405 014 4509		TR 2SC2412K T146 R	
405 163 1503	TR 2SA1179N-M6-TB		405 014 4608		TR 2SC2412K T146 S	
405 163 2708	TR 2SA1179N-M7-TB		405 015 8704	TR 2SC2812-L6-TB		
405 014 4509	TR 2SC2412K T146 R		405 015 8902	TR 2SC2812-L7-TB		
405 014 4608	TR 2SC2412K T146 S		405 163 1602	TR 2SC2812N-L6-TB0		
405 015 8704	TR 2SC2812-L6-TB		405 163 1701	TR 2SC2812N-L7-TB0		
405 015 8902	TR 2SC2812-L7-TB		Q3144	405 014 4509	TR 2SC2412K T146 R	
405 163 1602	TR 2SC2812N-L6-TB0					

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C1105	403 215 0900	CERAMIC 390P J 50V	C2154	403 164 0204	CERAMIC 0.1U Z 25V
C1106	403 164 0204	CERAMIC 0.1U Z 25V	C2155	403 164 0204	CERAMIC 0.1U Z 25V
C1107	403 164 0204	CERAMIC 0.1U Z 25V	C2156	403 164 0204	CERAMIC 0.1U Z 25V
C1108	403 164 0204	CERAMIC 0.1U Z 25V	C2157	403 164 0204	CERAMIC 0.1U Z 25V
C1109	403 283 6309	CERAMIC 1U Z 10V	C2158	403 164 0204	CERAMIC 0.1U Z 25V
C1110	403 283 6309	CERAMIC 1U Z 10V	C2159	403 164 0204	CERAMIC 0.1U Z 25V
C1112	403 283 6309	CERAMIC 1U Z 10V	C2160	403 164 0204	CERAMIC 0.1U Z 25V
C1113	403 164 0204	CERAMIC 0.1U Z 25V	C2167	403 283 6309	CERAMIC 1U Z 10V
C1114	403 164 0204	CERAMIC 0.1U Z 25V	C2168	403 164 0204	CERAMIC 0.1U Z 25V
C1115	403 164 0204	CERAMIC 0.1U Z 25V	C2170	403 164 0204	CERAMIC 0.1U Z 25V
C1116	403 164 0204	CERAMIC 0.1U Z 25V	C2171	403 164 0204	CERAMIC 0.1U Z 25V
C1117	403 266 8108	NP-ELECT 1U M 50V	C2172	403 164 0204	CERAMIC 0.1U Z 25V
C1119	403 162 4709	ELECT 10U M 16V	C2173	403 164 0204	CERAMIC 0.1U Z 25V
C1121	403 164 0204	CERAMIC 0.1U Z 25V	C2174	403 164 0204	CERAMIC 0.1U Z 25V
C1122	403 164 0204	CERAMIC 0.1U Z 25V	C2182	403 175 4109	ELECT 22U M 16V
C1123	403 164 0204	CERAMIC 0.1U Z 25V	C2184	403 175 4109	ELECT 22U M 16V
C1124	403 164 0204	CERAMIC 0.1U Z 25V	C2186	403 164 0204	CERAMIC 0.1U Z 25V
C1125	403 164 0204	CERAMIC 0.1U Z 25V	C2188	403 164 0204	CERAMIC 0.1U Z 25V
C1126	403 164 0204	CERAMIC 0.1U Z 25V	C2191	401 105 0603	MT-GLAZE 10K JA 1/16W
C1127	403 175 4505	ELECT 47U M 6.3V	C2192	403 145 9905	CERAMIC 22P J 50V
C1128	403 164 0204	CERAMIC 0.1U Z 25V	C2193	403 145 9905	CERAMIC 22P J 50V
C1129	403 175 4505	ELECT 47U M 6.3V	C3016	403 280 1604	ELECT 220U M 16V
C1132	403 280 0805	ELECT 330U M 6.3V	C3018	403 164 0204	CERAMIC 0.1U Z 25V
C1133	403 164 0204	CERAMIC 0.1U Z 25V	C3105	403 164 0204	CERAMIC 0.1U Z 25V
C1134	403 283 6309	CERAMIC 1U Z 10V	C3106	403 215 2201	CERAMIC 0.01U K 50V
C1135	403 280 0805	ELECT 330U M 6.3V	C3121	403 162 4709	ELECT 10U M 16V
C1136	403 283 6309	CERAMIC 1U Z 10V	C3122	403 164 0204	CERAMIC 0.1U Z 25V
C1137	403 283 6309	CERAMIC 1U Z 10V	C3123	403 298 9609	CERAMIC 0.1U K 16V
C1141	403 175 4505	ELECT 47U M 6.3V	C3124	403 298 9609	CERAMIC 0.1U K 16V
C1146	403 164 0204	CERAMIC 0.1U Z 25V	C3125	403 298 9609	CERAMIC 0.1U K 16V
C1147	403 283 6309	CERAMIC 1U Z 10V	C3131	403 215 2201	CERAMIC 0.01U K 50V
C1148	403 164 0204	CERAMIC 0.1U Z 25V	C3132	403 283 6309	CERAMIC 1U Z 10V
C1151	403 283 6309	CERAMIC 1U Z 10V	C3134	403 175 4109	ELECT 22U M 16V
C1152	403 283 6309	CERAMIC 1U Z 10V	C3135	403 164 0204	CERAMIC 0.1U Z 25V
C1161	403 283 6309	CERAMIC 1U Z 10V	C3136	403 164 0204	CERAMIC 0.1U Z 25V
C1162	403 145 9905	CERAMIC 22P J 50V	C3137	403 164 0204	CERAMIC 0.1U Z 25V
C1187	403 283 6309	CERAMIC 1U Z 10V	C3140	403 283 6309	CERAMIC 1U Z 10V
C1188	403 164 0204	CERAMIC 0.1U Z 25V	C3141	403 215 2201	CERAMIC 0.01U K 50V
C123	403 164 0204	CERAMIC 0.1U Z 25V	C3142	403 283 6309	CERAMIC 1U Z 10V
C146	403 283 6309	CERAMIC 1U Z 10V	C3143	403 164 0204	CERAMIC 0.1U Z 25V
C147	403 164 0204	CERAMIC 0.1U Z 25V	C3144	403 162 6604	ELECT 2.2U M 50V
C161	403 266 8108	NP-ELECT 1U M 50V	C3146	403 164 0204	CERAMIC 0.1U Z 25V
C162	403 323 8805	CERAMIC 2.2U Z 16V	C3147	403 266 8108	NP-ELECT 1U M 50V
	403 255 7907	CERAMIC 2.2U Z 16V	C3148	403 266 8108	NP-ELECT 1U M 50V
C163	403 164 0204	CERAMIC 0.1U Z 25V	C3149	403 266 8108	NP-ELECT 1U M 50V
C164	403 283 6309	CERAMIC 1U Z 10V	C3150	403 286 8508	ELECT 330U M 16V
C165	403 113 3805	CERAMIC 1000P K 50V	C3151	403 348 5803	CERAMIC 0.47U K 10V
C166	403 162 6208	ELECT 1U M 50V	C3152	403 348 5803	CERAMIC 0.47U K 10V
C167	403 164 0204	CERAMIC 0.1U Z 25V	C3153	403 139 7108	CERAMIC 12P J 50V
C168	403 283 6309	CERAMIC 1U Z 10V	C3154	403 139 7108	CERAMIC 12P J 50V
C2101	403 175 4802	NP-ELECT 10U M 10V	C3155	403 139 7108	CERAMIC 12P J 50V
C2102	403 164 0204	CERAMIC 0.1U Z 25V	C3157	403 157 2109	CERAMIC 13P J 50V
C2103	403 283 6309	CERAMIC 1U Z 10V	C3159	403 155 1500	CERAMIC 180P J 50V
C2104	403 164 0204	CERAMIC 0.1U Z 25V	C3160	403 215 2201	CERAMIC 0.01U K 50V
C2105	403 164 0204	CERAMIC 0.1U Z 25V	C3163	403 162 5300	ELECT 4.7U M 25V
C2106	403 164 0204	CERAMIC 0.1U Z 25V	C3164	403 343 8809	CERAMIC 0.47U Z 16V
C2107	403 283 6309	CERAMIC 1U Z 10V	C3165	403 153 9102	CERAMIC 5P C 50V
C2108	403 164 0204	CERAMIC 0.1U Z 25V	C3166	403 266 8108	NP-ELECT 1U M 50V
C2109	403 164 0204	CERAMIC 0.1U Z 25V	C3167	403 215 2102	CERAMIC 8200P K 50V
C2111	403 164 0204	CERAMIC 0.1U Z 25V	C3168	403 162 6000	ELECT 0.47U M 50V
C2112	403 164 0204	CERAMIC 0.1U Z 25V	C3169	403 153 9102	CERAMIC 5P C 50V
C2113	403 215 2201	CERAMIC 0.01U K 50V	C3172	403 157 3601	CERAMIC 100P J 50V
C2114	403 283 6309	CERAMIC 1U Z 10V	C3175	403 164 0204	CERAMIC 0.1U Z 25V
C2116	403 283 6309	CERAMIC 1U Z 10V	C3176	403 175 4109	ELECT 22U M 16V
C2117	403 164 0204	CERAMIC 0.1U Z 25V	C3177	403 162 6000	ELECT 0.47U M 50V
C2118	401 105 0405	MT-GLAZE 100 JA 1/16W	C4119	403 164 0204	CERAMIC 0.1U Z 25V
C2119	403 215 2201	CERAMIC 0.01U K 50V	C4126	403 215 2201	CERAMIC 0.01U K 50V
C2121	403 283 6309	CERAMIC 1U Z 10V	C4129	403 164 0204	CERAMIC 0.1U Z 25V
C2122	403 164 0204	CERAMIC 0.1U Z 25V	C4132	403 164 0204	CERAMIC 0.1U Z 25V
C2123	403 280 0805	ELECT 330U M 6.3V	C4133	403 164 0204	CERAMIC 0.1U Z 25V
C2124	403 215 2201	CERAMIC 0.01U K 50V	C4134	403 164 0204	CERAMIC 0.1U Z 25V
C2125	403 215 2201	CERAMIC 0.01U K 50V	C4135	403 162 4709	ELECT 10U M 16V
C2126	403 215 2904	CERAMIC 0.022U K 25V	C4137	403 348 5803	CERAMIC 0.47U K 10V
C2127	403 164 0204	CERAMIC 0.1U Z 25V	C4138	403 162 4709	ELECT 10U M 16V
C2128	403 283 6309	CERAMIC 1U Z 10V	C4139	403 298 9609	CERAMIC 0.1U K 16V
C2129	403 283 6309	CERAMIC 1U Z 10V	C4140	403 215 2201	CERAMIC 0.01U K 50V
C2131	403 215 2201	CERAMIC 0.01U K 50V	C4141	403 215 2201	CERAMIC 0.01U K 50V
C2133	401 219 1107	MT-GLAZE 1.8K FA 1/16W	C4142	403 215 2201	CERAMIC 0.01U K 50V
C2134	403 215 2201	CERAMIC 0.01U K 50V	C4143	403 215 2201	CERAMIC 0.01U K 50V
C2135	403 215 2201	CERAMIC 0.01U K 50V	C4144	403 215 2201	CERAMIC 0.01U K 50V
C2136	403 215 2201	CERAMIC 0.01U K 50V	C4145	403 215 2201	CERAMIC 0.01U K 50V
C2137	403 280 0805	ELECT 330U M 6.3V	C4146	403 215 2201	CERAMIC 0.01U K 50V
C2138	403 280 0805	ELECT 330U M 6.3V	C4147	403 215 2201	CERAMIC 0.01U K 50V
C2141	403 164 0204	CERAMIC 0.1U Z 25V	C4148	403 215 2201	CERAMIC 0.01U K 50V
C2143	403 283 6309	CERAMIC 1U Z 10V	C4157	403 162 4709	ELECT 10U M 16V
C2144	403 175 4505	ELECT 47U M 6.3V	C4158	403 348 5803	CERAMIC 0.47U K 10V
C2145	403 164 0204	CERAMIC 0.1U Z 25V	C4160	403 343 8809	CERAMIC 0.47U Z 16V
C2146	403 164 0204	CERAMIC 0.1U Z 25V	C4164	403 164 0204	CERAMIC 0.1U Z 25V
C2147	403 164 0204	CERAMIC 0.1U Z 25V	C4165	403 164 0204	CERAMIC 0.1U Z 25V
C2148	403 164 0204	CERAMIC 0.1U Z 25V	C4166	403 164 0204	CERAMIC 0.1U Z 25V
C2149	403 164 0204	CERAMIC 0.1U Z 25V	C4169	403 215 2201	CERAMIC 0.01U K 50V
C2150	403 164 0204	CERAMIC 0.1U Z 25V	C4171	403 215 2201	CERAMIC 0.01U K 50V
C2151	403 164 0204	CERAMIC 0.1U Z 25V	C4172	403 215 2201	CERAMIC 0.01U K 50V
C2152	403 164 0204	CERAMIC 0.1U Z 25V	C4181	403 164 0204	CERAMIC 0.1U Z 25V
C2153	403 164 0204	CERAMIC 0.1U Z 25V	C4182	403 283 6309	CERAMIC 1U Z 10V

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C4183	403 283 6309	CERAMIC 1U Z 10V	R1155	401 105 7503	MT-GLAZE 82K JA 1/16W
C4184	403 283 6309	CERAMIC 1U Z 10V	R1156	401 105 2102	MT-GLAZE 18K JA 1/16W
C4185	403 224 7006	CERAMIC 0.047U Z 50V	R1157	401 105 0504	MT-GLAZE 1K JA 1/16W
C4186	403 224 7006	CERAMIC 0.047U Z 50V	R1158	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C4187	403 283 6309	CERAMIC 1U Z 10V	R1159	401 105 5905	MT-GLAZE 560 JA 1/16W
C4188	403 164 0204	CERAMIC 0.1U Z 25V	R1161	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C5100	403 164 0204	CERAMIC 0.1U Z 25V	R1162	401 105 0504	MT-GLAZE 1K JA 1/16W
C5101	403 164 0204	CERAMIC 0.1U Z 25V	R1163	401 105 2706	MT-GLAZE 220 JA 1/16W
C5102	403 164 0204	CERAMIC 0.1U Z 25V	R1165	401 105 4502	MT-GLAZE 390 JA 1/16W
C5103	403 215 1006	CERAMIC 470P J 50V	R1166	401 105 5103	MT-GLAZE 47 JA 1/16W
C5104	403 298 9609	CERAMIC 0.1U K 16V	R1167	401 105 0504	MT-GLAZE 1K JA 1/16W
C5105	403 155 1302	CERAMIC 150P J 50V	R1168	401 105 0504	MT-GLAZE 1K JA 1/16W
C5106	403 139 7108	CERAMIC 12P J 50V	R1169	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C5107	403 164 0204	CERAMIC 0.1U Z 25V	R1171	401 105 5905	MT-GLAZE 560 JA 1/16W
C5108	403 164 0204	CERAMIC 0.1U Z 25V	R1172	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C5109	403 164 0204	CERAMIC 0.1U Z 25V	R1173	401 105 0504	MT-GLAZE 1K JA 1/16W
C5110	403 162 4709	ELECT 10U M 16V	R1174	401 105 2706	MT-GLAZE 220 JA 1/16W
C5111	403 280 0805	ELECT 330U M 6.3V	R1175	401 105 2706	MT-GLAZE 220 JA 1/16W
C5112	403 164 0204	CERAMIC 0.1U Z 25V	R1176	401 105 5905	MT-GLAZE 560 JA 1/16W
C5113	403 215 2201	CERAMIC 0.01U K 50V	R1177	401 105 5103	MT-GLAZE 47 JA 1/16W
C5114	403 155 1500	CERAMIC 180P J 50V	R1178	401 105 0504	MT-GLAZE 1K JA 1/16W
C5115	403 215 2201	CERAMIC 0.01U K 50V	R1183	401 105 2706	MT-GLAZE 220 JA 1/16W
C5116	403 164 0204	CERAMIC 0.1U Z 25V	R1184	401 105 4106	MT-GLAZE 3.3K JA 1/16W
C5117	403 164 0204	CERAMIC 0.1U Z 25V	R1187	401 105 0405	MT-GLAZE 100 JA 1/16W
C5118	403 164 0204	CERAMIC 0.1U Z 25V	R1188	401 105 0405	MT-GLAZE 100 JA 1/16W
C5119	403 164 0204	CERAMIC 0.1U Z 25V	R1189	401 105 0405	MT-GLAZE 100 JA 1/16W
C5120	403 153 9102	CERAMIC 5P C 50V	R121	401 226 1206	MT-GLAZE 150 FA 1/16W
C5121	403 164 0204	CERAMIC 0.1U Z 25V	R122	401 226 1206	MT-GLAZE 150 FA 1/16W
C5122	403 164 0204	CERAMIC 0.1U Z 25V	R123	401 226 1206	MT-GLAZE 150 FA 1/16W
C5123	403 164 0204	CERAMIC 0.1U Z 25V	R124	401 226 1206	MT-GLAZE 150 FA 1/16W
C5124	403 164 0204	CERAMIC 0.1U Z 25V	R125	401 105 0405	MT-GLAZE 100 JA 1/16W
C5125	403 164 0204	CERAMIC 0.1U Z 25V	R126	401 105 4106	MT-GLAZE 3.3K JA 1/16W
C5126	403 164 0204	CERAMIC 0.1U Z 25V	R131	401 226 1206	MT-GLAZE 150 FA 1/16W
C5128	403 155 4204	CERAMIC 15P J 50V	R132	401 226 1206	MT-GLAZE 150 FA 1/16W
C5129	403 155 1609	CERAMIC 33P J 50V	R133	401 226 1206	MT-GLAZE 150 FA 1/16W
C5130	403 157 1706	CERAMIC 8P D 50V	R134	401 226 1206	MT-GLAZE 150 FA 1/16W
C5132	403 162 6208	ELECT 1U M 50V	R147	401 105 0405	MT-GLAZE 100 JA 1/16W
C5133	403 139 7306	CERAMIC 18P J 50V	R148	401 105 0405	MT-GLAZE 100 JA 1/16W
C5134	403 215 2201	CERAMIC 0.01U K 50V	R149	401 105 0405	MT-GLAZE 100 JA 1/16W
C5135	403 139 7306	CERAMIC 18P J 50V	R161	401 105 4809	MT-GLAZE 390K JA 1/16W
C5136	403 157 1508	CERAMIC 3P C 50V	R162	401 105 4106	MT-GLAZE 3.3K JA 1/16W
C5137	403 157 1706	CERAMIC 8P D 50V	R163	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C5138	403 164 0204	CERAMIC 0.1U Z 25V	R164	401 105 0405	MT-GLAZE 100 JA 1/16W
C5139	403 153 9102	CERAMIC 5P C 50V	R165	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C5141	403 145 9905	CERAMIC 22P J 50V	R166	401 105 0405	MT-GLAZE 100 JA 1/16W
C5142	403 157 1706	CERAMIC 8P D 50V	R167	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C5143	403 164 0204	CERAMIC 0.1U Z 25V	R168	401 105 7305	MT-GLAZE 820 JA 1/16W
C5144	403 283 6309	CERAMIC 1U Z 10V	R169	401 105 4106	MT-GLAZE 3.3K JA 1/16W
C5145	403 164 0204	CERAMIC 0.1U Z 25V	R171	401 105 1501	MT-GLAZE 1.5K JA 1/16W
C5146	403 164 0204	CERAMIC 0.1U Z 25V	R172	401 105 2706	MT-GLAZE 220 JA 1/16W
C5147	403 164 0204	CERAMIC 0.1U Z 25V	R173	401 105 3000	MT-GLAZE 220K JA 1/16W
C5148	403 164 0204	CERAMIC 0.1U Z 25V	R174	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C5149	403 280 0805	ELECT 330U M 6.3V	R175	401 105 5202	MT-GLAZE 470 JA 1/16W
C5151	403 283 6309	CERAMIC 1U Z 10V	R176	401 105 5400	MT-GLAZE 47K JA 1/16W
C5152	403 164 0204	CERAMIC 0.1U Z 25V	R177	401 105 0504	MT-GLAZE 1K JA 1/16W
C5181	403 280 1604	ELECT 220U M 16V	R178	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C5182	403 164 0204	CERAMIC 0.1U Z 25V	R179	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C5183	403 153 9102	CERAMIC 5P C 50V	R180	401 218 4505	MT-GLAZE 2.2K FA 1/16W
C5184	403 153 9102	CERAMIC 5P C 50V	R182	401 219 1107	MT-GLAZE 1.8K FA 1/16W
C5185	403 153 9102	CERAMIC 5P C 50V	R183	401 105 2904	MT-GLAZE 22K JA 1/16W
RESISTOR			R184	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R100	401 105 3000	MT-GLAZE 220K JA 1/16W	R185	401 218 4505	MT-GLAZE 2.2K FA 1/16W
R101	401 105 5509	MT-GLAZE 470K JA 1/16W	R187	401 219 1107	MT-GLAZE 1.8K FA 1/16W
R102	401 105 5509	MT-GLAZE 470K JA 1/16W	R188	401 105 2904	MT-GLAZE 22K JA 1/16W
R103	401 105 0405	MT-GLAZE 100 JA 1/16W	R189	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R104	401 105 3000	MT-GLAZE 220K JA 1/16W	R190	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R105	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R192	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R106	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R193	401 105 4700	MT-GLAZE 39K JA 1/16W
R107	401 105 0405	MT-GLAZE 100 JA 1/16W	R194	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R108	401 105 3000	MT-GLAZE 220K JA 1/16W	R195	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R109	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R197	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R110	401 105 3000	MT-GLAZE 220K JA 1/16W	R198	401 105 4700	MT-GLAZE 39K JA 1/16W
R1101	401 105 5202	MT-GLAZE 470 JA 1/16W	R199	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R1102	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2101	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1103	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2102	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1104	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2103	401 105 1402	MT-GLAZE 150 JA 1/16W
R1105	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2104	401 235 4106	MT-GLAZE 120 FA 1/16W
R1106	401 105 5202	MT-GLAZE 470 JA 1/16W	R2105	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R1107	401 105 5202	MT-GLAZE 470 JA 1/16W	R2106	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R1108	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2107	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R1109	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R2108	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R111	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R2109	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1111	401 105 0405	MT-GLAZE 100 JA 1/16W	R2110	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1112	401 105 0405	MT-GLAZE 100 JA 1/16W	R2111	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1113	401 105 0405	MT-GLAZE 100 JA 1/16W	R2112	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1118	401 105 0405	MT-GLAZE 100 JA 1/16W	R2113	401 105 0405	MT-GLAZE 100 JA 1/16W
R1119	401 105 0405	MT-GLAZE 100 JA 1/16W	R2114	401 105 0405	MT-GLAZE 100 JA 1/16W
R1131	401 105 0405	MT-GLAZE 100 JA 1/16W	R2116	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1132	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2117	401 105 8104	MT-GLAZE 56K JA 1/16W
R1133	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2118	401 105 5905	MT-GLAZE 560 JA 1/16W
R1141	401 105 1105	MT-GLAZE 12K JA 1/16W	R2119	401 105 0504	MT-GLAZE 1K JA 1/16W
R1142	401 105 8104	MT-GLAZE 56K JA 1/16W	R2120	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R1149	401 105 0405	MT-GLAZE 100 JA 1/16W	R2121	401 105 0603	MT-GLAZE 10K JA 1/16W
R1151	401 105 0405	MT-GLAZE 100 JA 1/16W	R2122	401 105 0900	MT-GLAZE 120 JA 1/16W
R1152	401 105 0405	MT-GLAZE 100 JA 1/16W	R2123	401 226 1206	MT-GLAZE 150 FA 1/16W

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R2124	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R3193	401 105 0702	MT-GLAZE 100K JA 1/16W
R2125	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4101	401 217 5404	MT-GLAZE 47K FA 1/16W
R2126	401 105 0405	MT-GLAZE 100 JA 1/16W	R4102	401 105 0504	MT-GLAZE 1K JA 1/16W
R2127	401 105 0405	MT-GLAZE 100 JA 1/16W	R4103	401 105 0504	MT-GLAZE 1K JA 1/16W
R2128	401 105 0405	MT-GLAZE 100 JA 1/16W	R4104	401 105 0405	MT-GLAZE 100 JA 1/16W
R2129	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4105	401 105 0405	MT-GLAZE 100 JA 1/16W
R2130	401 105 4601	MT-GLAZE 3.9K JA 1/16W	R4106	401 105 0405	MT-GLAZE 100 JA 1/16W
R2131	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4108	401 105 0603	MT-GLAZE 10K JA 1/16W
R2132	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4109	401 105 0603	MT-GLAZE 10K JA 1/16W
R2140	401 038 2002	MT-GLAZE 270 JA 1/10W	R4110	401 105 0603	MT-GLAZE 10K JA 1/16W
R2141	401 105 0405	MT-GLAZE 100 JA 1/16W	R4111	401 105 0603	MT-GLAZE 10K JA 1/16W
R2142	401 105 0405	MT-GLAZE 100 JA 1/16W	R4112	401 114 0502	MT-GLAZE 2.2M JA 1/16W
R2144	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4113	401 105 0603	MT-GLAZE 10K JA 1/16W
R2145	401 105 0405	MT-GLAZE 100 JA 1/16W	R4116	401 105 0405	MT-GLAZE 100 JA 1/16W
R2146	401 105 0405	MT-GLAZE 100 JA 1/16W	R4117	401 105 0405	MT-GLAZE 100 JA 1/16W
R2147	401 105 0405	MT-GLAZE 100 JA 1/16W	R4118	401 105 0405	MT-GLAZE 100 JA 1/16W
R2148	401 105 0405	MT-GLAZE 100 JA 1/16W	R4119	401 105 0900	MT-GLAZE 120 JA 1/16W
R2149	401 105 0603	MT-GLAZE 10K JA 1/16W	R4122	401 105 0405	MT-GLAZE 100 JA 1/16W
R2150	401 038 2002	MT-GLAZE 270 JA 1/10W	R4124	401 105 0405	MT-GLAZE 100 JA 1/16W
R2151	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	R4125	401 105 0405	MT-GLAZE 100 JA 1/16W
R2153	401 105 0603	MT-GLAZE 10K JA 1/16W	R4126	401 217 4100	MT-GLAZE 22K FA 1/16W
R2155	401 105 0405	MT-GLAZE 100 JA 1/16W	R4127	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R2156	401 105 0405	MT-GLAZE 100 JA 1/16W	R4128	401 105 6001	MT-GLAZE 5.6K JA 1/16W
R2157	401 105 0504	MT-GLAZE 1K JA 1/16W	R4181	401 105 6605	MT-GLAZE 6.8K JA 1/16W
R2160	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R4182	401 105 7305	MT-GLAZE 820 JA 1/16W
R2161	401 105 7404	MT-GLAZE 8.2K JA 1/16W	R4183	401 105 0504	MT-GLAZE 1K JA 1/16W
R2162	401 105 0603	MT-GLAZE 10K JA 1/16W	R4184	401 105 6001	MT-GLAZE 5.6K JA 1/16W
R2163	401 105 2706	MT-GLAZE 220 JA 1/16W	R4186	401 158 4108	MT-GLAZE 4.7 JA 1/16W
R2164	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R4187	401 105 1907	MT-GLAZE 180 JA 1/16W
R2165	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4188	401 112 8005	MT-GLAZE 5.6 JA 1/16W
R2167	401 105 0405	MT-GLAZE 100 JA 1/16W	R4189	401 105 6605	MT-GLAZE 6.8K JA 1/16W
R2168	401 105 0405	MT-GLAZE 100 JA 1/16W	R4190	401 105 2904	MT-GLAZE 22K JA 1/16W
R2169	401 105 0405	MT-GLAZE 100 JA 1/16W	R4191	401 105 7305	MT-GLAZE 820 JA 1/16W
R2170	401 105 4007	MT-GLAZE 330 JA 1/16W	R5100	401 105 2904	MT-GLAZE 22K JA 1/16W
R2191	401 105 0504	MT-GLAZE 1K JA 1/16W	R5101	401 105 1709	MT-GLAZE 150K JA 1/16W
R2192	401 105 0504	MT-GLAZE 1K JA 1/16W	R5102	401 105 0504	MT-GLAZE 1K JA 1/16W
R2193	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R5103	401 105 0702	MT-GLAZE 100K JA 1/16W
R3105	401 105 0504	MT-GLAZE 1K JA 1/16W	R5104	401 105 4205	MT-GLAZE 33K JA 1/16W
R3106	401 105 1006	MT-GLAZE 1.2K JA 1/16W	R5105	401 105 0702	MT-GLAZE 100K JA 1/16W
R3107	401 105 5202	MT-GLAZE 470 JA 1/16W	R5106	401 105 8005	MT-GLAZE 1M JA 1/16W
R3108	401 105 2904	MT-GLAZE 22K JA 1/16W	R5107	401 105 5905	MT-GLAZE 560 JA 1/16W
R3109	401 105 7404	MT-GLAZE 8.2K JA 1/16W	R5108	401 105 7305	MT-GLAZE 820 JA 1/16W
R3110	401 105 0405	MT-GLAZE 100 JA 1/16W	R5109	401 217 3905	MT-GLAZE 3.3K FA 1/16W
R3120	401 105 0504	MT-GLAZE 1K JA 1/16W	R5110	401 105 8203	MT-GLAZE 68K JA 1/16W
R3121	401 037 9101	MT-GLAZE 180 JA 1/10W	R5111	401 217 3905	MT-GLAZE 3.3K FA 1/16W
R3122	401 037 9101	MT-GLAZE 180 JA 1/10W	R5113	401 105 1006	MT-GLAZE 1.2K JA 1/16W
R3130	401 105 6506	MT-GLAZE 680 JA 1/16W	R5116	401 105 7305	MT-GLAZE 820 JA 1/16W
R3131	401 105 0504	MT-GLAZE 1K JA 1/16W	R5117	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R3132	401 105 0306	MT-GLAZE 10 JA 1/16W	R5118	401 105 0504	MT-GLAZE 1K JA 1/16W
R3140	401 105 0504	MT-GLAZE 1K JA 1/16W	R5119	401 105 0603	MT-GLAZE 10K JA 1/16W
R3142	401 105 4007	MT-GLAZE 330 JA 1/16W	R5120	401 105 4700	MT-GLAZE 39K JA 1/16W
R3143	401 105 0603	MT-GLAZE 10K JA 1/16W	R5121	401 105 0603	MT-GLAZE 10K JA 1/16W
R3144	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R5122	401 105 7404	MT-GLAZE 8.2K JA 1/16W
R3145	401 105 0504	MT-GLAZE 1K JA 1/16W	R5123	401 105 0504	MT-GLAZE 1K JA 1/16W
R3147	401 105 0504	MT-GLAZE 1K JA 1/16W	R5124	401 105 0405	MT-GLAZE 100 JA 1/16W
R3148	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R5125	401 105 0504	MT-GLAZE 1K JA 1/16W
R3151	401 105 1501	MT-GLAZE 1.5K JA 1/16W	R5126	401 105 0603	MT-GLAZE 10K JA 1/16W
R3152	401 105 6506	MT-GLAZE 680 JA 1/16W	R5127	401 105 6506	MT-GLAZE 680 JA 1/16W
R3153	401 105 5202	MT-GLAZE 470 JA 1/16W	R5128	401 105 0504	MT-GLAZE 1K JA 1/16W
R3154	401 105 8104	MT-GLAZE 56K JA 1/16W	R5129	401 105 0603	MT-GLAZE 10K JA 1/16W
R3155	401 105 8104	MT-GLAZE 56K JA 1/16W	R5130	401 105 2904	MT-GLAZE 22K JA 1/16W
R3156	401 105 8104	MT-GLAZE 56K JA 1/16W	R5131	401 105 0504	MT-GLAZE 1K JA 1/16W
R3157	401 105 8104	MT-GLAZE 56K JA 1/16W	R5132	401 105 0603	MT-GLAZE 10K JA 1/16W
R3158	401 105 8104	MT-GLAZE 56K JA 1/16W	R5133	401 105 0405	MT-GLAZE 100 JA 1/16W
R3159	401 105 0504	MT-GLAZE 1K JA 1/16W	R5134	401 105 0405	MT-GLAZE 100 JA 1/16W
R3160	401 105 1204	MT-GLAZE 120K JA 1/16W	R5135	401 105 0405	MT-GLAZE 100 JA 1/16W
R3162	401 105 2706	MT-GLAZE 220 JA 1/16W	R5136	401 105 0405	MT-GLAZE 100 JA 1/16W
R3163	401 105 2706	MT-GLAZE 220 JA 1/16W	R5137	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3165	401 105 0405	MT-GLAZE 100 JA 1/16W	R5138	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3166	401 105 0405	MT-GLAZE 100 JA 1/16W	R5139	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3167	401 105 3307	MT-GLAZE 2.7K JA 1/16W	R5140	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3168	401 105 4304	MT-GLAZE 330K JA 1/16W	R5141	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3169	401 105 0504	MT-GLAZE 1K JA 1/16W	R5142	401 105 0504	MT-GLAZE 1K JA 1/16W
R3170	401 105 3000	MT-GLAZE 220K JA 1/16W	R5143	401 105 5202	MT-GLAZE 470 JA 1/16W
R3171	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R5150	401 105 4700	MT-GLAZE 39K JA 1/16W
R3173	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R5160	401 105 0504	MT-GLAZE 1K JA 1/16W
R3174	401 113 9506	MT-GLAZE 620K JA 1/16W	R5170	401 105 0504	MT-GLAZE 1K JA 1/16W
R3175	401 218 4505	MT-GLAZE 2.2K FA 1/16W	R5180	401 203 9904	MT-GLAZE 4.7K FA 1/16W
R3176	401 219 1602	MT-GLAZE 100K FA 1/16W	R5181	401 105 0405	MT-GLAZE 100 JA 1/16W
R3177	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R5182	401 105 0405	MT-GLAZE 100 JA 1/16W
R3178	401 105 6001	MT-GLAZE 5.6K JA 1/16W	R5183	401 105 0405	MT-GLAZE 100 JA 1/16W
R3179	401 286 3400	MT-GLAZE 10 FA 1/16W	R5184	401 113 4402	MT-GLAZE 75 JA 1/16W
R3180	401 105 0603	MT-GLAZE 10K JA 1/16W	R5185	401 105 0504	MT-GLAZE 1K JA 1/16W
R3181	401 105 0504	MT-GLAZE 1K JA 1/16W	R5187	401 113 4402	MT-GLAZE 75 JA 1/16W
R3182	401 105 0504	MT-GLAZE 1K JA 1/16W	R5188	401 105 0504	MT-GLAZE 1K JA 1/16W
R3183	401 105 5202	MT-GLAZE 470 JA 1/16W	R5191	401 113 4402	MT-GLAZE 75 JA 1/16W
R3184	401 105 0504	MT-GLAZE 1K JA 1/16W	R5192	401 105 0504	MT-GLAZE 1K JA 1/16W
R3185	401 105 0504	MT-GLAZE 1K JA 1/16W	COIL		
R3186	401 105 5202	MT-GLAZE 470 JA 1/16W	L101	645 014 2659	FILTER, EMI 10MHZ
R3187	401 105 0504	MT-GLAZE 1K JA 1/16W	L102	645 014 2659	FILTER, EMI 10MHZ
R3188	401 105 0504	MT-GLAZE 1K JA 1/16W	L1101	645 004 1587	INDUCTOR, 4.7U J
R3189	401 105 4007	MT-GLAZE 330 JA 1/16W	L1104	645 026 1008	INDUCTOR, 3.3U M
R3190	401 105 4007	MT-GLAZE 330 JA 1/16W	L1131	645 026 1008	INDUCTOR, 3.3U M
R3191	401 105 0405	MT-GLAZE 100 JA 1/16W	L1151	645 044 3626	FILTER, LP 7MHZ
R3192	401 105 8104	MT-GLAZE 56K JA 1/16W	L1161	645 044 3626	FILTER, LP 7MHZ

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
L1162	645 021 1607	INDUCTOR, 10U J	C622	403 156 8805	ELECT 1U M 50V
L121	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	C623	403 157 6800	CERAMIC 680P K 50V
L122	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	C625	403 147 9606	ELECT 1000U M 10V
L123	645 002 3910	FILTER, EMI 100MHZ		403 301 2306	ELECT 1000U M 10V
L124	645 002 3910	FILTER, EMI 100MHZ	C626	403 147 9606	ELECT 1000U M 10V
L125	645 014 2659	FILTER, EMI 10MHZ		403 301 2306	ELECT 1000U M 10V
L131	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	C650	403 134 6403	ELECT 2200U M 16V
L132	645 002 3910	FILTER, EMI 100MHZ	C651	403 134 6403	ELECT 2200U M 16V
L133	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	C652	403 164 0204	CERAMIC 0.1U Z 25V
L134	645 002 3910	FILTER, EMI 100MHZ	C653	403 155 1203	ELECT 3300U M 25V
L161	645 044 3626	FILTER, LP 7MHZ	C654	403 155 1203	ELECT 3300U M 25V
L2101	645 026 1008	INDUCTOR, 3.3U M	C655	403 164 0204	CERAMIC 0.1U Z 25V
L2102	645 026 1008	INDUCTOR, 3.3U M	C656	403 164 0204	CERAMIC 0.1U Z 25V
L2191	645 021 1614	INDUCTOR, 12U J	C657	403 126 4806	ELECT 3300U M 10V
L5101	645 026 1008	INDUCTOR, 3.3U M		403 313 6408	ELECT 3300U M 10V
L5102	645 021 1713	INDUCTOR, 39U J	C658	403 155 5607	ELECT 220U M 10V
L5103	645 021 1706	INDUCTOR, 33U J	C659	403 126 4806	ELECT 3300U M 10V
L5104	645 021 1737	INDUCTOR, 47U J		403 313 6408	ELECT 3300U M 10V
L5121	645 021 1713	INDUCTOR, 39U J	C661	403 126 4806	ELECT 3300U M 10V
DIODE				403 313 6408	ELECT 3300U M 10V
D101	407 187 8209	ZENER DIODE UDZ12B-TE-17		403 156 9208	ELECT 4.7U M 50V
D102	407 187 8209	ZENER DIODE UDZ12B-TE-17	C662		RESISTOR
D103	407 187 8209	ZENER DIODE UDZ12B-TE-17	R600	401 008 8607	CARBON 220K JA 1/2W
D104	407 187 8209	ZENER DIODE UDZ12B-TE-17	R601	402 078 5701	WIRE WOUND 3.9 JA 7W
D1101	407 149 0807	DIODE 1SS355-TE-17	R605	401 068 1501	OXIDE-MT 4.7 JA 2W
D1121	407 149 0807	DIODE 1SS355-TE-17	R606	401 263 0101	MT-GLAZE 100K JA 1W
D121	407 209 1201	ZD UDZS-TE-176.2B	R607	401 263 0101	MT-GLAZE 100K JA 1W
D122	407 209 1201	ZD UDZS-TE-176.2B	R608	401 263 0101	MT-GLAZE 100K JA 1W
D123	407 209 1201	ZD UDZS-TE-176.2B	R609	401 263 0101	MT-GLAZE 100K JA 1W
D124	407 209 1201	ZD UDZS-TE-176.2B	R611	401 069 4402	OXIDE-MT 68K JA 2W
D125	407 187 8209	ZENER DIODE UDZ12B-TE-17	R612	401 069 4402	OXIDE-MT 68K JA 2W
D131	407 209 1201	ZD UDZS-TE-176.2B	R614	401 240 7208	MT-GLAZE 33 JA 1/3W
D132	407 209 1201	ZD UDZS-TE-176.2B	R615	401 105 5905	MT-GLAZE 560 JA 1/16W
D133	407 209 1201	ZD UDZS-TE-176.2B	R616	401 258 8303	MT-GLAZE 150 JA 1/3W
D134	407 209 1201	ZD UDZS-TE-176.2B	R617	401 105 0504	MT-GLAZE 1K JA 1/16W
D2140	407 206 6308	ZD UDZS-TE-175.1B	R618	401 105 0603	MT-GLAZE 10K JA 1/16W
D3121	407 149 0807	DIODE 1SS355-TE-17	R619	402 079 7803	FUSIBLE RES 22 JH 1/4W
D3131	407 206 6308	ZD UDZS-TE-175.1B	R621	401 166 0802	MT-GLAZE 330 JA 1/2W
D4181	407 149 0807	DIODE 1SS355-TE-17	R622	402 080 7809	MT-GLAZE 150 KA 1W
D4182	407 149 0807	DIODE 1SS355-TE-17	R623	402 080 7908	MT-GLAZE 180 KA 1W
D5101	407 216 7609	VARACTOR DI HVU17	R653	401 105 5905	MT-GLAZE 560 JA 1/16W
MISCELLANEOUS			R654	401 105 0306	MT-GLAZE 10 JA 1/16W
TP141	645 036 5010	TERMINAL	R655	401 105 0504	MT-GLAZE 1K JA 1/16W
TP142	645 036 5010	TERMINAL	R656	402 079 7704	FUSIBLE RES 1.0 JH 1/4W
TP3141	645 036 5010	TERMINAL	R657	401 105 5103	MT-GLAZE 47 JA 1/16W
TP3142	645 036 5010	TERMINAL	VARIABLE RESISTOR		
TP5101	645 036 5010	TERMINAL	VA601	407 130 2902	VARISTOR ENC471D-14A
TP5102	645 036 5010	TERMINAL	VR652	645 002 3521	VR, SEMI, 470 S
TP5103	645 036 5010	TERMINAL	TRANSFORMER		
TP5181	645 036 5010	TERMINAL	▲ T621	645 043 3832	TRANS, POWER, PULSE
TP5182	645 036 5010	TERMINAL	COIL		
TP5183	645 036 5010	TERMINAL	▲ L611	645 047 0493	INDUCTOR, 4M
K101	645 040 9974	JACK, RCA-2	DIODE		
K121	645 040 9967	SOCKET, DIN 4P	▲ DB601	407 141 1000	DIODE RBV-408
K131	645 031 6067	SOCKET, BNC 2P	DB601A	610 292 3193	HEAT SINK-A MV6A
K3101	645 041 6071	SOCKET, I/O 176P	DB601B	411 047 0104	SCR PAN+SW+W 3X8
K3101A	610 289 9795	JOINT GUIDE BUSH ML6A	DS601	407 175 2400	THYRISTOR CR12AM-12
K3101B	610 289 9795	JOINT GUIDE BUSH ML6A	DS601B	411 047 0104	SCR PAN+SW+W 3X8
X1101	645 028 5622	OSC, CRYSTAL 20.000MHZ	DZ611	407 175 2806	ZD 02CZ12Y(TE85R)
	645 028 5646	OSC, CRYSTAL 20.000MHZ	DZ655	407 198 6607	ZD 02CZ6.8Z(TE85R)
X3141	610 012 0532	OSC, CERAMIC 500.0KHZ	D601	407 009 6901	DIODE RM11C
X3142	645 024 8788	OSC, CRYSTAL 3.579545MHZ	D602	407 009 6901	DIODE RM11C
	645 025 1108	OSC, CRYSTAL 3.579545MHZ	D603	407 009 6901	DIODE RM11C
X3143	645 024 8801	OSC, CRYSTAL 4.433619MHZ	D611	407 190 4106	DIODE SFPL-52V
	645 025 1122	OSC, CRYSTAL 4.433619MHZ	D612	407 124 6800	DIODE AG01A
X3145	645 028 1372	OSC, CRYSTAL 3.575611MHZ	D613	407 190 4106	DIODE SFPL-52V
X3146	645 028 1365	OSC, CRYSTAL 3.582056MHZ	D651	407 202 9808	DIODE FMB-26L
X5101	645 040 7819	OSC, CRYSTAL 17.734475MHZ	D651A	610 292 3223	HEAT SINK-D MV6A
			D651B	411 047 0104	SCR PAN+SW+W 3X8
*****			D652	407 164 2206	DIODE FMB-24L
610 295 5170 ASSY,PWB,POWER MV6A			D652B	411 047 0104	SCR PAN+SW+W 3X8
			D653	407 190 4106	DIODE SFPL-52V
			D655	407 164 2206	DIODE FMB-24L
			D655B	411 047 0104	SCR PAN+SW+W 3X8
INTEGRATED CIRCUIT			MISCELLANEOUS		
IC601	409 179 4503	IC STR81145A	IC601A	610 292 3209	HEAT SINK-B MV6A
IC632	409 421 4701	IC STR-Z2156	IC601B	411 046 8507	SCR PAN+SW+W 3X10
IC652	409 308 8600	IC SE005N	IC632A	610 292 3216	HEAT SINK-C MV6A
CAPACITOR			IC632B	411 047 0104	SCR PAN+SW+W 3X8
C602	403 222 1303	CERAMIC 1000P K 1K	IC632D	411 047 0104	SCR PAN+SW+W 3X8
C603	403 222 1303	CERAMIC 1000P K 1K	K6D	645 008 4485	PLUG, 10P
C604	403 146 5500	ELECT 2.2U M 450V	▲ PC611	408 014 9703	PC CNY17F-30PT1+6
C605	403 070 0909	CERAMIC 0.1U K 50V		408 016 8803	PC PC113 (VDE0884)
C606	403 180 4101	MT-POLYEST 0.1U K 630V	▲ PC612	408 014 9703	PC CNY17F-30PT1+6
C607	403 126 4608	ELECT 100U M 25V		408 016 8803	PC PC113 (VDE0884)
C608	404 085 7501	ELECT 820U M 250V	*****		
C609	404 085 7501	ELECT 820U M 250V	610 295 5187 ASSY,PWB,SUBPOWER MV6A		
C611	403 332 7806	ELECT 2.2U M 200V			
C612	403 237 7901	MT-COMPO 0.22U J 50V			
C613	403 113 3805	CERAMIC 1000P K 50V	TRANSISTOR		
C614	403 164 0204	CERAMIC 0.1U Z 25V	Q6601	405 014 4509	TR 2SC2412K T146 R
C615	403 245 4404	CERAMIC 470P K 2K		405 014 4608	TR 2SC2412K T146 S
C616	403 167 8603	CERAMIC 220P K 2K		405 015 8704	TR 2SC2812-L6-TB
C617	403 083 6806	POLYPRO 0.056U J 400V		405 015 8902	TR 2SC2812-L7-TB
C618	403 164 0204	CERAMIC 0.1U Z 25V		405 163 1602	TR 2SC2812N-L6-TB0
C619	403 164 0204	CERAMIC 0.1U Z 25V			
C621	403 148 1807	ELECT 220U M 35V			

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
Q6602	405 163 1701	TR 2SC2812N-L7-TB0	CAPACITOR		
	405 047 9007	TR 2SB1204-S-TL	C6601	403 358 1307	ELECT 330U M 25V
	405 047 9106	TR 2SB1204-T-TL	C6602	403 358 1307	ELECT 330U M 25V
Q6603	405 014 4509	TR 2SC2412K T146 R	C6603	403 358 1307	ELECT 330U M 25V
	405 014 4608	TR 2SC2412K T146 S	C6611	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C6612	403 350 5006	ELECT 1000U M 25V
	405 015 8902	TR 2SC2812-L7-TB	C6613	403 350 5006	ELECT 1000U M 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C6614	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C6615	403 148 0701	ELECT 2200U M 25V
Q6607	405 014 4509	TR 2SC2412K T146 R		403 313 6002	ELECT 2200U M 25V
	405 014 4608	TR 2SC2412K T146 S	C6617	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8704	TR 2SC2812-L6-TB	C6618	403 134 6403	ELECT 2200U M 16V
	405 015 8902	TR 2SC2812-L7-TB	C6621	403 119 7609	ELECT 2200U M 10V
	405 163 1602	TR 2SC2812N-L6-TB0		403 313 5906	ELECT 2200U M 10V
	405 163 1701	TR 2SC2812N-L7-TB0	C6622	403 119 7609	ELECT 2200U M 10V
Q6608	405 014 4509	TR 2SC2412K T146 R		403 313 5906	ELECT 2200U M 10V
	405 014 4608	TR 2SC2412K T146 S	C6623	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8704	TR 2SC2812-L6-TB	C6629	403 148 0305	ELECT 470U M 16V
	405 015 8902	TR 2SC2812-L7-TB	C6630	403 156 9208	ELECT 4.7U M 50V
	405 163 1602	TR 2SC2812N-L6-TB0	C6636	403 358 1307	ELECT 330U M 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C6637	403 350 5006	ELECT 1000U M 25V
Q6609	405 144 6503	TR 2SK2312	C6638	403 358 1307	ELECT 330U M 25V
Q6611	405 144 6503	TR 2SK2312	C6639	403 350 5006	ELECT 1000U M 25V
Q6616	405 047 9007	TR 2SB1204-S-TL	C6641	403 113 3805	CERAMIC 1000P K 50V
	405 047 9106	TR 2SB1204-T-TL	C6642	403 149 1400	ELECT 33U M 25V
Q6617	405 014 4509	TR 2SC2412K T146 R	C6643	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C6646	403 113 3805	CERAMIC 1000P K 50V
	405 015 8704	TR 2SC2812-L6-TB	C6647	403 149 1400	ELECT 33U M 25V
	405 015 8902	TR 2SC2812-L7-TB	C6648	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C6649	403 149 1400	ELECT 33U M 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C6651	403 164 0204	CERAMIC 0.1U Z 25V
Q6618	405 014 4509	TR 2SC2412K T146 R	C6655	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C6656	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C6660	403 369 2904	ELECT 680U M 25V
	405 015 8902	TR 2SC2812-L7-TB	C6661	403 358 1307	ELECT 330U M 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C6662	403 358 1307	ELECT 330U M 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C6663	403 369 2904	ELECT 680U M 25V
Q6621	405 047 9007	TR 2SB1204-S-TL	C6664	403 164 0204	CERAMIC 0.1U Z 25V
	405 047 9106	TR 2SB1204-T-TL	C6665	403 113 3805	CERAMIC 1000P K 50V
Q6622	405 014 4509	TR 2SC2412K T146 R	C6666	403 205 2808	CERAMIC 0.047U K 25V
	405 014 4608	TR 2SC2412K T146 S	C6667	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8704	TR 2SC2812-L6-TB	C6668	403 369 2904	ELECT 680U M 25V
	405 015 8902	TR 2SC2812-L7-TB	C6669	403 369 2904	ELECT 680U M 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C6672	403 149 9208	CERAMIC 0.01U Z 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C6675	403 164 0204	CERAMIC 0.1U Z 25V
Q6623	405 014 4509	TR 2SC2412K T146 R	C6676	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C6677	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C7601	403 113 3805	CERAMIC 1000P K 50V
	405 015 8902	TR 2SC2812-L7-TB	C7602	403 358 1307	ELECT 330U M 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C7603	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C7604	403 149 1400	ELECT 33U M 25V
Q6631	405 014 4509	TR 2SC2412K T146 R	C7605	403 350 5006	ELECT 1000U M 25V
	405 014 4608	TR 2SC2412K T146 S	C7607	403 358 1307	ELECT 330U M 25V
	405 015 8704	TR 2SC2812-L6-TB	C7608	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C7614	403 358 1307	ELECT 330U M 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C7626	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C7627	403 164 0204	CERAMIC 0.1U Z 25V
Q6632	405 014 4509	TR 2SC2412K T146 R	C7631	403 358 1109	ELECT 100U M 25V
	405 014 4608	TR 2SC2412K T146 S	RESISTOR		
	405 015 8704	TR 2SC2812-L6-TB	R6601	401 105 8203	MT-GLAZE 68K JA 1/16W
	405 015 8902	TR 2SC2812-L7-TB	R6602	401 105 4304	MT-GLAZE 330K JA 1/16W
	405 163 1602	TR 2SC2812N-L6-TB0	R6603	401 105 5103	MT-GLAZE 47 JA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	R6604	401 105 2201	MT-GLAZE 180K JA 1/16W
Q6633	405 014 4509	TR 2SC2412K T146 R	R6605	401 105 5301	MT-GLAZE 4.7K JA 1/16W
	405 014 4608	TR 2SC2412K T146 S	R6607	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 015 8704	TR 2SC2812-L6-TB	R6608	401 212 0206	MT-GLAZE 33K FA 1/16W
	405 015 8902	TR 2SC2812-L7-TB	R6609	401 162 6303	MT-GLAZE 330 JA 1W
	405 163 1602	TR 2SC2812N-L6-TB0	R6611	401 105 4502	MT-GLAZE 390 JA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	R6613	401 105 0603	MT-GLAZE 10K JA 1/16W
Q7602	405 047 9007	TR 2SB1204-S-TL	R6614	401 105 4007	MT-GLAZE 330 JA 1/16W
	405 047 9106	TR 2SB1204-T-TL	R6615	401 105 4007	MT-GLAZE 330 JA 1/16W
Q7603	405 014 4509	TR 2SC2412K T146 R	R6617	401 276 4707	MT-GLAZE 0.000 ZA 1/3W
	405 014 4608	TR 2SC2412K T146 S	R6621	401 105 8203	MT-GLAZE 68K JA 1/16W
	405 015 8704	TR 2SC2812-L6-TB	R6622	401 105 4304	MT-GLAZE 330K JA 1/16W
	405 015 8902	TR 2SC2812-L7-TB	R6623	401 105 5103	MT-GLAZE 47 JA 1/16W
	405 163 1602	TR 2SC2812N-L6-TB0	R6624	401 105 2201	MT-GLAZE 180K JA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	R6625	401 105 5301	MT-GLAZE 4.7K JA 1/16W
Q7604	405 014 4509	TR 2SC2412K T146 R	R6627	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 014 4608	TR 2SC2412K T146 S	R6628	401 212 0206	MT-GLAZE 33K FA 1/16W
	405 015 8704	TR 2SC2812-L6-TB	R6629	401 162 6303	MT-GLAZE 330 JA 1W
	405 015 8902	TR 2SC2812-L7-TB	R6633	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 163 1602	TR 2SC2812N-L6-TB0	R6634	401 105 5806	MT-GLAZE 56 JA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	R6637	401 276 4707	MT-GLAZE 0.000 ZA 1/3W
Q7611	405 014 4509	TR 2SC2412K T146 R	R6641	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 014 4608	TR 2SC2412K T146 S	R6642	401 105 5301	MT-GLAZE 4.7K JA 1/16W
	405 015 8704	TR 2SC2812-L6-TB	R6643	401 238 4400	MT-GLAZE 2.7K JA 1/3W
	405 015 8902	TR 2SC2812-L7-TB	R6644	401 238 4202	MT-GLAZE 1.5K JA 1/3W
	405 163 1602	TR 2SC2812N-L6-TB0	R6648	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	R6649	401 105 5301	MT-GLAZE 4.7K JA 1/16W
INTEGRATED CIRCUIT			R6650	401 105 0603	MT-GLAZE 10K JA 1/16W
IC6601	409 459 5404	IC FA7612CN	R6651	401 105 0603	MT-GLAZE 10K JA 1/16W
IC6602	409 459 5404	IC FA7612CN	R6652	401 105 1600	MT-GLAZE 15K JA 1/16W
IC6607	409 459 5404	IC FA7612CN	R6653	401 219 1602	MT-GLAZE 100K FA 1/16W
IC6611	409 428 9600	IC M62399FP	R6655	401 105 1600	MT-GLAZE 15K JA 1/16W
IC6612	409 505 6102	IC MD1222N	R6656	401 105 0702	MT-GLAZE 100K JA 1/16W

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R6661	402 079 4208	FUSIBLE RES 1.5 JH 1/10W	CAPACITOR		
R6665	401 105 0504	MT-GLAZE 1K JA 1/16W	C2691	403 358 1307	ELECT 330U M 25V
R6681	401 203 1106	MT-GLAZE 8.2 JA 1W	C2692	403 164 0204	CERAMIC 0.1U Z 25V
R6682	401 203 1106	MT-GLAZE 8.2 JA 1W	C2693	403 358 1307	ELECT 330U M 25V
R6685	401 105 0603	MT-GLAZE 10K JA 1/16W	C2694	403 164 0204	CERAMIC 0.1U Z 25V
R6687	401 105 0603	MT-GLAZE 10K JA 1/16W	C2696	403 358 1307	ELECT 330U M 25V
R6688	401 105 0603	MT-GLAZE 10K JA 1/16W	C2697	403 164 0204	CERAMIC 0.1U Z 25V
R6691	401 105 0702	MT-GLAZE 100K JA 1/16W	C2698	403 358 1307	ELECT 330U M 25V
R6692	401 105 8005	MT-GLAZE 1M JA 1/16W	C2699	403 358 1307	ELECT 330U M 25V
R6693	401 105 0603	MT-GLAZE 10K JA 1/16W	RESISTOR		
R6695	401 218 4505	MT-GLAZE 2.2K FA 1/16W	R2691	401 105 0603	MT-GLAZE 10K JA 1/16W
R6696	401 257 7000	MT-GLAZE 820 FA 1/16W	R2692	401 105 0603	MT-GLAZE 10K JA 1/16W
R6697	401 299 2803	MT-GLAZE 0.068 JA 1W	R2693	401 105 0603	MT-GLAZE 10K JA 1/16W
R6698	401 299 2803	MT-GLAZE 0.068 JA 1W	R2694	401 105 0603	MT-GLAZE 10K JA 1/16W
R7601	401 105 8203	MT-GLAZE 68K JA 1/16W	R2695	401 105 0603	MT-GLAZE 10K JA 1/16W
R7602	401 105 4304	MT-GLAZE 330K JA 1/16W	DIODE		
R7603	401 105 5103	MT-GLAZE 47 JA 1/16W	D2691	407 149 0807	DIODE 1SS355-TE-17
R7604	401 276 4707	MT-GLAZE 0.000 ZA 1/3W	D2692	407 149 0807	DIODE 1SS355-TE-17
R7607	401 105 4205	MT-GLAZE 33K JA 1/16W	D2693	407 149 0807	DIODE 1SS355-TE-17
R7611	401 162 6303	MT-GLAZE 330 JA 1W	D2694	407 149 0807	DIODE 1SS355-TE-17
R7614	401 105 2201	MT-GLAZE 180K JA 1/16W	D2695	407 149 0807	DIODE 1SS355-TE-17
R7615	401 105 5301	MT-GLAZE 4.7K JA 1/16W	MISCELLANEOUS		
R7617	401 105 0603	MT-GLAZE 10K JA 1/16W	K56C	645 004 2928	PLUG, 6P
R7618	401 105 0603	MT-GLAZE 10K JA 1/16W	K56E	645 005 7373	PLUG, 3P
R7625	401 105 2904	MT-GLAZE 22K JA 1/16W	K56F	645 005 7373	PLUG, 3P
R7626	401 105 2904	MT-GLAZE 22K JA 1/16W	K56G	645 005 7373	PLUG, 3P
R7627	401 105 0702	MT-GLAZE 100K JA 1/16W	K56H	645 004 2898	PLUG, 3P
R7628	401 105 0504	MT-GLAZE 1K JA 1/16W	K56J	645 004 2898	PLUG, 3P
R7629	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7631	401 105 8203	MT-GLAZE 68K JA 1/16W			
R7632	401 105 1006	MT-GLAZE 1.2K JA 1/16W			
R7633	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R7635	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7636	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7637	401 105 0702	MT-GLAZE 100K JA 1/16W			
R7638	401 105 0504	MT-GLAZE 1K JA 1/16W			
R7639	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7641	401 105 8203	MT-GLAZE 68K JA 1/16W			
R7642	401 105 1006	MT-GLAZE 1.2K JA 1/16W			
R7643	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R7645	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7646	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7647	401 105 0702	MT-GLAZE 100K JA 1/16W			
R7648	401 105 0504	MT-GLAZE 1K JA 1/16W			
R7649	401 105 2904	MT-GLAZE 22K JA 1/16W			
R7651	401 105 8203	MT-GLAZE 68K JA 1/16W			
R7652	401 105 1006	MT-GLAZE 1.2K JA 1/16W			
R7653	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R7661	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R7662	401 105 5400	MT-GLAZE 47K JA 1/16W			
R7663	401 105 5400	MT-GLAZE 47K JA 1/16W			
R7664	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
COIL					
L6601	645 007 8118	INDUCTOR, 390U K			</

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
Q9004	405 134 5905	TR 2SA1037AK-T146-R	C9043	403 175 4505	ELECT 47U M 6.3V
	405 147 2205	TR 2SA1037AK-S-T146	C9045	403 157 1904	CERAMIC 10P D 50V
	405 002 0308	TR 2SA1037K T146 R	C9046	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
	405 002 0407	TR 2SA1037K T146 S	C9047	403 164 0204	CERAMIC 0.1U Z 25V
	405 002 6706	TR 2SA1179-M6-TB	C9048	403 175 4505	ELECT 47U M 6.3V
	405 002 6904	TR 2SA1179-M7-TB	C9049	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1503	TR 2SA1179N-M6-TB	C9051	403 175 4505	ELECT 47U M 6.3V
	405 163 2708	TR 2SA1179N-M7-TB	C9053	403 157 1904	CERAMIC 10P D 50V
Q9012	405 047 9007	TR 2SB1204-S-TL	C9054	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
Q9013	405 014 4509	TR 2SC2412K T146 R	C9055	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C9056	403 175 4505	ELECT 47U M 6.3V
	405 015 8704	TR 2SC2812-L6-TB	C9057	403 280 1604	ELECT 220U M 16V
	405 015 8902	TR 2SC2812-L7-TB	C9058	403 280 1604	ELECT 220U M 16V
	405 163 1602	TR 2SC2812N-L6-TB0	C9059	403 280 0805	ELECT 330U M 6.3V
	405 163 1701	TR 2SC2812N-L7-TB0	C9061	403 280 0805	ELECT 330U M 6.3V
Q9016	405 047 9007	TR 2SB1204-S-TL	C9062	403 280 1604	ELECT 220U M 16V
Q9017	405 014 4509	TR 2SC2412K T146 R	C9063	403 280 1604	ELECT 220U M 16V
	405 014 4608	TR 2SC2412K T146 S	C9064	403 280 0805	ELECT 330U M 6.3V
	405 015 8704	TR 2SC2812-L6-TB	C9065	403 280 0805	ELECT 330U M 6.3V
	405 015 8902	TR 2SC2812-L7-TB	C9066	403 175 4505	ELECT 47U M 6.3V
	405 163 1602	TR 2SC2812N-L6-TB0	C9067	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C9068	403 175 4505	ELECT 47U M 6.3V
Q9021	405 047 9007	TR 2SB1204-S-TL	C9069	403 164 0204	CERAMIC 0.1U Z 25V
Q9022	405 014 4509	TR 2SC2412K T146 R	C9070	403 229 3508	ELECT 100U M 16V
	405 014 4608	TR 2SC2412K T146 S	C9071	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C9072	403 175 4505	ELECT 47U M 6.3V
	405 015 8902	TR 2SC2812-L7-TB	C9073	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C9074	403 229 3508	ELECT 100U M 16V
	405 163 1701	TR 2SC2812N-L7-TB0	C9075	403 164 0204	CERAMIC 0.1U Z 25V
Q9027	405 014 4509	TR 2SC2412K T146 R	C9076	403 175 4505	ELECT 47U M 6.3V
	405 014 4608	TR 2SC2412K T146 S	C9077	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C9078	403 229 3508	ELECT 100U M 16V
	405 015 8902	TR 2SC2812-L7-TB	C9079	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C9084	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C9091	403 366 6202	CERAMIC 22U Z 10V
Q9028	405 014 4509	TR 2SC2412K T146 R	C9092	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C9093	403 162 4006	ELECT 22U M 6.3V
	405 015 8704	TR 2SC2812-L6-TB	C9094	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C9095	403 162 4006	ELECT 22U M 6.3V
	405 163 1602	TR 2SC2812N-L6-TB0	C9096	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	RESISTOR		
INTEGRATED CIRCUIT			R9001	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9001	409 438 5500	IC TC4052BFT	R9002	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9002	409 438 5500	IC TC4052BFT	R9003	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9005	409 153 5601	IC MC74F244M	R9004	401 105 0405	MT-GLAZE 100 JA 1/16W
	409 451 4108	IC SN74F244NSR	R9005	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9006	409 476 0208	IC AD8184AR	R9006	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9007	409 476 0208	IC AD8184AR	R9007	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9008	409 476 0208	IC AD8184AR	R9008	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9009	409 461 7304	IC AD8057ART	R9009	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9011	409 461 7304	IC AD8057ART	R9010	401 105 0306	MT-GLAZE 10 JA 1/16W
IC9012	409 461 7304	IC AD8057ART	R9011	401 105 0405	MT-GLAZE 100 JA 1/16W
IC9013	409 438 5500	IC TC4052BFT	R9012	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9014	409 445 7306	IC QS3125QX	R9013	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9021	409 404 6302	IC M62320FP	R9015	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9022	409 404 6302	IC M62320FP	R9017	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9091	409 416 6505	IC BA05FP-E2	R9018	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9092	409 416 6505	IC BA05FP-E2	R9019	401 105 0603	MT-GLAZE 10K JA 1/16W
IC9093	409 416 6505	IC BA05FP-E2	R9020	401 105 0603	MT-GLAZE 10K JA 1/16W
CAPACITOR			R9021	401 105 0603	MT-GLAZE 10K JA 1/16W
C9001	403 175 4505	ELECT 47U M 6.3V	R9022	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C9002	403 164 0204	CERAMIC 0.1U Z 25V	R9023	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C9003	403 229 3508	ELECT 100U M 16V	R9024	401 105 0603	MT-GLAZE 10K JA 1/16W
C9004	403 164 0204	CERAMIC 0.1U Z 25V	R9025	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C9005	403 205 7803	TA-SOLID 2.2U M 16V	R9026	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C9006	403 205 7803	TA-SOLID 2.2U M 16V	R9027	401 105 0405	MT-GLAZE 100 JA 1/16W
C9008	403 205 7803	TA-SOLID 2.2U M 16V	R9028	401 105 0702	MT-GLAZE 100K JA 1/16W
C9009	403 205 7803	TA-SOLID 2.2U M 16V	R9029	401 105 0405	MT-GLAZE 100 JA 1/16W
C9011	403 205 7803	TA-SOLID 2.2U M 16V	R9030	401 105 0603	MT-GLAZE 10K JA 1/16W
C9012	403 205 7803	TA-SOLID 2.2U M 16V	R9031	401 105 0702	MT-GLAZE 100K JA 1/16W
C9014	403 175 4505	ELECT 47U M 6.3V	R9033	401 105 0702	MT-GLAZE 100K JA 1/16W
C9015	403 164 0204	CERAMIC 0.1U Z 25V	R9034	401 105 0405	MT-GLAZE 100 JA 1/16W
C9016	403 175 4505	ELECT 47U M 6.3V	R9035	401 105 0702	MT-GLAZE 100K JA 1/16W
C9017	403 164 0204	CERAMIC 0.1U Z 25V	R9036	401 105 0702	MT-GLAZE 100K JA 1/16W
C9018	403 175 4505	ELECT 47U M 6.3V	R9037	401 105 0405	MT-GLAZE 100 JA 1/16W
C9019	403 164 0204	CERAMIC 0.1U Z 25V	R9038	401 105 0702	MT-GLAZE 100K JA 1/16W
C9021	403 164 0204	CERAMIC 0.1U Z 25V	R9039	401 105 0405	MT-GLAZE 100 JA 1/16W
C9022	403 175 4505	ELECT 47U M 6.3V	R9040	401 105 0603	MT-GLAZE 10K JA 1/16W
C9023	403 164 0204	CERAMIC 0.1U Z 25V	R9041	401 105 0702	MT-GLAZE 100K JA 1/16W
C9024	403 175 4505	ELECT 47U M 6.3V	R9042	401 105 0405	MT-GLAZE 100 JA 1/16W
C9025	403 164 0204	CERAMIC 0.1U Z 25V	R9043	401 105 0702	MT-GLAZE 100K JA 1/16W
C9026	403 175 4505	ELECT 47U M 6.3V	R9047	401 105 0603	MT-GLAZE 10K JA 1/16W
C9027	403 164 0204	CERAMIC 0.1U Z 25V	R9048	401 105 0603	MT-GLAZE 10K JA 1/16W
C9028	403 175 4505	ELECT 47U M 6.3V	R9049	401 105 0603	MT-GLAZE 10K JA 1/16W
C9029	403 164 0204	CERAMIC 0.1U Z 25V	R9050	401 105 0603	MT-GLAZE 10K JA 1/16W
C9031	403 175 4505	ELECT 47U M 6.3V	R9051	401 105 0603	MT-GLAZE 10K JA 1/16W
C9032	403 164 0204	CERAMIC 0.1U Z 25V	R9052	401 105 0702	MT-GLAZE 100K JA 1/16W
C9033	403 175 4505	ELECT 47U M 6.3V	R9053	401 105 0405	MT-GLAZE 100 JA 1/16W
C9034	403 164 0204	CERAMIC 0.1U Z 25V	R9054	401 105 0702	MT-GLAZE 100K JA 1/16W
C9035	403 175 4505	ELECT 47U M 6.3V	R9055	401 105 0405	MT-GLAZE 100 JA 1/16W
C9037	403 157 1904	CERAMIC 10P D 50V	R9056	401 105 0702	MT-GLAZE 100K JA 1/16W
C9038	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9057	401 105 0405	MT-GLAZE 100 JA 1/16W
C9039	403 164 0204	CERAMIC 0.1U Z 25V	R9058	401 105 0702	MT-GLAZE 100K JA 1/16W
C9041	403 175 4505	ELECT 47U M 6.3V	R9063	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9042	403 164 0204	CERAMIC 0.1U Z 25V	R9064	401 105 0405	MT-GLAZE 100 JA 1/16W

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R9065	401 105 0405	MT-GLAZE 100 JA 1/16W	R9509	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R9066	401 105 0603	MT-GLAZE 10K JA 1/16W	R9511	401 105 0603	MT-GLAZE 10K JA 1/16W
R9067	401 105 0603	MT-GLAZE 10K JA 1/16W	R9512	401 105 0603	MT-GLAZE 10K JA 1/16W
R9068	401 105 0603	MT-GLAZE 10K JA 1/16W	R9513	401 105 0603	MT-GLAZE 10K JA 1/16W
R9069	401 105 0603	MT-GLAZE 10K JA 1/16W	R9515	401 105 0405	MT-GLAZE 100 JA 1/16W
R9071	401 105 0603	MT-GLAZE 10K JA 1/16W	R9516	401 105 0405	MT-GLAZE 100 JA 1/16W
R9072	401 105 0603	MT-GLAZE 10K JA 1/16W	R9517	401 105 0405	MT-GLAZE 100 JA 1/16W
R9073	401 105 3307	MT-GLAZE 2.7K JA 1/16W	R9518	401 105 0405	MT-GLAZE 100 JA 1/16W
R9074	401 105 1501	MT-GLAZE 1.5K JA 1/16W	R9519	401 105 0405	MT-GLAZE 100 JA 1/16W
R9075	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R9521	401 105 0405	MT-GLAZE 100 JA 1/16W
R9076	401 105 0603	MT-GLAZE 10K JA 1/16W	R9522	401 105 0405	MT-GLAZE 100 JA 1/16W
R9081	401 226 1206	MT-GLAZE 150 FA 1/16W	COIL		
R9082	401 226 1206	MT-GLAZE 150 FA 1/16W	L9001	645 026 1008	INDUCTOR, 3.3U M
R9083	401 105 0405	MT-GLAZE 100 JA 1/16W	L9002	645 026 1008	INDUCTOR, 3.3U M
R9084	401 226 1206	MT-GLAZE 150 FA 1/16W	L9003	645 026 1008	INDUCTOR, 3.3U M
R9085	401 226 1206	MT-GLAZE 150 FA 1/16W	L9004	645 026 1008	INDUCTOR, 3.3U M
R9086	401 105 0405	MT-GLAZE 100 JA 1/16W	L9005	645 026 1008	INDUCTOR, 3.3U M
R9087	401 226 1206	MT-GLAZE 150 FA 1/16W	L9006	645 026 1008	INDUCTOR, 3.3U M
R9088	401 226 1206	MT-GLAZE 150 FA 1/16W	DIODE		
R9089	401 105 0405	MT-GLAZE 100 JA 1/16W	D9001	407 149 0807	DIODE 1SS355-TE-17
R9093	401 105 0603	MT-GLAZE 10K JA 1/16W	D9002	407 149 0807	DIODE 1SS355-TE-17
R9094	401 105 0306	MT-GLAZE 10 JA 1/16W	D9003	407 149 0807	DIODE 1SS355-TE-17
R9095	401 105 0405	MT-GLAZE 100 JA 1/16W	D9011	407 206 5608	ZENER DIODE UDZS-TE-1710B
R9096	401 105 0405	MT-GLAZE 100 JA 1/16W	D9012	407 206 5608	ZENER DIODE UDZS-TE-1710B
R9097	401 105 0306	MT-GLAZE 10 JA 1/16W	D9013	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R9098	401 226 1206	MT-GLAZE 150 FA 1/16W	D9014	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R9099	401 226 1206	MT-GLAZE 150 FA 1/16W	D9021	407 190 4106	DIODE SFPL-52V
R9100	401 105 3307	MT-GLAZE 2.7K JA 1/16W	MISCELLANEOUS		
R9101	401 105 0405	MT-GLAZE 100 JA 1/16W	K90A	645 049 9708	SOCKET, PWB 40P
R9102	401 226 1206	MT-GLAZE 150 FA 1/16W	K90B	645 049 9708	SOCKET, PWB 40P
R9103	401 226 1206	MT-GLAZE 150 FA 1/16W	K90C	645 041 6064	PLUG, I/O 176P
R9104	401 105 0405	MT-GLAZE 100 JA 1/16W	K90C1	610 289 9788	JOINT GUIDE PIN ML6A
R9105	401 226 1206	MT-GLAZE 150 FA 1/16W	K90C2	610 289 9788	JOINT GUIDE PIN ML6A
R9106	401 226 1206	MT-GLAZE 150 FA 1/16W	K90D	645 041 6064	PLUG, I/O 176P
R9107	401 105 0405	MT-GLAZE 100 JA 1/16W	K90D1	610 289 9788	JOINT GUIDE PIN ML6A
R9110	401 105 1501	MT-GLAZE 1.5K JA 1/16W	K90D2	610 289 9788	JOINT GUIDE PIN ML6A
R9111	401 105 0603	MT-GLAZE 10K JA 1/16W	K90E	645 041 6064	PLUG, I/O 176P
R9112	401 105 0306	MT-GLAZE 10 JA 1/16W	K90E1	610 289 9788	JOINT GUIDE PIN ML6A
R9113	401 105 0405	MT-GLAZE 100 JA 1/16W	K90E2	610 289 9788	JOINT GUIDE PIN ML6A
R9114	401 105 0405	MT-GLAZE 100 JA 1/16W	K90G	645 032 6523	PLUG, 13P
R9115	401 105 0306	MT-GLAZE 10 JA 1/16W	K90K	645 009 8390	PLUG, ANT 2P
R9116	401 226 1206	MT-GLAZE 150 FA 1/16W	K90L	645 009 8390	PLUG, ANT 2P
R9117	401 226 1206	MT-GLAZE 150 FA 1/16W	K90M	645 009 8390	PLUG, ANT 2P
R9118	401 105 0405	MT-GLAZE 100 JA 1/16W	K90N	645 036 1326	TERMINAL
R9119	401 226 1206	MT-GLAZE 150 FA 1/16W	K90P	645 036 1326	TERMINAL
R9120	401 105 5301	MT-GLAZE 4.7K JA 1/16W	K90Q	645 041 8136	PLUG, 40P
R9121	401 226 1206	MT-GLAZE 150 FA 1/16W			
R9122	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9123	401 226 1206	MT-GLAZE 150 FA 1/16W			
R9124	401 226 1206	MT-GLAZE 150 FA 1/16W			
R9125	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9128	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9129	401 105 0306	MT-GLAZE 10 JA 1/16W			
R9130	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9131	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9132	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9133	401 105 0306	MT-GLAZE 10 JA 1/16W			
R9134	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9135	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9136	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9137	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9138	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9139	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9141	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9142	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9143	401 257 7000	MT-GLAZE 820 FA 1/16W			
R9144	401 113 4402	MT-GLAZE 75 JA 1/16W			
R9145	401 113 4402	MT-GLAZE 75 JA 1/16W			
R9146	401 113 4402	MT-GLAZE 75 JA 1/16W			
R9158	401 105 3307	MT-GLAZE 2.7K JA 1/16W			
R9159	401 105 1501	MT-GLAZE 1.5K JA 1/16W			
R9160	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
R9161	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9171	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9172	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9174	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9175	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9176	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9177	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9183	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9184	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9185	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9186	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9187	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9188	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9189	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9191	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9501	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9502	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
R9503	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
R9504	401 105 0603	MT-GLAZE 10K JA 1/16W			
R9505	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
R9506	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
R9507	401 105 0405	MT-GLAZE 100 JA 1/16W			
R9508	401 105 5301	MT-GLAZE 4.7K JA 1/16W			

610 292 1380 ASSY,PWB,MOTOR&AUDIO MV6A					
TRANSISTOR					
Q001	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q003	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q004	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
Q005	405 014 4509	TR 2SC2412K T146 R			
	405 014 4608	TR 2SC2412K T146 S			
	405 015 8704	TR 2SC2812-L6-TB			
	405 015 8902	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB0			
	405 163 1701	TR 2SC2812N-L7-TB0			
INTEGRATED CIRCUIT					
IC001	409 017 7208	IC LA4261			
IC1601	409 114 4803	IC LB1641			
IC1611	409 114 4803	IC LB1641			
IC1631	409 085 1900	IC LB1645N			
CAPACITOR					
C001	403 280 1802	ELECT 100U M 25V			
C003	403 215 2201	CERAMIC 0.01U K 50V			
C004	403 280 1802	ELECT 100U M 25V			
C006	403 215 2201	CERAMIC 0.01U K 50V			
C007	403 280 1802	ELECT 100U M 25V			
C008	403 162 6604	ELECT 2.2U M 50V			
C009	403 298 9609	CERAMIC 0.1U K 16V			
C010	403 298 9609	CERAMIC 0.1U K 16V			
C011	403 343 4900	ELECT 470U M 25V			
C012	403 298 9609	CERAMIC 0.1U K 16V			
C013	403 343 4900	ELECT 470U M 25V			
C014	403 343 4900	ELECT 470U M 25V			
C015	403 266 8801	NP-ELECT 2.2U M 50V			
C016	403 266 8801	NP-ELECT 2.2U M 50V			

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C017	403 280 1802	ELECT 100U M 25V	R6802	401 105 1600	MT-GLAZE 15K JA 1/16W
C018	403 343 4900	ELECT 470U M 25V	R6803	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C019	403 343 4900	ELECT 470U M 25V	R6804	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C021	403 343 4900	ELECT 470U M 25V	R6806	401 105 3307	MT-GLAZE 2.7K JA 1/16W
C026	403 343 4900	ELECT 470U M 25V	R6807	401 105 2003	MT-GLAZE 1.8K JA 1/16W
C1602	403 215 2201	CERAMIC 0.01U K 50V	R6808	401 105 1501	MT-GLAZE 1.5K JA 1/16W
C1603	403 215 2201	CERAMIC 0.01U K 50V	R6809	401 105 5202	MT-GLAZE 470 JA 1/16W
C1612	403 215 2201	CERAMIC 0.01U K 50V	R6812	401 105 2904	MT-GLAZE 22K JA 1/16W
C1613	403 215 2201	CERAMIC 0.01U K 50V	R6813	401 105 1600	MT-GLAZE 15K JA 1/16W
C1631	403 343 4900	ELECT 470U M 25V	R6814	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C1632	403 215 2201	CERAMIC 0.01U K 50V	R6816	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C1633	403 343 4900	ELECT 470U M 25V	R6817	401 105 3307	MT-GLAZE 2.7K JA 1/16W
C1642	403 215 2201	CERAMIC 0.01U K 50V	R6818	401 105 2003	MT-GLAZE 1.8K JA 1/16W
C1643	403 281 5205	CERAMIC 0.22U Z 16V	R6819	401 105 1501	MT-GLAZE 1.5K JA 1/16W
C1653	403 343 4900	ELECT 470U M 25V	R6821	401 105 5202	MT-GLAZE 470 JA 1/16W
C1654	403 215 2201	CERAMIC 0.01U K 50V	R6823	401 105 2904	MT-GLAZE 22K JA 1/16W
C1656	403 343 4900	ELECT 470U M 25V	R6824	401 105 1600	MT-GLAZE 15K JA 1/16W
C1893	403 164 0204	CERAMIC 0.1U Z 25V	R6826	401 105 6001	MT-GLAZE 5.6K JA 1/16W
C1894	403 164 0204	CERAMIC 0.1U Z 25V	R6827	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C1895	403 164 0204	CERAMIC 0.1U Z 25V	R6828	401 105 3307	MT-GLAZE 2.7K JA 1/16W
RESISTOR			R6829	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R001	401 105 3208	MT-GLAZE 270 JA 1/16W	R6831	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R002	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R6832	401 105 5202	MT-GLAZE 470 JA 1/16W
R003	401 105 2102	MT-GLAZE 18K JA 1/16W	DIODE		
R004	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D6801	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R005	401 105 2102	MT-GLAZE 18K JA 1/16W	D6802	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R006	401 105 3208	MT-GLAZE 270 JA 1/16W	D6803	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R007	401 105 2706	MT-GLAZE 220 JA 1/16W	D6804	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R008	401 105 0603	MT-GLAZE 10K JA 1/16W	MISCELLANEOUS		
R009	401 105 4205	MT-GLAZE 33K JA 1/16W	K96A	645 046 8254	PLUG, 30P
R011	401 148 6006	MT-GLAZE 2.2 JA 1/16W	K96B	645 005 8387	PLUG, 6P
R012	401 105 5905	MT-GLAZE 560 JA 1/16W	K96U	645 012 2248	PLUG, 4P
R013	401 148 6006	MT-GLAZE 2.2 JA 1/16W	SW6801	645 025 3478	SWITCH, PUSH 1P-2TX1
R014	401 105 5905	MT-GLAZE 560 JA 1/16W	SW6802	645 025 3478	SWITCH, PUSH 1P-2TX1
R016	401 105 0504	MT-GLAZE 1K JA 1/16W	SW6803	645 025 3478	SWITCH, PUSH 1P-2TX1
R017	401 105 6001	MT-GLAZE 5.6K JA 1/16W	SW6804	645 025 3478	SWITCH, PUSH 1P-2TX1
R018	401 105 0603	MT-GLAZE 10K JA 1/16W	SW6806	645 025 3478	SWITCH, PUSH 1P-2TX1
R021	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6807	645 025 3478	SWITCH, PUSH 1P-2TX1
R022	401 105 6001	MT-GLAZE 5.6K JA 1/16W	SW6809	645 025 3478	SWITCH, PUSH 1P-2TX1
R023	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6811	645 025 3478	SWITCH, PUSH 1P-2TX1
R024	401 105 6001	MT-GLAZE 5.6K JA 1/16W	SW6812	645 025 3478	SWITCH, PUSH 1P-2TX1
R028	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6813	645 025 3478	SWITCH, PUSH 1P-2TX1
R031	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6814	645 025 3478	SWITCH, PUSH 1P-2TX1
R035	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6816	645 025 3478	SWITCH, PUSH 1P-2TX1
R036	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6817	645 025 3478	SWITCH, PUSH 1P-2TX1
R1601	401 105 4106	MT-GLAZE 3.3K JA 1/16W	SW6819	645 025 3478	SWITCH, PUSH 1P-2TX1
R1602	401 105 4106	MT-GLAZE 3.3K JA 1/16W	SW6821	645 025 3478	SWITCH, PUSH 1P-2TX1
R1603	401 105 0504	MT-GLAZE 1K JA 1/16W	SW6822	645 025 3478	SWITCH, PUSH 1P-2TX1
R1604	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SW6824	645 025 3478	SWITCH, PUSH 1P-2TX1
R1611	401 105 4106	MT-GLAZE 3.3K JA 1/16W	SW6825	645 025 3478	SWITCH, PUSH 1P-2TX1
R1612	401 105 4106	MT-GLAZE 3.3K JA 1/16W			
R1613	401 105 0504	MT-GLAZE 1K JA 1/16W			
R1614	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R1631	401 105 4106	MT-GLAZE 3.3K JA 1/16W			
R1632	401 105 4106	MT-GLAZE 3.3K JA 1/16W			
R1633	401 105 0504	MT-GLAZE 1K JA 1/16W			
R1634	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
COIL					
L002	645 026 1008	INDUCTOR, 3.3U M			
DIODE					
D001	407 149 0807	DIODE 1SS355-TE-17			
D002	407 223 1003	ZENER DIODE 02DZ5.1Y(TPH3			
D1601	407 223 1003	ZENER DIODE 02DZ5.1Y(TPH3			
D1602	407 149 0807	DIODE 1SS355-TE-17			
D1603	407 149 0807	DIODE 1SS355-TE-17			
D1611	407 223 1003	ZENER DIODE 02DZ5.1Y(TPH3			
D1612	407 149 0807	DIODE 1SS355-TE-17			
D1613	407 149 0807	DIODE 1SS355-TE-17			
D1631	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D1632	407 149 0807	DIODE 1SS355-TE-17			
D1633	407 149 0807	DIODE 1SS355-TE-17			
MISCELLANEOUS					
IC001A	610 295 1271	ASSY, HEAT SINK MV6A			
IC001B	411 003 8908	SCR PAN+SW 3X6			
IC001D	411 004 4404	NUT HEX 3			
	411 054 7509	NUT HEX 3			
04	610 295 1370	HEAT SINK E-MV6A			
04	610 230 8341	RADIATOR MTG BRKT-S6KH			
K16A	645 041 8136	PLUG, 40P			
K16B	645 029 6314	PULG, 3P			
K16C	645 004 2904	PLUG, 4P			
K16D	645 004 2898	PLUG, 3P			
K16E	645 029 6321	PULG, 4P			
K16F	645 043 3719	PLUG, 3P			
K16H	645 029 6345	PULG, 6P			

610 292 1397 ASSY,PWB,CONTROL MV6A					
CAPACITOR					
C6801	403 298 9609	CERAMIC 0.1U K 16V			
C6802	403 298 9609	CERAMIC 0.1U K 16V			
C6803	403 298 9609	CERAMIC 0.1U K 16V			
RESISTOR					
R6801	401 105 2904	MT-GLAZE 22K JA 1/16W			

610 292 1403 ASSY,PWB,RS232C MV6A					
INTEGRATED CIRCUIT					
IC3801	409 380 6303	IC HIN232CB			
	409 273 3501	IC SP232ACT			
IC3803	409 380 6303	IC HIN232CB			
	409 273 3501	IC SP232ACT			
IC3804	409 438 5609	IC TC74ACT08FT			
CAPACITOR					
C3851	403 162 6208	ELECT 1U M 50V			
C3852	403 162 6208	ELECT 1U M 50V			
C3853	403 162 6208	ELECT 1U M 50V			
C3854	403 162 6208	ELECT 1U M 50V			
C3855	403 283 6309	CERAMIC 1U Z 10V			
C3856	403 175 4505	ELECT 47U M 6.3V			
C3857	403 162 4709	ELECT 10U M 16V			
C3858	403 162 4709	ELECT 10U M 16V			
C3859	403 162 6208	ELECT 1U M 50V			
C3861	403 162 6208	ELECT 1U M 50V			
C3862	403 162 6208	ELECT 1U M 50V			
C3863	403 162 6208	ELECT 1U M 50V			
C3864	403 175 4505	ELECT 47U M 6.3V			
C3865	403 283 6309	CERAMIC 1U Z 10V			
C3866	403 175 4505	ELECT 47U M 6.3V			
C3867	403 283 6309	CERAMIC 1U Z 10V			
RESISTOR					
R3851	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3852	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3853	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3856	401 105 0603	MT-GLAZE 10K JA 1/16W			
R3857	401 105 4007	MT-GLAZE 330 JA 1/16W			
R3858	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3859	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3861	401 105 5509	MT-GLAZE 470K JA 1/16W			
R3862	401 105 5509	MT-GLAZE 470K JA 1/16W			
R3863	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3864	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3865	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3866	401 105 0405	MT-GLAZE 100 JA 1/16W			
R3868	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R3869	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R3871	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R3872	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R3873	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	RESISTOR		
R3874	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6851	401 105 5202	MT-GLAZE 470 JA 1/16W
R3877	401 105 0405	MT-GLAZE 100 JA 1/16W	R6852	401 105 5202	MT-GLAZE 470 JA 1/16W
R3878	401 105 0405	MT-GLAZE 100 JA 1/16W	R6853	401 105 5202	MT-GLAZE 470 JA 1/16W
R3882	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6854	401 105 5202	MT-GLAZE 470 JA 1/16W
R3883	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6855	401 105 5202	MT-GLAZE 470 JA 1/16W
R3884	401 105 0405	MT-GLAZE 100 JA 1/16W	R6856	401 105 5202	MT-GLAZE 470 JA 1/16W
R3885	401 105 0405	MT-GLAZE 100 JA 1/16W	R6857	401 105 5202	MT-GLAZE 470 JA 1/16W
COIL			R6858	401 105 5202	MT-GLAZE 470 JA 1/16W
L3851	645 014 2659	FILTER,EMI 10MHZ	R6861	401 105 0405	MT-GLAZE 100 JA 1/16W
L3852	645 014 2659	FILTER,EMI 10MHZ	R6862	401 105 2805	MT-GLAZE 2.2K JA 1/16W
L3853	645 014 2659	FILTER,EMI 10MHZ	R6863	401 105 0405	MT-GLAZE 100 JA 1/16W
L3854	645 014 2659	FILTER,EMI 10MHZ	R6864	401 105 2805	MT-GLAZE 2.2K JA 1/16W
L3855	645 014 2659	FILTER,EMI 10MHZ	R6865	401 105 0405	MT-GLAZE 100 JA 1/16W
L3856	645 014 2659	FILTER,EMI 10MHZ	R6866	401 105 2805	MT-GLAZE 2.2K JA 1/16W
L3857	645 026 1008	INDUCTOR,3.3U M	R6867	401 105 0405	MT-GLAZE 100 JA 1/16W
L3858	645 014 2659	FILTER,EMI 10MHZ	R6868	401 105 2805	MT-GLAZE 2.2K JA 1/16W
L3859	645 014 2659	FILTER,EMI 10MHZ	DIODE		
DIODE			D6851	407 196 9907	LED SEL4828A
D3851	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6851A	610 290 9340	HOLDER LED A-MV6A
D3852	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6852	407 196 9709	LED SEL4228C
D3853	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6853	407 196 9808	LED SEL4428E
D3854	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6854	407 196 9709	LED SEL4228C
D3855	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6855	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
D3856	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6856	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
D3857	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6857	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
D3858	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6858	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
D3859	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	D6859	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
D3861	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	MISCELLANEOUS		
D3862	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)	K68B	645 005 8387	PLUG,6P
D3863	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3866	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)			
D3867	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)			
D3868	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)			
D3869	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3871	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3872	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3873	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3874	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)			
D3875	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)			
D3876	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3877	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3878	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3879	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3881	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3882	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3883	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
D3884	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)			
MISCELLANEOUS					
IC3802	408 016 8803	PC PC113 (VDE0884)			
K38A	645 027 8778	PLUG,D-SUB 9P			
K38B	645 027 8778	PLUG,D-SUB 9P			
K38C	645 028 0382	SOCKET,USB 4P			
K38D	645 000 2571	JACK,PHONE D8.0			
K38DA	610 266 0				

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
Q8071	405 014 4509	TR 2SC2412K T146 R	C8038	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C8043	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C8044	403 266 8108	NP-ELECT 1U M 50V
	405 015 8902	TR 2SC2812-L7-TB	C8045	403 308 2101	CERAMIC 0.056U K 16V
	405 163 1602	TR 2SC2812N-L6-TB0	C8046	403 215 2904	CERAMIC 0.022U K 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C8047	403 157 6909	CERAMIC 820P K 50V
Q8081	405 014 4509	TR 2SC2412K T146 R	C8048	403 215 2201	CERAMIC 0.01U K 50V
	405 014 4608	TR 2SC2412K T146 S	C8049	403 162 6208	ELECT 1U M 50V
	405 015 8704	TR 2SC2812-L6-TB	C8050	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C8052	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C8053	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1701	TR 2SC2812N-L7-TB0	C8061	403 164 0204	CERAMIC 0.1U Z 25V
Q8091	405 014 4509	TR 2SC2412K T146 R	C8063	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C8064	403 157 1904	CERAMIC 10P D 50V
	405 015 8704	TR 2SC2812-L6-TB	C8065	403 157 3106	CERAMIC 56P J 50V
	405 015 8902	TR 2SC2812-L7-TB	C8070	403 280 0508	ELECT 470U M 4V
	405 163 1602	TR 2SC2812N-L6-TB0	C8072	403 157 1904	CERAMIC 10P D 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C8073	403 164 0204	CERAMIC 0.1U Z 25V
Q8101	405 014 4509	TR 2SC2412K T146 R	C8075	403 157 3106	CERAMIC 56P J 50V
	405 014 4608	TR 2SC2412K T146 S	C8076	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C8077	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C8079	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C8082	403 157 1904	CERAMIC 10P D 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C8085	403 157 3106	CERAMIC 56P J 50V
Q8102	405 014 4509	TR 2SC2412K T146 R	C8086	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C8088	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C8090	403 347 5507	POS-SOLID 470U M 4V
	405 015 8902	TR 2SC2812-L7-TB	C8091	403 162 4709	ELECT 10U M 16V
	405 163 1602	TR 2SC2812N-L6-TB0	C8092	403 162 4709	ELECT 10U M 16V
	405 163 1701	TR 2SC2812N-L7-TB0	C8093	403 155 1500	CERAMIC 180P J 50V
INTEGRATED CIRCUIT			C8094	403 146 0505	CERAMIC 1200P K 50V
IC8001	410 365 2203	IC SII161ACT100	C8096	403 347 5507	POS-SOLID 470U M 4V
IC8015	409 462 2308	IC TC7SZ04FU-TE852	C8101	403 162 4709	ELECT 10U M 16V
IC8016	409 462 2308	IC TC7SZ04FU-TE852	C8102	403 162 4709	ELECT 10U M 16V
IC8017	409 462 2308	IC TC7SZ04FU-TE852	C8132	403 283 6309	CERAMIC 1U Z 10V
IC8020	410 391 2109	IC TC74VCX374FT(EL)	C8133	403 164 0204	CERAMIC 0.1U Z 25V
IC8021	409 484 2003	IC BA7078AF-E2	C8141	403 175 4505	ELECT 47U M 6.3V
IC8031	410 343 7008	IC SN74AHCT1G14DBVR	C8142	403 162 6208	ELECT 1U M 50V
IC8032	410 343 7008	IC SN74AHCT1G14DBVR	C8143	403 162 6208	ELECT 1U M 50V
IC8033	410 343 7008	IC SN74AHCT1G14DBVR	C8144	403 162 6208	ELECT 1U M 50V
IC8041	409 441 8406	IC LA7217M-T-TRM	C8145	403 162 6208	ELECT 1U M 50V
IC8051	409 445 7306	IC QS3125QX	C8151	403 162 6208	ELECT 1U M 50V
IC8061	409 429 6400	IC AD8055ART	C8152	403 164 0204	CERAMIC 0.1U Z 25V
IC8062	409 429 6400	IC AD8055ART	C8153	403 280 0805	ELECT 330U M 6.3V
IC8063	409 429 6400	IC AD8055ART	C8154	403 164 0204	CERAMIC 0.1U Z 25V
IC8064	410 343 7008	IC SN74AHCT1G14DBVR	C8156	403 164 0204	CERAMIC 0.1U Z 25V
IC8065	410 343 7008	IC SN74AHCT1G14DBVR	C8157	403 175 4505	ELECT 47U M 6.3V
IC8071	410 401 7506	IC TC74VCX16374FT	C8158	403 164 0204	CERAMIC 0.1U Z 25V
IC8072	410 401 7506	IC TC74VCX16374FT	C8171	403 280 0805	ELECT 330U M 6.3V
IC8073	410 401 7506	IC TC74VCX16374FT	C8172	403 164 0204	CERAMIC 0.1U Z 25V
IC8141	409 380 6303	IC HIN232CB	C8175	403 164 0204	CERAMIC 0.1U Z 25V
	409 273 3501	IC SP232ACT	C8176	403 280 0805	ELECT 330U M 6.3V
IC8151	410 296 5700	IC TWM7000-151020	C8177	403 164 0204	CERAMIC 0.1U Z 25V
IC8152	410 275 5707	IC TWM7000-162020	C8178	403 280 0805	ELECT 330U M 6.3V
	410 275 5806	IC TWM7000-162020	C8181	403 164 0204	CERAMIC 0.1U Z 25V
IC8171	409 395 5902	IC TC7SH00FU-(TE85L)	C8182	403 164 0204	CERAMIC 0.1U Z 25V
IC8172	409 416 6505	IC BA05FP-E2	C8190	403 164 0204	CERAMIC 0.1U Z 25V
IC8181	409 404 6302	IC M62320FP	C8191	403 205 2808	CERAMIC 0.047U K 25V
IC8182	409 404 6302	IC M62320FP	C8192	403 113 3805	CERAMIC 1000P K 50V
IC8191	409 505 6102	IC MD1222N	C8193	403 358 1307	ELECT 330U M 25V
IC8193	409 487 5803	IC 24C01CT/SN	C8194	403 215 2201	CERAMIC 0.01U K 50V
IC8194	409 434 8109	IC TC4053BFT-(EL)	C8195	403 358 1307	ELECT 330U M 25V
CAPACITOR			C8196	403 164 0204	CERAMIC 0.1U Z 25V
C8002	403 164 0204	CERAMIC 0.1U Z 25V	C8197	403 164 0204	CERAMIC 0.1U Z 25V
C8003	403 280 0508	ELECT 470U M 4V	C8198	403 113 3805	CERAMIC 1000P K 50V
C8004	403 164 0204	CERAMIC 0.1U Z 25V	RESISTOR		
C8005	403 157 3601	CERAMIC 100P J 50V	RB8001	645 028 0696	R-NETWORK 100X4 1/32W
C8006	403 157 3601	CERAMIC 100P J 50V	RB8002	645 028 0696	R-NETWORK 100X4 1/32W
C8007	403 157 3601	CERAMIC 100P J 50V	RB8003	645 028 0696	R-NETWORK 100X4 1/32W
C8008	403 157 3601	CERAMIC 100P J 50V	RB8004	645 028 0696	R-NETWORK 100X4 1/32W
C8009	403 164 0204	CERAMIC 0.1U Z 25V	RB8005	645 028 0696	R-NETWORK 100X4 1/32W
C8010	403 164 0204	CERAMIC 0.1U Z 25V	RB8006	645 028 0696	R-NETWORK 100X4 1/32W
C8012	403 157 3601	CERAMIC 100P J 50V	RB8007	645 028 0696	R-NETWORK 100X4 1/32W
C8013	403 280 0508	ELECT 470U M 4V	RB8008	645 028 0696	R-NETWORK 100X4 1/32W
C8014	403 164 0204	CERAMIC 0.1U Z 25V	RB8009	645 028 0696	R-NETWORK 100X4 1/32W
C8015	403 155 1500	CERAMIC 180P J 50V	RB8010	645 028 0696	R-NETWORK 100X4 1/32W
C8016	403 169 2807	CERAMIC 330P J 50V	RB8011	645 028 0696	R-NETWORK 100X4 1/32W
C8017	403 169 2807	CERAMIC 330P J 50V	RB8012	645 028 0696	R-NETWORK 100X4 1/32W
C8018	403 155 1500	CERAMIC 180P J 50V	RB8013	645 028 0696	R-NETWORK 100X4 1/32W
C8019	403 169 2807	CERAMIC 330P J 50V	RB8014	645 028 0696	R-NETWORK 100X4 1/32W
C8021	403 169 2807	CERAMIC 330P J 50V	RB8015	645 028 0696	R-NETWORK 100X4 1/32W
C8022	403 155 1500	CERAMIC 180P J 50V	RB8016	645 028 0696	R-NETWORK 100X4 1/32W
C8023	403 164 0204	CERAMIC 0.1U Z 25V	RB8021	645 028 0696	R-NETWORK 100X4 1/32W
C8024	403 280 0508	ELECT 470U M 4V	RB8022	645 028 0696	R-NETWORK 100X4 1/32W
C8025	403 169 2807	CERAMIC 330P J 50V	RB8023	645 028 0696	R-NETWORK 100X4 1/32W
C8026	403 267 0606	NP-ELECT 4.7U M 16V	RB8024	645 028 0696	R-NETWORK 100X4 1/32W
C8028	403 266 6807	NP-ELECT 0.1U M 50V	RB8031	645 028 0696	R-NETWORK 100X4 1/32W
C8029	403 162 6208	ELECT 1U M 50V	RB8032	645 028 0696	R-NETWORK 100X4 1/32W
C8030	403 164 0204	CERAMIC 0.1U Z 25V	RB8033	645 028 0696	R-NETWORK 100X4 1/32W
C8032	403 266 8108	NP-ELECT 1U M 50V	RB8034	645 028 0696	R-NETWORK 100X4 1/32W
C8033	403 162 6604	ELECT 2.2U M 50V	RB8131	645 026 8014	R-NETWORK 10KX4 1/16W
C8034	403 162 6208	ELECT 1U M 50V	R8001	401 105 5905	MT-GLAZE 560 JA 1/16W
C8035	403 157 3601	CERAMIC 100P J 50V	R8002	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C8036	403 164 0204	CERAMIC 0.1U Z 25V	R8003	401 105 4205	MT-GLAZE 33K JA 1/16W
C8037	403 280 0805	ELECT 330U M 6.3V	R8004	401 105 4205	MT-GLAZE 33K JA 1/16W

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R8005	401 105 4205	MT-GLAZE 33K JA 1/16W	R8151	401 105 0603	MT-GLAZE 10K JA 1/16W
R8006	401 105 4205	MT-GLAZE 33K JA 1/16W	R8152	401 105 0603	MT-GLAZE 10K JA 1/16W
R8007	401 105 4205	MT-GLAZE 33K JA 1/16W	R8153	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8008	401 105 4205	MT-GLAZE 33K JA 1/16W	R8154	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8009	401 105 4205	MT-GLAZE 33K JA 1/16W	R8155	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8010	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8156	401 105 0603	MT-GLAZE 10K JA 1/16W
R8011	401 105 0405	MT-GLAZE 100 JA 1/16W	R8157	401 105 0603	MT-GLAZE 10K JA 1/16W
R8012	401 113 6406	MT-GLAZE 5.1K JA 1/16W	R8158	401 105 0405	MT-GLAZE 100 JA 1/16W
R8013	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8159	401 105 0603	MT-GLAZE 10K JA 1/16W
R8014	401 105 5103	MT-GLAZE 47 JA 1/16W	R8161	401 105 0603	MT-GLAZE 10K JA 1/16W
R8015	401 105 5103	MT-GLAZE 47 JA 1/16W	R8162	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R8017	401 105 5103	MT-GLAZE 47 JA 1/16W	R8171	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8018	401 105 5103	MT-GLAZE 47 JA 1/16W	R8172	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8019	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8173	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8021	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8177	401 105 0405	MT-GLAZE 100 JA 1/16W
R8025	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8179	401 105 0603	MT-GLAZE 10K JA 1/16W
R8028	401 105 0405	MT-GLAZE 100 JA 1/16W	R8180	401 113 6406	MT-GLAZE 5.1K JA 1/16W
R8029	401 105 8005	MT-GLAZE 1M JA 1/16W	R8183	401 105 0603	MT-GLAZE 10K JA 1/16W
R8030	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8184	401 105 0603	MT-GLAZE 10K JA 1/16W
R8031	401 105 4601	MT-GLAZE 3.9K JA 1/16W	R8185	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8032	401 105 0405	MT-GLAZE 100 JA 1/16W	R8187	401 257 7000	MT-GLAZE 820 FA 1/16W
R8033	401 105 0405	MT-GLAZE 100 JA 1/16W	R8188	401 218 4505	MT-GLAZE 2.2K FA 1/16W
R8034	401 105 0405	MT-GLAZE 100 JA 1/16W	R8189	401 105 0603	MT-GLAZE 10K JA 1/16W
R8035	401 105 0405	MT-GLAZE 100 JA 1/16W	R8190	401 105 0405	MT-GLAZE 100 JA 1/16W
R8036	401 105 0405	MT-GLAZE 100 JA 1/16W	R8191	401 105 0405	MT-GLAZE 100 JA 1/16W
R8037	401 105 0405	MT-GLAZE 100 JA 1/16W	R8192	401 105 0603	MT-GLAZE 10K JA 1/16W
R8039	401 105 8005	MT-GLAZE 1M JA 1/16W	R8193	401 105 0603	MT-GLAZE 10K JA 1/16W
R8040	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R8194	401 290 1508	MT-GLAZE 0.1 JE 1/2W
R8042	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8195	401 105 0405	MT-GLAZE 100 JA 1/16W
R8043	401 105 0504	MT-GLAZE 1K JA 1/16W	R8196	401 105 0405	MT-GLAZE 100 JA 1/16W
R8044	401 105 0504	MT-GLAZE 1K JA 1/16W	R8197	401 105 8005	MT-GLAZE 1M JA 1/16W
R8045	401 105 1709	MT-GLAZE 150K JA 1/16W	R8198	401 105 0702	MT-GLAZE 100K JA 1/16W
R8046	401 105 0405	MT-GLAZE 100 JA 1/16W	R8199	401 105 0603	MT-GLAZE 10K JA 1/16W
R8048	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TRANSFORMER		
R8049	401 105 5905	MT-GLAZE 560 JA 1/16W	TE8001	645 036 5010	TERMINAL
R8050	401 105 4601	MT-GLAZE 3.9K JA 1/16W	TE8101	645 036 5010	TERMINAL
R8051	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	COIL		
R8052	401 105 5103	MT-GLAZE 47 JA 1/16W	L8001	645 026 1008	INDUCTOR, 3.3U M
R8053	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L8002	645 026 1008	INDUCTOR, 3.3U M
R8054	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L8003	645 026 1008	INDUCTOR, 3.3U M
R8056	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L8088	645 014 2659	FILTER, EMI 10MHZ
R8057	401 105 0603	MT-GLAZE 10K JA 1/16W	L8089	645 026 1008	INDUCTOR, 3.3U M
R8058	401 105 4205	MT-GLAZE 33K JA 1/16W	L8101	645 014 2659	FILTER, EMI 10MHZ
R8059	401 105 0603	MT-GLAZE 10K JA 1/16W	L8102	645 014 2659	FILTER, EMI 10MHZ
R8060	401 105 0603	MT-GLAZE 10K JA 1/16W	L8121	645 014 2659	FILTER, EMI 10MHZ
R8061	401 113 4402	MT-GLAZE 75 JA 1/16W	L8122	645 014 2659	FILTER, EMI 10MHZ
R8063	401 105 4502	MT-GLAZE 390 JA 1/16W	L8123	645 014 2659	FILTER, EMI 10MHZ
R8064	401 105 0504	MT-GLAZE 1K JA 1/16W	L8124	645 014 2659	FILTER, EMI 10MHZ
R8066	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L8125	645 014 2659	FILTER, EMI 10MHZ
R8067	401 105 0603	MT-GLAZE 10K JA 1/16W	L8126	645 014 2659	FILTER, EMI 10MHZ
R8071	401 113 4402	MT-GLAZE 75 JA 1/16W	L8141	645 014 2659	FILTER, EMI 10MHZ
R8073	401 105 4502	MT-GLAZE 390 JA 1/16W	L8191	645 037 7396	INDUCTOR, 22U M
R8075	401 105 0504	MT-GLAZE 1K JA 1/16W	DIODE		
R8076	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8061	407 209 1201	ZD UDZS-TE-176.2B
R8077	401 105 0603	MT-GLAZE 10K JA 1/16W	D8062	407 209 1201	ZD UDZS-TE-176.2B
R8078	401 105 0702	MT-GLAZE 100K JA 1/16W	D8071	407 209 1201	ZD UDZS-TE-176.2B
R8079	401 105 0702	MT-GLAZE 100K JA 1/16W	D8072	407 209 1201	ZD UDZS-TE-176.2B
R8081	401 113 4402	MT-GLAZE 75 JA 1/16W	D8081	407 209 1201	ZD UDZS-TE-176.2B
R8083	401 105 4502	MT-GLAZE 390 JA 1/16W	D8082	407 209 1201	ZD UDZS-TE-176.2B
R8085	401 105 0504	MT-GLAZE 1K JA 1/16W	D8088	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8086	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8091	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8087	401 105 0603	MT-GLAZE 10K JA 1/16W	D8092	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8088	645 048 4711	PROTECTOR, IC 0.75A 6V	D8093	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8090	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8094	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8091	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8095	407 149 0807	DIODE 1SS355-TE-17
R8092	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8096	407 149 0807	DIODE 1SS355-TE-17
R8093	401 105 0504	MT-GLAZE 1K JA 1/16W	D8101	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8094	401 105 0603	MT-GLAZE 10K JA 1/16W	D8102	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8095	401 105 5103	MT-GLAZE 47 JA 1/16W	D8103	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8096	401 105 5103	MT-GLAZE 47 JA 1/16W	D8104	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8097	401 105 5103	MT-GLAZE 47 JA 1/16W	D8121	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8098	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8122	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8101	401 105 5509	MT-GLAZE 470K JA 1/16W	D8123	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8102	401 105 5509	MT-GLAZE 470K JA 1/16W	D8124	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8103	401 105 0405	MT-GLAZE 100 JA 1/16W	D8125	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8104	401 105 0405	MT-GLAZE 100 JA 1/16W	D8126	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8105	401 105 3000	MT-GLAZE 220K JA 1/16W	D8127	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8106	401 105 3000	MT-GLAZE 220K JA 1/16W	D8128	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8107	401 105 3000	MT-GLAZE 220K JA 1/16W	D8141	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8108	401 105 3000	MT-GLAZE 220K JA 1/16W	D8142	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R8109	401 105 0405	MT-GLAZE 100 JA 1/16W	D8175	407 149 0807	DIODE 1SS355-TE-17
R8111	401 105 2805	MT-GLAZE 2.2K JA 1/16W	D8176	407 149 0807	DIODE 1SS355-TE-17
R8112	401 105 0405	MT-GLAZE 100 JA 1/16W	D8191	407 201 2701	DIODE RB051L-40-TE25
R8113	401 105 2805	MT-GLAZE 2.2K JA 1/16W	D8192	407 201 2701	DIODE RB051L-40-TE25
R8114	401 105 0405	MT-GLAZE 100 JA 1/16W	D8193	407 149 0807	DIODE 1SS355-TE-17
R8115	401 105 0405	MT-GLAZE 100 JA 1/16W	D8194	407 201 2701	DIODE RB051L-40-TE25
R8121	401 105 0603	MT-GLAZE 10K JA 1/16W	D8195	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8122	401 105 4205	MT-GLAZE 33K JA 1/16W	D8196	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8131	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8197	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8132	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D8198	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8133	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	MISCELLANEOUS		
R8134	401 105 0603	MT-GLAZE 10K JA 1/16W	TP80B	645 036 5010	TERMINAL
R8135	401 105 0603	MT-GLAZE 10K JA 1/16W	TP80G	645 036 5010	TERMINAL
R8136	401 105 0603	MT-GLAZE 10K JA 1/16W	TP80H	645 036 5010	TERMINAL
R8145	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TP80R	645 036 5010	TERMINAL

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
TP80V	645 036 5010	TERMINAL	405 015 8704	TR	2SC2812-L6-TB
K80A	645 048 4643	SOCKET, DVI 29P	405 015 8902	TR	2SC2812-L7-TB
K80A1	412 062 1909	SPECIAL SCREW	405 163 1602	TR	2SC2812N-L6-TB0
K80A2	412 062 1909	SPECIAL SCREW	405 163 1701	TR	2SC2812N-L7-TB0
K80H	645 041 6071	SOCKET, I/O 176P	INTEGRATED CIRCUIT		
K80H1	610 289 9795	JOINT GUIDE BUSH ML6A	IC1001	409 461 7304	IC AD8057ART
K80H2	610 289 9795	JOINT GUIDE BUSH ML6A	IC1002	409 461 7304	IC AD8057ART
K81A	645 040 9974	JACK, RCA-2	IC1003	409 461 7304	IC AD8057ART
K81B	645 041 1076	SOCKET, DIN 8P	IC1004	410 343 7008	IC SN74AHCT1G14DBVR
X8041	645 006 3459	OSC, CERAMIC 500.0KHZ	IC1005	410 343 7008	IC SN74AHCT1G14DBVR
X8151	645 021 1218	OSC, CERAMIC 8.00MHZ	IC1051	409 484 2003	IC BA7078AF-E2
	645 037 5187	OSC, CERAMIC 8.00MHZ	IC1052	410 343 7008	IC SN74AHCT1G14DBVR
X8152	645 021 1218	OSC, CERAMIC 8.00MHZ	IC1053	410 343 7008	IC SN74AHCT1G14DBVR
	645 037 5187	OSC, CERAMIC 8.00MHZ	IC1061	409 502 8703	IC TA1318N

610 292 1618 ASSY,PWB,COMPONENT MV6A					
TRANSISTOR					
Q1011	405 014 4509	TR 2SC2412K T146 R	IC2001	409 449 2802	IC AN5393FBQ
	405 014 4608	TR 2SC2412K T146 S	IC2041	409 461 7809	IC PQ20WZ11
	405 015 8704	TR 2SC2812-L6-TB	IC2061	409 051 2900	IC TC4053BF(EL)
	405 015 8902	TR 2SC2812-L7-TB	IC2071	409 470 2604	IC AD8183ARU
	405 163 1602	TR 2SC2812N-L6-TB0	IC2081	409 404 6302	IC M62320FP
	405 163 1701	TR 2SC2812N-L7-TB0	IC2082	409 463 7500	IC 24LC02BT/SN-T
Q1015	405 014 4509	TR 2SC2412K T146 R		409 417 5507	IC 24LC04BT/SN
	405 014 4608	TR 2SC2412K T146 S	IC3031	409 380 6303	IC HIN232CB
	405 015 8704	TR 2SC2812-L6-TB		409 273 3501	IC SP232ACT
	405 015 8902	TR 2SC2812-L7-TB	IC3051	410 296 5700	IC TWM7000-151020
	405 163 1602	TR 2SC2812N-L6-TB0	IC3061	410 275 5707	IC TWM7000-162020
	405 163 1701	TR 2SC2812N-L7-TB0		410 275 5806	IC TWM7000-162020
Q1061	405 014 4509	TR 2SC2412K T146 R	IC3071	409 416 6505	IC BA05FP-E2
	405 014 4608	TR 2SC2412K T146 S	IC3081	409 461 7304	IC AD8057ART
	405 015 8704	TR 2SC2812-L6-TB	IC3082	409 461 7304	IC AD8057ART
	405 015 8902	TR 2SC2812-L7-TB	IC3083	409 461 7304	IC AD8057ART
	405 163 1602	TR 2SC2812N-L6-TB0	IC3091	409 395 5902	IC TC7SH00FU-(TE85L)
	405 163 1701	TR 2SC2812N-L7-TB0	CAPACITOR		
Q1091	405 014 4509	TR 2SC2412K T146 R	C1001	403 267 0606	NP-ELECT 4.7U M 16V
	405 014 4608	TR 2SC2412K T146 S	C1002	403 267 0606	NP-ELECT 4.7U M 16V
	405 015 8704	TR 2SC2812-L6-TB	C1003	403 155 1500	CERAMIC 180P J 50V
	405 015 8902	TR 2SC2812-L7-TB	C1004	403 146 0505	CERAMIC 1200P K 50V
	405 163 1602	TR 2SC2812N-L6-TB0	C1005	403 157 1508	CERAMIC 3P C 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C1006	403 157 1904	CERAMIC 10P D 50V
Q1091	405 014 4509	TR 2SC2412K T146 R	C1007	403 157 1508	CERAMIC 3P C 50V
	405 014 4608	TR 2SC2412K T146 S	C1008	403 157 1904	CERAMIC 10P D 50V
	405 015 8704	TR 2SC2812-L6-TB	C1009	403 157 1508	CERAMIC 3P C 50V
	405 015 8902	TR 2SC2812-L7-TB	C1010	403 351 1106	POS-SOLID 47U M 16V
	405 163 1602	TR 2SC2812N-L6-TB0	C1011	403 157 1904	CERAMIC 10P D 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C1012	403 280 0805	ELECT 330U M 6.3V
Q2061	405 014 4509	TR 2SC2412K T146 R	C1013	403 164 0204	CERAMIC 0.1U Z 25V
	405 014 4608	TR 2SC2412K T146 S	C1014	403 280 0805	ELECT 330U M 6.3V
	405 015 8704	TR 2SC2812-L6-TB	C1015	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C1041	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C1051	403 267 0606	NP-ELECT 4.7U M 16V
	405 163 1701	TR 2SC2812N-L7-TB0	C1052	403 266 6807	NP-ELECT 0.1U M 50V
Q2062	405 134 5905	TR 2SA1037AK-T146-R	C1053	403 162 6208	ELECT 1U M 50V
	405 147 2205	TR 2SA1037AK-S-T146	C1054	403 266 8108	NP-ELECT 1U M 50V
	405 002 0308	TR 2SA1037K T146 R	C1055	403 162 6604	ELECT 2.2U M 50V
	405 002 0407	TR 2SA1037K T146 S	C1056	403 162 6208	ELECT 1U M 50V
	405 002 6706	TR 2SA1179-M6-TB	C1057	403 157 3601	CERAMIC 100P J 50V
	405 002 6904	TR 2SA1179-M7-TB	C1058	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1503	TR 2SA1179N-M6-TB	C1059	403 280 0805	ELECT 330U M 6.3V
	405 163 2708	TR 2SA1179N-M7-TB	C1063	403 162 6604	ELECT 2.2U M 50V
Q2063	405 014 4509	TR 2SC2412K T146 R	C1064	403 215 2201	CERAMIC 0.01U K 50V
	405 014 4608	TR 2SC2412K T146 S	C1065	403 229 3508	ELECT 100U M 16V
	405 015 8704	TR 2SC2812-L6-TB	C1066	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8902	TR 2SC2812-L7-TB	C1069	403 162 6208	ELECT 1U M 50V
	405 163 1602	TR 2SC2812N-L6-TB0	C1071	403 162 6208	ELECT 1U M 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C1072	403 280 1604	ELECT 220U M 16V
Q2071	405 014 4509	TR 2SC2412K T146 R	C2004	403 283 6309	CERAMIC 1U Z 10V
	405 014 4608	TR 2SC2412K T146 S	C2005	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8704	TR 2SC2812-L6-TB	C2006	403 149 9208	CERAMIC 0.01U Z 50V
	405 015 8902	TR 2SC2812-L7-TB	C2007	403 283 6309	CERAMIC 1U Z 10V
	405 163 1602	TR 2SC2812N-L6-TB0	C2008	403 149 9208	CERAMIC 0.01U Z 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C2009	403 283 6309	CERAMIC 1U Z 10V
Q2072	405 014 4509	TR 2SC2412K T146 R	C2011	403 157 1904	CERAMIC 10P D 50V
	405 014 4608	TR 2SC2412K T146 S	C2012	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8704	TR 2SC2812-L6-TB	C2014	403 157 1904	CERAMIC 10P D 50V
	405 015 8902	TR 2SC2812-L7-TB	C2015	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C2017	403 157 1904	CERAMIC 10P D 50V
	405 163 1701	TR 2SC2812N-L7-TB0	C2018	403 164 0204	CERAMIC 0.1U Z 25V
Q2073	405 014 4509	TR 2SC2412K T146 R	C2019	403 280 1604	ELECT 220U M 16V
	405 014 4608	TR 2SC2412K T146 S	C2021	403 162 4709	ELECT 10U M 16V
	405 015 8704	TR 2SC2812-L6-TB	C2022	403 164 0204	CERAMIC 0.1U Z 25V
	405 015 8902	TR 2SC2812-L7-TB	C2023	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
	405 163 1602	TR 2SC2812N-L6-TB0	C2024	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
	405 163 1701	TR 2SC2812N-L7-TB0	C2025	403 215 2201	CERAMIC 0.01U K 50V
Q2081	405 014 4509	TR 2SC2412K T146 R	C2026	403 215 2201	CERAMIC 0.01U K 50V
	405 014 4608	TR 2SC2412K T146 S	C2027	403 215 2201	CERAMIC 0.01U K 50V
	405 015 8704	TR 2SC2812-L6-TB	C2028	403 283 6309	CERAMIC 1U Z 10V
	405 015 8902	TR 2SC2812-L7-TB	C2029	403 283 6309	CERAMIC 1U Z 10V
	405 163 1602	TR 2SC2812N-L6-TB0	C2030	403 280 1604	ELECT 220U M 16V
	405 163 1701	TR 2SC2812N-L7-TB0	C2031	403 283 6309	CERAMIC 1U Z 10V
Q3011	405 014 4509	TR 2SC2412K T146 R	C2032	403 162 4709	ELECT 10U M 16V
	405 014 4608	TR 2SC2412K T146 S	C2033	403 175 4109	ELECT 22U M 16V
	405 015 8704	TR 2SC2812-L6-TB	C2034	403 162 5300	ELECT 4.7U M 25V
	405 015 8902	TR 2SC2812-L7-TB	C2037	403 164 0204	CERAMIC 0.1U Z 25V
	405 163 1602	TR 2SC2812N-L6-TB0	C2038	403 280 1604	ELECT 220U M 16V
	405 163 1701	TR 2SC2812N-L7-TB0	C2039	403 215 2201	CERAMIC 0.01U K 50V
Q3015	405 014 4509	TR 2SC2412K T146 R	C2040	403 280 1604	ELECT 220U M 16V
	405 014 4608	TR 2SC2412K T146 S			

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C2041	403 215 2201	CERAMIC 0.01U K 50V	R1038	401 105 0702	MT-GLAZE 100K JA 1/16W
C2042	403 215 2201	CERAMIC 0.01U K 50V	R1046	401 105 0405	MT-GLAZE 100 JA 1/16W
C2043	403 215 2201	CERAMIC 0.01U K 50V	R1051	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C2044	403 280 0805	ELECT 330U M 6.3V	R1053	401 105 8005	MT-GLAZE 1M JA 1/16W
C2045	403 164 0204	CERAMIC 0.1U Z 25V	R1054	401 105 4601	MT-GLAZE 3.9K JA 1/16W
C2046	403 266 8108	NP-ELECT 1U M 50V	R1055	401 105 0405	MT-GLAZE 100 JA 1/16W
C2047	403 266 8108	NP-ELECT 1U M 50V	R1056	401 105 0405	MT-GLAZE 100 JA 1/16W
C2048	403 266 8108	NP-ELECT 1U M 50V	R1058	401 105 0603	MT-GLAZE 10K JA 1/16W
C2049	403 215 2201	CERAMIC 0.01U K 50V	R1059	401 105 0405	MT-GLAZE 100 JA 1/16W
C2051	403 215 2201	CERAMIC 0.01U K 50V	R1061	401 105 0405	MT-GLAZE 100 JA 1/16W
C2052	403 215 2201	CERAMIC 0.01U K 50V	R1062	401 105 0405	MT-GLAZE 100 JA 1/16W
C2053	403 164 0204	CERAMIC 0.1U Z 25V	R1063	401 113 6604	MT-GLAZE 7.5K JA 1/16W
C2054	403 215 2201	CERAMIC 0.01U K 50V	R1064	401 113 5201	MT-GLAZE 360 JA 1/16W
C2055	403 215 2201	CERAMIC 0.01U K 50V	R1065	401 105 0405	MT-GLAZE 100 JA 1/16W
C2056	403 215 2201	CERAMIC 0.01U K 50V	R1066	401 105 0405	MT-GLAZE 100 JA 1/16W
C2057	403 157 6602	CERAMIC 470P K 50V	R1067	401 105 0405	MT-GLAZE 100 JA 1/16W
C2058	403 175 4505	ELECT 47U M 6.3V	R1068	401 105 0603	MT-GLAZE 10K JA 1/16W
C2061	403 283 6309	CERAMIC 1U Z 10V	R1069	401 105 0405	MT-GLAZE 100 JA 1/16W
C2062	403 283 6309	CERAMIC 1U Z 10V	R1070	401 105 3000	MT-GLAZE 220K JA 1/16W
C2063	403 205 2808	CERAMIC 0.047U K 25V	R1071	401 105 0405	MT-GLAZE 100 JA 1/16W
C2064	403 205 2808	CERAMIC 0.047U K 25V	R1072	401 105 3000	MT-GLAZE 220K JA 1/16W
C2065	403 283 6309	CERAMIC 1U Z 10V	R1073	401 105 0405	MT-GLAZE 100 JA 1/16W
C2066	403 280 1604	ELECT 220U M 16V	R1075	401 105 0603	MT-GLAZE 10K JA 1/16W
C2067	403 149 9208	CERAMIC 0.01U Z 50V	R1076	401 105 0405	MT-GLAZE 100 JA 1/16W
C2072	403 164 0204	CERAMIC 0.1U Z 25V	R1077	401 105 0405	MT-GLAZE 100 JA 1/16W
C2073	403 164 0204	CERAMIC 0.1U Z 25V	R1078	401 105 0405	MT-GLAZE 100 JA 1/16W
C2074	403 149 9208	CERAMIC 0.01U Z 50V	R1091	401 105 0603	MT-GLAZE 10K JA 1/16W
C2075	403 149 9208	CERAMIC 0.01U Z 50V	R1092	401 105 0603	MT-GLAZE 10K JA 1/16W
C2076	403 149 9208	CERAMIC 0.01U Z 50V	R1093	401 105 0603	MT-GLAZE 10K JA 1/16W
C2078	403 164 0204	CERAMIC 0.1U Z 25V	R1094	401 105 0603	MT-GLAZE 10K JA 1/16W
C2079	403 164 0204	CERAMIC 0.1U Z 25V	R2001	401 105 0405	MT-GLAZE 100 JA 1/16W
C2081	403 280 0607	ELECT 220U M 6.3V	R2002	401 105 0603	MT-GLAZE 10K JA 1/16W
C2082	403 149 9208	CERAMIC 0.01U Z 50V	R2003	401 105 0504	MT-GLAZE 1K JA 1/16W
C2083	403 149 9208	CERAMIC 0.01U Z 50V	R2004	401 105 0405	MT-GLAZE 100 JA 1/16W
C2085	403 149 9208	CERAMIC 0.01U Z 50V	R2005	401 105 0405	MT-GLAZE 100 JA 1/16W
C2086	403 280 0607	ELECT 220U M 6.3V	R2007	403 164 0204	CERAMIC 0.1U Z 25V
C2087	403 164 0204	CERAMIC 0.1U Z 25V	R2008	401 105 0504	MT-GLAZE 1K JA 1/16W
C2088	403 164 0204	CERAMIC 0.1U Z 25V	R2009	401 105 0504	MT-GLAZE 1K JA 1/16W
C2089	403 164 0204	CERAMIC 0.1U Z 25V	R2011	401 105 0405	MT-GLAZE 100 JA 1/16W
C2091	403 175 3300	ELECT 47U M 16V	R2012	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C2092	403 175 3300	ELECT 47U M 16V	R2013	401 105 1907	MT-GLAZE 180 JA 1/16W
C2093	403 175 3300	ELECT 47U M 16V	R2014	401 105 0405	MT-GLAZE 100 JA 1/16W
C3001	403 162 4709	ELECT 10U M 16V	R2015	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3002	403 162 4709	ELECT 10U M 16V	R2016	401 105 1907	MT-GLAZE 180 JA 1/16W
C3021	403 283 6309	CERAMIC 1U Z 10V	R2017	401 105 0405	MT-GLAZE 100 JA 1/16W
C3031	403 283 6309	CERAMIC 1U Z 10V	R2018	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3032	403 162 6208	ELECT 1U M 50V	R2019	401 105 1907	MT-GLAZE 180 JA 1/16W
C3033	403 162 6208	ELECT 1U M 50V	R2021	401 105 7404	MT-GLAZE 8.2K JA 1/16W
C3034	403 162 6208	ELECT 1U M 50V	R2022	401 105 4601	MT-GLAZE 3.9K JA 1/16W
C3035	403 162 6208	ELECT 1U M 50V	R2023	401 105 2102	MT-GLAZE 18K JA 1/16W
C3041	403 283 6309	CERAMIC 1U Z 10V	R2025	401 105 7503	MT-GLAZE 82K JA 1/16W
C3051	403 175 4505	ELECT 47U M 6.3V	R2026	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C3052	403 283 6309	CERAMIC 1U Z 10V	R2027	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C3053	403 162 6208	ELECT 1U M 50V	R2028	401 105 3406	MT-GLAZE 27K JA 1/16W
C3054	403 283 6309	CERAMIC 1U Z 10V	R2031	401 105 0603	MT-GLAZE 10K JA 1/16W
C3061	403 283 6309	CERAMIC 1U Z 10V	R2032	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3062	403 283 6309	CERAMIC 1U Z 10V	R2033	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3071	403 164 0204	CERAMIC 0.1U Z 25V	R2034	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3072	403 280 0805	ELECT 330U M 6.3V	R2035	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C3081	403 157 1508	CERAMIC 3P C 50V	R2042	401 113 5201	MT-GLAZE 360 JA 1/16W
C3082	403 157 1904	CERAMIC 10P D 50V	R2043	401 105 5301	MT-GLAZE 4.7K JA 1/16W
C3083	403 157 1508	CERAMIC 3P C 50V	R2044	401 105 2805	MT-GLAZE 2.2K JA 1/16W
C3084	403 157 1904	CERAMIC 10P D 50V	R2045	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
C3085	403 157 1508	CERAMIC 3P C 50V	R2046	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
C3086	403 157 1904	CERAMIC 10P D 50V	R2047	401 036 8907	MT-GLAZE 5.6 JA 1/8W
RESISTOR			R2050	401 105 0504	MT-GLAZE 1K JA 1/16W
RB3041	645 025 5380	R-NETWORK 10KX4 1/16W	R2060	401 105 0504	MT-GLAZE 1K JA 1/16W
	645 026 8014	R-NETWORK 10KX4 1/16W	R2061	401 105 0603	MT-GLAZE 10K JA 1/16W
R1001	401 226 1206	MT-GLAZE 150 FA 1/16W	R2062	401 105 4700	MT-GLAZE 39K JA 1/16W
R1002	401 226 1206	MT-GLAZE 150 FA 1/16W	R2063	401 105 0603	MT-GLAZE 10K JA 1/16W
R1003	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2064	401 105 4700	MT-GLAZE 39K JA 1/16W
R1004	401 226 1206	MT-GLAZE 150 FA 1/16W	R2065	401 158 4108	MT-GLAZE 4.7 JA 1/16W
R1005	401 226 1206	MT-GLAZE 150 FA 1/16W	R2066	401 105 0405	MT-GLAZE 100 JA 1/16W
R1006	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2067	401 158 4108	MT-GLAZE 4.7 JA 1/16W
R1007	401 226 1206	MT-GLAZE 150 FA 1/16W	R2068	401 105 4700	MT-GLAZE 39K JA 1/16W
R1008	401 226 1206	MT-GLAZE 150 FA 1/16W	R2069	401 105 0603	MT-GLAZE 10K JA 1/16W
R1009	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2070	401 105 0603	MT-GLAZE 10K JA 1/16W
R1010	401 113 4709	MT-GLAZE 130 JA 1/16W	R2071	401 105 0603	MT-GLAZE 10K JA 1/16W
R1011	401 113 4709	MT-GLAZE 130 JA 1/16W	R2072	401 105 0603	MT-GLAZE 10K JA 1/16W
R1012	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2073	401 105 0603	MT-GLAZE 10K JA 1/16W
R1014	401 105 0405	MT-GLAZE 100 JA 1/16W	R2074	401 105 0405	MT-GLAZE 100 JA 1/16W
R1015	401 113 4709	MT-GLAZE 130 JA 1/16W	R2075	401 105 0405	MT-GLAZE 100 JA 1/16W
R1016	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2076	401 105 0405	MT-GLAZE 100 JA 1/16W
R1018	401 105 0405	MT-GLAZE 100 JA 1/16W	R2077	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1019	401 113 4709	MT-GLAZE 130 JA 1/16W	R2078	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1022	401 105 4502	MT-GLAZE 390 JA 1/16W	R2079	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1024	401 105 0504	MT-GLAZE 1K JA 1/16W	R2081	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R1026	401 105 4502	MT-GLAZE 390 JA 1/16W	R2082	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1028	401 105 0504	MT-GLAZE 1K JA 1/16W	R2084	401 105 0405	MT-GLAZE 100 JA 1/16W
R1031	401 105 4502	MT-GLAZE 390 JA 1/16W	R2085	401 105 0405	MT-GLAZE 100 JA 1/16W
R1033	401 105 0504	MT-GLAZE 1K JA 1/16W	R2086	401 105 0405	MT-GLAZE 100 JA 1/16W
R1034	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2087	401 105 0405	MT-GLAZE 100 JA 1/16W
R1035	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2088	401 105 0603	MT-GLAZE 10K JA 1/16W
R1036	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2089	401 105 0603	MT-GLAZE 10K JA 1/16W
R1037	401 105 0702	MT-GLAZE 100K JA 1/16W	R2094	401 105 0603	MT-GLAZE 10K JA 1/16W

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R2095	401 105 0603	MT-GLAZE 10K JA 1/16W	D3013	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R2096	401 105 0603	MT-GLAZE 10K JA 1/16W	D3014	407 223 0501	ZENER DIODE 02DZ12Y(TPH3)
R2097	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D3015	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3)
R2098	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	MISCELLANEOUS		
R2099	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TP1001	645 036 5010	TERMINAL
R3001	401 105 5509	MT-GLAZE 470K JA 1/16W	TP1002	645 036 5010	TERMINAL
R3002	401 105 5509	MT-GLAZE 470K JA 1/16W	TP1003	645 036 5010	TERMINAL
R3003	401 105 0405	MT-GLAZE 100 JA 1/16W	TP2071	645 036 5010	TERMINAL
R3004	401 105 0405	MT-GLAZE 100 JA 1/16W	TP2072	645 036 5010	TERMINAL
R3006	401 105 2805	MT-GLAZE 2.2K JA 1/16W	TP2073	645 036 5010	TERMINAL
R3007	401 113 6604	MT-GLAZE 7.5K JA 1/16W	K10A	645 028 0412	SOCKET, BNC 5P
R3008	401 105 3000	MT-GLAZE 220K JA 1/16W	K10B	645 040 9974	JACK, RCA-2
R3009	401 105 3000	MT-GLAZE 220K JA 1/16W	K10C	645 041 1076	SOCKET, DIN 8P
R3011	401 105 3000	MT-GLAZE 220K JA 1/16W	K10H	645 041 6071	SOCKET, I/O 176P
R3012	401 105 0405	MT-GLAZE 100 JA 1/16W	K10H1	610 289 9795	JOINT GUIDE BUSH ML6A
R3013	401 105 2805	MT-GLAZE 2.2K JA 1/16W	K10H2	610 289 9795	JOINT GUIDE BUSH ML6A
R3014	401 105 0405	MT-GLAZE 100 JA 1/16W	X1061	645 046 9213	OSC, CERAMIC 503.0KHZ
R3015	401 105 3000	MT-GLAZE 220K JA 1/16W	X3051	645 021 1218	OSC, CERAMIC 8.00MHZ
R3016	401 105 0405	MT-GLAZE 100 JA 1/16W		645 037 5187	OSC, CERAMIC 8.00MHZ
R3017	401 105 2805	MT-GLAZE 2.2K JA 1/16W	X3061	645 021 1218	OSC, CERAMIC 8.00MHZ
R3018	401 105 0405	MT-GLAZE 100 JA 1/16W		645 037 5187	OSC, CERAMIC 8.00MHZ
R3021	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	*****		
R3022	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	ASSY PWB MAIN --- See page-93 ---		
R3031	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	*****		
R3045	401 105 0603	MT-GLAZE 10K JA 1/16W	TRANSISTOR		
R3046	401 105 0603	MT-GLAZE 10K JA 1/16W	Q1833	405 014 4509	TR 2SC2412K T146 R
R3047	401 105 0603	MT-GLAZE 10K JA 1/16W		405 014 4608	TR 2SC2412K T146 S
R3048	401 105 7909	MT-GLAZE 0.000 ZA 1/16W		405 015 8704	TR 2SC2812-L6-TB
R3051	401 105 0603	MT-GLAZE 10K JA 1/16W		405 015 8902	TR 2SC2812-L7-TB
R3052	401 105 0603	MT-GLAZE 10K JA 1/16W		405 163 1602	TR 2SC2812N-L6-TB0
R3053	401 105 7909	MT-GLAZE 0.000 ZA 1/16W		405 163 1701	TR 2SC2812N-L7-TB0
R3054	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	Q1834	405 014 4509	TR 2SC2412K T146 R
R3061	401 105 0603	MT-GLAZE 10K JA 1/16W		405 014 4608	TR 2SC2412K T146 S
R3062	401 105 0603	MT-GLAZE 10K JA 1/16W		405 015 8704	TR 2SC2812-L6-TB
R3063	401 105 0405	MT-GLAZE 100 JA 1/16W		405 015 8902	TR 2SC2812-L7-TB
R3064	401 105 0603	MT-GLAZE 10K JA 1/16W		405 163 1602	TR 2SC2812N-L6-TB0
R3065	401 105 0603	MT-GLAZE 10K JA 1/16W		405 163 1701	TR 2SC2812N-L7-TB0
R3066	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	Q1881	405 014 4509	TR 2SC2412K T146 R
R3072	401 035 4108	MT-GLAZE 0.000 ZA 1/8W		405 014 4608	TR 2SC2412K T146 S
R3081	401 105 4502	MT-GLAZE 390 JA 1/16W		405 015 8704	TR 2SC2812-L6-TB
R3083	401 105 0504	MT-GLAZE 1K JA 1/16W		405 015 8902	TR 2SC2812-L7-TB
R3084	401 105 4502	MT-GLAZE 390 JA 1/16W		405 163 1602	TR 2SC2812N-L6-TB0
R3086	401 105 0504	MT-GLAZE 1K JA 1/16W		405 163 1701	TR 2SC2812N-L7-TB0
R3087	401 105 4502	MT-GLAZE 390 JA 1/16W	Q2361	405 014 4509	TR 2SC241

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
IC1801	409 475 3705	IC M66500FP	IC4855	410 356 7606	IC SN74AHC1G04HDCKR
IC1811	409 339 3605	IC 24LC16BT/SN-T	IC4861	410 356 7903	IC SN74AHC1G08HDCKR
IC1821	410 364 6905	IC TC74ACT138FT-EL	IC4871	409 416 6505	IC BA05FP-E2
IC1822	410 367 1402	IC SN74LVC374APW	IC4881	410 325 4605	IC TC74LCX244FT
IC1823	409 301 5309	IC TC7S32FU-TE85L	IC4891	410 325 4704	IC HD74LVC244AT
IC1824	409 301 5309	IC TC7S32FU-TE85L	IC501	410 421 4400	IC 74LCX244MTCX
IC1851	409 421 8808	IC M62420FP	IC531	410 325 4605	IC TC74LCX244FT
IC1871	409 390 6201	IC EL2244CS	IC561	410 325 4704	IC HD74LVC244AT
IC1881	410 311 5708	IC MC74HCT244ADT	IC5630	410 421 4400	IC 74LCX244MTCX
	410 315 5506	IC HD74HCT244TV	IC5631	409 497 6302	IC BA09FP-E2
	410 356 7507	IC SN74HCT244PWR	IC6301	409 498 6004	IC CXA3562R
IC201	409 461 7304	IC AD8057ART	IC6321	409 498 6004	IC CXA3562R
IC211	409 461 7304	IC AD8057ART	IC6341	409 498 6004	IC CXA3562R
IC221	409 461 7304	IC AD8057ART	IC801	409 344 6509	IC UPC1093T-E1
IC231	409 461 7304	IC AD8057ART	IC802	409 461 7809	IC PQ20WZ11
IC2311	409 444 0902	IC AD9483KS-100	IC8201	410 319 4208	IC MB81G163222-80TQ
IC2331	409 357 6602	IC LT1260CS	IC8202	410 365 4603	IC MS82V16520-8AGA
IC2381	409 461 7304	IC AD8057ART	IC871	410 319 4208	IC MB81G163222-80TQ
IC2386	409 461 7304	IC AD8057ART	IC872	410 365 4603	IC MS82V16520-8AGA
IC2391	409 461 7304	IC AD8057ART	IC873	410 319 4208	IC MB81G163222-80TQ
IC2401	410 376 3404	IC XC2S100-5 PQ208C	IC874	410 365 4603	IC MS82V16520-8AGA
	410 388 2105	IC XC2S100-5 PQ208CES	IC887	410 402 7307	IC HD64F7045F28-B841-S
IC2404	410 325 4605	IC TC74LCX244FT	IC892	410 402 7901	IC HD64F7045F28-B841
	410 325 4704	IC HD74LVC244AT	IC9801	409 344 1900	IC MN1382-Q-TX
	410 421 4400	IC 74LCX244MTCX	IC9871	409 504 8206	IC AD9886KS-140
IC241	409 461 7304	IC AD8057ART	IC9892	409 416 6406	IC BA033FP-E2
IC251	409 461 7304	IC AD8057ART	IC9893	409 410 1001	IC UPC2933T-E1
IC2541	409 481 8602	IC LM76CHMX-5	IC9898	409 458 3401	IC M62393FP
IC2561	409 390 0001	IC LM7171AIMX	IC9901	410 407 1409	IC MBM29LV160BE-90-B875-S
	409 486 7709	IC LM7171BIMX	IC9902	410 407 1607	IC MBM29LV160BE-90-B875
IC2571	409 390 0001	IC LM7171AIMX	IC9903	410 365 5600	IC SN74LVCC4245APWR
	409 486 7709	IC LM7171BIMX	IC9904	410 365 5600	IC SN74LVCC4245APWR
IC2581	409 390 0001	IC LM7171AIMX	IC9905	410 311 5708	IC MC74HCT244ADT
	409 486 7709	IC LM7171BIMX	IC9906	410 315 5506	IC HD74HCT244TV
IC2591	409 390 0001	IC LM7171AIMX	IC9907	410 356 7507	IC SN74HCT244PWR
	409 486 7709	IC LM7171BIMX	IC9908	410 311 5708	IC MC74HCT244ADT
IC261	409 461 7304	IC AD8057ART	IC9909	410 315 5506	IC HD74HCT244TV
IC262	409 461 7304	IC AD8057ART	IC9910	410 356 7507	IC SN74HCT244PWR
IC263	409 461 7304	IC AD8057ART	IC9911	410 311 5708	IC MC74HCT244ADT
IC281	409 357 6602	IC LT1260CS	IC9912	410 315 5506	IC HD74HCT244TV
IC295	409 416 6505	IC BA05FP-E2	IC9913	410 356 7507	IC SN74HCT244PWR
IC301	409 502 4903	IC PW365-20U	IC9914	409 461 7304	IC AD8057ART
IC3201	410 321 8300	IC TC74VCX16244FT	IC9915	410 367 1501	IC M5M51008CFP-70HI
IC3202	410 321 8300	IC TC74VCX16244FT	IC9916	410 415 5208	IC M5M51008DFP-70HI
IC3203	410 321 8300	IC TC74VCX16244FT	IC9917	409 330 2508	IC TC7SH04FU-(TE85L)
IC3204	410 401 7407	IC TC74VCX244FT	IC9918	410 356 7606	IC SN74AHC1G04HDCKR
IC3231	410 403 4206	IC EP1K10TC144-1	IC9919	409 468 8908	IC ML60851CTB
IC3232	409 475 8403	IC SI-3025LS-TL	IC9920		
IC3270	409 462 2308	IC TC7S204FU-TE852	C1311	403 280 0508	ELECT 470U M 4V
IC3271	410 401 7506	IC TC74VCX16374FT	C1312	403 164 0204	CERAMIC 0.1U Z 25V
IC3272	410 321 8300	IC TC74VCX16244FT	C1331	403 149 9208	CERAMIC 0.01U Z 50V
IC3273	410 401 7506	IC TC74VCX16374FT	C1341	403 149 9208	CERAMIC 0.01U Z 50V
IC3274	410 321 8300	IC TC74VCX16244FT	C1351	403 280 0508	ELECT 470U M 4V
IC3275	410 401 7506	IC TC74VCX16374FT	C1352	403 164 0204	CERAMIC 0.1U Z 25V
IC3276	410 321 8300	IC TC74VCX16244FT	C1354	403 164 0204	CERAMIC 0.1U Z 25V
IC3277	410 391 2109	IC TC74VCX374FT(EL)	C1365	403 280 0805	ELECT 330U M 6.3V
IC3278	410 401 7407	IC TC74VCX244FT	C1367	403 280 0508	ELECT 470U M 4V
IC3295	410 337 0602	IC HD74LVC14T	C1368	403 164 0204	CERAMIC 0.1U Z 25V
IC3296	410 392 4706	IC SN74AHC1G125DCK	C1376	403 164 0204	CERAMIC 0.1U Z 25V
IC3297	410 392 4706	IC SN74AHC1G125DCK	C1377	403 164 0204	CERAMIC 0.1U Z 25V
IC3298	409 330 2508	IC TC7SH04FU-(TE85L)	C1503	403 164 0204	CERAMIC 0.1U Z 25V
	410 356 7606	IC SN74AHC1G04HDCKR	C1533	403 164 0204	CERAMIC 0.1U Z 25V
IC3299	409 439 8906	IC TC7WH125FU	C1563	403 164 0204	CERAMIC 0.1U Z 25V
IC3351	409 419 3709	IC MC10H351ML1	C1801	403 164 0204	CERAMIC 0.1U Z 25V
IC3401	410 403 4305	IC EP1K100QC208-2	C1802	403 164 0204	CERAMIC 0.1U Z 25V
IC3511	410 311 5708	IC MC74HCT244ADT	C1803	403 164 0204	CERAMIC 0.1U Z 25V
	410 315 5506	IC HD74HCT244TV	C1804	403 280 0805	ELECT 330U M 6.3V
	410 356 7507	IC SN74HCT244PWR	C1811	403 164 0204	CERAMIC 0.1U Z 25V
IC3521	410 311 5708	IC MC74HCT244ADT	C1821	403 164 0204	CERAMIC 0.1U Z 25V
	410 315 5506	IC HD74HCT244TV	C1822	403 164 0204	CERAMIC 0.1U Z 25V
	410 356 7507	IC SN74HCT244PWR	C1823	403 164 0204	CERAMIC 0.1U Z 25V
IC3561	409 422 5806	IC M62398FP	C1850	403 280 1604	ELECT 220U M 16V
IC401	409 487 8002	IC CXD3511Q	C1851	403 267 0606	NP-ELECT 4.7U M 16V
IC406	410 311 5708	IC MC74HCT244ADT	C1852	403 280 1604	ELECT 220U M 16V
	410 315 5506	IC HD74HCT244TV	C1853	403 215 2904	CERAMIC 0.022U K 25V
	410 356 7507	IC SN74HCT244PWR	C1854	403 272 5603	CERAMIC 0.033U K 16V
IC407	410 311 5708	IC MC74HCT244ADT	C1856	403 348 5803	CERAMIC 0.47U K 10V
	410 315 5506	IC HD74HCT244TV	C1857	403 149 9208	CERAMIC 0.01U Z 50V
	410 356 7507	IC SN74HCT244PWR	C1858	403 175 3300	ELECT 47U M 16V
IC408	410 311 5708	IC MC74HCT244ADT	C1859	403 164 0204	CERAMIC 0.1U Z 25V
	410 315 5506	IC HD74HCT244TV	C1861	403 272 5603	CERAMIC 0.033U K 16V
	410 356 7507	IC SN74HCT244PWR	C1862	403 348 5803	CERAMIC 0.47U K 10V
IC4201	410 362 7904	IC TC220C700TB-503	C1863	403 215 2904	CERAMIC 0.022U K 25V
IC4231	409 444 8700	IC ICS1523M-ER	C1864	403 280 1604	ELECT 220U M 16V
IC4261	409 475 8403	IC SI-3025LS-TL	C1865	403 164 0204	CERAMIC 0.1U Z 25V
IC4811	410 325 4605	IC TC74LCX244FT	C1866	403 280 1604	ELECT 220U M 16V
	410 325 4704	IC HD74LVC244AT	C1867	403 267 0606	NP-ELECT 4.7U M 16V
	410 421 4400	IC 74LCX244MTCX	C1871	403 157 1904	CERAMIC 10P D 50V
IC4821	410 325 4605	IC TC74LCX244FT	C1872	403 348 5803	CERAMIC 0.47U K 10V
	410 325 4704	IC HD74LVC244AT	C1873	403 157 1904	CERAMIC 10P D 50V
	410 421 4400	IC 74LCX244MTCX	C1881	403 164 0204	CERAMIC 0.1U Z 25V
IC4831	410 325 4605	IC TC74LCX244FT	C1893	403 164 0204	CERAMIC 0.1U Z 25V
	410 325 4704	IC HD74LVC244AT	C1894	403 164 0204	CERAMIC 0.1U Z 25V
	410 421 4400	IC 74LCX244MTCX	C1895	403 164 0204	CERAMIC 0.1U Z 25V
IC4851	409 330 2508	IC TC7SH04FU-(TE85L)	C202	403 164 0204	CERAMIC 0.1U Z 25V

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C204	403 164 0204	CERAMIC 0.1U Z 25V	C296	403 175 0606	ELECT 100U M 6.3V
C205	403 157 1904	CERAMIC 10P D 50V	C297	403 164 0204	CERAMIC 0.1U Z 25V
C206	403 267 0804	NP-ELECT 47U M 6.3V	C311	403 280 0508	ELECT 470U M 4V
C211	403 157 1904	CERAMIC 10P D 50V	C312	403 164 0204	CERAMIC 0.1U Z 25V
C212	403 267 0804	NP-ELECT 47U M 6.3V	C313	403 280 0508	ELECT 470U M 4V
C214	403 157 1508	CERAMIC 3P C 50V	C314	403 164 0204	CERAMIC 0.1U Z 25V
C215	403 157 1508	CERAMIC 3P C 50V	C315	403 164 0204	CERAMIC 0.1U Z 25V
C216	403 157 1508	CERAMIC 3P C 50V	C316	403 164 0204	CERAMIC 0.1U Z 25V
C221	403 157 1904	CERAMIC 10P D 50V	C3201	403 280 0508	ELECT 470U M 4V
C222	403 267 0804	NP-ELECT 47U M 6.3V	C3202	403 164 0204	CERAMIC 0.1U Z 25V
C2301	403 267 0804	NP-ELECT 47U M 6.3V	C3203	403 164 0204	CERAMIC 0.1U Z 25V
C2302	403 267 0804	NP-ELECT 47U M 6.3V	C3204	403 113 3805	CERAMIC 1000P K 50V
C2303	403 267 0804	NP-ELECT 47U M 6.3V	C3205	403 164 0204	CERAMIC 0.1U Z 25V
C2311	403 280 0805	ELECT 330U M 6.3V	C3206	403 164 0204	CERAMIC 0.1U Z 25V
C2312	403 164 0204	CERAMIC 0.1U Z 25V	C3207	403 113 3805	CERAMIC 1000P K 50V
C2313	403 280 0607	ELECT 220U M 6.3V	C3208	403 164 0204	CERAMIC 0.1U Z 25V
C2314	403 164 0204	CERAMIC 0.1U Z 25V	C3209	403 164 0204	CERAMIC 0.1U Z 25V
C2315	403 162 6208	ELECT 1U M 50V	C3211	403 113 3805	CERAMIC 1000P K 50V
C2316	403 164 0204	CERAMIC 0.1U Z 25V	C3212	403 164 0204	CERAMIC 0.1U Z 25V
C2318	403 164 0204	CERAMIC 0.1U Z 25V	C3213	403 164 0204	CERAMIC 0.1U Z 25V
C2319	403 164 0204	CERAMIC 0.1U Z 25V	C3231	403 280 0508	ELECT 470U M 4V
C232	403 164 0204	CERAMIC 0.1U Z 25V	C3232	403 164 0204	CERAMIC 0.1U Z 25V
C2321	403 164 0204	CERAMIC 0.1U Z 25V	C3233	403 280 0508	ELECT 470U M 4V
C2331	403 164 0204	CERAMIC 0.1U Z 25V	C3234	403 164 0204	CERAMIC 0.1U Z 25V
C2332	403 164 0204	CERAMIC 0.1U Z 25V	C3235	403 164 0204	CERAMIC 0.1U Z 25V
C2334	403 164 0204	CERAMIC 0.1U Z 25V	C3236	403 164 0204	CERAMIC 0.1U Z 25V
C2336	403 164 0204	CERAMIC 0.1U Z 25V	C3237	403 164 0204	CERAMIC 0.1U Z 25V
C2338	403 164 0204	CERAMIC 0.1U Z 25V	C3239	403 164 0204	CERAMIC 0.1U Z 25V
C234	403 164 0204	CERAMIC 0.1U Z 25V	C3241	403 164 0204	CERAMIC 0.1U Z 25V
C2370	403 164 0204	CERAMIC 0.1U Z 25V	C3261	403 164 0204	CERAMIC 0.1U Z 25V
C2377	403 280 0805	ELECT 330U M 6.3V	C3263	403 164 0204	CERAMIC 0.1U Z 25V
C2378	403 164 0204	CERAMIC 0.1U Z 25V	C3264	403 164 0204	CERAMIC 0.1U Z 25V
C2379	403 280 0805	ELECT 330U M 6.3V	C3265	403 164 0204	CERAMIC 0.1U Z 25V
C2381	403 157 1508	CERAMIC 3P C 50V	C3266	403 164 0204	CERAMIC 0.1U Z 25V
C2382	403 157 1904	CERAMIC 10P D 50V	C3271	403 280 0508	ELECT 470U M 4V
C2386	403 157 1508	CERAMIC 3P C 50V	C3272	403 113 3805	CERAMIC 1000P K 50V
C2387	403 157 1904	CERAMIC 10P D 50V	C3273	403 164 0204	CERAMIC 0.1U Z 25V
C2391	403 157 1508	CERAMIC 3P C 50V	C3274	403 164 0204	CERAMIC 0.1U Z 25V
C2392	403 157 1904	CERAMIC 10P D 50V	C3275	403 164 0204	CERAMIC 0.1U Z 25V
C2401	403 280 0508	ELECT 470U M 4V	C3276	403 164 0204	CERAMIC 0.1U Z 25V
C2402	403 164 0204	CERAMIC 0.1U Z 25V	C3277	403 113 3805	CERAMIC 1000P K 50V
C2403	403 280 0508	ELECT 470U M 4V	C3278	403 113 3805	CERAMIC 1000P K 50V
C2404	403 164 0204	CERAMIC 0.1U Z 25V	C3279	403 164 0204	CERAMIC 0.1U Z 25V
C2406	403 164 0204	CERAMIC 0.1U Z 25V	C3281	403 164 0204	CERAMIC 0.1U Z 25V
C2407	403 164 0204	CERAMIC 0.1U Z 25V	C3282	403 164 0204	CERAMIC 0.1U Z 25V
C2408	403 164 0204	CERAMIC 0.1U Z 25V	C3283	403 164 0204	CERAMIC 0.1U Z 25V
C2409	403 164 0204	CERAMIC 0.1U Z 25V	C3284	403 113 3805	CERAMIC 1000P K 50V
C2413	403 164 0204	CERAMIC 0.1U Z 25V	C3285	403 113 3805	CERAMIC 1000P K 50V
C2414	403 164 0204	CERAMIC 0.1U Z 25V	C3286	403 164 0204	CERAMIC 0.1U Z 25V
C2416	403 164 0204	CERAMIC 0.1U Z 25V	C3287	403 164 0204	CERAMIC 0.1U Z 25V
C2417	403 164 0204	CERAMIC 0.1U Z 25V	C3288	403 164 0204	CERAMIC 0.1U Z 25V
C2419	403 164 0204	CERAMIC 0.1U Z 25V	C3289	403 164 0204	CERAMIC 0.1U Z 25V
C2421	403 164 0204	CERAMIC 0.1U Z 25V	C3291	403 113 3805	CERAMIC 1000P K 50V
C2423	403 164 0204	CERAMIC 0.1U Z 25V	C3292	403 164 0204	CERAMIC 0.1U Z 25V
C2424	403 164 0204	CERAMIC 0.1U Z 25V	C3293	403 164 0204	CERAMIC 0.1U Z 25V
C2428	403 164 0204	CERAMIC 0.1U Z 25V	C3294	403 164 0204	CERAMIC 0.1U Z 25V
C2429	403 164 0204	CERAMIC 0.1U Z 25V	C3297	403 164 0204	CERAMIC 0.1U Z 25V
C2470	403 162 4709	ELECT 10U M 16V	C3351	403 164 0204	CERAMIC 0.1U Z 25V
C2471	403 164 0204	CERAMIC 0.1U Z 25V	C3352	403 304 1801	ELECT 100U M 6.3V
C2472	403 164 0204	CERAMIC 0.1U Z 25V	C3401	403 175 0606	ELECT 100U M 6.3V
C2473	403 162 4709	ELECT 10U M 16V	C3402	403 164 0204	CERAMIC 0.1U Z 25V
C2491	403 164 0204	CERAMIC 0.1U Z 25V	C3403	403 175 0606	ELECT 100U M 6.3V
C2501	403 280 1604	ELECT 220U M 16V	C3404	403 164 0204	CERAMIC 0.1U Z 25V
C2502	403 164 0204	CERAMIC 0.1U Z 25V	C3405	403 164 0204	CERAMIC 0.1U Z 25V
C2503	403 280 1604	ELECT 220U M 16V	C3410	403 164 0204	CERAMIC 0.1U Z 25V
C2504	403 164 0204	CERAMIC 0.1U Z 25V	C3411	403 164 0204	CERAMIC 0.1U Z 25V
C2511	403 164 0204	CERAMIC 0.1U Z 25V	C3414	403 164 0204	CERAMIC 0.1U Z 25V
C2520	403 280 1604	ELECT 220U M 16V	C3415	403 164 0204	CERAMIC 0.1U Z 25V
C2521	403 164 0204	CERAMIC 0.1U Z 25V	C3416	403 164 0204	CERAMIC 0.1U Z 25V
C2522	403 280 1604	ELECT 220U M 16V	C3417	403 164 0204	CERAMIC 0.1U Z 25V
C2530	403 280 1604	ELECT 220U M 16V	C3418	403 164 0204	CERAMIC 0.1U Z 25V
C2531	403 164 0204	CERAMIC 0.1U Z 25V	C3419	403 164 0204	CERAMIC 0.1U Z 25V
C2532	403 280 1604	ELECT 220U M 16V	C3421	403 164 0204	CERAMIC 0.1U Z 25V
C2541	403 164 0204	CERAMIC 0.1U Z 25V	C3425	403 164 0204	CERAMIC 0.1U Z 25V
C2563	403 157 1904	CERAMIC 10P D 50V	C3427	403 164 0204	CERAMIC 0.1U Z 25V
C2573	403 157 1904	CERAMIC 10P D 50V	C3428	403 164 0204	CERAMIC 0.1U Z 25V
C2583	403 157 1904	CERAMIC 10P D 50V	C3431	403 164 0204	CERAMIC 0.1U Z 25V
C2593	403 157 1904	CERAMIC 10P D 50V	C3432	403 164 0204	CERAMIC 0.1U Z 25V
C261	403 304 1801	ELECT 100U M 6.3V	C3433	403 164 0204	CERAMIC 0.1U Z 25V
C262	403 283 6309	CERAMIC 1U Z 10V	C3434	403 164 0204	CERAMIC 0.1U Z 25V
	403 336 5600	CERAMIC 1U Z 10V	C3511	403 164 0204	CERAMIC 0.1U Z 25V
C263	403 304 1801	ELECT 100U M 6.3V	C3521	403 164 0204	CERAMIC 0.1U Z 25V
C264	403 283 6309	CERAMIC 1U Z 10V	C3522	403 280 0805	ELECT 330U M 6.3V
	403 336 5600	CERAMIC 1U Z 10V	C3523	403 113 3805	CERAMIC 1000P K 50V
C265	403 155 4204	CERAMIC 15P J 50V	C3561	403 164 0204	CERAMIC 0.1U Z 25V
C266	403 157 1904	CERAMIC 10P D 50V	C3562	403 304 1801	ELECT 100U M 6.3V
C267	403 157 2109	CERAMIC 13P J 50V	C3563	403 113 3805	CERAMIC 1000P K 50V
C268	403 157 1904	CERAMIC 10P D 50V	C3564	403 164 0204	CERAMIC 0.1U Z 25V
C269	403 157 2208	CERAMIC 16P J 50V	C400	403 164 0204	CERAMIC 0.1U Z 25V
C270	403 157 1904	CERAMIC 10P D 50V	C401	403 280 0508	ELECT 470U M 4V
C281	403 164 0204	CERAMIC 0.1U Z 25V	C402	403 164 0204	CERAMIC 0.1U Z 25V
C282	403 164 0204	CERAMIC 0.1U Z 25V	C403	403 280 0508	ELECT 470U M 4V
C283	403 164 0204	CERAMIC 0.1U Z 25V	C404	403 164 0204	CERAMIC 0.1U Z 25V
C284	403 164 0204	CERAMIC 0.1U Z 25V	C405	403 113 3805	CERAMIC 1000P K 50V
C287	403 164 0204	CERAMIC 0.1U Z 25V	C406	403 164 0204	CERAMIC 0.1U Z 25V

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C409	403 164 0204	CERAMIC 0.1U Z 25V	C567	403 164 0204	CERAMIC 0.1U Z 25V
C410	403 164 0204	CERAMIC 0.1U Z 25V	C568	403 323 1301	CERAMIC 0.47U Z 10V
C411	403 164 0204	CERAMIC 0.1U Z 25V	C569	403 323 1301	CERAMIC 0.47U Z 10V
C412	403 164 0204	CERAMIC 0.1U Z 25V	C570	403 323 1301	CERAMIC 0.47U Z 10V
C413	403 164 0204	CERAMIC 0.1U Z 25V	C571	403 341 7507	ELECT 1000U M 25V
C415	403 113 3805	CERAMIC 1000P K 50V	C572	403 164 0204	CERAMIC 0.1U Z 25V
C416	403 164 0204	CERAMIC 0.1U Z 25V	C5811	403 164 0204	CERAMIC 0.1U Z 25V
C419	403 113 3805	CERAMIC 1000P K 50V	C5812	403 164 0204	CERAMIC 0.1U Z 25V
C420	403 164 0204	CERAMIC 0.1U Z 25V	C5813	403 164 0204	CERAMIC 0.1U Z 25V
C4201	403 280 0508	ELECT 470U M 4V	C5835	403 299 1602	CERAMIC 1U K 16V
C4202	403 164 0204	CERAMIC 0.1U Z 25V	C5836	403 341 7507	ELECT 1000U M 25V
C4204	403 164 0204	CERAMIC 0.1U Z 25V	C5837	403 341 7507	ELECT 1000U M 25V
C4205	403 164 0204	CERAMIC 0.1U Z 25V	C5853	403 164 0204	CERAMIC 0.1U Z 25V
C4206	403 164 0204	CERAMIC 0.1U Z 25V	C5864	403 164 0204	CERAMIC 0.1U Z 25V
C4208	403 164 0204	CERAMIC 0.1U Z 25V	C5865	403 341 7507	ELECT 1000U M 25V
C4209	403 164 0204	CERAMIC 0.1U Z 25V	C5866	403 341 7507	ELECT 1000U M 25V
C421	403 164 0204	CERAMIC 0.1U Z 25V	C5867	403 164 0204	CERAMIC 0.1U Z 25V
C4212	403 164 0204	CERAMIC 0.1U Z 25V	C5868	403 341 7507	ELECT 1000U M 25V
C4213	403 164 0204	CERAMIC 0.1U Z 25V	C5875	403 164 0204	CERAMIC 0.1U Z 25V
C4214	403 164 0204	CERAMIC 0.1U Z 25V	C5876	403 164 0204	CERAMIC 0.1U Z 25V
C4215	403 164 0204	CERAMIC 0.1U Z 25V	C6301	403 164 0204	CERAMIC 0.1U Z 25V
C4232	403 164 0204	CERAMIC 0.1U Z 25V	C6302	403 280 0508	ELECT 470U M 4V
C4233	403 162 4709	ELECT 10U M 16V	C6303	403 164 0204	CERAMIC 0.1U Z 25V
C4234	403 164 0204	CERAMIC 0.1U Z 25V	C6304	403 113 3805	CERAMIC 1000P K 50V
C4235	403 162 4709	ELECT 10U M 16V	C6307	403 164 0204	CERAMIC 0.1U Z 25V
C4236	403 164 0204	CERAMIC 0.1U Z 25V	C6308	403 164 0204	CERAMIC 0.1U Z 25V
C4237	403 155 1609	CERAMIC 33P J 50V	C6309	403 164 0204	CERAMIC 0.1U Z 25V
C4238	403 157 7302	CERAMIC 6800P K 50V	C6311	403 113 3805	CERAMIC 1000P K 50V
C4239	403 164 0204	CERAMIC 0.1U Z 25V	C6314	403 164 0204	CERAMIC 0.1U Z 25V
C4241	403 113 3805	CERAMIC 1000P K 50V	C6321	403 164 0204	CERAMIC 0.1U Z 25V
C4242	403 164 0204	CERAMIC 0.1U Z 25V	C6323	403 164 0204	CERAMIC 0.1U Z 25V
C4243	403 149 9208	CERAMIC 0.01U Z 50V	C6324	403 113 3805	CERAMIC 1000P K 50V
C4244	403 162 4709	ELECT 10U M 16V	C6325	403 164 0204	CERAMIC 0.1U Z 25V
C426	403 113 3805	CERAMIC 1000P K 50V	C6328	403 164 0204	CERAMIC 0.1U Z 25V
C4263	403 280 0508	ELECT 470U M 4V	C6329	403 164 0204	CERAMIC 0.1U Z 25V
C4264	403 164 0204	CERAMIC 0.1U Z 25V	C6331	403 164 0204	CERAMIC 0.1U Z 25V
C427	403 113 3805	CERAMIC 1000P K 50V	C6332	403 113 3805	CERAMIC 1000P K 50V
C428	403 113 3805	CERAMIC 1000P K 50V	C6335	403 164 0204	CERAMIC 0.1U Z 25V
C434	403 113 3805	CERAMIC 1000P K 50V	C6341	403 164 0204	CERAMIC 0.1U Z 25V
C440	403 164 0204	CERAMIC 0.1U Z 25V	C6343	403 164 0204	CERAMIC 0.1U Z 25V
C445	403 164 0204	CERAMIC 0.1U Z 25V	C6344	403 113 3805	CERAMIC 1000P K 50V
C446	403 164 0204	CERAMIC 0.1U Z 25V	C6345	403 164 0204	CERAMIC 0.1U Z 25V
C447	403 164 0204	CERAMIC 0.1U Z 25V	C6348	403 164 0204	CERAMIC 0.1U Z 25V
C449	403 113 3805	CERAMIC 1000P K 50V	C6349	403 164 0204	CERAMIC 0.1U Z 25V
C454	403 164 0204	CERAMIC 0.1U Z 25V	C6351	403 164 0204	CERAMIC 0.1U Z 25V
C456	403 164 0204	CERAMIC 0.1U Z 25V	C6352	403 113 3805	CERAMIC 1000P K 50V
C457	403 113 3805	CERAMIC 1000P K 50V	C6355	403 164 0204	CERAMIC 0.1U Z 25V
C458	403 164 0204	CERAMIC 0.1U Z 25V	C801	403 164 0204	CERAMIC 0.1U Z 25V
C461	403 164 0204	CERAMIC 0.1U Z 25V	C802	403 164 0204	CERAMIC 0.1U Z 25V
C463	403 164 0204	CERAMIC 0.1U Z 25V	C803	403 155 1609	CERAMIC 33P J 50V
C464	403 113 3805	CERAMIC 1000P K 50V	C804	403 155 1609	CERAMIC 33P J 50V
C465	403 164 0204	CERAMIC 0.1U Z 25V	C806	403 175 4505	ELECT 47U M 6.3V
C467	403 113 3805	CERAMIC 1000P K 50V	C807	403 164 0204	CERAMIC 0.1U Z 25V
C468	403 164 0204	CERAMIC 0.1U Z 25V	C808	403 215 1006	CERAMIC 470P J 50V
C471	403 113 3805	CERAMIC 1000P K 50V	C809	403 162 4709	ELECT 10U M 16V
C474	403 164 0204	CERAMIC 0.1U Z 25V	C811	403 283 6309	CERAMIC 1U Z 10V
C477	403 164 0204	CERAMIC 0.1U Z 25V		403 336 5600	CERAMIC 1U Z 10V
C481	403 164 0204	CERAMIC 0.1U Z 25V	C812	403 164 0204	CERAMIC 0.1U Z 25V
C4811	403 164 0204	CERAMIC 0.1U Z 25V	C813	403 164 0204	CERAMIC 0.1U Z 25V
C4821	403 164 0204	CERAMIC 0.1U Z 25V	C814	403 280 0805	ELECT 330U M 6.3V
C4831	403 164 0204	CERAMIC 0.1U Z 25V	C815	403 164 0204	CERAMIC 0.1U Z 25V
C4851	403 164 0204	CERAMIC 0.1U Z 25V	C816	403 164 0204	CERAMIC 0.1U Z 25V
C4855	403 164 0204	CERAMIC 0.1U Z 25V	C8201	403 164 0204	CERAMIC 0.1U Z 25V
C4861	403 164 0204	CERAMIC 0.1U Z 25V	C8202	403 164 0204	CERAMIC 0.1U Z 25V
C4862	403 280 0805	ELECT 330U M 6.3V	C8203	403 164 0204	CERAMIC 0.1U Z 25V
C4871	403 164 0204	CERAMIC 0.1U Z 25V	C8204	403 164 0204	CERAMIC 0.1U Z 25V
C4881	403 164 0204	CERAMIC 0.1U Z 25V	C8218	403 175 0606	ELECT 100U M 6.3V
C4891	403 341 7507	ELECT 100U M 25V	C8219	403 164 0204	CERAMIC 0.1U Z 25V
C501	403 280 1604	ELECT 220U M 16V	C8221	403 164 0204	CERAMIC 0.1U Z 25V
C502	403 164 0204	CERAMIC 0.1U Z 25V	C8222	403 164 0204	CERAMIC 0.1U Z 25V
C504	403 280 0805	ELECT 330U M 6.3V	C8223	403 164 0204	CERAMIC 0.1U Z 25V
C505	403 164 0204	CERAMIC 0.1U Z 25V	C8231	403 164 0204	CERAMIC 0.1U Z 25V
C506	403 164 0204	CERAMIC 0.1U Z 25V	C8232	403 157 7203	CERAMIC 3900P K 50V
C507	403 164 0204	CERAMIC 0.1U Z 25V	C8233	403 306 5401	CERAMIC 0.039U K 16V
C508	403 323 1301	CERAMIC 0.47U Z 10V	C8235	403 164 0204	CERAMIC 0.1U Z 25V
C509	403 323 1301	CERAMIC 0.47U Z 10V	C8237	403 164 0204	CERAMIC 0.1U Z 25V
C510	403 323 1301	CERAMIC 0.47U Z 10V	C8250	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C511	403 341 7507	ELECT 100U M 25V	C8251	403 164 0204	CERAMIC 0.1U Z 25V
C512	403 164 0204	CERAMIC 0.1U Z 25V	C8253	403 164 0204	CERAMIC 0.1U Z 25V
C531	403 280 1604	ELECT 220U M 16V	C8255	403 164 0204	CERAMIC 0.1U Z 25V
C532	403 164 0204	CERAMIC 0.1U Z 25V	C8257	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C534	403 280 0805	ELECT 330U M 6.3V	C8258	403 215 2904	CERAMIC 0.022U K 25V
C535	403 164 0204	CERAMIC 0.1U Z 25V	C8259	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C536	403 164 0204	CERAMIC 0.1U Z 25V	C8271	403 164 0204	CERAMIC 0.1U Z 25V
C537	403 164 0204	CERAMIC 0.1U Z 25V	C8272	403 164 0204	CERAMIC 0.1U Z 25V
C538	403 323 1301	CERAMIC 0.47U Z 10V	C8273	403 162 6208	ELECT 1U M 50V
C539	403 323 1301	CERAMIC 0.47U Z 10V	C8274	403 164 0204	CERAMIC 0.1U Z 25V
C540	403 323 1301	CERAMIC 0.47U Z 10V	C8275	403 164 0204	CERAMIC 0.1U Z 25V
C541	403 341 7507	ELECT 100U M 25V	C8281	403 283 6309	CERAMIC 1U Z 10V
C542	403 164 0204	CERAMIC 0.1U Z 25V		403 336 5600	CERAMIC 1U Z 10V
C561	403 280 1604	ELECT 220U M 16V	C8282	403 283 6309	CERAMIC 1U Z 10V
C562	403 164 0204	CERAMIC 0.1U Z 25V		403 336 5600	CERAMIC 1U Z 10V
C564	403 280 0805	ELECT 330U M 6.3V	C8283	403 322 7809	ELECT 220U M 6.3V
C565	403 164 0204	CERAMIC 0.1U Z 25V	C8284	403 113 3805	CERAMIC 1000P K 50V
C566	403 164 0204	CERAMIC 0.1U Z 25V	C8291	403 280 0805	ELECT 330U M 6.3V

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C8292	403 164 0204	CERAMIC 0.1U Z 25V	RB805	645 037 4920	R-NETWORK 3.3KX4 0.063W
C8296	403 175 0606	ELECT 100U M 6.3V	645 031 4070	R-NETWORK 3.3KX4 1/16W	
C8297	403 164 0204	CERAMIC 0.1U Z 25V	RB806	645 037 4920	R-NETWORK 3.3KX4 0.063W
C871	403 280 0508	ELECT 470U M 4V	645 031 4070	R-NETWORK 3.3KX4 1/16W	
C872	403 164 0204	CERAMIC 0.1U Z 25V	RB807	645 037 4920	R-NETWORK 3.3KX4 0.063W
C873	403 164 0204	CERAMIC 0.1U Z 25V	645 031 4070	R-NETWORK 3.3KX4 1/16W	
C874	403 164 0204	CERAMIC 0.1U Z 25V	RB9801	645 021 0365	R-NETWORK 100KX4 0.063W
C875	403 164 0204	CERAMIC 0.1U Z 25V	645 025 5397	R-NETWORK 100KX4 1/16W	
C876	403 164 0204	CERAMIC 0.1U Z 25V	RB9802	645 021 0365	R-NETWORK 100KX4 0.063W
C877	403 164 0204	CERAMIC 0.1U Z 25V	645 025 5397	R-NETWORK 100KX4 1/16W	
C878	403 164 0204	CERAMIC 0.1U Z 25V	R1302	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C879	403 164 0204	CERAMIC 0.1U Z 25V	R1303	401 105 0405	MT-GLAZE 100 JA 1/16W
C886	403 164 0204	CERAMIC 0.1U Z 25V	R1304	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C887	403 283 6309	CERAMIC 1U Z 10V	R1305	401 105 0405	MT-GLAZE 100 JA 1/16W
403 336 5600	CERAMIC 1U Z 10V		R1306	401 105 0405	MT-GLAZE 100 JA 1/16W
C888	403 157 6602	CERAMIC 470P K 50V	R1307	401 105 0405	MT-GLAZE 100 JA 1/16W
C892	403 164 0204	CERAMIC 0.1U Z 25V	R1311	401 105 2003	MT-GLAZE 1.8K JA 1/16W
C893	403 164 0204	CERAMIC 0.1U Z 25V	R1312	401 105 0306	MT-GLAZE 10 JA 1/16W
C894	403 280 0805	ELECT 330U M 6.3V	R1313	401 105 2003	MT-GLAZE 1.8K JA 1/16W
C9801	403 280 0508	ELECT 470U M 4V	R1314	401 105 0306	MT-GLAZE 10 JA 1/16W
C9802	403 164 0204	CERAMIC 0.1U Z 25V	R1321	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9804	403 113 3805	CERAMIC 1000P K 50V	R1322	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9805	403 153 9102	CERAMIC 5P C 50V	R1323	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9806	403 298 9609	CERAMIC 0.1U K 16V	R1332	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9807	403 164 0204	CERAMIC 0.1U Z 25V	R1334	401 105 0603	MT-GLAZE 10K JA 1/16W
C9809	403 164 0204	CERAMIC 0.1U Z 25V	R1337	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9811	403 280 0805	ELECT 330U M 6.3V	R1342	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C9812	403 164 0204	CERAMIC 0.1U Z 25V	R1343	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RESTSTOR			R1345	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2511	645 037 3107	R-NETWORK 10X4 0.063W	R1350	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1352	401 105 0603	MT-GLAZE 10K JA 1/16W
RB2512	645 037 3107	R-NETWORK 10X4 0.063W	R1355	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1356	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2513	645 037 3107	R-NETWORK 10X4 0.063W	R1358	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1366	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2514	645 037 3107	R-NETWORK 10X4 0.063W	R1369	401 276 4707	MT-GLAZE 0.000 ZA 1/3W
645 028 5981	R-NETWORK 10X4 1/16W		R1371	401 105 0405	MT-GLAZE 100 JA 1/16W
RB2515	645 037 3107	R-NETWORK 10X4 0.063W	R1372	401 105 0405	MT-GLAZE 100 JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1373	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2516	645 037 3107	R-NETWORK 10X4 0.063W	R1376	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1379	401 105 0603	MT-GLAZE 10K JA 1/16W
RB2521	645 037 3107	R-NETWORK 10X4 0.063W	R1381	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1383	401 105 0603	MT-GLAZE 10K JA 1/16W
RB2522	645 037 3107	R-NETWORK 10X4 0.063W	R1384	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1385	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2523	645 037 3107	R-NETWORK 10X4 0.063W	R1503	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1516	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2524	645 037 3107	R-NETWORK 10X4 0.063W	R1517	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1520	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2525	645 037 3107	R-NETWORK 10X4 0.063W	R1533	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1546	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2526	645 037 3107	R-NETWORK 10X4 0.063W	R1547	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1550	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2531	645 037 3107	R-NETWORK 10X4 0.063W	R1563	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1576	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2532	645 037 3107	R-NETWORK 10X4 0.063W	R1577	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1580	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2533	645 037 3107	R-NETWORK 10X4 0.063W	R1801	401 105 2003	MT-GLAZE 1.8K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1802	401 105 4106	MT-GLAZE 3.3K JA 1/16W
RB2534	645 037 3107	R-NETWORK 10X4 0.063W	R1811	401 105 0405	MT-GLAZE 100 JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1812	401 105 0405	MT-GLAZE 100 JA 1/16W
RB2535	645 037 3107	R-NETWORK 10X4 0.063W	R1813	401 105 5301	MT-GLAZE 4.7K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1814	401 105 5301	MT-GLAZE 4.7K JA 1/16W
RB2536	645 037 3107	R-NETWORK 10X4 0.063W	R1815	401 105 0405	MT-GLAZE 100 JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1816	401 105 0405	MT-GLAZE 100 JA 1/16W
RB301	645 020 7822	R-NETWORK 10KX4 0.063W	R1820	401 105 0603	MT-GLAZE 10K JA 1/16W
645 025 5380	R-NETWORK 10KX4 1/16W		R1821	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB331	645 031 3363	R-NETWORK 680X4 1/16W	R1822	401 105 0504	MT-GLAZE 1K JA 1/16W
RB332	645 031 3363	R-NETWORK 680X4 1/16W	R1823	401 105 2003	MT-GLAZE 1.8K JA 1/16W
RB333	645 031 3363	R-NETWORK 680X4 1/16W	R1824	401 105 4106	MT-GLAZE 3.3K JA 1/16W
RB334	645 031 3363	R-NETWORK 680X4 1/16W	R1825	401 105 2003	MT-GLAZE 1.8K JA 1/16W
RB335	645 031 3363	R-NETWORK 680X4 1/16W	R1826	401 105 2003	MT-GLAZE 1.8K JA 1/16W
RB336	645 031 3363	R-NETWORK 680X4 1/16W	R1829	401 105 0603	MT-GLAZE 10K JA 1/16W
RB337	645 031 3363	R-NETWORK 680X4 1/16W	R1841	401 105 0504	MT-GLAZE 1K JA 1/16W
RB338	645 031 3363	R-NETWORK 680X4 1/16W	R1843	401 105 0603	MT-GLAZE 10K JA 1/16W
RB339	645 031 3363	R-NETWORK 680X4 1/16W	R1844	401 105 0504	MT-GLAZE 1K JA 1/16W
RB341	645 031 3363	R-NETWORK 680X4 1/16W	R1846	401 105 0603	MT-GLAZE 10K JA 1/16W
RB342	645 031 3363	R-NETWORK 680X4 1/16W	R1850	401 105 2003	MT-GLAZE 1.8K JA 1/16W
RB343	645 031 3363	R-NETWORK 680X4 1/16W	R1851	401 105 4502	MT-GLAZE 390 JA 1/16W
RB4881	645 037 3107	R-NETWORK 10X4 0.063W	R1852	401 105 0405	MT-GLAZE 100 JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1853	401 105 0405	MT-GLAZE 100 JA 1/16W
RB4882	645 037 3107	R-NETWORK 10X4 0.063W	R1854	401 105 0702	MT-GLAZE 100K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1855	401 105 4502	MT-GLAZE 390 JA 1/16W
RB4883	645 021 0358	R-NETWORK 100X4 0.063W	R1856	401 105 2003	MT-GLAZE 1.8K JA 1/16W
645 031 3325	R-NETWORK 100X4 1/16W		R1857	401 105 1501	MT-GLAZE 1.5K JA 1/16W
RB4885	645 021 0358	R-NETWORK 100X4 0.063W	R1858	401 105 5301	MT-GLAZE 4.7K JA 1/16W
645 031 3325	R-NETWORK 100X4 1/16W		R1859	401 105 5301	MT-GLAZE 4.7K JA 1/16W
RB5811	645 020 7822	R-NETWORK 10KX4 0.063W	R1860	401 105 0603	MT-GLAZE 10K JA 1/16W
645 025 5380	R-NETWORK 10KX4 1/16W		R1861	401 105 0603	MT-GLAZE 10K JA 1/16W
RB5851	645 037 3107	R-NETWORK 10X4 0.063W	R1862	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1863	401 105 0603	MT-GLAZE 10K JA 1/16W
RB5852	645 037 3107	R-NETWORK 10X4 0.063W	R1864	401 105 0603	MT-GLAZE 10K JA 1/16W
645 028 5981	R-NETWORK 10X4 1/16W		R1865	401 105 0603	MT-GLAZE 10K JA 1/16W
RB804	645 037 4920	R-NETWORK 3.3KX4 0.063W	R1866	401 105 0603	MT-GLAZE 10K JA 1/16W
645 031 4070	R-NETWORK 3.3KX4 1/16W		R1867	401 105 0603	MT-GLAZE 10K JA 1/16W

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R1868	401 105 0603	MT-GLAZE 10K JA 1/16W	R2437	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1869	401 105 0603	MT-GLAZE 10K JA 1/16W	R2438	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1871	401 105 6605	MT-GLAZE 6.8K JA 1/16W	R2439	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1872	401 105 0504	MT-GLAZE 1K JA 1/16W	R244	401 105 0504	MT-GLAZE 1K JA 1/16W
R1873	401 105 0504	MT-GLAZE 1K JA 1/16W	R2440	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1874	401 105 6605	MT-GLAZE 6.8K JA 1/16W	R2441	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1876	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2442	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1877	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2443	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1878	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2445	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1881	401 105 0702	MT-GLAZE 100K JA 1/16W	R2446	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1883	401 105 0405	MT-GLAZE 100 JA 1/16W	R2447	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1884	401 105 0603	MT-GLAZE 10K JA 1/16W	R2448	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1885	401 105 0603	MT-GLAZE 10K JA 1/16W	R2449	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1888	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R245	401 105 5905	MT-GLAZE 560 JA 1/16W
R1889	401 105 0306	MT-GLAZE 10 JA 1/16W	R2451	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1898	401 105 0603	MT-GLAZE 10K JA 1/16W	R2452	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R201	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2453	401 105 0306	MT-GLAZE 10 JA 1/16W
R202	401 113 4402	MT-GLAZE 75 JA 1/16W	R2455	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R204	401 105 3901	MT-GLAZE 33 JA 1/16W	R2458	401 105 0306	MT-GLAZE 10 JA 1/16W
R205	401 105 0504	MT-GLAZE 1K JA 1/16W	R2460	401 105 0504	MT-GLAZE 1K JA 1/16W
R208	401 105 3901	MT-GLAZE 33 JA 1/16W	R2462	401 105 5905	MT-GLAZE 560 JA 1/16W
R211	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2463	401 105 0504	MT-GLAZE 1K JA 1/16W
R212	401 113 4402	MT-GLAZE 75 JA 1/16W	R2465	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R214	401 105 3901	MT-GLAZE 33 JA 1/16W	R2466	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R215	401 105 0504	MT-GLAZE 1K JA 1/16W	R2470	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R218	401 105 3901	MT-GLAZE 33 JA 1/16W	R2471	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R220	401 105 3901	MT-GLAZE 33 JA 1/16W	R2483	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R221	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2484	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R222	401 113 4402	MT-GLAZE 75 JA 1/16W	R2485	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R225	401 105 0504	MT-GLAZE 1K JA 1/16W	R2486	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R228	401 105 3901	MT-GLAZE 33 JA 1/16W	R2492	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2304	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2496	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2305	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2497	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2306	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2498	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R231	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R2501	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R2313	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2502	401 037 7800	MT-GLAZE 150 JA 1/10W
R2314	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2503	401 037 7800	MT-GLAZE 150 JA 1/10W
R2322	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2504	401 037 7800	MT-GLAZE 150 JA 1/10W
R2323	401 105 0504	MT-GLAZE 1K JA 1/16W	R251	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R2324	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R253	401 105 3901	MT-GLAZE 33 JA 1/16W
R233	401 105 3901	MT-GLAZE 33 JA 1/16W	R254	401 105 0504	MT-GLAZE 1K JA 1/16W
R2331	401 105 0603	MT-GLAZE 10K JA 1/16W	R2541	401 105 0405	MT-GLAZE 100 JA 1/16W
R2332	401 105 0603	MT-GLAZE 10K JA 1/16W	R2542	401 105 0405	MT-GLAZE 100 JA 1/16W
R2333	401 105 0603	MT-GLAZE 10K JA 1/16W	R2543	401 105 0603	MT-GLAZE 10K JA 1/16W
R2334	401 105 0504	MT-GLAZE 1K JA 1/16W	R255	401 105 5905	MT-GLAZE 560 JA 1/16W
R2335	401 105 0504	MT-GLAZE 1K JA 1/16W	R2561	401 105 5905	MT-GLAZE 560 JA 1/16W
R2336	401 105 0504	MT-GLAZE 1K JA 1/16W	R2562	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R2337	401 105 3901	MT-GLAZE 33 JA 1/16W	R2565	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2338	401 105 3901	MT-GLAZE 33 JA 1/16W	R2568	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2339	401 105 3901	MT-GLAZE 33 JA 1/16W	R2571	401 105 5905	MT-GLAZE 560 JA 1/16W
R234	401 105 0504	MT-GLAZE 1K JA 1/16W	R2572	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R235	401 105 5905	MT-GLAZE 560 JA 1/16W	R2575	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2351	401 105 0603	MT-GLAZE 10K JA 1/16W	R2578	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2352	401 105 0603	MT-GLAZE 10K JA 1/16W	R2581	401 105 5905	MT-GLAZE 560 JA 1/16W
R2353	401 105 0603	MT-GLAZE 10K JA 1/16W	R2582	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R2354	401 105 0603	MT-GLAZE 10K JA 1/16W	R2585	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2355	401 105 0603	MT-GLAZE 10K JA 1/16W	R2588	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2356	401 105 0603	MT-GLAZE 10K JA 1/16W	R2591	401 105 5905	MT-GLAZE 560 JA 1/16W
R2361	401 105 6506	MT-GLAZE 680 JA 1/16W	R2592	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R2362	401 105 2706	MT-GLAZE 220 JA 1/16W	R2595	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2363	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R2598	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2364	401 105 0603	MT-GLAZE 10K JA 1/16W	R261	401 105 2706	MT-GLAZE 220 JA 1/16W
R237	401 105 0405	MT-GLAZE 100 JA 1/16W	R263	401 105 0504	MT-GLAZE 1K JA 1/16W
R2371	401 105 0405	MT-GLAZE 100 JA 1/16W	R266	401 105 2706	MT-GLAZE 220 JA 1/16W
R2372	401 105 0405	MT-GLAZE 100 JA 1/16W	R268	401 105 0504	MT-GLAZE 1K JA 1/16W
R2373	401 105 0405	MT-GLAZE 100 JA 1/16W	R271	401 105 2706	MT-GLAZE 220 JA 1/16W
R2374	401 105 0405	MT-GLAZE 100 JA 1/16W	R273	401 105 0504	MT-GLAZE 1K JA 1/16W
R2375	401 105 0405	MT-GLAZE 100 JA 1/16W	R284	401 105 0504	MT-GLAZE 1K JA 1/16W
R2376	401 105 0405	MT-GLAZE 100 JA 1/16W	R285	401 105 0504	MT-GLAZE 1K JA 1/16W
R238	401 105 0405	MT-GLAZE 100 JA 1/16W	R286	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2382	401 105 3901	MT-GLAZE 33 JA 1/16W	R287	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2383	401 105 0504	MT-GLAZE 1K JA 1/16W	R288	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2387	401 105 3901	MT-GLAZE 33 JA 1/16W	R289	401 105 0504	MT-GLAZE 1K JA 1/16W
R2388	401 105 0504	MT-GLAZE 1K JA 1/16W	R290	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R239	401 105 0405	MT-GLAZE 100 JA 1/16W	R291	401 105 6506	MT-GLAZE 680 JA 1/16W
R2392	401 105 3901	MT-GLAZE 33 JA 1/16W	R292	401 105 2706	MT-GLAZE 220 JA 1/16W
R2393	401 105 0504	MT-GLAZE 1K JA 1/16W	R293	401 105 0603	MT-GLAZE 10K JA 1/16W
R2401	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R294	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R2402	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R295	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R241	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R296	401 105 2805	MT-GLAZE 2.2K JA 1/16W
R2415	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R301	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2417	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R302	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2419	401 105 0603	MT-GLAZE 10K JA 1/16W	R303	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R2423	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R304	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2425	401 105 0603	MT-GLAZE 10K JA 1/16W	R305	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R2426	401 105 0603	MT-GLAZE 10K JA 1/16W	R306	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2428	401 105 0306	MT-GLAZE 10 JA 1/16W	R307	401 105 0405	MT-GLAZE 100 JA 1/16W
R2429	401 105 0306	MT-GLAZE 10 JA 1/16W	R308	401 105 0405	MT-GLAZE 100 JA 1/16W
R243	401 105 3901	MT-GLAZE 33 JA 1/16W	R309	401 105 0405	MT-GLAZE 100 JA 1/16W
R2430	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R318	401 105 0603	MT-GLAZE 10K JA 1/16W
R2431	401 105 5905	MT-GLAZE 560 JA 1/16W	R3201	401 105 0405	MT-GLAZE 100 JA 1/16W
R2433	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R3203	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2434	401 105 0504	MT-GLAZE 1K JA 1/16W	R3204	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R2435	401 105 0504	MT-GLAZE 1K JA 1/16W	R3229	401 105 0405	MT-GLAZE 100 JA 1/16W
R2436	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R3232	401 105 0405	MT-GLAZE 100 JA 1/16W

Ref. No.		Part No.	Description			Ref. No.		Part No.	Description		
R3233	401	105 0405	MT-GLAZE	100	JA 1/16W	R3420	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3234	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3421	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3235	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3422	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3236	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3423	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3237	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3424	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3238	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3425	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3239	401	105 0405	MT-GLAZE	100	JA 1/16W	R3426	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R324	401	105 0405	MT-GLAZE	100	JA 1/16W	R3427	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3240	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3428	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3241	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3429	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3244	401	105 0306	MT-GLAZE	10	JA 1/16W	R343	401	105 0306	MT-GLAZE	10	JA 1/16W
R3245	401	105 0306	MT-GLAZE	10	JA 1/16W	R3430	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3246	401	105 0306	MT-GLAZE	10	JA 1/16W	R3431	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3248	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3432	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3249	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3433	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R325	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3434	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3250	401	105 0405	MT-GLAZE	100	JA 1/16W	R3435	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3251	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3436	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3254	401	105 0405	MT-GLAZE	100	JA 1/16W	R3437	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3255	401	105 0405	MT-GLAZE	100	JA 1/16W	R3438	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3256	401	105 0405	MT-GLAZE	100	JA 1/16W	R3439	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3257	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3440	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3258	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3441	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R326	401	105 0603	MT-GLAZE	10K	JA 1/16W	R3442	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3261	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3443	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3268	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3444	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3269	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3445	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3271	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3446	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3272	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3447	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3273	401	105 0405	MT-GLAZE	100	JA 1/16W	R3448	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3274	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3449	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3275	401	105 7909	MT-GLAZE	0.000	ZA 1/16W	R3450	401	105 7909	MT-GLAZE	0.000	ZA 1/16W
R3278	401	105 790									

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R3526	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R474	401 105 1402	MT-GLAZE 150 JA 1/16W
R3527	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R475	401 105 1402	MT-GLAZE 150 JA 1/16W
R3528	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R476	401 105 1402	MT-GLAZE 150 JA 1/16W
R353	401 105 6506	MT-GLAZE 680 JA 1/16W	R481	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R354	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R482	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R355	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R483	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3562	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4844	401 105 0504	MT-GLAZE 1K JA 1/16W
R3563	401 105 0504	MT-GLAZE 1K JA 1/16W	R4845	401 105 0504	MT-GLAZE 1K JA 1/16W
R3564	401 105 0504	MT-GLAZE 1K JA 1/16W	R4846	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3565	401 105 0603	MT-GLAZE 10K JA 1/16W	R4847	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R3566	401 105 0603	MT-GLAZE 10K JA 1/16W	R4855	401 105 0603	MT-GLAZE 10K JA 1/16W
R3567	401 105 0603	MT-GLAZE 10K JA 1/16W	R4857	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3568	401 105 0405	MT-GLAZE 100 JA 1/16W	R4858	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3569	401 105 0405	MT-GLAZE 100 JA 1/16W	R4859	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R357	401 105 0405	MT-GLAZE 100 JA 1/16W	R4861	401 105 0603	MT-GLAZE 10K JA 1/16W
R3571	401 105 1105	MT-GLAZE 12K JA 1/16W	R4865	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R3572	401 105 1105	MT-GLAZE 12K JA 1/16W	R4867	401 105 6001	MT-GLAZE 5.6K JA 1/16W
R3573	401 105 1105	MT-GLAZE 12K JA 1/16W	R4868	401 105 5202	MT-GLAZE 470 JA 1/16W
R3574	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4869	401 105 2003	MT-GLAZE 1.8K JA 1/16W
R3575	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R487	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3576	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4871	401 105 0900	MT-GLAZE 120 JA 1/16W
R358	401 105 0405	MT-GLAZE 100 JA 1/16W	R4872	401 105 0405	MT-GLAZE 100 JA 1/16W
R3581	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4873	401 105 0504	MT-GLAZE 1K JA 1/16W
R3582	401 105 2904	MT-GLAZE 22K JA 1/16W	R4874	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3583	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4875	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3584	401 105 2904	MT-GLAZE 22K JA 1/16W	R4876	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3585	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4877	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3586	401 105 2904	MT-GLAZE 22K JA 1/16W	R4878	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R359	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4879	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R361	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R488	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3611	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4881	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R3612	401 105 5400	MT-GLAZE 47K JA 1/16W	R4882	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3613	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R4883	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R3614	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4884	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R3615	401 105 5400	MT-GLAZE 47K JA 1/16W	R4885	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3616	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R4886	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3617	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R4887	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R3618	401 105 5400	MT-GLAZE 47K JA 1/16W	R4888	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R3619	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R489	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R363	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4891	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R371	401 105 0405	MT-GLAZE 100 JA 1/16W	R4892	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R372	401 105 0405	MT-GLAZE 100 JA 1/16W	R4893		

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R5631	401 105 5301	MT-GLAZE 4. 7K JA 1/16W	R7326	401 105 2607	MT-GLAZE 22 JA 1/16W
R5632	401 105 5301	MT-GLAZE 4. 7K JA 1/16W	R7327	401 105 2607	MT-GLAZE 22 JA 1/16W
R5633	401 105 4502	MT-GLAZE 390 JA 1/16W	R7328	401 105 2607	MT-GLAZE 22 JA 1/16W
R5634	401 105 4601	MT-GLAZE 3.9K JA 1/16W	R7329	401 105 2607	MT-GLAZE 22 JA 1/16W
R564	401 105 0306	MT-GLAZE 10 JA 1/16W	R7331	401 105 2607	MT-GLAZE 22 JA 1/16W
R565	401 105 0306	MT-GLAZE 10 JA 1/16W	R7332	401 105 2607	MT-GLAZE 22 JA 1/16W
R566	401 105 0306	MT-GLAZE 10 JA 1/16W	R7333	401 105 2607	MT-GLAZE 22 JA 1/16W
R567	401 105 0306	MT-GLAZE 10 JA 1/16W	R7334	401 105 2607	MT-GLAZE 22 JA 1/16W
R568	401 105 0306	MT-GLAZE 10 JA 1/16W	R7335	401 105 2607	MT-GLAZE 22 JA 1/16W
R569	401 105 0306	MT-GLAZE 10 JA 1/16W	R7336	401 105 2607	MT-GLAZE 22 JA 1/16W
R570	401 105 0306	MT-GLAZE 10 JA 1/16W	R7337	401 105 2607	MT-GLAZE 22 JA 1/16W
R571	401 105 0306	MT-GLAZE 10 JA 1/16W	R7338	401 105 2607	MT-GLAZE 22 JA 1/16W
R572	401 105 0306	MT-GLAZE 10 JA 1/16W	R7339	401 105 2607	MT-GLAZE 22 JA 1/16W
R573	401 105 0306	MT-GLAZE 10 JA 1/16W	R7341	401 105 2607	MT-GLAZE 22 JA 1/16W
R574	401 105 0603	MT-GLAZE 10K JA 1/16W	R7342	401 105 2607	MT-GLAZE 22 JA 1/16W
R575	401 105 0306	MT-GLAZE 10 JA 1/16W	R7343	401 105 2607	MT-GLAZE 22 JA 1/16W
R576	401 105 0306	MT-GLAZE 10 JA 1/16W	R7344	401 105 2607	MT-GLAZE 22 JA 1/16W
R577	401 105 1402	MT-GLAZE 150 JA 1/16W	R7345	401 105 2607	MT-GLAZE 22 JA 1/16W
R578	401 105 3208	MT-GLAZE 270 JA 1/16W	R7346	401 105 2607	MT-GLAZE 22 JA 1/16W
R579	401 105 1402	MT-GLAZE 150 JA 1/16W	R7347	401 105 2607	MT-GLAZE 22 JA 1/16W
R580	401 105 3208	MT-GLAZE 270 JA 1/16W	R7348	401 105 2607	MT-GLAZE 22 JA 1/16W
R5801	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7349	401 105 2607	MT-GLAZE 22 JA 1/16W
R5802	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R7361	401 105 2607	MT-GLAZE 22 JA 1/16W
R581	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R7362	401 105 2607	MT-GLAZE 22 JA 1/16W
R5831	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7363	401 105 2607	MT-GLAZE 22 JA 1/16W
R5832	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7364	401 105 2607	MT-GLAZE 22 JA 1/16W
R5834	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7365	401 105 2607	MT-GLAZE 22 JA 1/16W
R5835	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7366	401 105 2607	MT-GLAZE 22 JA 1/16W
R5836	645 030 1056	PROTECTOR, IC 3.8A 72V	R7367	401 105 2607	MT-GLAZE 22 JA 1/16W
R5837	401 105 7404	MT-GLAZE 8.2K JA 1/16W	R7368	401 105 2607	MT-GLAZE 22 JA 1/16W
R5838	401 105 1501	MT-GLAZE 1.5K JA 1/16W	R7370	401 105 2607	MT-GLAZE 22 JA 1/16W
R5839	401 105 2409	MT-GLAZE 2K JA 1/16W	R7371	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5842	402 080 6802	FUSIBLE RES 0.39 JH 1/4W	R7372	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5843	645 030 1056	PROTECTOR, IC 3.8A 72V	R7373	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5851	401 105 3307	MT-GLAZE 2.7K JA 1/16W	R7374	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5853	401 105 0405	MT-GLAZE 100 JA 1/16W	R7375	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5854	401 105 0405	MT-GLAZE 100 JA 1/16W	R7376	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5855	401 105 0405	MT-GLAZE 100 JA 1/16W	R7377	401 105 2607	MT-GLAZE 22 JA 1/16W
R5856	401 105 0405	MT-GLAZE 100 JA 1/16W	R7501	401 105 0306	MT-GLAZE 10 JA 1/16W
R5857	401 105 0405	MT-GLAZE 100 JA 1/16W	R7502	401 105 0306	MT-GLAZE 10 JA 1/16W
R5858	401 105 0405	MT-GLAZE 100 JA 1/16W	R7503	401 105 0306	MT-GLAZE 10 JA 1/16W
R5859	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R7504	401 105 0306	MT-GLAZE 10 JA 1/16W
R5860	401 105 0603	MT-GLAZE 10K JA 1/16W	R7505		

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
R805	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R896	401 105 0603	MT-GLAZE 10K JA 1/16W
R806	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9801	401 105 1501	MT-GLAZE 1.5K JA 1/16W
R809	401 105 0405	MT-GLAZE 100 JA 1/16W	R9803	401 105 8005	MT-GLAZE 1M JA 1/16W
R810	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9804	401 105 0405	MT-GLAZE 100 JA 1/16W
R812	401 105 0603	MT-GLAZE 10K JA 1/16W	R9805	401 105 0405	MT-GLAZE 100 JA 1/16W
R815	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9806	401 105 0405	MT-GLAZE 100 JA 1/16W
R816	401 105 0603	MT-GLAZE 10K JA 1/16W	R9807	401 105 0405	MT-GLAZE 100 JA 1/16W
R817	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9809	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R818	401 105 0603	MT-GLAZE 10K JA 1/16W	R9813	401 105 0702	MT-GLAZE 100K JA 1/16W
R820	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	COIL		
R821	401 105 5301	MT-GLAZE 4.7K JA 1/16W	L2311TM	645 008 0081	INDUCTOR, 390U K
R8218	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	L2341	645 040 7796	FILTER, LP 30MHZ
R822	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L2342	645 040 7796	FILTER, LP 30MHZ
R8222	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L2343	645 040 7796	FILTER, LP 30MHZ
R823	401 105 5301	MT-GLAZE 4.7K JA 1/16W	L2501	645 026 1008	INDUCTOR, 3.3U M
R8231	401 105 4106	MT-GLAZE 3.3K JA 1/16W	L2506	645 026 1008	INDUCTOR, 3.3U M
R8232	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	L3201	645 020 1776	INDUCTOR, 3.3U M
R8234	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L3202	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R8235	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L3231	645 020 1776	INDUCTOR, 3.3U M
R8236	401 105 0603	MT-GLAZE 10K JA 1/16W	L3232	645 020 1776	INDUCTOR, 3.3U M
R8237	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L3271	645 020 1776	INDUCTOR, 3.3U M
R824	401 105 4007	MT-GLAZE 330 JA 1/16W	L3351	645 026 1008	INDUCTOR, 3.3U M
R825	401 105 2904	MT-GLAZE 22K JA 1/16W	L3521	645 026 1008	INDUCTOR, 3.3U M
R8251	401 105 0405	MT-GLAZE 100 JA 1/16W	L401	645 020 1776	INDUCTOR, 3.3U M
R8252	401 105 0405	MT-GLAZE 100 JA 1/16W	L402	645 020 1776	INDUCTOR, 3.3U M
R8254	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L4231	401 037 5004	MT-GLAZE 0.000 ZA 1/10W
R8256	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L501	645 020 1776	INDUCTOR, 3.3U M
R827	401 105 2904	MT-GLAZE 22K JA 1/16W	L502	645 002 5129	INDUCTOR, 0.47U M
R8271	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L531	645 020 1776	INDUCTOR, 3.3U M
R8272	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L532	645 002 5129	INDUCTOR, 0.47U M
R8274	401 105 0306	MT-GLAZE 10 JA 1/16W	L561	645 020 1776	INDUCTOR, 3.3U M
R8275	401 105 0306	MT-GLAZE 10 JA 1/16W	L562	645 002 5129	INDUCTOR, 0.47U M
R8280	401 105 0603	MT-GLAZE 10K JA 1/16W	L6301	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R8281	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L8281	645 026 1008	INDUCTOR, 3.3U M
R8284	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	L9801	645 021 1645	INDUCTOR, 2.2U J
R8286	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	DIODE		
R8287	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D1301	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8288	401 105 0603	MT-GLAZE 10K JA 1/16W	D1851	407 223 1003	ZENER DIODE 02DZ5.1Y(TPH3
R8289	401 105 0603	MT-GLAZE 10K JA 1/16W	D1852	407 092 9506	DIODE SB07-03C-TB
R829	401 105 0900	MT-GLAZE 120 JA 1/16W	D2502	407 149 0807	DIODE 1SS355-TE-17
R8291	401 105 0405	MT-GLAZE 100 JA 1/16W	D2503	407 149 0807	DIODE 1SS355-TE-17
R8292	401 105 0405	MT-GLAZE 100 JA 1/16W	D4871	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R8296	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	D4872	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R831	401 105 5202	MT-GLAZE 470 JA 1/16W	D4873	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R832	401 105 0702	MT-GLAZE 100K JA 1/16W	D4874	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R833	401 105 0405	MT-GLAZE 100 JA 1/16W	D5631	407 149 0807	DIODE 1SS355-TE-17
R834	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D5801	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R835	401 105 0405	MT-GLAZE 100 JA 1/16W	D5811	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R836	401 105 0405	MT-GLAZE 100 JA 1/16W	D5812	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R837	401 105 0405	MT-GLAZE 100 JA 1/16W	D5813	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R838	401 105 0405	MT-GLAZE 100 JA 1/16W	D5831	407 223 5001	DIODE D1FM3
R839	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D5832	407 223 5001	DIODE D1FM3
R840	401 105 0603	MT-GLAZE 10K JA 1/16W	D5833	407 223 5001	DIODE D1FM3
R841	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D5862	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R842	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D5863	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R843	401 105 5301	MT-GLAZE 4.7K JA 1/16W	D5867	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R844	401 105 0504	MT-GLAZE 1K JA 1/16W	D5868	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R845	401 105 0504	MT-GLAZE 1K JA 1/16W	D5871	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R846	401 105 0504	MT-GLAZE 1K JA 1/16W	D5881	407 223 1102	ZENER DIODE 02DZ6.2Y(TPH3
R847	SEE PAGE-93		D801	407 092 9506	DIODE SB07-03C-TB
R848	401 105 0603	MT-GLAZE 10K JA 1/16W	MISCELLANEOUS		
R849	401 105 0405	MT-GLAZE 100 JA 1/16W	IC886	407 221 9704	SENSOR MPXA4115A6T1
R850	401 105 0603	MT-GLAZE 10K JA 1/16W	TPBLK	645 036 4266	TERMINAL
R851	401 105 0603	MT-GLAZE 10K JA 1/16W	TPCLKCG	645 036 4266	TERMINAL
R852	401 105 0603	MT-GLAZE 10K JA 1/16W	TPCLKI	645 036 4266	TERMINAL
R853	401 105 2904	MT-GLAZE 22K JA 1/16W	TPCOAST	645 036 4266	TERMINAL
R854	401 105 2904	MT-GLAZE 22K JA 1/16W	TPDCKE	645 036 4266	TERMINAL
R855	401 105 2904	MT-GLAZE 22K JA 1/16W	TPDCLK	645 036 4266	TERMINAL
R856	401 105 2904	MT-GLAZE 22K JA 1/16W	TPDENB	645 036 4266	TERMINAL
R857	401 105 5301	MT-GLAZE 4.7K JA 1/16W	TPDENG	645 036 4266	TERMINAL
R858	401 105 5301	MT-GLAZE 4.7K JA 1/16W	TPDENR	645 036 4266	TERMINAL
R859	401 105 0603	MT-GLAZE 10K JA 1/16W	TPDHS	645 036 5010	TERMINAL
R861	401 105 0405	MT-GLAZE 100 JA 1/16W	TPDVS	645 036 5010	TERMINAL
R862	401 105 5301	MT-GLAZE 4.7K JA 1/16W	TPGADCL	645 036 4266	TERMINAL
R863	401 105 5301	MT-GLAZE 4.7K JA 1/16W	TPGCKLO	645 036 4266	TERMINAL
R864	401 105 0405	MT-GLAZE 100 JA 1/16W	TPGFBK	645 036 5010	TERMINAL
R865	401 105 0405	MT-GLAZE 100 JA 1/16W	TPGHS	645 036 5010	TERMINAL
R866	401 105 2003	MT-GLAZE 1.8K JA 1/16W	TPGPEN	645 036 5010	TERMINAL
R867	401 105 4106	MT-GLAZE 3.3K JA 1/16W	TPGREF	645 036 5010	TERMINAL
R868	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPGVS	645 036 5010	TERMINAL
R869	401 105 4304	MT-GLAZE 330K JA 1/16W	TPHCG	645 036 4266	TERMINAL
R870	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPHSFO	645 036 4266	TERMINAL
R871	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPHV	645 036 5010	TERMINAL
R873	401 105 0603	MT-GLAZE 10K JA 1/16W	TPMCK	645 036 4266	TERMINAL
R875	401 105 0603	MT-GLAZE 10K JA 1/16W	TPMSCL	645 036 4266	TERMINAL
R877	401 105 5301	MT-GLAZE 4.7K JA 1/16W	TPMSDA	645 036 4266	TERMINAL
R878	401 105 0405	MT-GLAZE 100 JA 1/16W	TPNMI	645 036 5010	TERMINAL
R879	401 105 0504	MT-GLAZE 1K JA 1/16W	TPRSTPW1	645 036 5010	TERMINAL
R880	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPRXDPW	645 036 4266	TERMINAL
R882	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPSINTR	645 036 4266	TERMINAL
R886	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	TPTXDPW	645 036 4266	TERMINAL
R890	401 105 0603	MT-GLAZE 10K JA 1/16W	TPV	645 036 5010	TERMINAL
R891	401 105 0603	MT-GLAZE 10K JA 1/16W	TPVCG	645 036 4266	TERMINAL
R893	401 105 0603	MT-GLAZE 10K JA 1/16W	TP1351	645 036 5010	TERMINAL
R895	401 105 0603	MT-GLAZE 10K JA 1/16W	TP1352	645 036 5010	TERMINAL


Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
TP1381	645 036 5010	TERMINAL			
TP201	645 036 5010	TERMINAL			
TP211	645 036 5010	TERMINAL			
TP221	645 036 5010	TERMINAL			
TP2301R	645 036 5010	TERMINAL			
TP2302G	645 036 5010	TERMINAL			
TP2303B	645 036 5010	TERMINAL			
TP2401-H	645 036 5010	TERMINAL			
TP2401-V	645 036 5010	TERMINAL			
TP2516	645 036 5010	TERMINAL			
TP2517	645 036 5010	TERMINAL			
TP2526	645 036 5010	TERMINAL			
TP2527	645 036 5010	TERMINAL			
TP2536	645 036 5010	TERMINAL			
TP2537	645 036 5010	TERMINAL			
TP2561	645 036 5010	TERMINAL			
TP2571	645 036 5010	TERMINAL			
TP303	645 036 4266	TERMINAL			
TP304	645 036 4266	TERMINAL			
TP32DE	645 036 5010	TERMINAL			
TP32H1	645 036 5010	TERMINAL			
TP32H2	645 036 5010	TERMINAL			
TP32V1	645 036 5010	TERMINAL			
TP32V2	645 036 5010	TERMINAL			
TP401	645 036 5010	TERMINAL			
TP402	645 036 5010	TERMINAL			
TP4201	645 036 4266	TERMINAL			
TP4202	645 036 4266	TERMINAL			
TP4203	645 036 4266	TERMINAL			
TP4204	645 036 4266	TERMINAL			
TP4205	645 036 4266	TERMINAL			
TP4232	645 036 5010	TERMINAL			
TP801	645 036 5010	TERMINAL			
TP820B	645 036 5010	TERMINAL			
TP820G	645 036 5010	TERMINAL			
TP820R	645 036 5010	TERMINAL			
K1301	645 029 6338	PULG, 5P			
K2B	645 009 8390	PLUG, ANT 2P			
K2G	645 009 8390	PLUG, ANT 2P			
K2R	645 009 8390	PLUG, ANT 2P			
K25D	645 050 2309	SOCKET, FPC 32P			
K25E	645 050 2309	SOCKET, FPC 32P			
K25F	645 050 2309	SOCKET, FPC 32P			
K301	645 005 6949	PLUG, SIDE-ZR-SM3 6P			
K302	645 030 5702	SOCKET, FPC 50P			
K32A	645 040 6775	SOCKET, PWB 40P			
K32B	645 040 6775	SOCKET, PWB 40P			
K8A	645 041 8136	PLUG, 40P			
K8B	645 042 6834	PLUG, 30P			
K8D	645 030 6679	PLUG, 32P			
K8E	645 041 8136	PLUG, 40P			
K8F	645 041 0079	PLUG, 13P			
K8P	645 029 6314	PULG, 3P			
K8Q	645 029 6338	PULG, 5P			
K8R	645 043 3719	PLUG, 3P			
K8S	645 029 6314	PULG, 3P			
K8U	645 029 6314	PULG, 3P			
K8V	645 029 6321	PULG, 4P			
K8W	645 023 8659	PLUG, 5P			
K8X	645 023 8659	PLUG, 5P			
X1331	645 047 6587	OSC, CRYSTAL 26.000MHZ			
X1341	645 029 6468	OSC, CRYSTAL 27.000MHZ			
X801	645 035 2249	OSC, CRYSTAL 6.7584MHZ			
X9801	645 035 8906	OSC, CRYSTAL 48MHZ			

Electrical Parts List

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
*****			*****		
	ASSY PWB MAIN MY6A			ACCESSORIES FOR PLC-XF30NL ONLY. (009MY6AL)	
R847	610 293 0894	ASSY PWB MAIN MY6A		645 015 3976	CABLE, FXAF
	401 105 8203	MT-GLAZE 68K JA 1/16W		610 234 0969	CABLE
*****				610 293 9699	COMPL, COVER LENS A-MV6A (including "****")
	ACCESSORIES FOR PLC-XF30 ONLY. (009MY6A)		**	610 290 9258	COVER LNS B-MV6A
	645 015 3976	CABLE, FXAF	**	610 293 8937	COVER LNS C-MV6A
	610 234 0969	CABLE	**	610 293 8944	COVER LNS D-MV6A
**	610 293 9699	COMPL, COVER LENS A-MV6A (including "****")		610 289 1645	COMPL, HOLDER LENS-ML6A (including "****")
**	610 290 9258	COVER LNS B-MV6A	***	412 062 4009	SPECIAL SCREW
**	610 293 8937	COVER LNS C-MV6A	***	411 001 9303	SCR BIN 4X10
**	610 293 8944	COVER LNS D-MV6A	***	610 289 1676	HOLDER LENS A-ICPP
	610 289 1645	COMPL, HOLDER LENS-ML6A (including "****")	AA9901	645 047 7867	ASSY, REMOCON CXJT
***	412 062 4009	SPECIAL SCREW	A9901C	610 283 3867	RC-BATTERY LID-CXFJ
***	411 001 9303	SCR BIN 4X10		610 294 3115	LENS INST MANUAL-MV6A
***	610 289 1676	HOLDER LENS A-ICPP		645 031 8207	ADAPTOR, MAC/IBM
AA9901	645 047 7867	ASSY, REMOCON CXJT		645 043 9704	ADAPTOR, DVI/VGA
A9901C	610 283 3867	RC-BATTERY LID-CXFJ		610 294 3344	COVER, DUST-MV6A
	610 294 3115	LENS INST MANUAL-MV6A		645 002 9189	CORD, POWER-3.0MK
	645 031 8207	ADAPTOR, MAC/IBM	▲	645 002 9196	CORD, POWER-3.0MK, EU
	645 043 9704	ADAPTOR, DVI/VGA		645 003 1137	CORD, POWER-3.0MK, UK
▲	610 294 3344	COVER, DUST-MV6A		645 030 6624	CABLE, INTERFACE VGA
▲	645 002 9189	CORD, POWER-3.0MK		645 039 7196	CABLE, MOUSE MAC
▲	645 002 9196	CORD, POWER-3.0MK, EU		645 039 7202	CABLE, MOUSE PS/2
	645 003 1137	CORD, POWER-3.0MK, UK		645 039 7219	CABLE, MOUSE SRAL
	645 030 6624	CABLE, INTERFACE VGA		645 043 3702	CABLE, DVI-D
	645 039 7196	CABLE, MOUSE MAC	Owner's Manual	See the Production change notice of the cover. (Page-1)	
	645 039 7202	CABLE, MOUSE PS/2		*****	
	645 039 7219	CABLE, MOUSE SRAL		SANYO --	
	645 043 3702	CABLE, DVI-D		*****	
Owner's Manual	See the Production change notice of the cover. (Page-1)			*****	
*****				*****	
	ACCESSORIES FOR PLC-XF30N ONLY. (009MY6AA)			*****	
	645 015 3976	CABLE, FXAF		*****	
	610 234 0969	CABLE		*****	
	610 293 9699	COMPL, COVER LENS A-MV6A (including "****")		*****	
**	610 290 9258	COVER LNS B-MV6A		*****	
**	610 293 8937	COVER LNS C-MV6A		*****	
**	610 293 8944	COVER LNS D-MV6A		*****	
	610 289 1645	COMPL, HOLDER LENS-ML6A (including "****")		*****	
***	412 062 4009	SPECIAL SCREW		*****	
***	411 001 9303	SCR BIN 4X10		*****	
***	610 289 1676	HOLDER LENS A-ICPP		*****	
AA9901	645 047 7867	ASSY, REMOCON CXJT		*****	
A9901C	610 283 3867	RC-BATTERY LID-CXFJ		*****	
	610 294 3115	LENS INST MANUAL-MV6A		*****	
	645 031 8207	ADAPTOR, MAC/IBM		*****	
	645 043 9704	ADAPTOR, DVI/VGA		*****	
▲	610 294 3344	COVER, DUST-MV6A		*****	
▲	645 002 9189	CORD, POWER-3.0MK		*****	
▲	645 002 9196	CORD, POWER-3.0MK, EU		*****	
	645 003 1137	CORD, POWER-3.0MK, UK		*****	
	645 030 6624	CABLE, INTERFACE VGA		*****	
	645 039 7196	CABLE, MOUSE MAC		*****	
	645 039 7202	CABLE, MOUSE PS/2		*****	
	645 039 7219	CABLE, MOUSE SRAL		*****	
	645 043 3702	CABLE, DVI-D		*****	
Owner's Manual	See the Production change notice of the cover. (Page-1)			*****	
*****				*****	





1 2 3 4 5 6 7 8 9 10 11 12

A

B

C


D

E


F

G

H




1 2 3 4 5 6 7 8 9 10 11 12

































Enhancer & Clock converter
SDM16A-08


ASSY MAIN 4 16


SCHEMATIC DIAGRAM S8









0SDMY6A----10
CPU_IO_USB









The Terminal board D-SUB15 does not exist in some particular models.

B1 Block diagram -- Signal lines

BLOCKDIAGRAM

A

B

C

D

E

F

G

H

A

B

C



D

E


F

G


H



B2 Block diagram -- System control



P2 PWB parts location diagram



P3 PWB parts location diagram

