

QUICK START GUIDE

Package Contents

Olympia USB Adaptor
CD-ROM
Quick Start Guide

System Requirements

Your Desktop PC or Notebook PC should match the following requirements in order to run the software:

Hardware: Pentium II Class PC, CPU speed 200MHz or above
RAM: Minimum 64MB (128MB recommended)
USB port: supports USB 1.1 standard
Operating System: Windows 2000, Windows 98SE, Windows Me, Windows XP Professional, Windows XP Home Edition.
CD-ROM drive

Quick Software Setup and Driver Installation

For Windows XP: Click “Start”, “Control Panel”, “Data, Time, Language and Regional Options”. “Regional and Language Options”, and then Select the region and Click “OK”.

For Windows 2000: Click “Start” “Setting”, “Control Panel”, and then Select the region and Click “OK”.

Do not insert Bluetooth USB Dongle before BTW software has been installed.

1. Insert the Software installation CD into the CD-ROM drive of your PC or Notebook and Follow instructions given on the screen to install the software.

Install Olympia USB Dongle Device Driver

1. Plug the Olympia USB Dongle into the USB port.
2. The “Add New “Hardware Wizard” window appears. Choose “Automatic search for a better driver [Recommended]; (Note: choose “CD-ROM drive) then click on Next.
3. The system will find the setup files and follow the instruction of the setup file to copy drivers. Confirm the device driver found; click on Next.
4. Confirm the completion of driver installation; click on Finish. (If you’re experiencing difficulty in installing the device, please go to “Troubleshooting” in the User Manual for more details)
5. A “My Bluetooth Places” icon appears on the desktop. The “My Bluetooth Places” program, provides a quick and easy way to perform different application services through Bluetooth connections.
6. For detailed explanations and the operation of how to use the “My Bluetooth Places” program, please find the ‘User’s Manual and Application Setup Guide in the CD-ROM.
7. For latest version and information of software and firmware, please find it from www.olympia-life.com

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.