



# VILTA User Manual



2017.12

## Contents

### Overview

Packing List	03
Product Overview	04

### Quick Start

App Installation	05
Smartphone Installation and Balance	06
App Connection	09

### Start Up

Control Panel Introduction	10
App Menu Introduction	15
App Operation	17

### Specifications

Specifications Parameter	20
Technical Parameter	20
Other Specification	21

Warranty	Information	23	3
----------	-------------	----	---



## Packing List

VILTA

- Portable Bag
- Charging Cable
- Lanyard

User Manual













## Product Overview



## App Installation

- Download App on Freevision's official website www.freevisiontech.com.
- For iOS user, search "FV Share" in App Store.



 For Android user, search "FV Share" in Google Play or scan below QR Code





Android 4.3 above or iOS 9.0 above required.

### Smartphone Installation & Balance

 • VILTA wont work únless mounting the phone. Smartphone detection can be closed in App.
 • Always keep your phone well balanced in level prior to power on, or it will greatly affect working performance.







2 Put your phone in and keep it close to the tilt axis motor.

Please ensure back camera of phone is outward and not covered.









## App Connection



- Turn on bluetooth and unlock the phone screen rotation. Ensure phone can be displayed horizontally.
- Open App, tap Connect to enter the device list. Choose your gimbal to connect.
- The light of shutter button will go out after successfully connected.



## Control Panel Instruction

### (01) Shutter Button



Single Tap	Photo Mode	Take Photo
Double Tap	Selfie Mode	Front & Back Camera Switch
Long Press for 2s	Video Mode	Recording On/Off







Red light glints Green light glints Warning (Abnormal Condition) Busy/Auto Calibration



Abnormal conditions of VILT Ainclude absence of phone, motor damage, internal fault, etc.





 Semi-follow Mode (default) Single tap Mode Button Status Indicator is yellow

Tilt and Roll Axes are locked. Pan Axis smoothly moves with handle.





 Follow Mode Double tap Mode Button Status Indicator is red

Roll Axis is locked. Pan and Tilt Axes smoothly move with handle.

Lock Mode
 Quadruple tap Mode Button
 Status Indicator is green

Tilt, Roll and Pan Axes are locked.Smartphone always keeps the current shooting direction.

 Center the smartphone Triple tap Mode Button

The smartphone returns to the front.

Focusing

Long press Mode Button.









### 04 Joystick



#### **Basic Function**



2 When toggling joystick upward or downward, VILTA will rotate corresponding vertical direction.

Direction of control can be modified in advanced setting of App.

#### Advanced Funtion

- Zoom—Long press mode button and toggle joystick upward or downward.
- Exposure—Long press mode button and toggle joystick left or right.
- Roll Axis Angle—Long press mode button and toggle joystick left or right.

Adjustment of exposure and roll axis angle can be swtiched in advanced setting of App.



### (05) Micro-USB Charging Port



- When charging, status indicator alternately glints in red, yellow and green.
- When fully charged, the status indicator is green.
- Please apply charging cable with standard configuration to charge VILTA.
- When the power button glints, please charge VILTA .

When the charging current is 2A, it takes 2.0 hours to be fully charged, which allows 17 working hours. Datum come from laboratory test.





Directly adjust the shooting direction by hand. Manual mode can be turned off in VILTA App.



## App Menu Introduction



#### 01) General Settings

Camera

Video Resolution, Panorama Quality

Gimbal

Rotation Speed Settings, Dead Zone Settings, Mode Button+Toggle Joystick, Phone Detection, Gimbal Calibration, Reset All

- Joystick Sensitivity, Speed, Dead Zone, Direction
- Information
   Gimbal Battery Information, Gimbal Information, App

#### 02 Gimbal Settings

Scene Modes:

Walk Mode, Sport Mode, Custom Mode

- Follow Modes:
   Follow Mode, Semi-follow Mode, Lock Mode
- Manual Mode
- Phone Charge

#### O3 Camera Settings

#### Camera Mode:

Time-lapse, Panorama, Long Exposure, Beauty, HDR, Filter, White Balance, Grid

Video Mode:

Slow Motion, Beauty, Filters, Time Lapse, Motion Time Lapse, Motion Lapse, White Balance, Grid

04) Return

Tap imes to return to App home page

#### (05) Information

Gimbal Battery, Bluetooth Connection Status

#### 06 Documents

Preview and storage location of photos and videos.

#### 07) IntelliTrace

Tap () to turn on IntelliTrace. Tap () to turn off IntelliTrace. Frame the subject and VILTA will track in real time.

Answering a phone when recording or in IntelliTrace, the shooting will be automatically stopped.



#### 08 Photo/Video Switch

Tap Photo video to switch

9 Front/Back Camera Switch

Tap 💿 to switch

#### 10 Flashlight Status

- Display the current flashlight status
- Tap & to switch working state 7 & & &

### App Operation

#### Photo Mode

① Panorama

Tap () to enter panorama. Choose 180,°330,° 3\*3 , 3\*5, VILTA will automatically shoot and compund panorama. Photo will be automatically saved to documents.

#### Video Mode

#### IntelliTrace

1. Tap 🖵 and choose sport mode in scene mode.

2. Tap  $\bigotimes$  to start IntelliTrace. Frame the subject on your phone screen.

 Tap 
 to start recording. VILTA wil intelligently identify and automatically track the subject to take video.

4. Tap ( ) to exit recording. Tap ( ) to exit IntelliTrace. Video will be automatically saved to documents.

#### ① Time Lapse

1. Switch to video mode. Tap (O) and choose time lapse.

2. Set shutter interval and time of duration. Tap Start.

3. Tap ( ) to exit recording. Video will be automatically saved to documents.

#### (3) Motion Time Lapse

- 1. Switch to video mode. Tap 🙆 and choose motion time lapse.
- 2. Set shooting points

#### Auto Mode

- Manually adjust phone to ideal shooting point. Take photo at that direction and it will be shown as shooting point A on App. Likewise, the rest shooting points can be done in the same approach.
- According to the shooting points, VILTA will automatically generate shooting path.
- Adjust smoothness of the shooting path.

#### Manual Mode



- Freely set the shooting path by directly drawing on your phone screen.
- 3. Set shutter interval and time of duration. Tap Start.

(04) Slow Motion Video

1. Tap 🙆 and open Slow Motion.

2. Tap () to start recording. Tap () to exit recording. Videos will be automatically saved to documents.



#### 1. Photo Editing

- Enter App home page and tap = on the bottom
- Tap 💉 to choose the photo and editing (Filter, Beautify, Adjust, Mosaric, Crop, Paint )
- Tap Sto confirm editing

#### 2. Video Editing

- Tap 🖋 to choose the video and editing (Add Video, Video Editing, Add Music, Filter, Adjust)
- Tap v to confirm editing

### Specifications Parameter

Name	VILTA
Item No.	VT10
Dimensions	275*115*40mm(Folded)
Weight	520g
Supported Phones	Phones Width: 48 ~ 85mm

### Technical Parameter

01)	Mechanical Rotation Range	
	Tilt	±125°
	Roll	±90°
	Pan	360° (Infinite Rotation)

02	Controllable Rotation Range	
	Tilt	±115°
	Roll	±45°
	Pan	360° (Infinite Rotation)





Adaptive Rotation Speed ( ±500°/s)



Static Accuracy Tilt: 0.003° Roll: 0.003° Pan: 0.005° Dynamic Accuracy Tilt: 0.02° Roll: 0.02° Pan: 0.03°



Battery Type Voltage Working Current Battery Capacity Energy Consumption Intelligent Lithium Battery 7.4V Static: 100MA Dynamic: 5A 1900MAh 14.06Wh 1W

## Other Specification

Operating Temperature Wireless Type -10°C~40°C Bluetooth 4.2



### Warning

- Do not expose to fire or high heat
- Drop and collision will break VILTA. Please caution.
- Not water-proof. No water or liquid cleaning agent.
- Do not disassemble, repair or modify VILTA .
- Please apply charging cable complying with public safety regulation.
- Do not interfere VILTA operation when working.
- Not suitable for children.
- Not include smartphones.
- When mounting motion cameras, close the smartphone detection in App, or VILTA will not work.

### Warranty Rules

From the purchase date, you enjoy free repair within 12 months with this card if it occurs any quality problems.

If your VILTA meets the following requirements, you can enjoy the warranty policy :

- If within 7 days of purchase and it occurs manufacturing defect, the customer can choose to have a full refund(based on the invoice price) or exchange the product for a new one;
- Within 1year of purchase, you can enjoy free repair if it is non man-made problem,
- The Product has not been refitted, dissembled or modified.
- Valid purchase proof is provided

### Non Warranty Rules

If your VILTA falls under one of the following situations, we will charge appropriate maintenance cost :

- A man-made problem affecting the quality or product;
- Damage caused by refitting, disassemble, or opening of the shell;
- An uncontrollable incident (earthquake, fire, flood, war) resulting damage;
- Damage caused by not using as stated in the user manual

### Warranty Information

- The customer is at first required to pay the product return delivery fee. After Freevision after-sale service center receives the product, it will undergo a test;
- If the product does not conform to the conditions for free repair, Freevision will assess the problem and cost of repair, the customer has the right to repair or deliver it back.
- When you receive the repair service, please provide valid purchase proof and this warranty card.Please note: the warranty card only becomes valid after sale. The card can not be altered, or it will be deemed invalid.
- Freevision reserves the right of final interpretation.



## Customer Information

Name:		
TEL:		
Zip Code:		
Email:		
Address:		

## Dealer Information

Name:		
TEL:		
Zip Code:		
Email:		
Address:		

## Product Information

Item No.:		
Product Code:		
Purchase Date:		



## Warranty Card

				Inspection Date
				Repair Date
				Cause
				Result
				Technician Signiture

### IC WARNING

### **ISEDC RSS warning**

This device complies with Industry Canada licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

 l'appareil ne doit pas produire de brouillage, et
 l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



### **ISEDC Radiation Exposure Statement:**

This equipment complies with ISEDC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Cet appareil est

conforme aux limites d'exposition de rayonnement RF ISEDC établies pour un environnement non contrôlé.

Cetémetteur ne doit pas être co-implanté oufonctionner en conjonction avec toute autreantenne ou transmetteur.



## FCC WARNING

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



### Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.







Feel free to share your photos and videos with us and we might put them on our website.



Facebook.com/FreevisionVILTA

Twitter.com/FreeVisionVILTA

instagram.com/freevision\_vilta