DEPARTMENT OF THE ARMY TECHNICAL BULLETIN

CALIBRATION PROCEDURE FOR FREQUENCY COUNTER HEWLETT-PACKARD MODELS 5345A, 5345A/E28 AND 5345AOPT12

Headquarters, Department of the Army, Washington, DC 25 June 2001

Approved for public release; distribution is unlimited

REPORTING OF ERRORS AND RECOMMENDED IMPROVEMENTS You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedure, please let us know. Mail your letter or DA Form 2028 to: Commander, U. S. Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA-NP, Redstone Arsenal, AL 35898-5230. A reply will be furnished to you. You may also send in your comments electronically to our e-mail address: 2028@redstone.army.mil or FAX 256-842-6546/DSN 788-6546.

SECTION I.		IDENTIFICATION AND DESCRIPTION	Paragraph	Page
		Test instrument identification	1	2
		Forms, records, and reports	2	2
		Calibration description	3	2
	II.	EQUIPMENT IDENTIFICATION		
		Equipment required	4	3
		Accessories required	5	3
II	III.	CALIBRATION PROCESS		
		Preliminary instructions	6	4
		Equipment setup	7	4
		Time base stability	8	5
		Sensitivity	9	6
		A12 Interface I/O	10	8
		Power supply	11	9
		Final procedure	12	12

This bulletin supersedes TB 9-6625-1996-35, dated 13 November 1985.

SECTION I IDENTIFICATION AND DESCRIPTION

1. Test Instrument Identification. This bulletin provides instructions for the calibration of Frequency Counter, Hewlett-Packard, Models 5345A, 5345A/E28 and 5345AOPT12. The manufacturer's manuals were used as the prime data sources in compiling these instructions. The equipment being calibrated will be referred to as the TI (test instrument) throughout this bulletin.

a. Model Variations. Differences among models are listed within the text.

b. Time and Technique. The time required for this calibration is approximately 2 hours, using the dc and low frequency technique.

2. Forms, Records, and Reports.

a. Forms, records and reports required for calibration personnel at all levels are prescribed by TB 750-25.

b. Adjustments to be reported are designated (R) at the end of the sentence in which they appear. When adjustments are in tables, the (R) follows the designated adjustment. Report only those adjustments made and designated with (R).

3. Calibration Description. TI parameters and performance applications which pertain to this calibration are in table 1.

Test instrument parameters	Performance specifications		
Time base:	Frequency: 10 MHz		
	Aging rate (after 24 hour warmup): $< 5 \times 10^{-10}$ per day		
	Line voltage variation		
	(for 10% variation): $<1 \times 10^{-10}$ 15 minutes after change		
Channel A and B sensitivity:	Separate inputs:		
	25 mV rms: dc to 500 MHz (dc coupled)		
	Common inputs:		
	50 mV rms: dc to 400 MHz (dc coupled)		
A12 interface I/O	Range: -2 to +2 V dc		
	Accuracy: ±0.0005 V dc		

Table 1.	Calibration	Description
----------	-------------	-------------

SECTION II EQUIPMENT REQUIREMENTS

4. Equipment Required. Table 2 identifies the specific equipment to be used in this calibration procedure. This equipment is issued with Secondary Transfer Calibration Standards Set AN/GSM-287 or AN/GSM-705. Alternate items may be used by the calibrating activity. The items selected must be verified to perform satisfactorily prior to use and must bear evidence of current calibration. The equipment must meet or exceed the minimum use specifications listed in table 2. The accuracies listed in table 2 provide a four-to-one ratio between the standard and TI.

5. Accessories Required. The accessories required for this calibration are common usage accessories, issued as indicated in paragraph **4** above, and are not listed in this calibration procedure. The following peculiar accessories are also required for this calibration: Adapter, SMC jack to BNC plug, Hewlett-Packard Model 1250-0831; Extender Boards, 10-terminal circuit board extenders (05345-60201 and 05345-60202); and Extender Cable, Hewlett-Packard Model 05345-60205.

	1 1 1	1
		Manufacturer and model
Common name	Minimum use specifications	(part number)
AUTOTRANSFORMER	Range: 105 to 125 V ac	General Radio, Type
	Accuracy: ±1%	W10MT3AS3 (7910809) or
		Ridge, Model 9020A (9020A)
		or Ridge, Model 9020F (9020F)
FUNCTION GENERATOR	Range: 10 Hz to 30 MHz	(SG-1288/G)
	Amplitude: 0 to 40 mV rms	
	Accuracy: ±3% (±1.5 dB)	
FREQUENCY DIFFERENCE	Range: 10 MHz	3.7 to 12.4 GHz, Hewlett-
METER	Resolution: 1 part in 10 ⁻¹⁰ per day	Packard, Model 537A
		(7910718-2)
MULTIMETER	Range: -2 to +2 Vdc	Hewlett-Packard, Model
	Accuracy: ±0.000125%	3458A (3458A)
	Range: 0 to \pm 15 V dc	
	Accuracy: ±0.03%	
OSCILLOSCOPE	Bandwidth: 100 MHz	Tektronix, Type 2465BOPT46
	Sensitivity: 50 mV/div	(2465BOPT46)
	Sweep rate: 10 ns/div	
	Accuracy: ±3%	
SIGNAL GENERATOR	Range: 30 to 500 MHz	(SG-1207/U)
	Amplitude: 0 to 40 mV rms	
	Accuracy: ±3% (±1.5 dB)	
TIME/FREQUENCY	Frequency: 10 MHz	Autek Systems Corp. Model
WORKSTATION	Accuracy: 1.25 parts in 10 ⁻¹⁰ per day	620 (MIS-38946)

Table 2. Minimum Specifications of Equipment Required

SECTION III CALIBRATION PROCESS

6. Preliminary Instructions

a. The instruction outlined in paragraphs **6** and **7** are preparatory to the calibration process. Personnel should become familiar with the entire bulletin before beginning the calibration.

b. Items of equipment used in this procedure are referenced within the text by common name as listed in table 2.

c. Unless otherwise specified, verify the result of each test and, whenever the test requirement is not met, take corrective action before continuing with the calibration. Adjustments required to calibrate the TI are included in this procedure. Additional maintenance information is contained in the manufacturer's manual for this TI.

d. Unless otherwise specified, all controls and control settings refer to the TI.

7. Equipment Setup

WARNING

HIGH VOLTAGE is used or exposed during the performance of this calibration. DEATH ON CONTACT may result if personnel fail to observe safety precautions. REDUCE OUTPUT(S) to minimum after each step within the performance check where applicable.

a. Remove protective cover from TI only when necessary to make adjustments. Replace cover after completing the adjustments.

b. Connect TI rear panel **DIGITAL BUS 1.0 LOAD** to controller GPIB0 (opt 12 only).

c. Connect TI to autotransformer, connect autotransformer to a 115 V ac source and adjust for 115 V ac output.

d. Set **POWER** switch to **ON** and allow at least 1 hour for stabilization. If TI has been disconnected from line power for more than 24 hours, allow at least 24 hours for warmup before beginning calibration.

e. Set TI rear panel **INT STD/EXT STD** switch to **INT STD** and **INTERNAL/EXT ARM/EXT GATE** switch to **INTERNAL** (OPT 12 only).

f. Position controls as listed in (1) through (10) below:

- (1) **FUNCTION** switch to **FREQ A**.
- (2) **GATE TIME** switch to **100 ms**.
- (3) **DISPLAY POSITION** switch to **AUTO**.

- (4) **SAMPLE RATE** control fully ccw.
- (5) **CHANNEL A** and **B LEVEL** controls to **PRESET**.
- (6) **CHANNEL A** and **B SLOPE** switches to + (positive).
- (7) CHANNEL A and B input impedance switches to 50 W.
- (8) CHANNEL A and B ATTEN switches to X1.
- (9) CHANNEL A and B AC-DC switches to DC.
- (10) CHECK-COM A-SEP switch to SEP.

8. Time Base Stability

a. Performance Check

(1) Connect time/frequency workstation **OUTPUT 1 MHz** to frequency difference meter **REF INPUT**.

(2) Connect TI **FREQ STD OUTPUT 10 MHz** (rear panel) to frequency difference meter **SIG INPUT**.

(3) Adjust A18 FREQ ADJ (fig. 1) for minimum difference indication on frequency difference meter.



Figure 1. Test instrument - top view.

(4) Allow at least 24 hours for stabilization. Frequency difference meter indication will remain within 5 parts in 10^{-10} .

(5) Adjust autotransformer output to 105 V and allow 15 minutes for stabilization. Verify that TI oscillator drift is less than 1 part in 10⁻¹⁰.

(6) Adjust autotransformer output to 125 V and allow 15 minutes for stabilization. Verify that TI oscillator drift is less than 1 part in 10^{-10} .

(7) Adjust autotransformer output to 115 V.

b. Adjustments. No further adjustments can be made.

9. Sensitivity

a. Performance Check

- (1) Set function generator as listed in (a) through (c) below:
 - (a) **Output Type** to **UnBalanced 600**
 - (b) Function to **Sine Wave**.
 - (b) Frequency to **10 Hz**.
 - (c) Amplitude to **1 mV**.

(2) Position TI controls as listed in (a) through (f) below:

- (a) CHANNEL A LEVEL control to PRESET.
- (b) CHANNEL A SLOPE switch to +.
- (c) **CHANNEL A 50W/1MW** switch to **50W**.
- (d) CHANNEL A ATTEN X1/X10 switch to X1.
- (e) **CHANNEL A AC/DC** switch to **DC**.
- (f) CHECK/COM A/SEP switch to SEP.

(3) Connect TI **CHANNEL A** input to function generator **Function Output Unbalanced**.

(4) Press the function generator **Enter** key to enable the knob, and slowly rotate the function generator knob cw until TI display **GATE** light flashes and indication is stable at approximately 10 Hz.

(5) Verify that the function generator indicates within limits specified in table 3. If not perform **b** below.

(6) Repeat technique of 1 through (5) above for remaining settings listed in table 3.

Table 3. Sensitivity					
Test CHECK-COM		Function generator/signal		Function generator/signal	
instrument	A-SEP switch	generator	frequency	generator in	dications
input	setting	set	ting	(≤)	
CHANNEL A	SEP	10	Hz	0.071	VPP
CHANNEL A	SEP	10	kHz	0.071	VPP
CHANNEL A	SEP	100	kHz	0.071	VPP
CHANNEL A	SEP	1	MHz	0.071	VPP
CHANNEL A ¹	SEP	10	MHz	0.025	VRMS
CHANNEL A	SEP	100	MHz	0.025	VRMS
CHANNEL A	SEP	500	MHz	0.025	VRMS
CHANNEL A ²	COM A	10	Hz	0.141	VPP
CHANNEL A	COM A	10	kHz	0.141	VPP
CHANNEL A	COM A	100	kHz	0.141	VPP
CHANNEL A	COM A	1	MHz	0.141	VPP
CHANNEL A ¹	COM A	10	MHz	0.050	VRMS
CHANNEL A	COM A	100	MHz	0.050	VRMS
CHANNEL A	COM A	400	MHz	0.050	VRMS

¹Substitute the signal generator for the function generator. ²Substitute the function generator for the signal generator.

b. Adjustments

(1) Substitute signal generator for function generator.

(2) Connect signal generator **RF OUTPUT** connector to TI **CHANNEL A** input.

(3) Connect signal generator **EXT REF INPUT** connector (rear panel) to TI **FREQ STD OUTPUT 10 MHz** connector (rear panel).

(4) Extend front panel display assembly using extender cable 05345-60205. Disconnect CHAN A P1 caple from A9 J1 CHA (CHAN B P2 cable to A9 J2 CH B for **CHANNEL B**) and connect A9 J1 CH A (A9 J2 CH B for **CHANNEL B**) to oscilloscope **CHANNEL A**.

(5) Position TI **CHANNEL A** and **CHANNEL B** controls as listed in (a) through (f) below:

- (a) **LEVEL** control to **PRESET.**
- (b) **SLOPE** switch to +.
- (c) **IMPEDANCE** switch to **50W**.
- (d) **ATTEN** switch to **X1**.
- (e) **COUPLING** switch to **DC**.
- (f) **CHECK-COM A-SEP** switch to **SEP**.
- (6) Set signal generator frequency to 100 MHz and amplitude to 25 mV.
- (7) Position oscilloscope controls as listed in (a) through (f) below:
 - (a) **CH1 VOLTS/DIV** switch to **.2 V**.
 - (b) **SEC/DIV** switch to **20 ns**.
 - (c) Pull delayed sweep switch and set to **10 ns**.
 - (d) Set **TRIGGER MODE** pushbutton to **AUTO**.
 - (e) Set **TRIGGER SOURCE** pushbutton to **VERT**.
 - (f) Set **TRIGGER COUPLING** pushbutton to **DC**.

(8) Adjust A3R41 (fig. 2)(A3R3 (fig. 2) for **CHANNEL B**) for a symmetrical waveform displayed on oscilloscope (R).



Figure 2. A3 input attenuator (cmponent side).

(9) While alternately setting CHANNEL A and CHANNEL B SLOPE switches to (+) and (-), observe that waveform maintains its symmetrical form.

(10) Repeat (8) and (9) above as required to compensate for interaction.

(11) Disconnect oscilloscope and signal generator from TI, reinstall TI from panel, and reconnect CHAN A P1 cable to A9 J1 CH A and CHAN B P2 cable to A9 J2 CH B.

(12) Replace TI covers.

10. A12 Interface I/O

a. Performance Check

NOTE

This option can only be calibrated in an automated mode. The TI must be connected to a controller with a properly configured GPIB IEEE interface card.

NOTE

If you are running this section with any controller and or software other than the fielded controller and the ICE environment, you will have to write the required mnemonics and take reading as per the software that you are using.

(1) Connect TI and multimeter IEEE connectors to the controller GPIB0.

(2) Assure TI address is set to 2 and multimeter address is set to 12.

(3) Adjust TI CHANNEL A and CHANNEL B LEVEL controls to PRESET.

(4) Remove screws holding TI top cover. Do not remove top cover until instructed.

(5) Press the **RESET** key on the multimeter.

(6) Output the following mnemonic string to the TI: I2B500A500I1.

(7) Connect multimeter Input **HI** and **LO** to TI rear panel **CHAN A TRIG LEVEL**.

(8) Output the following mnemonic string to the TI: B500A000I1.

(9) Retrieve the reading from the multimeter. If the reading is not within limits listed in table 4, perform the listed adjustment.

(10) Repeat technique of (7) through (9) above for remaining table 4 entries.

Table 4. A12 Interface 1/0.					
	Connect multimeter to	Multimeter indication			
Output	test instrument			Perform adjust	
mnemonic	rear panel connector	Min	Max	listed below	
B500A000I1	CHAN A TRIG LEVEL	-2.0005	-1.9995	b 1	

Table 4. A12 interface I/O.

A:00I1	CHAN A TRIG LEVEL	1.9995	2.0005	b 2
B000I1	CHAN B TRIG LEVEL	-2.0005	-1.9995	b 3
B:00I1	CHAN B TRIG LEVEL	1.9995	2.0005	b 4

b. Adjustments

NOTE

Remove top cover to make adjustments, then replace top cover before repeating (a) above.

(1) Adjust A12 pot A (R69) (fig. 3) for a –2.0000 \pm 0.0005 V dc multimeter indication (R).

(2) Adjust A12 pot B (R74) (fig. 3) for a 2.0000 \pm 0.0005 V dc multimeter indication (R).

(3) Adjust A12 pot D (R86) (fig. 3) for a –2.0000 \pm 0.0005 V dc multimeter indication (R).

(4) Adjust A12 pot C (R82) (fig. 3) for a –2.0000 \pm 0.0005 V dc multimeter indication (R).



Figure 3. I/O adjustment location.

11. Power Supply

NOTE

Do not perform power supply check if all other parameters are within tolerance.

a. Performance Check

(1) Mount circuit board A6 (fig. 1) on extender boards.

(2) Connect multimeter between A6TP6 and + 5 V RET (fig. 4). If multimeter does not indicate between 4.98 and 5.02 V dc, perform $\mathbf{b}(1)$ below.

(3) Connect multimeter between A6TP3 and - 5.2 V RET (fig. 4). If multimeter does not indicate between -5.18 and -5.22 V, perform $\mathbf{b}(2)$ below.

(4) Replace circuit board A6 in TI and mount circuit board A7 (fig. 1) on extender boards.

(5) Connect multimeter between A7TP1 (A7TP2; serial prefix 1428A and prior) and + 15 RET (fig. 4). If multimeter does not indicate between 14.98 and 15.02 V, perform $\mathbf{b}(3)$ below.

(6) Connect multimeter between A7TP3 (A7TP7; serial prefix 1428A and prior) and -15 V RET (fig. 4). If multimeter does not indicate between -14.98 and - 15.02 V, perform **b**(4) below.

b. Adjustments

(1) Adjust R19 (fig. 4) for 5.00 V indication on multimeter (R).

(2) Adjust R29 (fig. 4) for 5.20 V indication on multimeter (R).

(3) Adjust R16 (fig. 4) (R18 (fig. 4); serial prefix 1428A and prior) for +15.00 V indication on multimeter (R).

(4) Adjust R17 (fig. 4) (R24 (fig. 4); serial prefix 1428A and prior) for -15.00 V indication on multimeter (R).



Figure 4. Power supply circuit boards.

12. Final Procedure

- **a**. Deenergize and disconnect all equipment.
- **b**. Annotate and affix DA label/form in accordance with TB 750-25.

By Order of the Secretary of the Army:

ERIC K. SHINSEKI General, United States Army Chief of Staff

OFFICIAL:

Jul B. Huhn

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 0116212

Distribution:

To be distributed in accordance with IDN 342172, requirements for calibration procedure TB 9-6625-1996-35.

K4XL's 🌮 BAMA

This manual is provided FREE OF CHARGE from the "BoatAnchor Manual Archive" as a service to the Boatanchor community.

It was uploaded by someone who wanted to help you repair and maintain your equipment.

If you paid anyone other than BAMA for this manual, you paid someone who is making a profit from the free labor of others without asking their permission.

You may pass on copies of this manual to anyone who needs it. But do it without charge.

Thousands of files are available without charge from BAMA. Visit us at http://bama.sbc.edu