

IDPLUS OPERATION

During the account setup process an automatic calendar date and time to transmit dose data was set.

At the scheduled date and time, the badge will attempt to transmit data to Mirion's secure servers. If communication does not occur, the badge will attempt to communicate every hour for 24 hours without intervention.

If the dosimeter is unable to communicate, the data will be stored until the next successful connection is established. Additionally, manual reads can be performed at any time by pressing the button on the back of the badge.

When performing manual reads push and hold the button on the back of the badge for at least 3 seconds.

FCC Part 15.21 statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RSS-GEN, Sec. 7.1.3 – (licence-exempt radio apparatus)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. Attention:

Les changements ou modifications de cet appareil non expressément approuvé par le fabricant peuvent annuler votre droit à utiliser cet équipement.