SAMSUNG ELECTRONICS


SAMSUNG

EO-BG93••

SAMSUNG







- Copyright © 2015 Samsung Electronics
 Bluetooth® is a registered trademark of
 Bluetooth SIG, Inc. worldwide.

 Please read this manual before using the device
 to ensure safe and proper use.

 Images may differ in appearance from the
 actual product. Content is subject to change
 without prior notice. You can access the
 full user manual for more information. Visit
 www.samsung.com to view device information,
 the user manual, and more.

Device layout

a	Charger port	9	Multifunction/Talk button	
0	Microphone	0	Power switch	
G	Neckband (Vibration area)	0	Rubber o-ring	
0	Volume button	0	Left earphone	
(Notification light	(3	Right earphone	
0	Magnet			

Charging the battery
Before using the headset for the first time, you must charge the battery.
Open the charging port cover and connect the headset to a charger.



- Chargers are sold separately.
 The charger should remain close to the electric socket and easily accessible while charging.
 The socket-outlet shall be installed near the equipment and shall be easily accessible.

Turning the headset on or off

Slide the Power switch to turn on or off the headset.



When you turn on the headset for the first time, it enters Bluetooth pairing mode.

Connecting devices via Bluetooth

You can receive incoming calls or listen to multimedia files when your headset is connected to Bluetooth-enabled devices.

- Turn on the headset, and then press and hold the Multifunction button for about three seconds to enter Bluetooth pairing mode. The notification light flashes red and blue.
- On your other device, activate the Bluetooth feature and tap Samsung Level U ANC from the list.

Connecting additional devices

The headset can connect to up to two Bluetoothenabled devices at the same time. For more information, refer to the user manual.

Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

website.

The headset contains magnets in its earbuds. The American Heart Association (US) and the Medicines and Healthcare Products Regulatory Agency (UK) both warn that magnets can affect the operation of implanted pacemakers, cardioverters, defibrillators, insulin pumps or other electro medical devices (collectively, "Medical Device") within the range of 15 cm (6 inches). If you are a user of any of these Medical Devices, DO NOT USE THE HEADSET UNLESS YOU HAVE CONSULTED WITH YOUR PHYSICIAN Use manufacturer-approved batteries.

Use manufacturer-approved batteries, chargers, accessories, and supplies Do not touch the device with wet hands

Do not drop or cause an impact to the charger or the device

Do not bend or twist the device excessively

The device can be used in locations with an ambient temperature of 0°C to 35°C. You can store the device at an ambient temperature of -20°C to 50°C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan

Do not allow children or animals to chew or suck the device

Do not disassemble, modify, or repair your device

Do not use a headset while driving or riding. Doing so may distract your attention and cause an accident, or may be illegal depending on your region



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods.

Correct disposal



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste.

This product is RoHS compliant.



This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste.

Removing the battery

- Removing the battery
 To remove the battery, you must visit an authorised service centre with the provided instructions.
 For your safety, you must not attempt to remove the battery. If the battery is not properly removed, it may lead to damage to the battery and device, cause personal injury, and/or result in the device being unsafe.
 Samsung does not accept liability for any damage or loss (whether in contract or tort, including negligence) which may arise from failure to precisely follow these warnings and instructions, other than death or personal injury caused by Samsung's negligence.

 Remove the rubber cover from the left side of the neckband by pulling it from the end of the left neckband. Then, remove the left neckband.

 Separate the earphone cable from the
- 2. Separate the earphone cable from the neckband cover.
- 3. Remove the neckband cover.
- 4. Disconnect the battery connector.
- 5. Lift the battery and cut the cables.
- 6. Remove the battery.





Declaration of Conformity

Declaration of Conformity

Product details
For the following
Product: Bluetooth Stereo Headset
Model(s): EO-86935

Declaration & Applicable standards
We hereby declare, that the product above is in compliance with
the essential requirements of the R&TTE Directive (1999/S/EC)
by application of EN.
SAFETY EN.60950-1: 2006 + A11: 2009 + A1: 2010 + A12: 2011
SAR EN.62479: 2010
EMC EN.301.489-1 V19.20 (09-2011)
EN.DI SAI SOURCE (2011/6/EVI) on the restriction of the use of certain hazardous substances in electrical and electronic equipment by application of EN.5081: 2012.

Representative in the EU
Samsung Bectronics Euro QALab.
Blackdoushe Business Park
Saxony Way, Yateley, Hampshire
GU46-66G, UK
2016.00.00
Stephen Colclough / EU Representative
(Place and date of issue)
(Name and signature of authorised person)
* This is not the address of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your product.