

TRANSIT™ – USER GUIDE FOR TRANSLATION:

USER GUIDE



User Guide

About

Setup

Info

Help

Safety

Regulations

Volume 'DOWN'

Option '∞' Button

Volume 'UP'

Press to OPEN Kickstand

Kickstand

Momentum Port™

Power Switch with LED

3.5mm Audio Input

Micro USB for Charging

TRANSIT™

The Ultimate Portable Speaker – Timeless Design & Unmatched Sonic Performance.

Portable High Performance

TRANSIT™ provides amazing room filling sound usually produced by speakers several times larger. Whether on the road or on your nightstand, its portable size, stylish design and unmatched performance makes TRANSIT the perfect companion for modern lifestyle.

incredible sound & Wireless freedom!

TRANSIT utilizes the most advanced transducer and acoustic technologies available today. SOEN™ wizards have engineered the most compelling acoustic engine for high performance portable speakers. These exclusive SOEN transducers combined with our other groundbreaking technologies including the revolutionary Momentum Port provide rich and, vibrant sound with thumping bass!

ABOUT SOEN AUDIO

SOEN was founded in California by industry leading designers, engineers and craftsmen brought together by their passions to create the world's finest audio products. We are committed to continuously push the frontiers of acoustics and bring you many more amazing products in future. The SOEN team thanks you for choosing TRANSIT and hopes that you will enjoy it for years!

For More Info

Learn more about our latest products and high-performance technologies online at: www.SoenAudio.com

Join the SOEN Tribe on Facebook

Keep in touch and stay informed about new SOEN products and member benefits available exclusively for our Facebook family. www.Facebook.com/SoenAudio

COMPATIBILITY

WIRELESS

TRANSIT works with any wireless Bluetooth® device profile 2.0 or above, including:

Phones / Smartphones

Tablets

MP3 Players

Computers equipped with Bluetooth wireless stereo

NOTE: When the 3.5mm jack is plugged in Bluetooth will be automatically turned off.

WIRED

TRANSIT will also work with any device that has a 3.5mm stereo output headphone jack.

PACKAGE CONTENTS

- TRANSIT Wireless Speaker
- Fold Flat MagPro™ Protective Cover
- Long-Life Rechargeable Battery
- Compact Wall Charger
- 36" (91cm) USB Charging Cable
- 36" (91cm) 3.5mm Stereo Audio Cable

POWER SWITCH LED LIGHT

White: Power is ON.

Red: Battery needs to be charged.

Purple: Battery is charging.

Blue Flashing: Searching for previously connected Bluetooth device, or in pairing mode.

Brief Green Flashing: TRANSIT is plugged and switched 'OFF' indicating the battery is fully charged.

Brief Purple Flashing: TRANSIT is plugged and switched 'OFF' indicating the battery is charging.

CONNECT TO YOUR BLUETOOTH DEVICE

Watch quick & easy setup videos for some of the most popular smartphones and tablets online at www.SoenAudio.com

Scan the QR code for direct access to the setup videos online.

1. Switch TRANSIT 'ON'.

TRANSIT comes partially charged and ready to use right out of the box. Just switch it 'ON'. If the light is **RED** or does not come 'ON' plug TRANSIT in using the included USB cable and charger. No damage will occur to the speaker or battery if used before a full charge.

2. Press-and-hold the Option button '∞' until TRANSIT begins emitting the Bluetooth pairing tone. The LED light on the switch will begin flashing blue indicating TRANSIT is in Bluetooth pairing mode and available to connect with your Bluetooth device. NOTE: while in Bluetooth pairing mode, TRANSIT will emit the Bluetooth pairing tone every 3 seconds.

3. On the phone or device you are connecting, access the Bluetooth settings, turn Bluetooth 'ON', then 'Add' or 'Search' for devices. When "TRANSIT" appears in the device list, select it. If a passcode is required, enter "0000". Once TRANSIT™ connects, it will emit the 'Connected' tone and the blue flashing light will stop. Time to Rock!

For additional Bluetooth setup help, review the instruction manual that came with the device you are trying to connect.

NOTE: This is a one-time setup for each device you connect to TRANSIT. To pair TRANSIT with another device, repeat the steps above. TRANSIT will remember up to 8 devices. After pairing more than 8 devices, the 1st device will have to be paired with TRANSIT again, in order to connect.

Bluetooth Auto-Reconnect

For your convenience, TRANSIT remembers the devices it pairs with, and will attempt to reconnect (for 15 seconds) to the last connected device every time it is turned 'ON'. If your device is out of range or has its Bluetooth feature turned 'OFF', TRANSIT will not be able to reconnect automatically. If the device goes out of range or loses connection with TRANSIT, you can easily reconnect by pressing the '∞' button once.

PLAY AUDIO USING THE 3.5MM CABLE

1. Connect the included 3.5mm stereo audio cable to any audio output device, and plug it into the TRANSIT '3.5mm Audio Input' jack.

NOTE: When the 3.5mm jack is plugged in Bluetooth will be automatically turned off.

CHARGING & PLAY TIME

The TRANSIT long-life battery is charged with the included wall charger using the provided USB to micro USB cable.

- An empty battery takes between 2 to 3 hours to fully charge using the wall charger, and will last between 4 to 8 hours on a full charge (actual battery playtime depends on volume level and playback content).
- The battery can be charged with the TRANSIT switched ON or OFF.

On Apple® iOS devices: The battery level of TRANSIT will be shown directly next to the battery level of your iPad® or iPhone®.

NOTE: The battery is not user replaceable.

AUTOMATIC 'SLEEP' MODE

To extend the battery playtime, TRANSIT automatically enters 'Sleep' mode if no Bluetooth or wired audio is playing. To wake TRANSIT from the 'Sleep' mode, simply press any button and the system will restart. TRANSIT will then attempt to reconnect using Bluetooth, or playback over the 3.5mm audio cable if it is plugged in.

PHONE CALLS

TRANSIT provides a great speakerphone experience for hands-free phone calls by utilizing an advanced integrated microphone and PreciseTalk™ technology.

Accept Call or End Call: Press the Option '∞' button once.

Reject Call: Press and hold the Option '∞' button until the 'REJECT Call' tone is heard.

KICKSTAND

The flip-out Kickstand feature allows TRANSIT to fold flat so it can easily slip into a computer bag or backpack pocket.

OPEN the Kickstand: Press the grooved button located on the back center of TRANSIT.

CLOSE the Kickstand: Press the kickstand closed and it will lock in place.

MagPro™ COVER

The self-attaching MagPro Cover helps to protect TRANSIT when on the go, and folds flat for easy storage when not in use. The cover utilized magnets to attach to the front and sides of TRANSIT.

To attach the cover, simply open the flaps, position it over the front and sides of the speaker grill and the magnets will hold the cover in place.

WARRANTY INFO

Through precision engineering, high quality materials and rigorous testing, we have worked hard to ensure the reliability of TRANSIT exceeds expectations.

. TRANSIT is backed by SOEN Audio with a one-year limited warranty against hardware defects. For any problems please visit www.SoenAudio.com for help and contact information.

STORAGE & TEMPERATURE

Do not leave the TRANSIT exposed to extreme temperatures above 130°F (45°C) or below 32°F (0°C). Prolonged exposure to extreme temperatures can cause damage to the TRANSIT battery and electronics. Do not leave TRANSIT exposed to direct sunlight for extended periods of time as this may damage or discolor the device.

TROUBLESHOOTING

1. Unable to connect or pair with Bluetooth Device.
 - a. Confirm that your phone, tablet, or device is compatible with Bluetooth version 2.0 or above by checking the user guide of the device you are trying to connect.
 - b. Make sure the 3.5mm audio cable is **NOT** plugged into TRANSIT. (NOTE: when the 3.5mm jack is plugged in, Bluetooth is automatically turned off.)
 - c. Follow the connection instructions in the 'SETUP' section of this User Guide.
 - d. Switch TRANSIT 'OFF' and back 'ON', and confirm the power LED light is lit white or purple. If the light is red or does not come on, plug TRANSIT in to charge the battery.
 - e. Make sure the volume on the TRANSIT is turned up by pressing the '+' button until you see the LED flash quickly.

2. Audio is dropping out.

- a. Move TRANSIT closer to the connected Bluetooth device.
- b. Make sure TRANSIT is charged, or plugged in and charging. The LED should be white, or if plugged in and charging, it should be purple.

3. AUDIO IS DISTORTED.

- a. Lower the volume on TRANSIT by pressing the '-' button.
- b. The best audio clarity will be achieved using the 3.5mm audio input cable.
- c. Make sure the TRANSIT Momentum Port is not blocked or obstructed.
- d. Switch TRANSIT 'OFF' and back 'ON'.
- e. Play a variety of tracks to confirm that the audio content is not corrupted or low (bit-rate) quality.

4. TRANSIT will not playback using 3.5mm audio input.

- a. Make sure the volume level is turned up on TRANSIT by pressing the '+' button until you see the LED flash quickly.
- b. Confirm audio is playing on your source device, and that the volume is turned up on the source device.
- c. Make sure the 3.5mm audio jack is plugged in FULLY to both TRANSIT and the source device.
- d. Confirm that there is no damage to the audio cable.
- e. Make sure TRANSIT is switched 'ON' and the power light is 'ON' and white, or purple.
- f. Make sure TRANSIT is charged or plugged in and charging.

Static Discharge

TRANSIT is designed to withstand normal static discharges, but in the event of a significant static discharge TRANSIT may lose Bluetooth connection or cause the LED light to momentarily change color or turn off. To correct, simply turn the power switch 'OFF' and back 'ON'.

TECH. SPECIFICATIONS

- Bluetooth v2.1+EDR compliant. Profiles: A2DP (wireless stereo Bluetooth), HFP
- Bluetooth wireless range: 33ft (10m)
- Size: 3.8in (96.8mm) wide, 6.6in (169mm) long x 1.3in (33.25mm) thin
- Weight: 1.1 lb. (0.5kg)
- Battery: Long-Life Lithium Ion
- Wall Charger: 5VDC 1A
- Micro USB port for charging.
- Temperature range for use: 130°F (45°C) or below 32°F (0°C)

BLUETOOTH INFO

- The typical range for Bluetooth is up to 33ft (10m).

- TRANSIT can pair with up to 8 devices, but can only playback from one device at a time.

SAFETY INFO

Please fully read all safety warnings carefully to ensure safety and prevent property damage.

Fire & Electrical Shock Hazard

- Do not expose TRANSIT to moisture, liquid, humidity, or rain because this may result in electrical shock, or damage to the device.
- Do not use TRANSIT near a bathtub, sink, sauna, pool, steam room or any moist environment because this may result in electrical shock or damage to the device.
- Do not drop, disassemble, open, bend, microwave, burn, or manipulate TRANSIT or any of its accessories because this may result in electrical shock.
- Do not insert foreign objects into TRANSIT, including any openings including the Momentum Port opening or speaker grill because this may result in electrical shock, or damage to the device.
- Only clean TRANSIT with a dry cloth when the device is unplugged from the charger.
- Do not block any of the openings of TRANSIT including the Momentum Port when it is in use.
- Do not use TRANSIT near any heat source including open flame, heater, stove, or radiator as this may cause permanent damage to TRANSIT.

Battery / Charging Hazard

- Do not remove or attempt to remove the non-user-replaceable battery. The battery is NOT replaceable.
- Do not dispose of TRANSIT in a fire; this could result in the battery exploding causing injury or death.
- Only charge the battery in accordance with the user instructions for TRANSIT. Use of non-specified charging method may cause damage to the battery or electronics and could result in fire and the battery exploding causing injury or death.
- Do not dismantle TRANSIT or charger because this may result in electrical shock.
- Do not charge TRANSIT in or around damp areas because this may result in electrical shock.
- Do not clean TRANSIT when it is plugged in. Only clean TRANSIT when it is unplugged from the charger.

AUTOMOBILE ACCIDENT HAZARD

- Do not become distracted by this product while driving.
- Do not position TRANSIT or any of its accessories near, on, above, or in front of any of your vehicle's airbags because serious injury or damage may result when an airbag deploys.

CAUTIONS

- TRANSIT contains no user serviceable components, attempting to open the speaker will void the warranty.
- Use only the supplied wall charger to charge TRANSIT. Other chargers may look similar but may cause damage to
- TRANSIT and may cause damage to the battery/electronics and could result in fire and the battery exploding causing injury or death.

- Where the mains plug of wall charger is used as the disconnect device, such disconnect device shall remain readily operable.
- Switch TRANSIT'OFF' using the power switch before boarding an aircraft, unless allowed by your airline.
- Do not place TRANSIT close to the edge of a table/shelf as vibrations from music playback may cause TRANSIT to shift and fall, and may cause damage to TRANSIT or anyone or anything affected by the fall.

PRODUCT DISPOSAL

- If you wish to dispose of this product, please do so in accordance with applicable national legislation or other rules in your country for the treatment of old electrical and electronic equipment.



This symbol indicates that the electrical and electronic equipment should not be disposed as general household waste at its end-of-life. Instead, the product should be handed over to the applicable collection point for the recycling in accordance with your national legislation. By disposing of this product correctly, you will help to conserve natural resources and will help prevent potential negative effects on the environment and human health that could otherwise be caused by inappropriate waste handling of this product.

For more information about collection point and recycling of this product, please contact your local municipal office, your household waste disposal service or the shop where you purchased the product. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

REGULATIONS

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules and Industry Canada RSS-210.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC statements

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio RSS-210.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Designed & Engineered by SOEN Audio,
31368 Via Colinas, Suite 106, Westlake Village
California 91362 USA

Phone/Fax: 1.888.418.3676
www.SoenAudio.com

© 2013 SOEN Audio All rights reserved. SOEN™, the SOEN™ logo and TRANSIT™ are trademarks of SOEN Audio
31368 Via Colinas Suite 106 Westlake Village CA USA.

Apple®, iPad® and iPhone® are trademarks of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logo are owned by Bluetooth® SIG, Inc. and any use of such marks by SOEN is under license.940-0042-001