

**BTC009**  
**Bluetooth hands free kit**  
**User Manual**

|  |          |
|--|----------|
| ■ <b>Before using</b> .....                        | <b>2</b> |
| 1. Brief introduction.....                         | 2        |
| 2. Overview.....                                   | 2        |
| 3. Installation.....                               | 2        |
| ■ <b>Using the hands free kit</b> .....            | <b>3</b> |
| 1. Pairing with Bluetooth enabled phone.....       | 3        |
| 2. Switching the hands free kit on/off.....        | 4        |
| 3. Making call with the hands free kit.....        | 4        |
| 4. Automatic connecting with Bluetooth device..... | 5        |
| 5. Indicator light.....                            | 5        |
| ■ <b>Care and maintenance</b> .....                | <b>6</b> |
| ■ <b>FAQ</b> .....                                 | <b>6</b> |
| ■ <b>Specification</b> .....                       | <b>7</b> |

## ■ Before using

### 1. Brief introduction

Welcome to use this Bluetooth hands free kit, BTC009. The product adopts echo cancellation technology and provides high-level sound quality. At the same time, it has simple hands free operation. Please read this user manual carefully before using it.

### 2. Overview




### 3. Installation

- 1) Insert the Hands free kit into your car's cigarette lighter socket;
- 2) Make sure the microphone is facing up towards the driver, and is unobstructed;
- 3) Make sure the speaker head is facing up towards the driver and there is not barrier between the driver and the hands free kit.

## ■ Using the hands free kit

### 1. Pairing with Bluetooth enabled phone

Please make sure your mobile phone has Bluetooth function that is available. Specific pairing steps may vary with different mobile phones. Please refer to your mobile phone user manual for further information. The steps are as follows:



- 1) Insert the hands free kit into your car's cigarette lighter socket;
- 2) Make sure your hands free kit is off (refer to "switching the hands free kit on/off");
- 3) Press and hold red button  for 7-8 seconds, and then release it until red and blue lights flashes alternately. The hands free kit entered into pairing mode.
- 4) Switch on Bluetooth function of mobile phone and search the Bluetooth device. After searched, select "BTC009" in the Bluetooth device list.
- 5) According to indication, enter password or PIN No.:"0000", and press the key of "Yes" or "confirm".
- 6) After successful pairing, select "BTC009" in the Bluetooth device list, and press

“connect”. After successful connecting, the blue light will flash once every 5 seconds.








**Remarks:**




- ◆ The pairing mode will last 2 minutes. The hands free kit will exit pairing mode automatically if it can't be connected with any other device after 2 minutes. If you want to continue to pair the hands free kit with Bluetooth device, please switch off the hands free kit firstly, and then re-pair according to steps 1-6 mentioned above.
- ◆ After successful pairing, the hands free kit and mobile phone will remember each other, the hands free kit will not need to re-pair with Bluetooth device when use next time unless the pairing information is deleted because of new pairing.
- ◆ The hands free kit can pair with 8 paired devices, when paired devices exceed 8 Bluetooth devices, the first one will be replaced.
- ◆ When you switch on the hands free kit every time, it will connect with last connected device automatically. If you want to pair it with other device, please switch off Bluetooth function of current Bluetooth device paired with the hands free kit firstly, and then pair the hands free kit with new device according to steps 1~6 mentioned above.

**2. Switching the hands free kit on/off**

| Function                      | Operation  |
|-------------------------------|--|
| Switch on the hands free kit  | Press and hold red button  for about 3-5 seconds, and then release it until the blue indicator light flashes. |
| Switch off the hands free kit | Press and hold red button  for about 3-5 seconds, and then release it until the red indicator light flashes.  |

**3. Making call with the hands free kit**

| Function        | The status of the hands free kit | Operation   |
|-----------------|----------------------------------|---|
| Answer call     | Ringing                          | Short press green button  once   |
| Reject call     | Ringing                          | Short press red button  once   |
| Cancel calling  | Calling                          | Short press red button  once   |
| End call        | Conversation mode                | Short press red button  once   |
| Adjust volume   | Conversation mode                | Adjust volume wheel   |
| Transfer call   | Conversation mode                | Short press green button  once to transfer the call to mobile phone, short press  once again to transfer the call to the hands free kit<br><b>Remark:</b> Maybe some mobile phones have to operate on the mobile phone to transfer the call to the hands free kit |
| Microphone mute | Conversation mode                | Press and hold green button  for about 2 seconds, and then release it until hearing indication tone. When the microphone is mute, the  |

|                  |  |  |
|------------------|--|--|
|                  |  | hands free kit sounds indication tone every 5 seconds  |
| Cancel mute      | Conversation mode (microphone mute)            | Press and hold green button  for about 2 seconds, and then release it until hearing indication tone |
| Redial last call | Standby mode (connected with Bluetooth device) | Press and hold green button  for about 2 seconds, and then release it until hearing indication tone |
| Voice dial       | Standby mode (connected with Bluetooth device) | Short press green button  once  |

**Remarks:**

- ◆ Not all the mobile phones support all the functions listed above. Please refer to your mobile phone user manual for further information.
- ◆ For some mobile phones, when you press the answer button on the phone, the call will be transferred to mobile phone. At this time, you need to transfer the call to the hands free kit through operating on your mobile phone. Please refer to your mobile phone user manual for further information.

**4. Automatic connecting with Bluetooth device**

The hands free kit will connect with last paired device automatically when turn on it every time.

**Remarks:**

- ◆ The hands free kit only try to connect with last connected device.
- ◆ Before connecting with Bluetooth device, please switch on Bluetooth function of your Bluetooth device.
- ◆ For some Bluetooth devices, take some Nokia mobile phones for example, you have to set up to allow automatic connecting on the mobile phone.

**5. Indicator light**

| Indicator light                         | The status of hands free kit                         |
|---|--|
| Red and blue lights flashes alternately | Pairing mode   |
| Blue light flashes once every 1 second  | Not connected with Bluetooth device                  |
| Blue light flashes once every 5 seconds | Connected with Bluetooth device or conversation mode |
| Blue light flashes quickly              | Incoming call/calling                                |

## ■ **Care and maintenance**

Please read the following suggestions carefully, that will help you to fulfill any warranty obligations and enjoy this product for many years.

- ◆ Keep dry and don't put it in the damp place, so as not to affecting the interior circuit of product.
- ◆ Don't put the product under the sunlight or place in hot areas. High temperature will shorten the life of electronic device, destroy the battery, or distort certain plastic.
- ◆ Don't expose the product in the cold areas. It may damage the internal circuit board.
- ◆ Don't try to take apart the product. It may damage the product if you are not professional.
- ◆ Don't fall off on the floor or knock the hard substance. It may damage interior circuit.
- ◆ Don't use intensify chemical or detergent to clean the product.
- ◆ Don't scrap the surface with sharp things.

If the product can't work normally, please send it to the regularly asserted store. The staff will help you to solve the problem warmly.

## ■ **FAQ**

### **1. Why can not my mobile phone find the hands free kit?**

The mobile phone will not find the hands free kit if the hands free kit is not in the pairing mode, Make sure the hands free kit is in the pairing mode and in the effective working range, the mobile phone can pair with the hands free kit.

### **2. Why is the effect of call not good?**

- a) Please make sure the hands free kit in the strong signal areas;;
- b) Please make sure the hands free kit is in the effective working range.

### **3. How far is the effective rang between the hands free kit and mobile phone?**

According to the Bluetooth standard, the max. controllable range of Class2 hands free kit is 10 meters. It varies under different environment.

### **4. Why is there no sound from the loudspeaker of the hands free kit during a conversation?**

- a) Please make sure the hands free kit has already connected with mobile phone well;
- b) Pleaser make sure the volume of the hands free kit has already been adjusted to proper position.

## ■ Specification

|                            |                         |
|----------------------------|-------------------------|
| <b>Bluetooth version</b>   | Bluetooth V 2.0         |
| <b>Bluetooth profiles</b>  | Headset, Hands free     |
| <b>Effective range</b>     | 10m                     |
| <b>Power supply</b>        | DC 12V $\approx$ 300 mA |
| <b>Working temperature</b> | -10 ~ 45°C              |
| <b>Storage temperature</b> | -20~70°C                |
| <b>Dimension</b>           | 72*50*38mm              |
| <b>Weight</b>              | 48g                     |

### Note

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

**Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**