

## Phosphate 3

Range(s): 0-3.00 ppm  $\text{PO}_4^{3-}$ , 0-0.98 ppm P, 0-2.24 ppm  $\text{P}_2\text{O}_5$   
20-3000 ppb  $\text{PO}_4^{3-}$ , 0-980 ppb P, 0-2240 ppb  $\text{P}_2\text{O}_5$



### Procedure

Note: When testing multiple samples simultaneously, a separate sample cell with an unreacted sample of the water tested must be used to zero the colorimeter. Please note that varying the test procedure from the original can affect the precision of the test.

Note: Glassware that has not been properly cleaned may contaminate the sample and affect test results. Clean glassware thoroughly before use with phosphate-free detergent (available in local stores); then rinse with Hydrochloric Acid 3N (R-0737) followed by DI Water (R-0833) or sample water.

1. Turn on the Colorimeter.
2. For results to be displayed in terms of ppm, select a test menu (ALL TESTS, RECENT TESTS, or FAVORITES) containing Phosphate 3 using  $\blacktriangleleft\blacktriangleright$ .

For results to be displayed in terms of ppb, select a test menu (ALL TESTS, RECENT TESTS, or FAVORITES) containing Phosphate 3000 using  $\blacktriangleleft\blacktriangleright$ .

3. Select the appropriate test (Phosphate 3 or Phosphate 3000) using  $\blacktriangle\blacktriangledown$ ; then press ENTER  $\odot$ .
4. Select a chemical form ( $\text{PO}_4$ , P, or  $\text{P}_2\text{O}_5$ ) for expression of test results using  $\blacktriangle\blacktriangledown$ .
5. Rinse and fill 25 mm sample cell to 10 mL mark with sample; then cap.
6. Insert sample cell into sample cell compartment. Align marks per User's Manual.
7. Select ZERO using  $\blacktriangleleft\blacktriangleright$ ; then press ENTER  $\odot$ . Zero will be displayed.
8. Remove sample cell from sample cell compartment; then remove cap.

9. Add 1 mL Phosphate 3 - Reagent A; then swirl to mix.
10. Using the 0.05 g dipper spoon, add 1 level dipper Phosphate 3 - Reagent B; then cap and swirl to mix for 30 seconds.
11. Insert sample cell into sample cell compartment. Align marks.
12. Select TIMER using  $\blacktriangleleft\blacktriangleright$ ; then press ENTER  $\odot$ .
13. Select START using  $\blacktriangleleft\blacktriangleright$ ; then press ENTER  $\odot$ . (A 5-minute [05:00] countdown will begin.) Immediately select AUTO using  $\blacktriangleleft\blacktriangleright$ ; then press ENTER  $\odot$ .
14. When the timer beeps, the instrument will read the sample and the result will be displayed.

### Interferences

Arsenate, all levels – positive interference  
Biguanide (as product) > 20 ppm – negative interference  
Nitrite > 250 ppm – negative interference

The following analytes were tested to the levels listed and found not to cause any interference up to the specified values:

Alkalinity, Total ( $\text{CaCO}_3$ ) – 500 ppm  
Azole (BT) – 5 ppm

Azole (TT) – 5 ppm  
Chloride – 3600 ppm  
Copper – 5 ppm  
Fluoride – 10 ppm  
Hardness, Calcium ( $\text{CaCO}_3$ ) – 1000 ppm  
Iron, Ferric – 10 ppm  
Iron, Ferrous – 10 ppm  
Molybdenum – 10 ppm

Nitrate – 2000 ppm  
Phosphonate (HEDP) – 20 ppm  
Polymer – 20 ppm  
Silica – 150 ppm  
Sulfate – 1000 ppm  
Sulfite – 100 ppm  
Zinc – 10 ppm

**Test Method**

Molybdenum Blue

Under acidic conditions, phosphate reacts with ammonium molybdate producing a heteropoly acid, which is then reduced with ascorbic acid to produce an intense blue color proportional to the concentration of phosphate in a sample.

**Estimated  
Detection Limit**

0.02 ppm  $\text{PO}_4^{3-}$  (20 ppb  $\text{PO}_4^{3-}$ )

**Precision**

Using two lots of reagent and a standard solution of 1.5 ppm  $\text{PO}_4^{3-}$  (1500 ppb  $\text{PO}_4^{3-}$ ), an individual analyst obtained a standard deviation with the instrument of  $\pm 0.01$  ppm  $\text{PO}_4^{3-}$  (10 ppb  $\text{PO}_4^{3-}$ ).

**Application**

Industrial Water, Potable Water, Recreational Water, and Wastewater

**Ordering Info****Reagent Pack**

K-8005 Phosphate 3

Formulated for exclusive use with Taylor's TTi® Colorimeter.

**Reagent Pack Components**

R-8005A Phosphate 3 - Reagent A

R-8005B Phosphate 3 - Reagent B

**Optional Reagents & Accessories**

R-0737 Hydrochloric Acid 3N

R-0833 DI Water



31 Loveton Circle, Sparks, MD 21152 U.S.A.  
800-TEST KIT (837-8548) • 410-472-4340  
customerservice@taylortechnologies.com