Pen Genevations

How to install the PC application

■ Download the PenHub Software on the website(www.pengenerations.com)






- It takes longer time in WinXP than other OS because the .NET framework is also installed.

How to Bluetooth pairing(Registering) in PC

■ In case of using the EZ dongle



Attach the EZ dongle to the USB port.

Check the LED of EZ dongle whether it is blinking or not.

Turn on the ADP-601 pen.

Check the LED of EZ dongle and ADP-601 whether they keep turning on.

■ In case of using the embedded Bluetooth of PC or using the common Bluetooth dongle



- Some PC doesn't support to connect Bluetooth pairing with pen directly. Please use the common Bluetooth dongle or EZ dongle or the common Bluetooth dongle at this time.
- Please disable or delete the embedded Bluetooth hardware in the PC when common Bluetooth dongle conflict with the PC's
- Using the pen for the first time



ADP-601 can be easily connected with PC by tapping the pen tip on the note or anything after Bluetooth registering.

(The top GREEN LED keeps turning on when ADP-601 is connected to PC successfully.)


■ Re-registration for using EZ dongle

 If user fail to do Bluetooth pairing repeatedly or try to use another ADP-601, please refer the step in below;

RESET BUTTON


A. Attach the EZ dongle to USB port of PC

B. Press the "RESET SWITCH" on the EZ dongle with a sharp things such as pin. Then, the LED on EZ dongle start to blink quickly.
C. Turn on the ADP-601.



Specification

Model	PGD - 601
Weight	2.4g
Communication	Bluetooth 2.0
Host Interface	USB 2.0(Type A)
Bluetooth Profile	HID (ADP-601 Proprietary)
Dimension	7.0mm x 2.0mm x 1.2mm(L x W x D




Notice

- Please keep this user's guide in an easily accessible place and read through the complete document before the dongle is used.
- Dongle only supports ADP-601 digital pen and has no memory inside.
- Do not open or disassemble the dongle, take special care not to damage.
- Do not drop the dongle or allow any other kind of strong impact.
- Consult your point of purchase if the dongle needs repair.
- Dongle may cause a choking hazard.
- Do not expose the dongle to water or any other fluids. It is not waterproof or water resistant. Do not leave it in damp conditions.
- Do not expose the dongle to extreme temperatures or direct sunlight.
- The dongle is intended for indoor usage.
- Clean with a dry cloth. Do not use water, soap, detergent or other chemicals which may deform the dongle.

Quick Setup Guide

For PGD-601



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.