

1.5 User Manual & Datasheet

CS3180 Wetness Sensor User Manual

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and*
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. Product description

CS3180 is a wetness sensor to be used with CS3300 all-in-one bridge/registration center together. It communicate with CS3300 via Bluetooth 4.1.

2. Set up procedure

A. Registration :

- Unpack CS3180 from the standard packing and insert into the slot on the top of CS3300 as below.



-
- Wait for 15 seconds. A security key will be written into the memory of CS3180 automatically.

B. Normal Mode :

- After step A, remove CS3180 from the slot and plug it into the sensor pad.
- CS3180 is ready for use.
-