

CODAWheel Manual

CODAWheel is a remote control designed for smartphones, based on Bluetooth Low Energy (BLE) technology. Its primary purpose is to facilitate the use of voice command services such as Siri® or Google Now® in Bluetooth hands-free mode in your car. Further, you can also edit its settings to perform various tasks using the configuration app, CODAWheel.

Minimum Requirements

- iOS® ver 7.0 and up with Siri or Android® Kitkat with Google Now and support for BLE.
- Factory-built or 3rd party in-car Bluetooth hands-free system/device recommended for voice command inside a vehicle.

1. Activating CODAWheel

Turn power on by sliding the button on the back of CODAWheel. Through Bluetooth Low Energy (BLE) technology, CODAWheel's stand-by time is expected to last several years and therefore, turning off power is virtually not necessary under normal conditions. You may attach double sided tapes or Velcro® sticky fastener to the back of the CODAWheel for mounting purposes.

2. Pairing CodaWheel

Before pairing, make sure that CODAWheel is not connected to any smartphone. If connected, it will not enter the pairing mode. To disconnect CODAWheel, turn Bluetooth off on the smartphone.

Press the button on CODAWheel for 15 seconds until green and red LEDs flash alternately. CODAWheel is now ready for pairing. From your smartphone, go to Bluetooth settings and initiate pairing. For step-by-step instructions, please refer to your smartphone manual.

3. Configuration Application

CODAWheel is pre-configured to emulate smartphone's Home button. Using the configuration application, you can change its settings to perform tasks such as:

- Voice command: Click to start Siri or Google Now.
- Voice command with music control: Emulate headphone in-line remote button.
- Camera shutter release: With a camera application running, click to take photos.
- Compatible applications: Use CODAWheel as a remote button for 3rd party applications. Refer to the application manual for details.

The name of the configuration application is CODAWheel. It can be downloaded and installed from Apple App Store® or Google Play Store® on your smartphone.

4. Sleep Mode

To conserve battery power, CODAWheel enters sleep mode after a period of inactivity. Click CODAWheel to leave sleep mode. Red LED will start to blink and the connection between your phone and CODAWheel will resume. Once CODAWheel becomes active, it does not require any other setup.

5. Mounting

CODAWheel can easily be placed anywhere in your car. You can attach it on the steering wheel, dashboard, or next to gear shift. Included in the box are double sided tape and Velcro sticky fastener for mounting purposes.

One-Year Limited Warranty.

Enustech warrants the said product to be free from defects in materials and workmanship for 1 year. If the said product is found to be defective, Enustech will repair or replace it. If you have any questions, comments or concerns about the said product, please contact :

Email:

Phone:

www.bcoda.com

Technical Support

www.bCoda.com/support

(C) 2014 Enustech Inc. All rights reserved.

bCoda^(tm) and CODAWheel^(tm) are registered trademarks of Enustech, Inc. Korea.

iPhone®, iOS®, Siri®App Store® are registered trademarks of Apple Inc.

Android® and Play Store® are registered trademarks of Google Inc.

Velcro® is a registered trade mark of Velcro Industries B.V.

Bluetooth® word mark and logos are registered trademarks owned by Bluetooth
SIG, Inc.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

IMPORTANT NOTE:

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Manuel de CODAWheel

CODAWheel est une télécommande conçue pour les smartphones, basée sur la technologie de Bluetooth Low Energy (BLE). Son principal objectif est de faciliter l'utilisation des services de commande vocale comme Siri® ou Google Now® dans le mode Bluetooth mains-libres dans votre voiture. En outre, vous pouvez également modifier les paramètres pour effectuer diverses tâches en utilisant l'application de configuration, CODAWheel.

Exigences minimales

iOS® version 7.0 avec Siri ou Android® KitKat avec Google Now et assistance pour BLE.

Système mains-libres Bluetooth préfabriqué ou tierce partie dans votre voiture/dispositif recommandé pour la commande de voix à l'intérieur d'un véhicule.

1. Mise en route de CODAWheel

Mettez sous tension en faisant glisser le bouton à l'arrière de CODAWheel. Grâce à la technologie de Bluetooth Low Energy (BLE), la durée d'utilisation de CODAWheel devrait durer plusieurs années et, par conséquent, la mise hors tension n'est pas nécessaire pratiquement dans des conditions normales. Vous pouvez mettre des adhésifs à double face ou des fixations collantes de velcro® à l'arrière du CODAWheel pour le coller sur une surface.

2. Couplage CODAWheel

Avant le couplage, assurez-vous que le CODAWheel n'est pas connecté à aucun smartphone. S'il est connecté, le mode de couplage ne fonctionnera pas. Pour déconnecter le CODAWheel, désactivez le Bluetooth sur le Smartphone.

Appuyez sur le bouton « ON » du CODAWheel pendant 15 secondes jusqu'à ce que les LED vertes et rouges clignotent en alternance. Le CODAWheel est maintenant prêt pour le couplage. De votre smartphone, allez dans les paramètres du Bluetooth et activer le couplage. Pour obtenir des instructions étape-par-étape, veuillez vous référer au manuel de votre smartphone.

3. Application de la configuration

CODAWheel est pré-configuré pour émuler le bouton Accueil du smartphone. En utilisant l'application de la configuration, vous pouvez modifier ses paramètres pour effectuer des tâches telles que:

- Commande vocale: Cliquez pour lancer Siri ou Google Now.

- Commande vocale avec le contrôle de musique: Emulez le casque sur le bouton de la télécommande en ligne.

- Le déclencheur de l'obturateur de l'appareil photo: Avec une application de l'appareil photo en marche, cliquez pour prendre des photos.

- Applications compatibles: Utilisez CODAWheel comme un bouton de la télécommande pour les applications de tierce partie. Reportez-vous au manuel de l'application pour plus de détails.

= Le nom de l'application de la configuration est CODAWheel. Elle peut être téléchargée et installée à partir de l'Apple App Store® ou de Google Play Store® sur votre smartphone.

4. Mode veille

Pour économiser la batterie, CODAWheel passe en mode veille après une période d'inactivité. Cliquez sur CODAWheel pour quitter le mode veille. Le LED rouge se met à clignoter et la connexion entre votre téléphone et CODAWheel se réactivera. Une fois que CODAWheel devient actif, il ne nécessite aucune autre configuration.

5. Montage

CODAWheel peut facilement être placé n'importe où dans votre voiture. Vous pouvez l'attacher sur le volant, le tableau de bord, ou à côté du changement de vitesse. Un adhésif double face et la fixation collante de velcro pour la fixation sont inclus dans la boîte.

Garantie limitée d'un an

Enustech garantit ce produit pour les défauts sur le matériel et sur la fabrication pour 1 an. Si ce produit s'avère défectueux, Enustech s'engage à le réparer ou à le remplacer. Si vous avez des questions, des commentaires ou des préoccupations concernant ce produit, veuillez contacter :

Email

Téléphone

www.bcoda.com

Soutien technique

www.bCoda.com/support

(C) 2014 Enustech Inc. Tous droits réservés.

bCoda(tm) et CODAWheel(tm) sont des marques déposées de Enustech, Inc. Corée

iPhone®, iOS®, Siri®, App Store® sont des marques déposées d'Apple Inc.

Android® et Play Store® sont des marques déposées de Google Inc.

Velcro ® est une marque déposée de Velcro Industries BV

La marque et les logos de Bluetooth® sont des marques déposées appartenant à Bluetooth SIG, Inc.

"This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device."