

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
A0	Release for SWKT production	06/27/18	MA

Front

ListenTALK  
Quick Start Guide

• LKR-12



**LISTEN** TECHNOLOGIES  
For more information visit  
[www.listentech.com](http://www.listentech.com)



## INTRODUCTION

### Thank you for purchasing ListenTALK!

For additional details on use, adjustment, or programming, download the full ListenTALK Operations Manual from [www.listentech.com/support/manuals](http://www.listentech.com/support/manuals). To purchase headsets and other accessories, visit: [www.listentech.com/shop-listen](http://www.listentech.com/shop-listen).

### Charge ListenTALKs

Remove the protective screen cover and clear plastic battery isolation tab. Fully charge by connecting Micro USB to USB charger or charge in the optional Docking Station. Status LED will flash and then be lit solid when fully charged. Optionally, insert three AAA alkaline batteries into Transceivers equipped with the Alkaline Battery Case.


### Power On

Press and hold Power Button to turn on. Press and hold three seconds to turn off. Green LED will flash and then be lit solid green when device is on and paired to a group leader. Green LED will continue flashing if receiver is not paired to a group or the leader is not turned on.

While unit is on, momentarily press Power Button to activate the LED Status. If the unit is paired the status LED will flash green once followed by the white LED flashing the battery status: 1 = 1/4, 2 = 1/2, 3 = 3/4 and 4 = Full.

## Application Notes

- Size: Width - 222.25mm Height - 82.55mm
- Material: Regular paper weight
- Print Color(CMYK): 4/4 CMYK
- Fonts: Open Sans Regular  
Open Sans Regular Italic  
Open Sans Semibold  
Open Sans Bold  
Open Sans Bold Italic
- Fold: 5 Panel, 4 folds
- Template file for mass printing
- All material must meet RoHS requirements
- USE ARTWORK FILE FOR PRINT - THIS IS A CONTROL DOCUMENT ONLY
- NO SUBSTITUTIONS without prior consent from Listen Technologies



Accordian fold

© 2018 Listen Technologies Corporation®  
All Rights Reserved 2018

Visit Listen at [www.listentech.com](http://www.listentech.com)  
or telephone +1.801.233.8992 or  
1.800.330.0891

20180516

**LISTEN**  
TECHNOLOGIES

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LISTEN TECHNOLOGIES CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF LISTEN TECHNOLOGIES CORPORATION IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:

DIMENSIONS ARE IN MILLIMETERS TOLERANCES:  
FRACTIONAL  $\pm 1/10$   
ANGULAR: MACH  $\pm 1$  BEND  $\pm 1$   
ONE PLACE DECIMAL  $\pm .05$   
TWO PLACE DECIMAL  $\pm .005$

INTERPRET GEOMETRIC TOLERANCING PER:

MATERIAL  
See Notes

FINISH  
See Notes

DO NOT SCALE DRAWING

DRAWN

CHECKED

ENG APPR.

MFG APPR.

Q.A.

COMMENTS:

NAME

MA

DATE

06/27/18

ITEM # 103266

TITLE:  
CARD REFERENCE  
QUICK LKR-12

SIZE PART:

B FILE-005874

REV

A0

SCALE: 1:1 WEIGHT:

SHEET 1 OF 4

ListenTALK  
Quick Start Guide

• LKR-12



**LISTEN** TECHNOLOGIES  
For more information visit  
[www.listentech.com](http://www.listentech.com)



INTRODUCTION

Thank you for purchasing  
ListenTALK!

For additional details  
on use, adjustment, or  
programming, download the  
full ListenTALK Operations  
Manual from [www.listentech.com/support/manuals](http://www.listentech.com/support/manuals). To  
purchase headsets and  
other accessories, visit: [www.listentech.com/shop-listen](http://www.listentech.com/shop-listen).

Charge ListenTALKs

Remove the protective  
screen cover and clear  
plastic battery isolation tab.  
Fully charge by connecting  
Micro USB to USB charger  
or charge in the optional  
Docking Station. Status LED  
will flash and then be lit  
solid when fully charged.  
Optionally, insert three  
AAA alkaline batteries into  
Transceivers equipped with  
the Alkaline Battery Case.

Power On

Press and hold Power Button  
to turn on. Press and hold  
three seconds to turn off.  
Green LED will flash and  
then be lit solid green when  
device is on and paired to a  
group leader. Green LED will  
continue flashing if receiver is  
not paired to a group or the  
leader is not turned on.

While unit is on, momentarily  
press Power Button to  
activate the LED Status. If the  
unit is paired the status LED  
will flash green once followed  
by the white LED flashing the  
battery status: 1 = 1/4, 2 =  
1/2, 3 = 3/4 and 4 = Full.

**LISTEN**  
TECHNOLOGIES

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED  
IN THIS DRAWING IS THE SOLE  
PROPERTY OF LISTEN  
TECHNOLOGIES CORPORATION.  
ANY REPRODUCTION IN PART OR  
AS A WHOLE WITHOUT THE  
WRITTEN PERMISSION OF LISTEN  
TECHNOLOGIES CORPORATION IS  
PROHIBITED.

UNLESS OTHERWISE SPECIFIED:

DIMENSIONS ARE IN  
MILLIMETERS TOLERANCES:  
FRACTIONAL  $\pm 1/10$   
ANGULAR: MACH  $\pm 1$  BEND  $\pm 1$   
ONE PLACE DECIMAL  $\pm .05$   
TWO PLACE DECIMAL  $\pm .005$

INTERPRET GEOMETRIC  
TOLERANCING PER:

MATERIAL  
See Notes

FINISH  
See Notes

DO NOT SCALE DRAWING

DRAWN

CHECKED

ENG APPR.

MFG APPR.

Q.A.

COMMENTS:

NAME

MA

DATE

06/27/18

ITEM # 103266

TITLE:  
CARD REFERENCE  
QUICK LKR-12

SIZE PART:

B FILE-005874

REV

A0

SCALE: 1:1 WEIGHT:

SHEET 2 OF 4

</

6

5

4

3

2

1

D

D

C

C

B

B

A

A

6


5

4

3

2

1



PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED  
IN THIS DRAWING IS THE SOLE  
PROPERTY OF LISTEN  
TECHNOLOGIES CORPORATION.  
ANY REPRODUCTION IN PART OR  
AS A WHOLE WITHOUT THE  
WRITTEN PERMISSION OF LISTEN  
TECHNOLOGIES CORPORATION IS  
PROHIBITED.

UNLESS OTHERWISE SPECIFIED:

DIMENSIONS ARE IN  
MILLIMETERS TOLERANCES:  
FRACTIONAL  $\pm 1/10$   
ANGULAR: MACH  $\pm 1$  BEND  $\pm 1$   
ONE PLACE DECIMAL  $\pm .05$   
TWO PLACE DECIMAL  $\pm .005$

INTERPRET GEOMETRIC TOLERANCING PER:

MATERIAL  
See Notes

FINISH	See Notes
--------	-----------

DO NOT SCALE DRAWING

DRAWN

CHECKED

1	ENG APPR.
---	-----------

MFG APPR.

Q.A.

COMMENTS:

NAME

MA

DATE \_\_\_\_\_

06/27/18

**ITEM # 103266**

TITLE: CARD REFERENCE  
QUICK LKR-12

SIZE <b>B</b>	PART: <b>FILE-005874</b>	REV <b>A0</b>
------------------	-----------------------------	------------------

SCALE: 1:1	WEIGHT:	SHEET 4 OF 4
------------	---------	--------------