



Smart Life

Thank you for using smart camera

Basic Parameters

Product Name: Smart Camera
Pixel: 1.0Mp/2.0MP
Video Compression: H.264 High Profile
Image Enhancement: Digital Wide Dynamic 3D Noise Reduction
Local Storage: MicroTF Card (64G Max)
Wireless Encryption: WEP/WPA/WPA2 Encryption
Power Input: 12V 1A(Min)
Total Power Consumption: 12W (Max)
WirelessStandard: 2.4G 802.11 b/g/n
Support Platform: Android/iOS

Component Description:

Reset Button: Long press "reset" hole 5sec, reset success.

It is recommended to insert 8-64GB high-speed Micro TF card, otherwise it will not be able to store, view historical video and support important functions such as firmware upgrading.

01

2. Install APP


Download APP: scan the QR code below to download and install. Register and login; open the "Smart Life" APP to register and login according to the prompts.



02


3.1. Add The Device-Scan QR code mode

- Make sure Wi-Fi is available and connected to the Internet.
- Connect the camera to the power, then system startup completed.
- Open "Smart Life" APP, press the "+" in the upper right corner of the main screen (Figure 01); choose "Security & Sensor", click "Smart Camera" (Figure 02) to add camera; and then click "Next step" (Figure 03);




03

- If the mobile phone is not connected to wi-fi, please click "Connect to Wi-Fi" (Figure 04);
- It will jump to the WLAN interface and connects Wi-Fi (Figure 05).Please note that only 2.4 GH Wi-Fi network is supported;
- If the phone is connected to Wi-Fi (Figure 06);




04

- click "Confirm". It will jump to the interface to prompt to scan the QR code with camera and click "Continue" (Figure. 07);
- A QR code will prompt on your screen and you need to scan it with the Smart Camera. (the camera is about 20-30 cm away from the mobile phone lens). Then click "hear the prompt sound" (Figure. 08).
- "connecting" (Figure. 09);



05


- When the progress reaches 100%,connection completed(Figure 10), and click "Finish";
- Then jump to preview interface (Figure 11)
- After closing the device preview interface, the interface returns to the APP home page. At this time, the connected device will appear on the APP home page (Figure 12). Then you can click directly to the device interface to see the monitoring situation without re-adding afterwards.



06

3. 2. Add The Device-AP Mode


If you want to use AP Mode,press the reset button on the machine. You make sure Wi-Fi is available and connected to the Internet.
• Connect the camera to the power, system startup completed.
• Open "Smart Life" APP, press the "+" in the upper right corner of the main screen (Figure 13); choose "Security & Sensor". click "Smart Camera" (Figure 14) to add camera ; Alternatively, choose "other ways" to add (as shown in Figure 15);



07


Note : Before using the "AP Mode",you need to switch to "AP Mode" by lightly pressing the "Reset key" of the device.

- Then click "hot spot configuration" (Figure 16);
- Then click "compatibility mode", clicks"Next" (Figure 17);
- Then click "change Network" (Figure 18);




08

- Then enter the password to complete the connection (Figure 19);
- Click Back and return to the APP compatible mode interface, where the Wi-Fi name and the connected Wi-Fi name are displayed Password, click the "Confirm" button (Figure 20);
- The page jumps to where the interface prompts "Wi-fi" to connect to the device hotspot and clicks "Connect" (Figure 21)




09

- The interface jumps to the WALN connection interface, finds Wi-Fi at the beginning of "Smart Life", and clicks on the connection (Figure 22);
- When the connection is completed, click back and return to the APP interface, at which time the APP display device is connected (Figure 23).
- At this time, the device has been successfully connected; the interface jumps to "Add Device Successful" (Figure 24);




10

- Then click "connected", it will jump to the Preview Interface of the Device (Figure 25)
- Close the device preview interface and the interface returns to the APP home page.(Fig. 26). After entering the device interface to view, no need to re-add, click directly into the device interface to view .



11

4.APP Video Browsing Details



- ①Preview mode
- ②Monitor Switch
- ③About device
- ④SQ
- ⑤Full screen

12

5.Matters Need Attention

Try to keep away from the metal space;
Avoid the furniture , microwave oven blocked;
Avoid the space where the audio, video and data lines are wound, and keep the space away from them as large as possible;
Ensure that as close as possible to the coverage of wireless Wi-Fi signals. Switching network environment;
In the new network environment, please press the reset hole about 5 seconds, then connect to the network.

13

The name and content of the harmful substances in the product

Part Name	Harmful Substance					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
shell	○	○	○	○	○	○
Board	X	○	○	○	○	○
charger	○	○	○	○	○	○
annex	○	○	○	○	○	○

This form is based on the provisions of SJ/T 11364.

This product conforms to RoHS environmental protection requirements. At present, there is no mature technology in the world to replace or reduce the lead content in the electronic ceramics, porcelain, optical glass, steel and copper alloy.

14

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.
Warning: Changes or modifications made to this device not expressly approved by Xian Chishine Optoelectronics Technology Co.,Ltd may void the FCC authorization to operate this device.
Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Radiation Exposure StatementThis equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Mobile:.....
Address:.....
Model:..... Camera ID:.....
Device store:..... Date of purchase:.....
Store address:.....
Store contact number:.....

Maintenance voucher of intelligent
Customer:..... Mobile:.....
Address:.....
Model:..... Camera ID:.....
Device store:..... Date of purchase:.....
Store address:.....
Store contact number:.....

Maintenance voucher of intelligent
Customer:..... Mobile:.....
Address:.....
Model:..... Camera ID:.....
Device store:..... Date of purchase:.....
Store address:.....
Store contact number:.....

Maintenance voucher of intelligent
Customer:..... Mobile:.....
Address:.....
Model:..... Camera ID:.....
Device store:..... Date of purchase:.....
Store address:.....
Store contact number:.....