#### WARNINGS

- . Do not expose to damp.
- Do not use solvents or abrasive materials to clean the BT 809.
- Do not expose to high temperatures (the battery might explode).
- Only use the original recharger supplied in the box.
- Do not dismantle either the earpiece or the battery recharger.
- If the earpiece is not going to be used for some time, we recommend that you recharge the battery and store everything in a cool, dry place.
- Keep the product out of the reach of children. (certain small parts could be swallowed)
- The fully charged battery has power for 4-6 hours talking time, 150-200 hours standby time. However, the time may vary when used with different mobile phones or other compatible Bluetooth devices, usage settings, usage styles, and environments.
- Leaving the device in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 0° and 50°C. Advice with a hot or cold battery may not work temporarily, even when the battery is fully charger. Battery performance is particularly limited in temperatures well below freezing.



## BT809X

User's guide

## BT809X

Thank you for choosing the BT 809 Bluetooth earpiece. Before using it for the first time, follow the instructions printed below.



#### CHARGING THE BATTERY OF THE EARPIECE

The earpiece uses a battery with high performance "Lithium Polymer" technology. The first time you use the earpiece, the battery inside may not be charged and it will be necessary to charge it up.

Recharge. Connect the battery recharger to the electric socket and to the earniece. The red light will come on and the recharging process will begin. When the battery has been recharged the light will go off. It will take about two hours to fully recharge the battery.

Battery dead. When the BT 809 battery has almost run down, the light will flash red and a been will be heard in the earniece.

NOTE: to extend the life of the battery, we recommend that you leave the BT 809 switched off while recharging and only recharge it when it is dead. If the BT 809 has not been used for some time, it may take a few minutes for the red light to come on.

#### Status

LED Stand-by Flashing BLUE "Find me" mode Flashing RED/BLUE Calling Quick flashing BLUE Battery dead Slow flashing RED Recharge Fixed RED

#### SWITCHING ON. CONNECTING AND SWITCHING OFF THE EARPIECE

#### Switching on.

Press the multifunction button and keep it pressed until the blue light flashes three times (about 1 second). The BT 809 will switch to

Connecting. After switching on the BT 809. briefly press the multifunction button to connect the earniece to the last device with which it has been associated (only after making the association).

Switching off. Press the multifunction button and keep it pressed until the red light flashes three times (about 5 seconds).

#### ASSOCIATION OF THE EARPIECE WITH A BLUETOOTH DEVICE

Before using the Bluetooth headset, you must associate it with the device you are going to use it with (telephone/PC).

#### ASSOCIATION

- . Ensure that the BT 809 is switched off. Press the multifunction button and keep it pressed until the light starts flashing red/blue (about 3 seconds), in this way the earniece is ready to be picked up by other devices ("find me" mode).
- · Run the search for new Bluetooth accessories from your device (phone/PC)\* At the end of the search the name of our earpiece will appear on the display (the name may vary from device to device).
- Select the BT Headset and, when requested to do so, enter the PIN 1234, then press "OK".
- . The phone/PC will tell you that the new bluetooth device has been associated, while the BT 809 light will flash blue (stand-by).
- NOTE: With some phones it might be necessary to authorise connection from the phone.
- \* To make the association, follow the instructions in the user manual supplied with the phone or with the PC Bluetooth

interface. The BT 809 will stay in "Find me" mode for a maximum of two minutes. If the association is not completed within this time, the earniece will revert automatically to stand-by.

#### USING THE BT 809 WITH MOBILE PHONES

After associating our earpiece with a phone it can be used to manage calls with the various functions supported.

ATTENTION: the possibility to use all the functions of our earniece depends exclusively on the functions supported by the phone in use (e.g.; if the phone does not support voice calls, this function will not be available).

Answering calls. When you receive a call, the BT 809 will play the tune (or the musical notes depending on the phone) in the earniece. Briefly press the multifunction button to answer.

Ending calls. During a call, briefly press the multifunction button to end the conversation.

Refusing a call. When you receive a call, wait to hear the tune, then press the "Multifunction" button for 3 seconds (vou will hear a beep in the earpiece and the call will be refused).

Regulating the volume. During a conversation or in stand-by mode, repeatedly press the "Volume +" button to increase the incoming volume or the "Volume -" button to lower it.

Transferring calls. Using the BT 809 it is possible, during a phone call, to transfer the conversation from the earniece to the telephone and vice versa.

#### Farset > Mohile nhone

Press and hold the "Volume +" button for 1 second. You will hear a been in the headset and the conversation will be transferred to the phone.

#### Mobile phone > Earset

Press and hold the "Volume +" button for 1 second. You will hear a been in the headset and the conversation will be transferred to the earpiece. (With Nokia phones all you have to do is press the multifunction button for 1 second)

Voice calls. While the earniece is in stand-by mode, briefly press the multifunction button and, when requested to do so, pronounce the name of the person you wish to call.

ATTENTION: to use this function the name has to be vocally recorded in the phone book

#### Recalling the last number.

Press and hold the "Multifunction" button for 3 seconds. You will hear a been in the headset and call the last number called

"MUTE" function. During a conversation, press the "Volume -" button for 1 second to activate "Mute" mode. To deactivate it , press and hold the "Volume -" button for 1 second again.

Call Waiting: During a conversation press and hold "Multifunction" betton for 3 seconds. You will hear a been in the headset and a call active, another call is on hold. To deactivate. press and hold the "Multifunction" button for 1 second again. (Some cell phone does not contain the call waiting function.)

#### USING THE BT 809 WITH A PC

Connection. Start the connection from the PC. When you hear the tune in the headset. briefly press the multifunction button to accept the connection.

ATTENTION: it is important that the connection is made in this way. If the connection is activated from the headset it may not be possible to use it as an audio peripheral (in this case, disconnect and repeat the connection).

Listening to music. To use the BT 809 as an audio peripheral it is necessary to proceed as follows

- Enter the "Control Panel".
- Select "Sounds and multimedia" then select the "Audio" folder \*\*.
- . In the "Sound Reproduction" section, select the "Bluetooth Audio" peripheral \* \*. In this way all the musical files will be

reproduced using our earpiece as the preferred listening peripheral.

\*\* The settings may vary depending on the operating system.

Use with SKYPE. After connection, start the "Skype" system installed to use our headset during conversation.

ATTENTION: it is necessary to have configured a Skype account to use this service.

# BT809X

## **FCC Notice to Users**

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID: TB6-BT809X on the product label.

Perfect Tech Co., Ltd has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is

subject to the following two conditions: (1) This device may not

cause harmful interference, and (2) this device must accept any

interference received, including interference that may cause

undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to part 15 of the FCC

Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy

and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

· Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and the

receiver.

· Connect the equipment to an outlet on a

circuit different

from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.