

Radio Control

Full Function School Bus with Light and Sound Activity Controller

INSTRUCTIONS:

Your SUPERTOYS™ "Full Function School Bus with Light and Sound Activity Controller" is designed to provide you with many hours of driving fun.

Please follow these directions:

Batteries: One 9-volt and 6 AA batteries required (not included).

Battery Installation for School Bus

1. Use a Phillips screwdriver to remove the screw in the bus' battery compartment cover, then use a coin to turn the knob toward "OPEN". Remove the cover.
2. Place the batteries in the compartment as indicated by the polarity symbols (+ and -) marked inside.
3. Replace the cover and tighten the screw.

Battery Installation for Dashboard

1. Use a Phillips screwdriver to remove the screw in the dashboard controller's battery compartment cover. Remove the cover.
2. Place the batteries in the compartment as indicated by the polarity symbols (+ and -) marked inside.
3. Replace the cover and tighten the screw.

"Helpful Hints"

(maintenance and performance tips)

1. Check batteries frequently.
2. Always replace with fresh alkaline batteries.
3. Check battery terminals for contact.
4. To save batteries, always turn ignition key off when not in operation.
5. Designed to run on most smooth surfaces.
6. If the car does not perform properly, you may need fresh batteries. The 9-volt lasts longer than the AA - so test batteries frequently. Replace batteries if:
 - a) Car speed reduces considerably or if after letting the button go, car continues to move
 - b) Controller - truck does not respond properly to controller.





Setting the volume

1. Remove the controller's battery compartment cover.
2. To limit the volume to a low range, slide "VOLUME" to "LO". To allow a higher volume, slide "VOLUME" to "HI".
3. Replace the cover and tighten the screw.

Playing with the bus

1. Push "ON"/"OFF" at the bottom of the bus to "ON".
2. Turn the key on the dashboard controller to "ON" to start up the dashboard.

Turn Signal Lever



3. Push the gear shift forward to move school bus forward. Pull the gear shift back to move bus backward. The indicator on the dashboard turns on.
4. Turn the steering wheel on the dashboard to the left to turn the bus to the left, or to the right to turn the bus to the right. The indicator on the dashboard turns on.
5. Push the turn signal lever down and watch the left turn indicator flash. Push the lever up and watch the right turn indicator flash. The turn signal makes a ticking sound when you push it either way.

NOTE: Your Drive My School Bus stops when it runs into anything, but the motor keeps running. When this happens, hold down or release the controller's power knob so the bus changes direction, or move it by hand.

Care

To enjoy your Drive My School Bus for a long time:

- Keep the bus dry. If it gets wet, wipe it dry immediately.
- Use and store the bus only in normal temperature environments.
- Handle the product gently and carefully. Don't drop it.
- Wipe the bus with a damp cloth occasionally to keep it looking new.



ART NO. 4009-W
All Rights World-Wide Reserved
SUPERTOYS U.S.A., INC.
200 FIFTH AVE., ROOM 201 NEW YORK, NY 10011 U.S.A.
CAUTION: NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS
ITEM CONTAINS GLASS BULB & SMALL COMPONENTS
MADE IN CHINA

Warning : Change or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.