
## SMA BAND



## DYNAMIC HEART RATE **SMART BAND**

INSTRUCTIONS

#### ·SMA BAND Diagrams·



- · SMA BAND bracelet is touch screen operation, touch area like shown as picture, light touch switch function interface
- SMA BAND bracelet have wake up function, Shake hand to check freely
- \* When you received the bracelet, please charge it, Then the bracelet will power on

#### ·Download/Install APP·



Google play GOOGLE PLAY:SMA HEALTH TRACKER



- Use your phone to scan QR code download and install the SMA APP Support
- Android 4.3 or above, Bluetooth 4.0 IOS 8.0 or above

#### ·Bluetooth paring·

- 1.Register and log in account according to the App instructions
- (XOpen the phone Bluetooth, and keep watch with power and close to the phone)
- 2.Click APP-Setting-Connect watch and choose SMA BAND bracelet



After the band show press the touch area to confirm.

3.Press the "Pair" on the APP (Note: When IOS users unable to pair smart band, please check the phone Settings - Bluetooth -Sma07- forget this device)



4. Pair successful, click on "Start Now"



## Data Synchronization ·



Pull down on APP sport page, sync smart band data to app

#### ·Function·

1.Manual monitor:


Long press to test the heart rate, sport state will be shown when you testing your heart rate continuous, Long press to exit heart rate mode



\* When you start to monitor the heart rate, please make sure the strap fasten and no

light-leaking.
The right way to wear watch can obtain the most accurate heart rate monitor data

Target Heart Rate=(220-age)x(40%-100%)



The best heart rate range for exercise is 60%-80%

\* SMA-BAND heart rate and sport state is relative personal profile, only for reference

#### ·Function



2. Automatic monitoring: Set in the APP "Coach setting "
"Heart rate setting" select time



#### ·Function·



Activity tracking Record the whole day steps of the SMA-BAND bracelet you wear.



Distance

Record the whole day distance of the SMA-BAND bracelet you wear.



Calories Record the whole day calories



Message

Can read all of message push (include facebook, what's pp, twitter, email and so on)Support more than 40 different languages

#### ·Function



Call remind Vibrate and display the caller ID.



Set alarm and remark on app, vibrate to remind and show on band, long press to exit



Sleep monitor

Calculate the sleeping duration, deep sleep, light sleep per night when you wear SMA-Band to sleep



Selfie control

Open the selfie control on Phone APP, SMA-Band remote control phone's camera

#### ·Function·



Anti-lost The phone is separated from SMA-Band in excess of 30 feet,

the band will vibrate Sedentary



Smart band will alert you when you are inactive and needs physical activity thus allowing you to live a healthier life

Press the touch button more than 5s to return main page when there is alarm, sedentary, anti-lost functions appear in the screen.

## The Specification

Weight	20g
Battery	Poly-Li
Call function	Bluetooth 4.0
Display	OLED
Operating	Touch screen
Bluetooth Signal	8-10m
Waterproof	Ip65
Case thickness	10.8mm
Strap length	14.5-21cm

## · F.A.Q ·

If the phone can not pair with the band, Please check your phone:setting-bluetooth ,if you can see Sm07 signal on phone, it means fitness tracker Bluetooth no problem. Please check if the band was paired with other phone, if paired, please unpair it on app, Beside this, IOS need go setting-Bluetooth to forget the device for Sm07, Then pair with band on APP again.
If Above method can't solve the problem of SMA-BAND Bluetooth signal , ① please go to "Pedometer" page and long press the touch button twice, appear ②Go to "Distance" page long press touch button twice, appear 3 Go to "Calories" page long press touch button once, appear 5 SMA-BAND will be Reset successfully

Recharge Attention:

SMA-BAND use magnetic pogo pin recharge cable, as the magnet with anode and cathode, please recharge according to the magnetic right way. (The right recharge way is when you put the cable close to the band, the band will suck the cable automatically. Otherwise, you will feel that the band reject the cable.) The nominal voltage of the charger should be \$5V. If the magnetic on the band and the cable rejects each other, you still charge the band, or nominal voltage of the charge >5V, it will cause a short circuit board Such damage will not under the warranty.

## ·The Guarantee Terms·

The company follow the principle of "creating value for customers"

Smawatch enjoy 1 year warranty since the acquisition date. If products are damage or malfunction, confirmed by accredited technical personnel of the company as in normal use circumstances, the company will provide free maintenance.

The following cases does not belong to the warranty scope:

A.Accidental or artificial damage B.Life waterproof, can't swim or covered in water

C.Test, repair, or disassemble Smawatch by technologists which are not authorized and confirmed by manufacturer

D.Smudginess caused by artificial conditions E.Products damage due to using or connecting to equipment which is not the complete set of our

F.Normal aging during product's lift span

Facebook

SMAWATCH520



Google +



 $Shenzhen\,Smart\,Care\,Technology\,Limited\,(\,smart\,watch\,)$ 

Shenzhen smart care technology limited www.smawatch.com

TEL: +86-755-27915058-808 FAX: +86-755-25737350 ADD: 9A, Block A, Central Building,

Baoyuan Road, Xixiang Town, Bao'an District, Shenzhen China

## FCC Compliance

This device complies with Part 15 of the FCC Rules.

conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference

received including interference that may cause undesired

for compliance

Note: This equipment has been tested and found to comply with the limits for a Class B digital

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

This equipment generates, uses and can radiate radio

interference to radio communications. However, there is no guarantee that interference will not a particular installation. If this equipment does

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

Connect the equipment into an outlet on a circuit different from that to which the receiver is

The device has been evaluated to meet general RF exposure requirement.

# G.other damage caused by force majeure

Email:sales@smawatch.com

Operation is subject to the following two

Warning: Changes or modifications to this unit not expressly approved by the party responsible could void the user's authority to operate the

harmful interference in a residential installation.

frequency energy and, if not installed and used in accordance with the instructions, may cause

cause harmful interference to radio or television

Reorient or relocate the receiving antenna Increase the separation between the equipment

Consult the dealer or an experienced radio/TV technician for help.

The device can be used in portable exposure condition without restriction.