



We don't just think of life.

ECC RESTRUCTURED INFORMATION

© 2003 Marstek Electronics, Inc. All rights reserved. This document is the property of Marstek Electronics, Inc. and is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Marstek Electronics, Inc.

INTRODUCTION
This manual provides information on how to use the 10-line cordless telephone system. It includes information on the features and functions of the system, as well as instructions on how to install and use the system. The system is designed to provide a reliable and secure communication system for your home or office.

INSTALLATION
Before you begin, please read the safety information and warnings. The system is designed to be used in a dry location. Do not use the system in a wet or damp location. The system is not to be used near water or flammable materials. The system is not to be used near children or pets. The system is not to be used near electrical equipment.

DESKTOP INSTALLATION
To install the system on a desktop, please follow the following steps:
1. Plug the power cord into the power outlet.
2. Plug the telephone cord into the telephone jack on the back of the base unit.
3. Plug the antenna into the antenna port on the back of the base unit.
4. Turn on the power to the system.

INTRODUCTION
This manual provides information on how to use the 10-line cordless telephone system. It includes information on the features and functions of the system, as well as instructions on how to install and use the system. The system is designed to provide a reliable and secure communication system for your home or office.

BEFORE YOU BEGIN
Before you begin, please read the safety information and warnings. The system is designed to be used in a dry location. Do not use the system in a wet or damp location. The system is not to be used near water or flammable materials. The system is not to be used near children or pets. The system is not to be used near electrical equipment.

PARTS CHECKLIST
Make sure you have received all the parts listed below. If you are missing any parts, please contact your retailer or the manufacturer for more information.

MOBILE JACK REQUIREMENTS
The system is designed to be used with a mobile jack. The mobile jack must be installed in a dry location. The mobile jack must be installed in a location that is accessible to the user. The mobile jack must be installed in a location that is not near water or flammable materials.

DIGITAL SECURITY SYSTEM
The system is designed to provide a secure communication system. The system uses a digital security system to protect your conversations. The system is designed to be used in a secure location.

INSTALLATION
Before you begin, please read the safety information and warnings. The system is designed to be used in a dry location. Do not use the system in a wet or damp location. The system is not to be used near water or flammable materials. The system is not to be used near children or pets. The system is not to be used near electrical equipment.

DESKTOP INSTALLATION
To install the system on a desktop, please follow the following steps:
1. Plug the power cord into the power outlet.
2. Plug the telephone cord into the telephone jack on the back of the base unit.
3. Plug the antenna into the antenna port on the back of the base unit.
4. Turn on the power to the system.

WALL MOUNT INSTALLATION
To install the system on a wall, please follow the following steps:
1. Mark the location for the base unit on the wall.
2. Drill a hole in the wall for the base unit.
3. Mount the base unit to the wall.
4. Plug the power cord into the power outlet.
5. Plug the telephone cord into the telephone jack on the back of the base unit.
6. Plug the antenna into the antenna port on the back of the base unit.
7. Turn on the power to the system.

RECEIVING A CALL
When you receive a call, the base unit will ring. Pick up the handset to answer the call. The handset will have a display screen that shows the caller's number. The handset will also have a speaker that allows you to hear the caller.

FLASH
When you receive a call, the base unit will flash. This indicates that there is a message waiting for you. Press the flash button on the handset to retrieve the message.

VOLUME
The volume of the handset can be adjusted. Press the volume buttons on the handset to increase or decrease the volume. The volume can be adjusted for each handset.

RINGER SWITCH
The ringer switch can be used to turn the ringer on or off. Press the ringer switch on the handset to turn the ringer on or off. The ringer can be turned on or off for each handset.

RINGER TONE
The ringer tone can be adjusted. Press the ringer tone buttons on the handset to select a different ringer tone. The ringer tone can be selected for each handset.

MUTE
The handset has a mute button. Press the mute button on the handset to mute the handset. The handset will have a mute indicator light that is on when the handset is muted.

MEMORY
The system has a memory feature. The system can store up to 100 numbers in memory. The system can be used to dial a number stored in memory. The system can be used to dial a number stored in memory.

CHANGING A NUMBER IN MEMORY
To change a number in memory, press the memory button on the handset. The handset will display the number in memory. Press the memory button again to change the number. The handset will display the new number.

STORING A STORED NUMBER
To store a number in memory, press the memory button on the handset. The handset will display the number. Press the memory button again to store the number. The handset will display the number stored in memory.

STORING A REDIAL NUMBER
To store a redial number in memory, press the redial button on the handset. The handset will display the number. Press the redial button again to store the number. The handset will display the number stored in memory.

STORING A PAUSE IN MEMORY
To store a pause in memory, press the pause button on the handset. The handset will display the pause. Press the pause button again to store the pause. The handset will display the pause stored in memory.

STORING A REDIAL NUMBER
To store a redial number in memory, press the redial button on the handset. The handset will display the number. Press the redial button again to store the number. The handset will display the number stored in memory.

STORING A PAUSE IN MEMORY
To store a pause in memory, press the pause button on the handset. The handset will display the pause. Press the pause button again to store the pause. The handset will display the pause stored in memory.

CHANGING THE BATTERY
To change the battery, remove the back cover of the handset. Remove the old battery. Insert the new battery. Replace the back cover. The handset will be ready to use.

BATTERY SAFETY PRECAUTIONS
Do not short-circuit the battery. Do not use the battery in a fire or near heat. Do not use the battery in a wet or damp location. Do not use the battery in a location with a strong magnetic field. Do not use the battery in a location with a strong electric field.

TROUBLESHOOTING GUIDE
If the handset does not work, please check the following items:
1. Check the battery level.
2. Check the handset volume.
3. Check the handset ringer.
4. Check the handset mute.
5. Check the handset display.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CHANGING THE BATTERY
To change the battery, remove the back cover of the handset. Remove the old battery. Insert the new battery. Replace the back cover. The handset will be ready to use.

BATTERY SAFETY PRECAUTIONS
Do not short-circuit the battery. Do not use the battery in a fire or near heat. Do not use the battery in a wet or damp location. Do not use the battery in a location with a strong magnetic field. Do not use the battery in a location with a strong electric field.

TROUBLESHOOTING GUIDE
If the handset does not work, please check the following items:
1. Check the battery level.
2. Check the handset volume.
3. Check the handset ringer.
4. Check the handset mute.
5. Check the handset display.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

CONNECTING THE BELT CLIP
To connect the belt clip, press the belt clip button on the handset. The handset will display the belt clip. Press the belt clip button again to connect the belt clip. The handset will display the belt clip connected.

MEMORY
The system has a memory feature. The system can store up to 100 numbers in memory. The system can be used to dial a number stored in memory. The system can be used to dial a number stored in memory.

CHANGING A NUMBER IN MEMORY
To change a number in memory, press the memory button on the handset. The handset will display the number in memory. Press the memory button again to change the number. The handset will display the new number.

STORING A STORED NUMBER
To store a number in memory, press the memory button on the handset. The handset will display the number. Press the memory button again to store the number. The handset will display the number stored in memory.

STORING A REDIAL NUMBER
To store a redial number in memory, press the redial button on the handset. The handset will display the number. Press the redial button again to store the number. The handset will display the number stored in memory.

STORING A PAUSE IN MEMORY
To store a pause in memory, press the pause button on the handset. The handset will display the pause. Press the pause button again to store the pause. The handset will display the pause stored in memory.

STORING A REDIAL NUMBER
To store a redial number in memory, press the redial button on the handset. The handset will display the number. Press the redial button again to store the number. The handset will display the number stored in memory.

STORING A PAUSE IN MEMORY
To store a pause in memory, press the pause button on the handset. The handset will display the pause. Press the pause button again to store the pause. The handset will display the pause stored in memory.

SERVICE
If you have any questions or need assistance, please contact your retailer or the manufacturer. The manufacturer's website is available at www.marstek.com. The manufacturer's phone number is 1-800-888-8888.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.

ACCESSORY ORDER FORM
To order accessories, please fill out this form. The form includes fields for the item name, quantity, and price. The form can be used to order a variety of accessories for the system.