

labeled "CELLULAR PHONE".

- 4.2.4 An external antenna adapter is required (sold separately) to connect the AMPLIFIER to the cellphone. External antenna adapters connect directly to the antenna extension cable
- 4.2.5 Connect the DC power supply to the AMPLIFIER. Verify that both the OUTSIDE ANTENNA and the ADAPTER EXTENSION CABLE are connected before powering up the AMPLIFIER.

NOTE: Visit our website at www.wilsonelectronics.com for the latest adapter cross reference chart. If your phone's adapter is not available from your retailer contact us at 1-866-294-6996 and we will help you locate one in your area. For further assistance contact our technical support Toll-Free at 1-866-294-1660.

NOTE: iDEN Antennas are recommended for iDEN Amplifier 814001.

5. AMPLIFIER SPECIFICATIONS

DIRECT CONNECTION AMPLIFIER PHYSICAL SPECIFICATIONS

Connectors FME-Male 50 Ohms

Dimensions 5.5x4.3x1.4 (inch) or 14.0x10.8x3.5 (cm)

Weight 1.32 Pounds or 600G

iDEN #814001 AMPLIFIER SPECIFICATIONS

| Frequency | 806-821MHz Uplink 851-866MHz Downlink | |
|---------------------|---------------------------------------|--|
| Gain (up/down) | Cell Site Controlled-Max 10/10db | |
| Flatness (up/down) | (+/- 2dB / +/-3dB) | |
| Max RF (up/down) | (+35dBm/+15dBm) | |
| Noise Figure (down) | (3.5dB nominal) | |
| Isolation | Uplink/Downlink 90dB | |
| Power Consumption | 1.5A@12V | |

6. OPTIONAL ACCESSORIES/ANTENNA OPTIONS

- 6.1 Coax Cable Extensions 50Ω (see chart on pg.7)
- 6.2 Antenna Options (see chart on last page)
- 6.3 N-Female To FME-Female Adapter Adapts 9913 Coax to the 814001 Bi-directional Amplifier.
- 6.4 Lightning Suppressor (In-Building application)
 WARNING: Lightning protection is recommended for all In-Building installations
- 6.5 Hardwire Power Supply Kit.



7. WARNINGS

WARNING: Verify that both the outside antenna and adapter extension cable are connected before powering up the AMPLIFIER.

RF SAFETY WARNING: (MOBILE ONLY) The outside antenna must be mounted with a separation distance of at least 15.5 inches from any of the vehicle occupants or nearby persons and must not be

any of the vehicle occupants or nearby persons and must not be co-located or operating in conjunction with any other antenna or amplifier. Use of a cellular amplifier with antenna gains higher than 5.12dBi is in violation of FCC regulations for which the offender is fully liable. All Wilson Mobile Antennas are 5.12dBi or less.

WARNING: (IN-BUILDING ONLY) Lightning protection is recommended for all in-building installations.

RF SAFETY WARNING: (IN-BUILDING ONLY) When using in-building, the outside antenna must be fixed-mounted on an outdoor permanent structure with a separation of at least 20 feet from all persons during normal operation.

8. TECH SUPPORT

If you need further assistance with your installation:

- 1) Call us Toll-Free at 866-294-1660
- 2) E-mail tech support at tech@wilsonelectronics.com
- 3) Go to www.wilsonelectronics.com


Our Hours of Operation are: 8:00 AM – 4:30 PM (Mountain Time)

EXTENSION CABLE CHART (RG 58 - FME connectors / 9913 - N connectors)

| 951101 | 5' Extension Cable RG 58 Low Loss Coax | (0.6 db loss) |
|--------|---|--|
| 951102 | 10' Extension Cable RG 58 Low Loss Coax | (1.2 db loss) |
| 951103 | 15' Extension Cable RG 58 Low Loss Coax | (1.8 db loss) |
| 951104 | 20' Extension Cable RG 58 Low Loss Coax | (2.4 db loss) Used with the Yagi Antenna - (N-Male to FME Female) |
| 951108 | 20' Extension Cable 9913 Ultra Low Loss Coax | Only use 9913 Low Loss Coax for extensions 20' or longer (0.8 db loss) |
| 951105 | 30' Extension Cable 9913 Ultra Low Loss Coax | (1.2 db loss) |
| 951106 | 50' Extension Cable 9913 Ultra Low Loss Coax | (2.0 db loss) |
| 951107 | 100' Extension 9913 Low Loss Coax | (4.0 db loss) |

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Leaving the amplifier on in an unused vehicle for days may drain your battery. This can be avoided by plugging into an ignition switched outlet or by using the small white switch located on the power supply.



15 DAY MONEY BACK GUARANTEE

All Wilson products have a 15 day money back guarantee with Proof of Purchase

1 YEAR WARRANTY

The Wilson amplifier is warranted for one year against defects in workmanship and/or materials and will be repaired or replaced, at the discretion of the manufacturer. to the original purchaser with dated proof of purchase or sales receipt.

If you have questions about your amplifier please call technical support call 1-866-294-1660 or E-mail tech@wilsonelectronics.com

Most warranty cases can be handled by taking the amplifier and the recept to the store where it was purchased. If inconvenient, the amplifier and a copy of the receipt, may be sent to the factory, at purchasers expense, where it may be repaired or replaced and returned shipping paid. Warranty does not cover damages caused by abuse, misuse, and negligence.