


OMNILOCK® ACCESS CONTROL SYSTEMS

INSTALLATION INSTRUCTIONS FOR PORTAL GATEWAY PG-B SERIES




SECTION 1: CHECK OPERATION

Verify proper operation of the Portal Gateway as specified in the Wireless Access Management System (WAMS) Installation Guide.

SECTION 2: INSTALL THE PORTAL GATEWAY

- a. Refer to the WAMS Installation Guide to determine the optimum location for mounting the Portal Gateway.
- b. Insure that a 120VAC power outlet and an Ethernet connection are available.
- c. Mount the Portal Gateway in the selected location using the mounting screws provided.
 - 1. Wood Screw, pan head, #10- Recommended pilot hole 1/8 inch diameter.
 - 2. Drywall Anchor- Recommended pilot hole 3/8 inch diameter.
 - 3. Concrete Screw- Recommended pilot hole 5/32 inch diameter.
- d. Connect the furnished 12VDC Power Supply to the 120VAC outlet and connect the 12VDC connector to the Portal Gateway. Observe that the "Power" indicator is on.
- e. Connect the Ethernet to the Portal Gateway. Observe that the "Link" indicator is on.
- f. After approximately 30 seconds, observe that the "Activity" indicator is flashing.



(Website: WWW.OMNILOCK.COM)

