



## REMOTE CONTROL


- 1.Back home
- 2.Manual control
- 3.On/Pause
- 4.Power levels (Turbo/Normal/Eco)
- 5.Edge mode
- 6.Mopping mode
- 7.Find your robot




•The following operation and modes can be activated from the remote control.


### EDGE MODE

Press the  on the remote control for the robot to start cleaning under this mode. It will automatically start cleaning along walls, around furniture etc.

Note: press  button to switch between the 3 modes: Turbo/Normal/Eco





### MOPPING MODE


Press the  on the remote control for the robot to start mopping under this mode.

Note: confirm that the water tank and mop bracelet are properly installed.

### PAUSE

While the robot is operating, press  on the App, the remote control or on the robot to pause it and press  to resume cleaning.


### SLEEPING

The robot will automatically enter sleeping mode after 5 minutes of no operation. Press  on the App, the remote control or on the robot to start it up again.

**Warning:**

- After 12 hours of no operation, the robot will automatically turn off.
- The robot will not enter sleeping mode during charging.

**SUCTION POWER LEVEL POWER**

Press  on the remote control to select the desired power level. Choose between Eco (low power), Normal (medium power) and Turbo (maximum power).

**FIND YOUR ROBOT**

Press  on the remote control to find your robot and there will be a voice prompt locating your robot.

**FCC STATEMENT**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.