

1.INTERFACES:

- A HDMI port
- ® Micro USB 5V In
- © Power indicator



2.HARDWARE INSTALLATION:

- 1. Plug MIGUcast to an HDMI port on your TV
- 2. For power, connect the USB from MIGUcast to an available USB port on your TV, or any other powered USB port
- 3. Select the HDMI port MIGUcast is connected to as the source



3.DOWNLOAD THE MIGU TV APP:





Card number and factory password can be found App Store printed within the user manual

4.WI-FI CONNECTION:

- 1. Use "My device" in the MIGU TV app (make sure mobile device Wi-Fi sharing has been enabled, as MIGUcast and paired mobile devices must be in the same Wi-Fi network, or WAN)
- 2. Scan the QR code and follow app prompts for network connection and configuration



5.VIDEO CAST:

When MIGUcast is setup, you can begin changing sources. When the icon a is displayed. you can click it to cast video to MIGUcast and play it on the TV screen from a mobile device





FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

IC WARNING STATEMENT

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ce matériel est conforme aux limites de dose d'exposition aux rayonnements, fac / ic rss-102 énoncée dans un autre environnement.cette egipment devrait être installé et exploité avec distance minimale de 20 entre le radiateur et votre corps.