







|  |  |  |  |   |  |   |   |  |  |   |
|--|--|--|--|---|--|---|---|--|--|---|
|  <p><b>MoWood ECHO</b><br/>Alarm Clock Speaker</p> | <p><b>Table of contents</b></p> <ul style="list-style-type: none"> <li>1 Features ..... 1</li> <li>2 Included in this Package ..... 2</li> <li>3 Technology Specification ..... 3</li> <li>4 Diagram of the LED Display&amp; the Button ..... 4</li> <li>5 Operating Instruction of the Button and DC &amp; Aux-in Jack ..... 5</li> <li>5.1 Time Settings ..... 5</li> <li>5.2 Alarm Settings ..... 5</li> <li>5.3 Date Settings ..... 6</li> <li>5.4 Bluetooth Function ..... 7</li> <li>5.5 Hands free Function ..... 8</li> <li>5.6 Aux-in Jack ..... 8</li> <li>5.7 Temperature Display Setting ..... 8</li> <li>5.8 USB outlet port ..... 8</li> <li>6 Playing and Connection diagram ..... 9</li> <li>7 Disposal of your old product ..... 9</li> </ul> | <p>Dear customer, thanks for your purchasing MO Wood Echo Alarm Clock Speaker. Please read all safety instructions before proceeding for your safety and proper usage.</p> <p><b>1 Features</b></p> <ul style="list-style-type: none"> <li>• Pure wood, bottom surface, splash appearance.</li> <li>• Hign-quality clock, alarm, Bluetooth speaker and thermometer function all in one.</li> <li>• LED digital display.</li> <li>• Secondary touch buttons.</li> <li>• 3.5mm stereo line-in cable (included) for playing other audio devices.</li> <li>• Easy paired with Bluetooth-enabled devices, enjoy music freely.</li> <li>• Simple appearance, easy configuration.</li> <li>• Built-in microphone, have a clear call through Bluetooth hands free function.</li> <li>• Built-in high-quality speakers, bright melody, deep bass. Music performance beyond your imagination.</li> <li>• DV 2.1A USB outlet port for traditional USB charging for most devices.</li> </ul> | <p><b>2 Included in this package</b></p> <p>(Please check the accessories included in the package after purchasing)</p> <ul style="list-style-type: none"> <li>MO main unit 1 pcs</li> <li>3.5mm jack audio cable 1 pcs</li> <li>Power Adapter 1 pcs</li> <li>User manual 1 pcs</li> </ul> <p><b>3 Technology Specification</b></p> <ul style="list-style-type: none"> <li>• Bluetooth Version: A, Subclassical</li> <li>• Bluetooth Protocol: A2DP, AVRCP, HFP, HSP</li> <li>• Bluetooth Range: 10.M</li> <li>• Output Power: RMS 3W/5W</li> <li>• Speaker: 4Ω 2W 1.5w</li> <li>• Frequency Response: 60Hz-20KHz</li> <li>• SN Ratio: &gt; 70dB</li> <li>• Distortion: &lt;1%</li> <li>• Cable: 3.5mm jack audio cable</li> <li>• Power Adapter: AC100-240V 50/60Hz</li> <li>• DC 5V 1.2A</li> <li>• Product Net Weight: 0.91kg</li> <li>• Product Dimension: 221X140X65mm</li> </ul> | <p><b>4 Diagram of the LED Display&amp; the Button</b></p>  <p>Fig.1 LED Display</p>  <p>Fig.2 The Top Button</p> | <p>① DC 5V<br/>Power jack</p> <p>② AUX<br/>Support other audio sources (3.5mm standard)</p> <p>③ W<br/>Turn on alarm/tone of alarm stop alarm</p> <p>④ M<br/>Adjust tone/touch hour model stop alarm</p> <p>⑤ Temp<br/>Temperature sensor</p> <p>⑥ [ ]<br/>Set alarm/stop alarm</p> <p>⑦ [ ]<br/>Set sleep/stop alarm</p> <p>⑧ [ ]<br/>Volume down</p> <p>⑨ [ ]<br/>Power/answer/call/end call/talk on or off Bluetooth</p> <p>⑩ [ ]<br/>Volume up</p> <p>⑪ [ ]<br/>Silence</p> <p>⑫ [ ]<br/>USB outlet port</p> | <p><b>5 Operating Instruction of the Button and DC &amp; Aux-in Jack</b></p> <p>Connect the adapter with the unit to turn on the unit. The Time display on the LED screen will be shown during the first use of the unit. The figure on the right side is the room temperature. There is about 2 degree difference between the displaying temperature and the actual temperature.</p> <p><b>5.1 Time Settings</b></p> <p>Press "M" to switch 12-hour mode and 24-hour mode.</p> <p>① 12-hour mode, a single hour figure begins to flash; in 24-hour mode, both the ten-hour figure begins to flash. After confirm the hour mode, press [ ] the HOUR figure begins to flash. Press [ ] to adjust the HOUR. Press [ ] again, the HOUR figure begins to flash. Press [ ] to adjust the MINUTE. To set time setting, Press [ ] to confirm your setting (ding for 1.5 seconds also exit time setting automatically).</p> <p><b>5.2 Date Settings</b></p> <p>After time setting, it switches to Date settings automatically. The MONTH figure begins to flash. Press [ ] to adjust the MONTH. Press [ ] to confirm it and the DATE figure begins to flash. Press [ ] to adjust the DATE, and then Press [ ] to confirm and exit the settings.</p> | <p><b>5.3 Alarm Settings</b></p> <p>Press "W" to turn on alarm. The alarm indicator light begins to flash on the LED screen will be shown during the first use of the unit. Press "W" again, the alarm indicator light stops flashing. The alarm clock works everyday (See Fig.4).</p> <p>Press "M" to turn on alarm. The alarm indicator light begins to display on the LED screen. (See Fig.4) Press [ ] to set alarm time. The HOUR figure begins to flash. Press [ ] to adjust the HOUR. Press [ ] again, the MINUTE figure begins to flash. Press "W" to set alarm setting. Press [ ] to confirm your setting (ding for 1.5 seconds also exit alarm setting automatically). When alarm is on, it can set for one hour. Press any key [ ] or "W" to stop the alarm. After stop the alarm, the alarm indicator light goes out. Press [ ] to turn on alarm, the clock set lights up. When it begins to flash, it means the alarm clock only works for one time. When it stops to flash, it means the alarm clock works everyday. Press [ ] to turn off alarm, the clock set goes out.</p> |  <p><b>5.4 Bluetooth Function</b></p> <p>When connecting the power with the unit, the unit is under Bluetooth mode.</p> <p>Go to smartphone or the pairing device settings and turn on Bluetooth, searching Bluetooth device. Choose "W1" by "Hotspot" to pair. When it is successfully paired, you will hear a "DING" sound. Music can be played from the paired device now. When playing music, press "PL" to pause. Press [ ] again to continue music (See Fig.5). Hold and press "V" and "M" to volume up and down.</p> <p><b>5.5 Handsfree Function</b></p> <p>When playing music under Bluetooth mode, the phone call is coming in, press "PL" to answer the call. Press "PL" to end the call, the music playing continues.</p> | <p><b>5.6 AUX-in Jack</b></p> <p>When the unit is on, connect the device to AUX-in Jack on the back of the unit with a 3.5mm stereo audio cable. The unit will switch to AUX mode automatically and play AUX-in audio sources only (See Fig.6).</p> <p><b>5.7 Temperature Display Setting</b></p> <p>Factory default Celsius. Long press "M" for 5 seconds to display CF. Press "M" to switch to C. Press [ ] to switch to F. Press [ ] to confirm the setting.</p> <p><b>5.8 USB outlet port</b></p> <p>USB outlet port suitable for writing additional USB cables to power other devices.</p> <p>USB cable part can not connect PC with data transmission.</p> | <p><b>6 Playing and Connection diagram</b></p>  <p>Fig.3 Bluetooth connection of MoWood Echo Alarm Clock Speaker</p>  <p>Fig.4 USB connection of MoWood Echo Alarm Clock Speaker</p> <p>Fig.5 Bluetooth connection</p> <p><b>7 Disposal of your old product</b></p> <p>The crossed-out wheeled trash can symbol on the rating label indicates that the product is covered by the European Directive 2002/96/EC.</p> |
|--|--|--|--|---|--|---|---|--|--|---|

**DISCLAIMER:**  
 This document is subject to change without notice. (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO/TV INTERFERENCE CAUSED BY UNAUTHORIZED ALTERATIONS TO THIS EQUIPMENT. SUCH ALTERATIONS WILL VOID THE WARRANTY AND MAY BE A VIOLATION OF FEDERAL COMMUNICATIONS COMMISSION REGULATIONS.**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation.

The equipment generates, uses and can radiate radio frequency energy and, if not shielded and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to you or others, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.