

ASUS Transformer Pad User Manual

TF500T

ASUS is devoted to creating environment-friendly products and packagings to safeguard consumers' health while minimizing the impact on the environment. The reduction of the number of the manual pages complies with the reduction of carbon emission.

For the detailed user manual and related information, refer to the user manual included in the Transformer Pad or visit the ASUS Support Site at <http://support.asus.com/>

Charging your battery pack

Once the Transformer Pad is fully-charged, ensure that you unplug it from the power source. Some electronic items are not designed to be kept plugged to a power source for long periods of time.

If you wish to use the battery power, ensure to fully charge your battery pack before going on long trips. Remember that the power adapter charges the battery pack as long as it is plugged to an AC power source. It takes much longer to charge the battery pack when your Transformer Pad is in use.







Airplane precautions

Ask an airline personnel if you want to use your Transformer Pad onboard the aircraft. Most airlines have restrictions in using electronic devices, and allow its use only when the plane reaches its cruising altitude.



There are three types of airport security devices: X-ray scanner (for luggages placed on conveyor belts), metal detectors (a walk-through security checking device), and magnetic wands (hand-held devices for checking on passengers). You can send your Transformer Pad through the X-ray scanner, but do not send your Transformer Pad through the metal detectors or checked by magnetic wands.

Package Contents

	
ASUS Transformer Pad	USB charger
	
USB Dock cable	User manual
	
Cleaning cloth	Warranty card

DRAFT v2


DRAFT v2



- If any of the items is damaged or missing, contact your retailer.
- The bundled power plug varies with country or region.

Getting to know your ASUS Transformer Pad

Front view



DRAFT v2

DRAFT v2

1 Light sensor

The light sensor detects the amount of light in your environment and automatically adjusts the brightness of your Transformer Pad's touch screen panel.


2 Built-in camera

Use the built-in camera to take pictures, record videos, video conferencing, and other interactive applications.

3 Touch screen panel

The touch screen panel allows you to operate your Transformer Pad using touch gestures.

Rear view



1 Volume button

Press this button to increase or decrease the volume.

2 Built-in camera

Use the built-in camera to take pictures, record videos, video conferencing, and other interactive applications.

3 Camera LED flash

Use the flash to take photos when lighting conditions are poor or when there is a backlight.

4 Power button

Press and hold the Power button to turn on your Transformer Pad.

When your Transformer Pad is on, press the Power button to put it in sleep mode or wake it up from sleep mode.

Two-color battery charge indicator

Dim: The power charger is not plugged to the Transformer Pad.

White: The battery is 100% charged.

Orange: The Transformer Pad is in battery charging mode.


5 Audio speaker system

Your Transformer Pad is equipped with a built-in high quality stereo speakers.


6 Dock connector

- Insert the power adapter into this port to supply power to your Transformer Pad and charge the internal battery pack.
 - Connect the USB Dock cable to the Transformer Pad and another system (notebook or desktop PC) for data transmission.
 - Dock the Transformer Pad to the mobile dock for keyboard and USB connectivity.
-

Left view



Right view

**1 Micro SD card slot**

Insert Micro SD card into this slot.

2 Reset hole

If the system becomes unresponsive, insert a paper clip into the hole to force-restart your Transformer Pad.



Forcing the system to restart may result to data loss. We strongly recommend that you back up your data regularly.

3 Micro HDMI port

Insert a micro HDMI cable into this port to connect to an HDMI device.


4 3.5mm Headphone output/Microphone input combo jack

Connect an amplified speaker or headphones to this port. You can also connect a microphone for voice narrations or simple audio recording.

5 Built-in microphone

The built-in mono microphone can be used for video conferencing, voice narrations, or simple audio recordings.

Charging your ASUS Transformer Pad



DRAFT v2




- Use only the power adapter and the USB Dock cable to charge your Transformer Pad. Using a different power adapter may damage your Transformer Pad.
- Ensure that the 40-pin USB connector is fully inserted into your ASUS Transformer Pad.
- Do not leave the Transformer Pad connected to the power supply once it is fully charged. Some electrical devices are not designed to be left connected to the power supply for extended periods of time.
- The input voltage range between the wall outlet and the power adapter is AC 100V–240V, and the output voltage of the power adapter is DC 15V, 1.2A.
- Charge the Transformer Pad for **8 hours** before using it for the first time.

DRAFT v2

Turning your Transformer Pad on

To turn your device on:

Press and hold the power button for one (1) second.



Declarations and Safety Statements

Federal Communications Commission Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The highest SAR value for the device as reported to the FCC is 1.270 W/kg when placed next to the body.

The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: MSQTF500T.

This device is compliance with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C.

Canada, Industry Canada (IC) Notices

This Class B digital apparatus complies with Canadian ICES-003 and RSS-210.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has been evaluated for and shown compliant with the IC Specific Absorption Rate ("SAR") limits when installed in specific host products operated in portable exposure conditions.

Canada's REL (Radio Equipment List) can be found at the following web address: <http://www.ic.gc.ca/app/sitt.reltel/srch/nwRdSrch.do?lang=eng>

Additional Canadian information on RF exposure also can be found at the following web address: <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>

Canada, avis d'Industry Canada (IC)

Cet appareil numérique de classe B est conforme aux normes canadiennes ICES-003 et RSS-210.

Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par l'appareil de sans fil Dell est inférieure à la limite d'exposition aux fréquences radio d'Industry Canada (IC). Utilisez l'appareil de sans fil Dell de façon à minimiser les contacts humains lors du fonctionnement normal.

Ce périphérique a été évalué et démontré conforme aux limites SAR (Specific Absorption Rate – Taux d'absorption spécifique) d'IC lorsqu'il est installé dans des produits hôtes particuliers qui fonctionnent dans des conditions d'exposition à des appareils portables.

Ce périphérique est homologué pour l'utilisation au Canada. Pour consulter l'entrée correspondant à l'appareil dans la liste d'équipement radio (REL - Radio Equipment List) d'Industry Canada rendez-vous sur:

<http://www.ic.gc.ca/app/sitt.reltel/srch/nwRdSrch.do?lang=eng>

Pour des informations supplémentaires concernant l'exposition aux RF au Canada rendez-vous sur : <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>

Prevention of Hearing Loss

To prevent possible hearing damage, do not listen at high volume levels for long periods.



CE Mark Warning



CE marking for devices without wireless LAN/Bluetooth

The shipped version of this device complies with the requirements of the EEC directives 2004/108/EC "Electromagnetic compatibility" and 2006/95/EC "Low voltage directive".



CE marking for devices with wireless LAN/ Bluetooth

This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.

The highest CE SAR value for the device is 0.548 W/kg.

Power Safety Requirement

Products with electrical current ratings up to 6A and weighing more than 3Kg must use approved power cords greater than or equal to: H05VV-F, 3G, 0.75mm² or H05VV-F, 2G, 0.75mm².

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for detailed recycling information in different regions.

Coating notice

To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the Transformer Pad's body except where the IO ports are located.



Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



DO NOT throw the battery in municipal waste. The symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.



DO NOT throw the Tablet PC in municipal waste. This product has been designed to enable proper reuse of parts and recycling. The symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products.



SAFE TEMP: This device should only be used in environments with ambient temperatures between 0°C (32°F) and 35°C (95°F).

Copyright Information

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS and ASUS Transformer Pad logo are trademarks of ASUSTek Computer Inc.

Information in this document is subject to change without notice.

Copyright © 2012 ASUSTeK COMPUTER INC. All Rights Reserved.

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Manufacturer	ASUSTek COMPUTER INC.
Address, City	No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C
Country	TAIWAN
Authorized Representative in Europe	ASUS COMPUTER GmbH
Address, City	HARKORT STR. 21-23, 40880 RATINGEN
Country	GERMANY

