


# Fast. Easy. Setup!




## 1 Install the driver

Insert the support CD into the optical drive or download the driver from:

[http://www.asus.com/networking/USB-AC53\\_Nano/HelpDesk\\_Download/](http://www.asus.com/networking/USB-AC53_Nano/HelpDesk_Download/)




Double click **setup.exe** to launch the InstallShield Wizard.




## 2 Prepare your USB-AC53 Nano

Connect your USB-AC53 Nano to your computer's USB ports.



When the installation is complete, you can connect your computer to a wireless network.




# ¡Configuración rápida y sencilla!



## 1 Instalación del controlador

Inserte el CD de soporte en la unidad óptica o descargue el controlador en:

[http://www.asus.com/networking/USB-AC53\\_Nano/HelpDesk\\_Download/](http://www.asus.com/networking/USB-AC53_Nano/HelpDesk_Download/)




Haga doble clic en **setup.exe** para iniciar el Asistente de instalación. Asistente de instalación.




## 2 Prepare su USB-AC53 Nano

Conecte su USB-AC53 Nano a los puertos USB de su equipo.



Cuando se haya completado la instalación, podrá conectar su equipo a una red inalámbrica.




USB-AC53 Nano Guide de démarrage rapide

# Rapide. Facile. Configurez !

## 1 Installer le pilote

Insérez le CD de support dans le lecteur optique ou téléchargez le pilote à l'adresse suivante :

[http://www.asus.com/networking/USB-AC53\\_Nano/HelpDesk\\_Download/](http://www.asus.com/networking/USB-AC53_Nano/HelpDesk_Download/)




Double-cliquez sur `setup.exe` pour lancer l'assistant d'installation.




## 2 Préparer votre USB-AC53 Nano

Connectez votre USB-AC53 Nano à l'un des ports USB de votre ordinateur.



Lorsque l'installation est terminée, vous pouvez connecter votre ordinateur à un réseau Wi-Fi.



### Federal Communications Commission Statement

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. SAR compliance of this product has only been verified for use with typical laptop computers. To comply with RF exposure limits, user must not simultaneously operate wireless products in adjacent USB-ports or card slots.

### Canada, avis d'Industry Canada (IC)

Aucune modification apportée à l'appareil par l'utilisateur, quelle qu'en soit la nature. Tout changement ou modification peuvent annuler le droit d'utilisation de l'appareil par l'utilisateur.

This Class B digital apparatus complies with Canadian ICES-003. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and  
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 Canada. Pour réduire le risque d'interférence aux autres utilisateurs, le type d'antenne et son gain doivent être choisis de façon que la puissance isotrope rayonnée équivalente (PIRE) ne dépasse pas ce qui est nécessaire pour une communication réussie. Cet appareil est conforme à la norme RSS Industrie Canada exempts de licence norme(s). Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne peut pas provoquer d'interférences et  
 (2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et  
 (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le fonctionnement sur la bande 5,15–5,25Ghz est limité à une utilisation intérieure uniquement.

### ISED(IC) RF Radiation Exposure Statement:

This EUT is compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209.

Cet appareil est conforme aux limites d'exposition DAS incontrôlée pour la population générale de la norme CNR-102 d'Industrie Canada et a été testé en conformité avec les méthodes de mesure et procédures spécifiées dans IEEE 1528 et IEC 62209.

Dual-band Wireless-AC1200 USB Adapter  
 Model: USB-AC53 Nano  
 ASUSTek Computer Inc.

**FCC** ASUS  
**USB-AC53 Nano**  
 FCC ID : MSQ-USBACRN00  
 IC: 3568A-USBACRN00 CAN ICES-3 (B)/NMB-3(B)