





Start Here



Designed exclusively for use with the VUDU product.
© 2008 VUDU, Inc. All Rights Reserved.

FCC Warning Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following 2 conditions:

- 1) this device may not cause harmful interference and
- 2) this device must accept any interference, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are design to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the installation instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the outlet into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Prohibition of Co-Location


This device and its antenna(s) must not be co-located or used in conjunction with any other antenna or transmitter.

Safety Information


To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum of 20 cm between the radiator and your body. Use only the supplied antenna.

What's Included

Wireless adapter
HOME NETWORK **1**



Wireless adapter
VUDU BOX **2**




(2) Ethernet network cables



(1) USB to DC cable




(2) AC to DC power cables




HOME NETWORK 1

1. Locate the provided 5-foot Ethernet cable. Connect one end to the wireless adapter marked HOME NETWORK 1. Connect the other end to your home network router or modem.




- 2.** Locate the provided power adapter plug. Insert one end into the DC-IN socket of HOME NETWORK **1**. Plug the other end into a wall outlet.





HOME NETWORK 1

- 3.** The LED indicators for Power and Ethernet on HOME NETWORK 1 will light up.




1. Locate the provided 10-foot Ethernet cable. Connect one end to the wireless adapter marked vudu box 2. Connect the other end to your VUDU box.





2. Locate the provided USB power cord. Insert one end into the DC-IN socket of **VUDU BOX 2**. Affix the other end to one of the USB ports on the VUDU box—on the back or left side.

- 3.** The LED indicators for Power and Ethernet on VUDU BOX 2 will light up.



The LED indicators for Power and Ethernet on VUDU BOX 2 will light up and, after a few seconds, the LED indicator for Wireless will start blinking. The wireless adapters have been set up successfully.

Going forward, when the LED indicators for Wireless and/or Ethernet start to blink, data is being transmitted.

Should you have any questions or problems, please refer to the Wireless Kit Instructions at www.vudu.com/vudu_documentation.html or call Customer Care at 1-888-554-8838 (VUDU).