

# EVOLUTION 2

## BLUETOOTH HEADPHONES



### Quick Start Guide


Item # MZX667




1. Make sure the following items are included in your package.



MZX667 Headphones




AUX Cable




USB Cable

2. For a look at the various buttons and parts of your headphones, view the graphic below.



3. **Charging:** When charging, a red LED light will illuminate. and the red LED indicator light turn off when fully charged. Your headphones can take up to two hours to fully charge.




#### 4. Power ON/Power OFF Your Headphones:

-Press and hold the Power button for approximately 3 seconds to power on your headphones. Your headphones will automatically connect with the last phone they were paired with.

-Once powered on, you can press and hold the Power button again for approximately 3 seconds to power off your headphones. The LED Indicator light will briefly turn red before powering off.

**NOTE:** In order to save power, your headphones will automatically power off if left unpaired and idle for over 10 minutes.





#### 5. Pairing Your Headphones With a Bluetooth Phone

-Press and hold the Power button for around 3 seconds. When your headphone is ready to pair with a Bluetooth audio source, it will go into pairing mode, with red and blue LED lights will flash alternately.

-Go to the Bluetooth Manager of your Bluetooth device. Search Bluetooth devices and select "Evolution 2" to start connecting.

-If required, enter the PIN code "0000" and confirm the entry. Once paired, the headphone will connect to your Bluetooth device automatically.



#### 6. Listening to Music

##### Play/Pause

**Press the Power button:** To play or pause music.


##### Next/Previous Song

Press and hold the Volume Up or Volume Down buttons for 2 seconds to advance to the next song or go back to the previous one.

##### Increase/Decrease Volume

Press the Volume Up or Volume Down buttons to increase or decrease the volume.

**NOTE:** Music will automatically pause when a call is dialed out or when there is an incoming call. It will resume when the call ends.



#### 7. Using Your Headphones During Phone Calls

##### Last Number Redialing

Quickly tap on the Answer button twice and the last number that you dialed will be redialed.

##### Answering an Incoming Call


To answer an incoming call, quickly press the Answer button.

##### Ending a Call

To end a call, quickly press the Answer button.

##### Adjusting Volume


By pressing the Volume Up or Volume Down buttons you can increase or decrease the volume of the phone call.



#### Important Note

You can also use the 3.5mm Audio Cable to connect audio devices through the Auxiliary Port on your headphones.

Note that when using the Audio cable instead of the standard wireless Bluetooth connection, the Volume Up, Volume Down and Play/Pause buttons do not function. Please use your audio source to control these functions.



#### Technical Support

For technical support issues please visit our website at [www.alteclansing.com](http://www.alteclansing.com). You can find manuals and FAQ's at the website. Can't find what you are looking for? Call 1-855-292-4087 to access our technical support information on the phone.

# EVOLUTION 2

BLUETOOTH HEADPHONES



## Quick Start Guide

Item # MZX667



### SOFT PADDED HEADBAND & EAR CUPS

Provides hours of listening comfort

### EXTENDABLE HEADBAND

Extends for extra comfort

### SOUND

Warm and rich bass sound that brings out the best in music

### DISPLAY

Displays battery life on iPhone or iPad

### MICROPHONE

Conveniently built-in mic

### SPECIFICATIONS

Drivers: 40mm

Frequency range: 20Hz-20kHz

## Altec Lansing One Year Warranty Card

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

### What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

### To Obtain Warranty Service and Troubleshooting information:

Call 1-855-292-4087 or Visit our website at [www.alteclansing.com](http://www.alteclansing.com).

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared.

**NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.**

**Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates. Uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions. May cause harmful interference to radio or -television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/ TV technician for help.

# JUST LISTEN.



FCC ID: SF4-SH731