


Waterproof

Bluetooth Mono Speaker

USER'S GUIDE

Ver.:1.2



CAUTION: To use this product properly, please read the user's guide before installing.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:

The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Functional Introduction




1. ON/OFF/Play/Pause/Answer
2. Volume down
3. Volume up
4. Power Led Indicator(RED)
5. BT Led Indicator(GREEN)
6. MIC

7. Cover holder
8. Micro-USB Connector
9. Speaker
10. Clip
11. Hanging hook

ON or OFF

Power ON / OFF: Press and hold the power button about 3 seconds then the power will turn ON. When it is on, press and hold the power button about 3 seconds the power will OFF.



Pairing your Bluetooth Speaker

* Before using your Bluetooth Speaker for the first time, please ensure your mobile phone or laptop is Bluetooth-Activate.

* The process for pairing your Bluetooth Speaker may differ depending on the make and model of your mobile phone or computer

* You can normally find instructions for pairing the device in your mobile phone or laptop user guide.

Step 1: Place the Bluetooth Speaker and your mobile phone no more than one meter apart.

Step 2: Press the power button and hold about 6 seconds, get into pairing mode.

Step 3: Consult your mobile phone or laptop user manual and activate your device's Bluetooth function.

Step 4: Place your mobile phone or laptop within one meter of the Bluetooth Speaker to locate the headset, which will appear as "PMF" on the Bluetooth device list.

Step 5: choice the PMF. They will auto pairing each other completed.

Step 6: Once the Bluetooth Speaker is paired with your mobile device, you can find the meaning of the LED light by consulting the "Status table"


Step 7: Click "return" to go back to the mobile phone's main screen. On certain models of mobile phones, a headphones icon will be visible.

Step 8: Your Bluetooth Speaker can now be used on outgoing or incoming calls.

LED status

Power ON	Green	3 flashes
Power off	Green	3 flashes
Pairing	Green	flash 150ms by 1 times
Pairing OK	Green	flash 10sec by 1 times
Pairing fail	Green	flash 5 sec per 1 flashes after 1min power off
Back to link	Green	500ms per 1 flashes link after 10sec per flashes
Low battery	Red	>3.6v 4sec per 1 flashes ≥ 3.4v power off
Calls mode	Green	5sec by 3 flashes
Call in the mode	Green /Red	Green & Red Flashes 4sec per cycle
Music mode	Green /Red	Green & Red Flashes 4sec per cycle

Charge



Function	LED
Charge	Red always ON
Power Full	N/A

Reminders

1. Keep away from water and moisture.
2. Keep away from heat source.
3. Do not drop, bend or crush the product.
4. **Hold on to the product when removing the USB cord.**
5. To reduce the risk of being shocked, please do not disassemble the product.

WARNING: Listening to excessively loud music can damage your hearing.

1. Avoiding hearing damage : Repeatedly or frequently using headphones at a volume of 80 decibels or louder can make you feel like the volume ought to be louder. This can cause you to continually increase the volume and can result in volume settings that pose a danger to your hearing.

2. Using hearing safely : To protect your health, please keep the volume on your Headset below 80 decibels and do not listen for too long a period of time. If you get a headache, feel dizzy or feel uncomfortable, please cease use.