## Honeywell

SEE THE NEXT PAGE FOR THE FCC INFO.

PREK4460-1V5 8/05 Rev A

# **ADEMCO 6150RF Keypad/Transceiver**

### INSTALLATION AND SETUP GUIDE

#### **GENERAL INFORMATION**

The 6150RF Keypad/Transceiver is a combination unit incorporating a normally-open relay output and the functions of:

- 6150 Fixed Addressable Keypad
- 5881M RF Receiver
- 5800TM Transmitter Module

The 6150RF Keypad/Transceiver may be used on any control panel that supports the 6150 Keypad (e.g., VISTA-10P/10SE, VISTA-15/15P, VISTA-20P/20SE/20HWSE, VISTA-40, VISTA-50P, VISTA-128B/128BP, 4110DL, 4110XM, 4140XMP)

#### **Wireless Features**

The 6150RF supports the following:

- 5828/5828V wireless keypads.
- Up to 8 wireless keys locally (programmed directly into 6150RF) without occupying any zones supported by the control panel.
- Button-type transmitters (e.g., 5804, 5804BD) for local operation.
- A maximum of 16 transmitters programmed into any 5800 Series-supported control panel.
- Wireless keys with high-security (e.g., 5804E).
- RF jam detection when the receiver is enabled.

The 6150 provides the following:

- Low-battery indications for the local wireless keys.
- A nominal range of 200' for the RF transmitters (some transmitters have a shorter range).
- Wireless key support for control panels that do not support RF themselves (such as 4110DL).



The 5802, 5802MN, 5802MN2, 5804, 5804BD, 5804BDV, 5804E, 5804WATCH, 5805BDV, 5814, 5816TEMP, 5819, 5819SBRS, 5819SWHS, and 5850 transmitters are not intended for UL installations.

#### 6150RF Application Guide

The following guide outlines how to program the wireless keys, RF receiver, and the House ID in the 6150RF for your installation

System Control Panel	Are you using					045005 0	
	RF keys beyond	RF receivers beyond	RF keypads and/or Edirectional devices o		Program Wireless Keys	6150RF Programming Options	
	system's capacity?	system's capacity?	more than 1 partition	1	Into	Receiver Enable	House ID Source***
4110DL, 4110XM, 4140XMP, VISTA- 20HWSE	N/A	N/A	N/A		6150RF	OFF	Local [0]
VISTA-10P, VISTA-10SE, VISTA-15, VISTA-15P, VIA-30PSE	NO	NO	N/A		System	ON [1]	System [1]
	YES	NO	N/A		6150RF	ON [1]	System [1]
	YES	YES	N/A		6150RF	OFF [0]	Local [0]
VISTA-20SE, VISTA-20P	NO	NO	NO		System	ON [1]	System [1]
	YES	NO	NO	$\overline{}$	6150RF	ON [1]	System [1]
	YES	YES	NO	T	6150RF	OFF [0]	Local [0]
	NO	YES	YES*	1	System	OFF [0]	Local [0]
	YES	YES	YES*		6150RF	OFF [0]	Local [0]
VISTA-40, VISTA-50P, VISTA-128B, VISTA-128BP	NO	NO	NO**		System	ON [1]	System [1]
	YES	NO	NO**		61 <b>5</b> 0RF	ON [1]	System [1]
	YES	YES	NO**		615 <mark>0</mark> RF	OFF [0]	Local [0]
	NO	YES	YES		System	OFF [0]	Local [0]
	YES	YES	YES		6150 <b>R</b> F	OFF [0]	Local [0]

- \* Two 6150RFs are needed for this application: one assigned to partition 1 and one assigned to partition 2.
- \*\* If using an RF keypad on only one partition, the 6150RF's partition assignment must match the partition se in field 1\*48.
- \*\*\* If set for Local on a partition control, the 6150RF's partition assignment must match the one programmed in the BD device.

#### **Programming Features**

- Auto Enroll mode for programming wireless keys.
- Provides a method for deleting a serial number and reenrolling a new one in its place.
- Provides default settings for the wireless key functions.

#### Additional Features

- Sends status signals (Armed, Ready, etc.) to bi-directional units such as 5804BDV, 5805BDV and 5828/5828V.
- Operates the on-board relay in conjunction with the receiver (e.g., to trip a garage door opener).

Note: This particular feature is not intended for UL installations.

- Activates relays programmed into the control panel.
- Provides an End User mode to enable/disable local wireless keys (e.g., if a user accidentally loses a wireless key). (Refer to the 6150RF User Guide for this procedure.)

#### APPLICATION GUIDELINES

Use the following guidelines when planning an installation:

- Local wireless keys (wireless keys programmed directly into the 6150RF) may be used regardless of whether the RF receiver in the 6150RF is enabled or disabled.
- If using bi-directional devices, be sure to enable the transmitter module in the 6150RF.
- If transmitters are programmed into the control panel, be sure to enable the receiver. (Make sure you do not exceed the number of receivers supported by the control panel.)
- If a local wireless key is programmed to arm/disarm or to trigger a relay on the control panel, a user code must be entered into the 6150RF. This user code must also be programmed into the control panel.
- You must set the House ID only if you are using RF keypads and/or bi-directional devices; AND the House ID Source is the 6150RF (Local).

#### **SPECIFICATIONS**

Physical: 6-1/4" H x 4-7/8" W x 1" D

(158.75mm x 123.8mm x 25.4mm)

**Wiring:** Refer to Wiring Table on page 2

Range: 200' nominal

Frequency: 345 MHz

Voltage: 12VDC

Current: Standby 80mA

Backlighting on and Sounder on 105mA

Relay: Normally-Open, 1A, 28VDC

**Sounder:** Piezo-electric (fire alarm is loud pulsing tone;

burglary/audible panic alarm is two tone

sound

FOR DETAILS ON THE LIMITATIONS OF THE ENTIRE ALARM SYSTEM, REFER TO THE INSTALLATION INSTRUCTIONS FOR THE CONTROL PANEL WITH WHICH THIS DEVICE IS USED.

#### FCC ID: CFS8DL6150RFT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

IC: 573F-6150RFT

#### FEDERAL COMMUNICATIONS COMMISSION (FCC) Part 15 STATEMENT

This equipment has been tested to FCC requirements and has been found acceptable for use. The FCC requires the following statement for your information:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- If using an indoor antenna, have a quality outdoor antenna installed.
- Reorient the receiving antenna until interference is reduced or eliminated.
- Move the radio or television receiver away from the receiver/control.
- Move the antenna leads away from any wire runs to the receiver/control.
- Plug the receiver/control into a different outlet so that it and the radio or television receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user or installer may find the following booklet prepared by the Federal Communications Commission helpful: "Interference Handbook"

This booklet is available from the U.S. Government Printing Office, Washington, DC 20402.

The user shall not make any changes or modifications to the equipment unless authorized by the Installation Instructions or User's Manual. Unauthorized changes or modifications could void the user's authority to operate the equipment.

#### **LIMITED WARRANTY**

Honeywell International Inc., acting through its Security & Custom Electronics business ("Seller") 165 Eileen Way, Syosset, New York 11791, warrants its product(s) to be in conformance with its own plans and specifications and to be free from defects in materials and workmanship under normal use and service for 24 months from the date stamp control on the product(s) or, for product(s) not having a manufacturer's date stamp, for 12 months from date of original purchase unless the installation instructions or catalog sets forth a shorter period, in which case the shorter period shall apply. Seller's obligation shall be limited to repairing or replacing, at its option, free of charge for materials or labor, any product(s) which is proved not in compliance with Seller's specifications or proves defective in materials or workmanship under normal use and service. Seller shall have no obligation under this Limited Warranty or otherwise if the product(s) is altered or improperly repaired or serviced by anyone other than Honeywell factory service. Connection of any device(s) to a communicating bus of a Honeywell security system (e.g., keypad bus, polling loop) other than those manufactured or approved by Honeywell shall void this warranty. For warranty service, return product(s) transportation prepaid, to MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. IN NO CASE SHALL SELLER BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, OR UPON ANY OTHER BASIS OF LIABILITY WHATSOEVER, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

Seller does not represent that the product(s) it sells may not be compromised or circumvented; that the product(s) will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the product(s) will in all cases provide adequate warning or protection. Customer understands that a properly installed and maintained alarm system may only reduce the risk of a burglary, robbery, fire, or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result. CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE OR OTHER LOSS BASED ON A CLAIM THAT THE PRODUCT(S) FAILED TO GIVE WARNING. HOWEVER, IF SELLER IS HELD LIABLE, WHETHER DIRECTLY OR INDIRECTLY, FOR ANY LOSS OR DAMAGE ARISING UNDER THIS LIMITED WARRANTY OR OTHERWISE, REGARDLESS OF CAUSE OR ORIGIN, SELLER'S MAXIMUM LIABILITY SHALL NOT IN ANY CASE EXCEED THE PURCHASE PRICE OF THE PRODUCT(S), WHICH SHALL BE THE COMPLETE AND EXCLUSIVE REMEDY AGAINST SELLER.

This warranty replaces any previous warranties and is the only warranty made by Seller on this product(s). No increase or alteration, written or verbal, of the obligations of this Limited Warranty is authorized.