

INTRODUCTION


Congratulations on your purchase of the SmartBridge Power Controller. Your Power Controller allows you to use your PC to power on and off any device that operates at up to 8 amps. This Quick Start Guide describes how to set up and troubleshoot your Power Controller. For a full system set-up manual, please visit our website: www.smartbridge.net

USING YOUR POWER CONTROLLER

Using your computer and Wireless System Gateway, you locally manage the Power Controller to turn devices on and off.

How It Works

The Power Controller enables you to turn on and off devices remotely from your PC. For example, you can have SmartBridge turn a lamp on and off.



Package Contents



Wireless Power Controller

Installing Your Power Controller


Consult the SmartBridge System Setup manual for details.

1. Plug the device into the Power Controller.
2. Plug the Power Controller into a wall outlet. The Power Controller handles devices up to 8 amps, so it should not be used with heavy-duty electrical devices.

Feature Locator

Features and Specifications

- LED indicates power is available
- Typical range open Air (line of sight): 200 feet (60 m)
- Typical range indoors: 50 feet (15 m)
- Dimensions: 2.027" x 1.417" x 4.257"
- Communication frequency: 908 ~ 919 MHz



TROUBLESHOOTING

Problem

Wireless System Gateway does not recognize the Power Controller

Solution

- Position the Power Controller in closer proximity to your Gateway and try again.
- Ensure that there are no other wireless devices interfering with the Power Controller. The Power Controller transmits on the 915 MHz frequency.

Problem

Device does not turn on/off when specified

Solution

- Ensure that the Power Controller has been registered properly with the Wireless System Gateway by logging into your SmartBridge program and reviewing the Devices list.
- Place the Power Controller in another location closer to the Wireless Gateway.

FAQ

How far away can the Power Controller be placed from my Wireless Gateway?

Typically 50 feet (15 meters).

Can I place the Power Controller in a different room than my Wireless Gateway?

Yes, the Power Controller and Wireless Gateway use radio frequencies to communicate with each other. These frequencies can go through objects like walls, ceilings, and floors.

Can I use the Power Controller outdoors?

No, the Power Controller is restricted to indoor use only.

What can I plug into the power module?

You can plug in any 110V device that draws no more than 8 amps. Devices that require higher loads may cause the Power Controller to fail. Do not plug power strips into the Power Controller as multiple devices could exceed 8 amps.

REGULATORY INFORMATION

FCC Notices:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Model: OLPOWER

ICES-003 Statement

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Model: OLPOWERA

LIMITED WARRANTY

SmartBridge Power Controller

BRK Brands, Inc., ("BRK") the maker of First Alert® brand products warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. BRK, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. BRK dealers, service centers, or retail stores selling BRK products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than BRK or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

BRK shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

How to Obtain Warranty Service

For customer service, technical support, and warranty claims, contact our Customer Support Center at 1-800-323-9005 Monday - Friday 7:30 am to 5:00 pm Central Standard Time.

Registration

Register your product at:
www.smartbridge.net

© 2012 BRK Brands, Inc. All rights reserved.
Distributed by BRK Brands, Inc.
3901 Liberty Street Road, Aurora, IL 60504-8122

SmartBridge™ is a registered trademark of BRK Brands, Inc.
First Alert® is a registered trademark of the First Alert Trust used under license.